



Tire Chain Kit	
Part No. 56-2700 Part No. 63-3040	Installation Instructions

1. Block up the rear of the snowthrower frame so that the wheels are off the ground.
2. Remove the pins that secure the wheels to the axles and remove the wheels.

Note: On models equipped with the Power Shift feature, insert a spacer (included in the kit) onto each end of the axle. Spacers are not used on the other models.

3. Lay the chains out flat with the locking link to the outside.
4. Wrap the tire chains around the tires, hooking the inside links and locking the outside links. Pinch the inside links closed.
5. Slide the wheels onto the axles and secure them with the pins previously removed. On the machines with installed spacers, pin the wheels to the outer axle holes.

©1989, 2000 The Toro Company
All Rights Reserved



Tire Chain Kit	
Part No. 56-2700 Part No. 63-3040	Installation Instructions

1. Block up the rear of the snowthrower frame so that the wheels are off the ground.
2. Remove the pins that secure the wheels to the axles and remove the wheels.

Note: On models equipped with the Power Shift feature, insert a spacer (included in the kit) onto each end of the axle. Spacers are not used on the other models.

3. Lay the chains out flat with the locking link to the outside.
4. Wrap the tire chains around the tires, hooking the inside links and locking the outside links. Pinch the inside links closed.
5. Slide the wheels onto the axles and secure them with the pins previously removed. On the machines with installed spacers, pin the wheels to the outer axle holes.

©1989, 2000 The Toro Company
All Rights Reserved

