



48 inch Vacuum Bagger

5xi Garden Tractor Attachment

Model No. 79310—210000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.


Contents

Description	Page	Description	Page
Drive Assembly	3	Deck Assembly	6
Blower Housing Assembly	4	Bag and Frame Assembly	7
Bag Assembly – Top	5		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	HYD	hydraulic
ASM	assembly	INC	incorporated
CARR	carriage	LH	left hand
DEG	degrees	NI	nylon insert
FH	flat head	PPH	Phillips pan head
GA	gauge	PTH	Phillips truss head
HF	hex flange	PTO	power take off
HH	hex head	RH	right hand
HHF	hex head flange	SFH	slotted fillister head
HLH	hex lag head	SHH	slotted hex head
HJ	hex jam	SQH	square head
HOC	height-of-cut	SHWH	slotted hex washer head
HS	hex socket	SPH	slotted pan head
HSBH	hex socket button head	SRH	slotted round head
HSFH	hex socket flat head	STD	standard
HSH	hex socket head	TAP	self tapping
HWH	hex washer head	TTH	Torx truss head
HWHTF	hex washer head thread forming	WH	wing head



Sheet No.: 2

Drive Assembly

Ref. No.	Part No.	Qty.	Description
1	79-7110	1	Spring-Compression
2	79-2020	1	Spring-Rod
3	79-1970	1	Idle Arm ASM
4	3296-39	2	Nut-Lock, NI
5	92-7099	1	Pulley-Idler
6	3256-4	2	Washer-Flat
7	107213	1	Spacer
8	3256-24	1	Washer-Flat
9	323-10	1	Screw-HH
10	323-9	1	Screw-HH
11	93-1622	1	Pulley-Idler
12	79-7490	1	V-Belt
13	79-7280-03	1	Support-Shield, Belt
14	100284	2	Bushing
15	3256-26	1	Washer-Flat
16	3272-7	1	Pin-Cotter
17	79-7440	1	Bracket-Support, Housing
18	32128-20	4	Nut-HF
19	3256-3	1	Washer-Flat
20	3230-1	3	Screw-CARR
21	3230-16	1	Screw-CARR
22	3256-23	1	Washer-Flat
23	3272-10	1	Pin-Cotter
24	79-1380-03	1	Blower Mounting ASM




Sheet No.: 3

Blower Housing Assembly

Ref. No.	Part No.	Qty.	Description
1	32128-20	6	Nut-HF
3	3217-26	2	Nut-Hex
4	3256-14	2	Washer-Flat
5	32105-13	1	Screw-SHH
6	79-7230-03	1	Latch-Blower
7	79-7390	1	Spring-Extension
8	3296-42	1	Nut-Lock, NI
9	3290-479	1	Fastener-Panel
10	82-5690	1	Retainer-Duct
11	22-9741	1	Spacer-Interlock
12	3220-6	2	Nut-Jam
13	3253-8	2	Washer-Lock
14	251-341	4	Flange
15	251-288	2	Bearing-Ball
16	3230-16	6	Screw-CARR
17	79-6890	1	Housing-Vac, Blower
18	3229-22	6	Screw-CARR
19	79-4300-03	1	Impeller
20	79-7170-03	1	Cover-Blower, Bottom
21	3256-22	7	Washer-Flat
22	3296-56	6	Nut-Lock, NI
23	321-4	1	Screw-HH
24	3257-40	1	Key-Hi Pro
25	79-1470	1	Shaft-Blower
26	7038	1	Spacer
27	79-1460	1	Pulley-Blower


Ref. No.	Part No.	Qty.	Description



Bag Assembly – Top

Ref. No.	Part No.	Qty.	Description
1	115880	2	Grip
2	115481-03	2	Latch-Bagger, Top
3	114439	24	Rivet-Pop
4	9202704	4	Washer
5	92-1734	1	Top-Bagger
6	321-4	4	Screw-HH
7	3296-42	4	Nut-Lock, NI
8	2412-91	2	Clamp
10	88-9570	1	Stiffener ASM
10:2	92-7113	1	Decal-Caution
11	3296-39	2	Nut-Lock, NI
12	114966	1	Clamp-Seal
13	117239	1	Seal-Chute
14	92-1736-03	1	Support-Screen
15	114969	1	Feeler-Fill, Bag
16	3218-1	1	Nut-Jam
17	32144-8	1	Screw-HH
18	3256-49	1	Washer-Flat
19	233-68	1	Knob
20	100-6152	1	Chute-Discharge
21	118320	1	Handle-Tapered
22	114960	1	Pin-Spring
23	114962	2	Spring-Extension
24	9790944	2	Spacer
25	114967	1	Screen-Bagger
26	114955-03	1	Frame ASM

Ref. No.	Part No.	Qty.	Description
27	323-6	2	Screw-HH
28	114961-03	1	Hinge-Bag, Top
30	116347	1	Decal-Twin, Easy





Sheet No.: 5

Deck Assembly

Ref. No.	Part No.	Qty.	Description
1	86-9300	1	Shield-Belt
2	321-3	2	Screw-HH
4	98-5096	1	Shield ASM
4:2	92-7108	1	Decal-Danger
5	3234-26	3	Screw
6	94-7589-03	1	Adapter-Shield
7	79-7130	1	Pulley
8	322-3	1	Screw-HH
9	32128-20	1	Nut-HF
10	79-7000-03	1	Pivot Bracket ASM
11	9266714	2	Screw-HWH
12	88-1870	2	Bracket-Support, Shield
13	3296-42	2	Nut-Lock, NI
14	79-0470	4	Rivet-Pop
15	3256-56	5	Washer-Flat
16	3296-39	4	Nut-Lock, NI
17	98-3096	1	Weight
18	323-4	2	Screw-HH
19	323-45	2	Screw-HH

Ref. No.	Part No.	Qty.	Description



Sheet No.: 6

Bag and Frame Assembly

Ref. No.	Part No.	Qty.	Description
1	114972-03	2	Frame-Bag
2	95-3865-03	1	Bracket-Attach, Quick
3	3296-39	4	Nut-Lock, NI
4	94-7899-03	1	Support-Bagger
5	323-6	4	Screw-HH
6	3296-29	4	Nut-Lock
7	114974-03	2	Clamp
8	114973-03	2	Hanger-Bag
9	3230-1	4	Screw-CARR
10	93-1623	2	Bag-Depth
11	9335064	2	Pin-Cotter, Hair

Ref. No.	Part No.	Qty.	Description

