



Form No. 3425-728 Rev F

**Count on it.**

# Parts Catalog

## 30in TurfMaster HDX Walk-Behind Lawn Mower

Model No. 22215—Serial No. 400000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Deck Assembly . . . . . 4

Blade and Spindle Assembly . . . . . 6

Pulleys and Idler Assembly No. 126-7890 . . . . . 8

Side Discharge Chute Assembly . . . . . 10

Grass Bag Assembly . . . . . 12

Engine and Fuel Tank Assembly . . . . . 14


Front Wheel and Bumper Assembly . . . . . 16

Transmission and HOC Assembly . . . . . 18

Handle Assembly . . . . . 20

Attachments and Accessories . . . . . 22


# Deck Assembly



## Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 136-5900           | 1           | Deck ASM                | 21          | 116-6933           | 1           | Pin-Hinge             |
| 1:2         | 94-8072            | 1           | Decal-Danger            | 22          | 116-6229           | 1           | Seal-Door             |
| 1:3         | 93-7009            | 1           | Decal-Danger            | 23          | 32151-72           | 1           | Ring-Retaining        |
| 1:4         | 116-8528           | 1           | Decal                   | 24          | 116-7573           | 1           | Spring-Torsion, Cover |
| 1:5         | 120-9570           | 2           | Decal-Warning           | 25          | 116-8355           | 1           | Rear Door ASM         |
| 3           | 133-8107-01        | 1           | Frame                   | 25:2        | 116-7583           | 1           | Decal-Warning         |
| 4           | 133-8177           | 1           | Chute                   | 28          | 116-6966           | 1           | Clip-Seal             |
| 5           | 3230-5             | 2           | Bolt-CARR               | 29          | 121-5793-03        | 1           | Door-Access           |
| 6           | 139-1674           | 1           | Decal                   | 30          | 121-5840           | 2           | Fastener              |
| 8           | 3296-29            | 2           | Nut-Lock, NI            | 31          | 130-2352-01        | 1           | Baffle-Control        |
| 10          | 121-5810           | 1           | Cover-Belt              | 32          | 104-8300           | 4           | Nut-HF, NI            |
| 11          | 126-4345           | 1           | Decal-Patent            | 33          | 3230-23            | 4           | Screw-CARR            |
| 12          | 46-8091            | 4           | Screw-HWH               | 36          | 32144-86           | 1           | Screw-HWHTF           |
| 13          | 138-3224           | 1           | Bracket-Cable, Traction | 37          | 138-5332-01        | 1           | Cover-Frame           |
| 14          | 120-5225           | 1           | Plug-Mulch              | 38          | 107069             | 1           | Clip                  |
| 15          | 121-5841           | 1           | Shield-Trailing         | 40          | 126-7151           | 1           | Plug-Button           |
| 16          | 49-2040            | 9           | Screw-HWHTF             | 99          | 125-5072           | 1           | Frame Plate Kit       |
| 17          | 1-513658           | 2           | Bumper                  | 99:1        | 125-2542           | 1           | Plate-Frame           |
| 18          | 65-5100            | 1           | Handle-Door             | 99:2        | 3229-3             | 3           | Screw-CARR            |
| 19          | 117-1092           | 2           | Screw-PTH               | 99:3        | 3296-42            | 3           | Nut-Lock, NI          |
| 20          | 116-6351-03        | 1           | Bracket-Hinge           |             |                    |             |                       |


# Blade and Spindle Assembly



## Blade and Spindle Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 121-9107           | 2           | Spindle ASM           | 17          | 126-6453           | 1           | Bracket-Idler           |
| 1:2         | 120-7935           | 2           | Spacer                | 18          | 120-7024           | 2           | Screw-Shoulder, HWH     |
| 1:3         | 136-5441           | 2           | Bearing-Ball          | 19          | 120-3335           | 1           | Belt-Synchronous        |
| 2           | 132-4498           | 8           | Screw-HWH             | 20          | 120-5245-03        | 1           | Guide-Belt, Spindle     |
| 3           | 120-5234           | 1           | Shaft-Spindle         | 21          | 120-5236           | 2           | Adapter-Blade           |
| 4           | 120-5235           | 1           | Shaft-Spindle         | 22          | 121-5808           | 1           | Spring-Extension, Brake |
| 5           | 121-9100           | 2           | Sprocket              | 23          | 125-2466           | 2           | Bolt-Blade              |
| 6           | 130-6664           | 1           | Pulley-Brake, Spindle | 24          | 49-2040            | 2           | Screw-HWHTF             |
| 7           | 109-9505           | 2           | Washer-Spring         | 25          | 120-7082           | 1           | Pulley-Idler            |
| 8           | 3296-19            | 2           | Nut-Hex               | 26          | 322-6              | 1           | Screw-HH                |
| 9           | 322-13             | 1           | Screw-HH              | 27          | 3296-47            | 1           | Nut-Lock, NI            |
| 10          | 136-5903           | 1           | Brake Arm ASM         | 28          | 116-6358-03        | 2           | Blade-Rotary            |
| 10:4        | 131-0819           | 2           | Bushing-Sleeve        | 29          | 121-2336           | 1           | Spring-Flat             |
| 11          | 5-4460             | 2           | Washer-Pivot          | 30          | 131-0823           | 1           | Spacer-Brake            |
| 13          | 9114524            | 1           | Bolt-TAP, HH          | 31          | 126-7151           | 2           | Plug-Button             |
| 14          | 3256-3             | 4           | Washer-Flat           | 32          | 131-4504           | 1           | Adapter-Bore            |
| 15          | 3296-29            | 2           | Nut-Lock, NI          | 33          | 133-1964           | 1           | Hose-Coolant            |
| 16          | 126-7890           | 1           | Pulleys And Idler Kit | 34          | 32144-57           | 2           | Screw                   |

# Pulleys and Idler Assembly No. 126-7890




## Pulleys and Idler Assembly No. 126-7890 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 126-5880           | 2           | Pulley-Idler, Flat |
| 2           | 126-7151           | 2           | Plug-Button        |
| 3           | 131-4504           | 1           | Adapter-Bore       |
| 4           | 3256-3             | 3           | Washer-Flat        |
| 5           | 32144-57           | 2           | Screw              |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 6           | 126-6453           | 1           | Bracket-Idler       |
| 7           | 120-7024           | 2           | Screw-Shoulder, HWH |
| 8           | 9114524            | 1           | Bolt-TAP, HH        |
| 9           | 3296-29            | 1           | Nut-Lock, NI        |
| 10          | 121-2336           | 1           | Spring-Flat         |


Side Discharge Chute Assembly



## Side Discharge Chute Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 322-38             | 1           | Screw-HH                 | 7:3         | 121-9196           | 1           | Bracket-Chute      |
| 2           | 121-9195           | 1           | Hinge                    | 7:4         | 46-8560            | 2           | Screw-HHFTF        |
| 3           | 99-8445            | 2           | Screw-HWH                | 7:5         | 112-6416           | 1           | Bracket-Cover      |
| 4           | 125-2478           | 1           | Spacer                   | 7:6         | 94-4496            | 2           | Screw-PPH          |
| 5           | 121-9193           | 1           | Spring-Torsion           | 7:7         | 3230-18            | 2           | Screw-CARR         |
| 6           | 125-5093-01        | 1           | Cover-Discharge          | 7:8         | 104-8300           | 2           | Nut-HF, NI         |
| 7           | 116-9754           | 1           | Side Discharge Chute ASM | 8           | 104-8300           | 1           | Nut-HF, NI         |
| 7:2         | 116-9752-03        | 1           | Guard-Chute              |             |                    |             |                    |


# Grass Bag Assembly



## Grass Bag Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 121-5775           | 1           | Grass Bag ASM      |
| 3           | 116-5596-03        | 1           | Frame-Bag          |

# Engine and Fuel Tank Assembly




# Engine and Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 119-1892           | 1           | Hose-Fuel                 | 16          | 109-0304           | 2           | Hose-Fuel               |
| 2           | 137-9181           | 1           | Pulley-Engine             | 17          | 1-603770           | 1           | Valve-Fuel              |
| 3           | 121-5765           | 1           | V-Belt                    | 18          | 2412-98            | 6           | Clamp-Hose              |
| 4           | 133-8151           | 1           | Belt-V                    | 20          | 115-0962           | 1           | Hose-Vent, Canister     |
| 5           | 138-5331-03        | 1           | Rod-Guide, Belt           | 21          | 130-6440-03        | 1           | Bracket-Mount, Throttle |
| 6           | 95-1727            | 3           | Screw-Taptite             | 22          | 3229-30            | 1           | Screw-CARR              |
| 7           | 3290-465           | 1           | Washer-Belleville         | 23          | 130-9655           | 1           | Control-Throttle        |
| 8           | 3212-4             | 1           | Screw-HH                  | 24          | 104-7201           | 1           | Nut-HF                  |
| 9           | 109-6528           | 1           | Decal-Recoil              | 26          | 139-5916           | 1           | Filter-Fuel             |
| 10          |                    | 1           | Engine-Kawasaki Fj180V ●■ | 27          | 116-9313           | 1           | Decal-Warning, Engine   |
| 11          | 115-0954-03        | 1           | Mount-Tank                | 28          | 130-9654           | 1           | Wire-Control            |
| 12          | 114-0280           | 1           | Tank-Fuel                 | 29          | 130-9656           | 1           | Decal-Throttle, Choke   |
| 13          | 137-4127           | 1           | Cap-Fuel                  | 30          | 49-2040            | 2           | Screw-HWHTF             |
| 14          | 116-8929           | 3           | Screw-HWH                 | 31          | 104662             | 3           | Spacer                  |
| 15          | 46-8091            | 2           | Screw-HWH                 |             |                    |             |                         |

● Not serviced separately

■ Obtain parts from [www.kawpower.com](http://www.kawpower.com)


# Front Wheel and Bumper Assembly



## Front Wheel and Bumper Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|---------------------|
| 1           | 104-8300           | 11          | Nut-HF, NI           | 12          | 120-9465           | 1           | Spring-Torsion      |
| 2           | 121-5781           | 4           | Bushing-Front        | 13          | 3274-55            | 1           | Screw-HSBH          |
| 3           | 321-7              | 4           | Screw-HH             | 14          | 3296-42            | 4           | Nut-Lock, NI        |
| 4           | 104-8301           | 2           | Nut-HF, NI           | 15          | 3230-23            | 10          | Screw-CARR          |
| 5           | 139-1740           | 1           | Front Axle ASM       | 16          | 94-2413            | 1           | Nut-U               |
| 6           | 133-2639           | 2           | Wheel                | 17          | 121-2337           | 1           | Spring-Torsion      |
| 6:2         | 133-2603           | 2           | Bearing-Ball         | 18          | 136-9077           | 1           | Decal-HOC, Front    |
| 6:3         | 125-1077           | 1           | Spacer               | 19          | 125-2486           | 1           | Spacer              |
| 7           | 139-6616           | 1           | Front Bumper ASM     | 20          | 121-9187-03        | 1           | Shield              |
| 7:2         | 139-1675           | 1           | Decal-Turfmaster HDX | 21          | 117-0871           | 1           | Decal               |
| 7:3         | 116-7581           | 1           | Decal-Warning        | 22          | 3256-22            | 2           | Washer-Flat         |
| 8           | 121-9168-03        | 2           | Brace                | 23          | 321-8              | 2           | Screw-HH            |
| 9           | 131-9690           | 1           | Mandrell-Spring      | 24          | 104-7201           | 2           | Nut-HF              |
| 10          | 94-5780            | 1           | Screw-HWH            | 25          | 323-13             | 2           | Screw-HH            |
| 11          | 139-1744           | 1           | Lock-Height, Adj     | 26          | 74-1671            | 2           | Spacer-Cover, Wheel |


# Transmission and HOC Assembly



## Transmission and HOC Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 137-9172-03        | 1           | HOC Plate Assembly          | 23          | 139-1737           | 1           | Lock-Height, Adj        |
| 2           | 137-9173-03        | 1           | HOC Plate Assembly          | 24          | 138-5393           | 1           | Spring-Extension        |
| 3           | 701243             | 7           | Screw-Thd Roll, HWH         | 25          | 104-8300           | 4           | Nut-HF, NI              |
| 4           | 137-9183           | 2           | Bearing Retainer ASM        | 26          | 3230-2             | 1           | Bolt-CARR               |
| 5           | 137-4779           | 4           | Bearing-Ball, Custom        | 27          | 137-9185           | 2           | Cover-Bearing           |
| 6           | 136-9111           | 2           | Gear-Pinion, 15T            | 28          | 133-2670           | 1           | Transmission-Mv702      |
| 7           | 32151-61           | 2           | Ring-Retaining              | 28:1        | 139-1837           | 1           | Pulley & Fan Repair Kit |
| 8           | 3230-23            | 1           | Screw-CARR                  | 28:2        | 139-1842           | 1           | Idler Pulley Repair Kit |
| 9           | 136-7095           | 2           | Cover-Wheel                 | 28:2:3      | 139-1845           | 1           | Spring-Tension, Belt    |
| 10          | 133-8104-03        | 1           | Bracket-Transmission, Front | 28:3        | 139-8974           | 1           | Clutch Lever Repair Kit |
| 11          | 3230-4             | 2           | Bolt-CARR                   | 29          | 120-7950           | 2           | Screw-Torx              |
| 12          | 121-2368           | 1           | Spring-Torsion              | 30          | 36-4780            | 2           | Washer-Plain            |
| 13          | 104-8301           | 2           | Nut-HF, NI                  | 31          | 3296-47            | 1           | Nut-Lock, NI            |
| 14          | 125-2540           | 1           | Washer-Plain                | 32          | 138-5394-03        | 1           | Bracket-Mount, Brake    |
| 15          | 137-9174           | 2           | 10.5 In. Wheel ASM          | 33          | 138-5398           | 1           | Caliper-Brake, Disc     |
| 17          | 121-2397           | 1           | Bracket                     | 34          | 32144-4            | 4           | Screw-HWH               |
| 18          | 131-5385           | 1           | Rear Axle ASM               | 35          | 138-5395           | 1           | Hub-Rotor               |
| 19          | 116-7127           | 1           | Decal-HOC, Rear             | 36          | 933156             | 1           | Pin-Roll                |
| 20          | 52-2860            | 1           | Washer                      | 37          | 138-5396           | 1           | Disc-Rotor              |
| 21          | 119-2267           | 1           | Screw-Shoulder, BHTF        | 38          | 32144-1            | 1           | Screw-Taptite           |
| 22          | 120-9471           | 1           | Bolt-Shoulder               | 39          | 609471             | 1           | Screw                   |

# Handle Assembly



## Handle Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|----------------------|
| 1           | 137-4767-03        | 1           | Handle                | 17          | 138-5368           | 1           | Spacer               |
| 2           | 116-8208-03        | 2           | Support-Handle        | 18          | 139-1817           | 1           | Washer-Stepped       |
| 3           | 116-7230           | 4           | Screw-HHF             | 19          | 139-1819           | 1           | Lever-Brake          |
| 4           | 3230-4             | 2           | Bolt-CARR             | 20          | 117-9965           | 1           | Spacer               |
| 5           | 104-8300           | 3           | Nut-HF, NI            | 21          | 32144-1            | 1           | Screw-Taptite        |
| 6           | 139-1815           | 1           | Bail-Traction, Coated | 22          | 1-807512           | 2           | Bolt-CARR            |
| 7           | 137-4810           | 1           | Bail-BBC, Coated      | 23          | 3230-7             | 1           | Bolt-CARR            |
| 8           | 42-3560            | 3           | Bolt-Shoulder         | 24          | 116-2690           | 1           | Bushing-Stepped      |
| 9           | 104-7201           | 8           | Nut-HF                | 25          | 109-9318           | 1           | Spring-Lever, BBC    |
| 10          | 92-2267            | 1           | Screw-Handle          | 26          | 116-2998           | 1           | Lever-BBC            |
| 11          | 137-4759           | 1           | Cable-BBC             | 27          | 3229-5             | 2           | Screw-CARR           |
| 12          | 137-4807           | 1           | Cable-Traction        | 28          | 106-6801           | 1           | Anchor-Cable         |
| 13          | 3256-1             | 1           | Washer-Flat           | 29          | 138-5399           | 1           | Cable-Brake, Parking |
| 14          | 106-7260           | 2           | Washer-Curved         | 30          | 139-5405           | 1           | Decal-Brake, Parking |
| 15          | 139-1818-03        | 1           | Mount-Lever, Brake    | 99          | 614249             | 4           | Tie-Cable ●          |
| 16          | 139-1813           | 1           | Link-Actuation, Brake |             |                    |             |                      |

● Not illustrated

# Attachments and Accessories

## For 22215 30in TurfMaster HDX Walk-Behind Lawn Mower

| Product Name             | Model/Part  |
|--------------------------|-------------|
| Atomic Blade 15.4in..... | 120-9500-03 |
| Mulching Kit.....        | 125-5064    |
| Idler Pulley Kit.....    | 126-7890    |

**Notes:**



**Count on it.**