



Form No. 3368-640 Rev G

Count on it.

Parts Catalog

Greensmaster® Flex™ 2100 Traction Unit

Model No. 04040—Serial No. 312000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame and Handle Mount Assembly	4
Grass Basket Assembly	5
Left Side Transmission Assembly	6
Right Side Transmission Assembly	7
Clutch Assembly	8
Clutch Assembly No. 117-1485	9
Differential and Traction Drum Assembly	10
Differential Assembly No. 115-6711	11
Drum Drive Assembly	12
Engine Assembly	13
Shift Lever Assembly	14
Handle Assembly	15
Throttle and Console Assembly	16
Crankcase Assembly	17
Crankshaft and Piston Assembly	18
Intake and Exhaust Assembly	19
Air Cleaner Assembly	21
Governor Assembly	22
Recoil and Shroud Assembly	23
Recoil Assembly	24
Fuel Tank Assembly	25
Carburetor Assembly	26
Flywheel and Coil Assembly	27
Gear Reduction Assembly	28
Attachments and Accessories	29




Frame and Handle Mount Assembly

Ref.	Part Number	Qty.	Description
1	120-9241	2	Retainer-Handle
2	120-9717	2	Pin-Hair
3	115-7295	5	Bushing-Straight
4	119-4042	8	Nut-HF, NI
5	115-7217-01	1	Frame
6	115-7110-01	1	Frame-Rear
7	115-7287-01	1	Frame-Roll
8	115-7160	1	Plate-Side, LH
9	115-7293	8	Washer-Hardened
10	115-7024	6	Screw-HHF
11	117-1396	4	Link
12	93-2561	8	Bushing-Flange
13	115-7255-03	1	Kickstand
14	115-7258	1	Spring-Torsion, RH
15	120-9715	2	Screw-CARR
16	120-9696	1	Screw-HH
17	120-9739	1	Pin-Lock


Ref.	Part Number	Qty.	Description
18	107-8885	1	Spring-Compression
19	119-4041	1	Nut-HF
20	120-9697	1	Spacer
21		1	Grass Basket ASM ●
22	115-7108	2	Screw-HHF
23	115-7234-03	1	Weight-Counter
24	131-6150	3	Screw-HWHTF
25	115-7088	2	Clamp-Handle
26	115-7089	2	Clamp-Handle, Offset
27	120-9698	4	Bolt-CARR
28	120-9699	2	Screw-CARR
29	119-4040	6	Nut-Flange, NI
30	115-6991	4	Bumper-Rubber
31	115-6990	2	Bolt-Shoulder
32	701197	1	E-Ring
36	32180-030	1	Clip-Tie
37	120-9740	1	Spacer

● Not serviced separately



Grass Basket Assembly


Ref.	Part Number	Qty.	Description
1	120-2666	1	Basket ASM
1:2	120-2661	1	Lip-Basket
1:3	3290-382	7	Rivet-Pop
2	115-7281-03	1	Mount-Handle, Basket
3	119-4040	6	Nut-Flange, NI
4	119-4012	6	Screw-HWHTF
5	120-9646	2	Washer-Flat



Left Side Transmission Assembly

Ref.	Part Number	Qty.	Description
1	115-7150	1	Housing-Transmission
2	115-7158	1	Housing-Extension
3	251-82	2	Bearing-Ball
4	115-6747	1	Pulley-Driven
5	119-1138	4	Screw-HWH
6	95-0715	2	Pin-Dowel
7	32151-47	1	Ring-Retaining
8	93-2561	2	Bushing-Flange
9	108-2973	2	Bushing-Flange
10	115-7126	1	Lever-Clutch, Reel
11	115-7131	1	Ring-Brake, Reel
12	115-6869	1	Bearing-Ball, Stainless
13	115-7243	1	Ring-Retaining, EXT
14	115-7130	1	Disc-Brake, Reel
15	115-7123	2	Pin-Pivot, Clutch
16	115-7124	1	Fork-Clutch, Reel
17	115-7125	1	Hub-Clutch, Reel


Ref.	Part Number	Qty.	Description
18	115-7127	1	Hub-Drive, Reel
19	115-7138	1	Shaft-Clutch
20	115-7222	1	Spacer
21	115-6870	2	Bearing-Ball, Sealed
22	115-7139	1	Pulley-Clutch, Reel
23	115-6811	1	Collar-Bearing
24	115-6923	1	Shield-Bearing, Flocked
25	115-7143	1	Spring-Wave
26	115-7144	1	Washer-Flat
27	115-6755	1	Ring-Retaining
28	3257-30	1	Key-Woodruff
29	3290-485	1	Washer-Wave
30	38-7820	1	Bearing-Ball
31	115-7249	1	Spacer
32	115-7288	1	Plug
33	32120-47	1	Ring-Retaining, External
34	120-9571	1	Decal-Release, Traction



Right Side Transmission Assembly

Ref.	Part Number	Qty.	Description
1	120-9597	1	Transmission Cover ASM
1:2	120-9570	1	Decal-Warning
2	115-7140	1	Gasket-Housing, Main
3	115-6743	1	Belt-Drive, Main
4	115-5142	2	Screw-HHF
5	115-7292	2	Washer-Hardened
6	115-7285	1	Pulley-Driven
7	115-7209	1	Washer-Wave
8	120-9686	2	Screw-HH
9	115-7129	2	Bushing-Pulley, Idler
10	38-7820	6	Bearing-Ball
11	115-6873	2	Pulley-Idler
12	115-7133	1	Pulley-Idler
13	115-6845	1	Screw-Shoulder
14	32151-12	1	Ring-Retaining


Ref.	Part Number	Qty.	Description
15	93-2561	4	Bushing-Flange
16	115-6847	1	Idler-Drive, Main
17	115-6842	1	Spring-Extension
18	115-7128	1	Lever-Spring
19	119-4041	1	Nut-HF
20	1239	1	Setscrew
21	120-9695	1	Nut-Jam
22	119-1138	8	Screw-HWH
23	119-4033	2	Pin-Spring
24	115-6867	1	Coupling-Flex
25	115-6876	1	Shaft-Hex
26	115-6874	1	Wire-Shaft, Drive
27	115-6875	1	Tube-Hex
28	119-4040	1	Nut-Flange, NI
30	120-9738	1	Screw-HH



Clutch Assembly

Ref.	Part Number	Qty.	Description
1	115-7162	1	Housing-Clutch
2	115-5142	5	Screw-HHF
3	115-7142	1	Grommet-Lever, Clutch
4	115-7292	1	Washer-Hardened
5	117-1485	1	Clutch ASM
6	115-7137	1	Shaft-Clutch
7	38-7820	1	Bearing-Ball
8	115-7136	1	Pulley-Drive
9	115-6869	1	Bearing-Ball, Stainless
10	115-6923	1	Shield-Bearing, Flocked
11	115-7143	1	Spring-Wave
12	115-7144	1	Washer-Flat
13	115-6755	1	Ring-Retaining
14	119-4041	1	Nut-HF
15	119-1138	7	Screw-HWH
16	115-7090-03	1	Bracket-Cable, Traction
17	93-2561	2	Bushing-Flange

Ref.	Part Number	Qty.	Description
18	115-7082	1	Lever-Bellcrank
19	115-7245	1	Bellcrank Rod ASM
19:1	282-27	1	Clevis-Adj
19:2	3220-2	2	Nut-Jam
19:3	115-7084	1	Rod-Bellcrank
19:4	1-543017	1	Balljoint-RH
20	120-9694	1	Pin-Clevis
21	120-9716	1	Pin-Cotter
22	119-4040	1	Nut-Flange, NI
23	120-9696	1	Screw-HH
24	115-6845	1	Screw-Shoulder
25	115-7276	1	Endpiece-Coupler, 15Mm
25:1	3245-41	2	Screw-HSH
26	88-7150	1	Key-Square
27	120-9552-03	1	Guard-Coupler
28	131-6150	2	Screw-HWHTF
29	3290-378	1	Tie-Cable




Clutch Assembly No. 117-1485

Ref.	Part Number	Qty.	Description
1	120-9663	2	Bearing-Ball
2	120-9664	1	Bearing-Ball
3	120-9665	1	Spring-Wave
4	120-9666	1	Seal-Oil
5	120-9667	1	Ring-Retaining, Internal
6	120-9668	1	Ring-Retaining, Internal
7	120-9669	1	Ring-Retaining, Internal
8	120-9670	3	Ring-Retaining, External
9	120-9674	1	Cover-Airgap

Ref.	Part Number	Qty.	Description
10		1	Housing-Rotating ●
11		1	Housing-Fixed ●
12		1	Plate-Mounting ●
13		1	Disc-Friction ●
14		1	Insert ●
15		1	Hub ●
16	120-9671	2	Shim-30 Mm
17	120-9672	6	Shim-45 Mm
18	120-9673	1	Cup-Spring


● Not serviced separately



Differential and Traction Drum Assembly


Ref.	Part Number	Qty.	Description
1	115-7154	1	Housing-Drive, Drum
2	115-7295	1	Bushing-Straight
3	93-2561	4	Bushing-Flange
4	115-7119	1	Lever-Brake
5	115-7118	1	Lever-Traction
6	115-6769	2	Key-Sq
7	115-7135	1	Shaft-Drum
8	115-6760	1	Gear-Spur, Long
9	115-6711	1	Differential ASM
10	115-6757	1	Drum-Traction, RH
11	115-7025	1	Nut-Jam
12	253-134	1	Seal-Grease
13	115-6759	1	Drum-Traction, LH
14	115-6860	2	Bearing-Ball, Stainless
15	115-6784	1	Nut-Bearing

Ref.	Part Number	Qty.	Description
16	115-6785	1	Shaft-Hex, LH
17	115-7019	2	Bushing-Straight
18	95-0715	2	Pin-Dowel
19	120-9688	1	Screw-HH
20	120-9691	1	Washer-Flat
21	115-7121	1	Lever-Traction, Engage
22	32120-47	2	Ring-Retaining, External
23	115-7120	1	Lever-Brake, Cable
24	32151-47	1	Ring-Retaining
26	131-6150	1	Screw-HWHTF
27	115-7023	1	Collar-Lock
28	115-7284	1	Pin
29	115-7210	1	Washer-Thrust
30	340-64	1	O-Ring



Differential Assembly No. 115-6711


Ref.	Part Number	Qty.	Description
1	115-7017	1	Housing-Differential
2	115-6865	1	Cover-Differential
4	115-6866	6	Pin-Differential
5	115-6715	6	Gear-Spur, Dual
6	115-6862	9	Spacer-Differential, Natural
7	115-6716	3	Gear-Spur
8	3274-101	6	Screw-HSH
9	251-310	2	Bearing-Ball



Drum Drive Assembly


Ref.	Part Number	Qty.	Description
1	115-7156	1	Cover-Drive, Drum
2	119-1138	11	Screw-HWH
3	115-7141	1	Gasket-Housing, Drum
4	115-6786	1	Shaft-Hex, RH
6	115-6717	1	Gear-Spur
7	115-6846	1	Brake-Band
8	32120-46	1	Ring-Retaining
9	115-7211	1	Bushing-Flanged
10	115-6841	1	Spring-Extension
11	115-6744	1	Belt-Drive, Drum

Ref.	Part Number	Qty.	Description
12	115-7116	1	Pin-Mount, Brake
13	120-9687	1	Pin-Clevis, Brake
14	32151-12	1	Ring-Retaining
15	38-7820	2	Bearing-Ball
16	115-7133	1	Pulley-Idler
17	115-6845	1	Screw-Shoulder
18	93-2561	2	Bushing-Flange
19	115-7235	1	Idler-Drum
20	115-6860	1	Bearing-Ball, Stainless
21	115-7294	1	Washer-Wave



Engine Assembly


Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	120-9550	1	Engine ASM	4	115-7278	1	Sleeve-Coupler
1:2	120-9240-03	1	Guard-Muffler	5	115-7075	1	Base-Engine
1:3	120-9551	2	Screw-HWH	6	115-7292	2	Washer-Hardened
1:4	115-7352	1	Bracket-Guard, Muffler	7	120-9686	4	Screw-HH
1:5	115-7355	1	Decal-Warning	8	119-4041	6	Nut-HF
1:6	104-2628	2	Screw	9	115-7024	1	Screw-HHF
1:7	112-1540	1	Ferrite-Snap On	10	115-7293	1	Washer-Hardened
2	88-7150	1	Key-Square	11	120-9683	4	Washer-Plain
3	115-7277	1	Endpiece-Coupler	12	120-6304	1	Harness-Wire
3:1	3245-41	2	Screw-HSH	13	120-9738	2	Screw-HH



Shift Lever Assembly

Ref.	Part Number	Qty.	Description
1	104-2065	1	Screw-HWH
2	105-2442	1	Ball-Detent
3	105-2443	1	Spring-Detent
4	115-6992	1	Link-Arm, Shift
5	115-6997	2	Screw-Shoulder
6	115-7066	1	Link-Shifter
7	115-7071	2	Bumper-Sleeve, Rubber
9	115-7073	1	Spacer
10	115-7206	1	Spring Lever ASM
11	115-7098	1	Handle-Shift
12	115-7219	1	Spring-Extension
13	120-9703	1	Pin-Latch
14	120-9708	10	Bushing
15	120-9746	1	Latch-Shifter
16	115-7099	1	Lever-Transport


Ref.	Part Number	Qty.	Description
17	120-9711	1	Lever-Shift, Reel
18	120-9712	1	Lever-Cam, Reel
19	251-259	1	Bearing-Ball
20	119-4067	1	Screw-HH
21	120-9693	1	Screw-PPH
22	120-9683	1	Washer-Plain
23	120-9680	2	Washer-Flat
24	120-9747	1	Screw-Shoulder
25	364-0371	2	Nut-Hex
26	120-9684	1	Nut-Lock
27	32121-68	1	Pin-Roll
28	613328	3	Ring-Retaining
29	120-9704	1	Spring-Extension
30	120-9729	1	Collar-Spring



Handle Assembly

Ref.	Part Number	Qty.	Description
1	99-6247	2	Bushing-Bronze
2	104-2065	2	Screw-HWH
3	119-4040	7	Nut-Flange, NI
4	120-9676	4	Screw-Plastite
5	115-6966	2	Shift Lever Pin ASM
6	115-7055-03	1	Bracket-Shifter
7	115-7063-03	1	Mount-Shift
8	115-7068	1	Bracket-Mount, Switch
9	115-7078-03	1	Handle-Lower
10	115-7299	1	Spring-Extension
11	115-7172	1	Cable-Clutch, Reel
12	115-7216-03	1	Bail
13	115-7229	1	Latch-Brake
14	115-7230	1	Spring-Extension
15	115-7231	1	Washer
16	115-7232	1	Lever-Brake
17	115-7238	1	Keeper-Lever, Brake
18	115-7250	1	Cover-Console


Ref.	Part Number	Qty.	Description
19	120-9726	1	Upper Handle ASM
19:2	120-9593	1	Decal-Warning
20	115-7291	1	Spacer-Latch, Brake
21	119-1224	1	Screw-HSBH
22	120-9551	4	Screw-HWH
23	120-9678	6	Screw-HHF
24	115-7260	5	Screw-HSBH
25	119-4041	5	Nut-HF
26	112-4004	1	Screw-Shoulder
27	364-0371	1	Nut-Hex
28	115-7171	1	Cable-Brake
29	115-7271	1	Decal-Shift, Gear
30	115-7051	1	Decal-Throttle
31	115-7267	1	Decal
32	120-9598	1	Decal-Brake
33	3290-378	1	Tie-Cable
34	3290-337	1	Nut-Speed



Throttle and Console Assembly

Ref.	Part Number	Qty.	Description
1	115-6949	1	Pin-Cable, Throttle
2	120-9680	1	Washer-Flat
3	110-1758	1	Ring-Retaining
4	119-4040	1	Nut-Flange, NI
5	117-1397	1	Cable-Clutch, Traction
6	115-7226-03	1	Mount-Throttle
7	115-6947	1	Wheel-Control, Throttle
8	115-6941	1	Spacer
9	108-3153	1	Screw-HSBH
10	120-9679	1	Washer-Flat
11	121-4619	1	Spring-Compression
12	115-7208-03	1	Panel-Switch
13	117-1398	1	Cable-Throttle

Ref.	Part Number	Qty.	Description
14	120-6379	1	Sensor-Ferrous Proximity, NC
15	99-7420	1	Plug-Hole
16	1-323430	1	Module-Interlock
17	104-2065	5	Screw-HWH
18	120-9748	4	Screw-HWH
19	364-0371	5	Nut-Hex
20	120-6326	1	Sensor-Proximity, Ferrous
21	119-1347	1	Meter-Hour
22	95-8999	1	Switch
23	120-9551	2	Screw-HWH
24	115-7274	1	Decal-Console




Crankcase Assembly

Ref.	Part Number	Qty.	Description
20	121-0571	2	Guide-Valve
26	121-0611	1	Seal-Stem
30	121-0540	1	Seal-Oil
40	121-0546	1	Bearing-Ball
50	121-0608	2	Pipe-Knock
60	121-0512	2	Stud
70	121-0511	2	Stud
75	121-0539	1	Seal-Oil
80	121-0538	1	Plug
90	121-0532	1	Gasket
210	121-0607	1	Main Bearing Cover ASM
230	121-0544	1	Bearing-Ball
250	121-0652	1	Governor Gear ASM
260	121-0641	1	Sleeve-Governor
268	121-6351	2	Pin-Straight


Ref.	Part Number	Qty.	Description
270	121-6352	1	Gauge-Oil
280	121-6374	1	Gasket
300	121-0502	6	Bolt-Flange
610	121-0672	1	Cylinder Head ASM (Serial No. 1Xxxxxxx)
610	125-9159	1	Cylinder Head ASM (Serial No. 2Xxxxxxx)
620	121-0585	1	Gasket-Head
630	121-0519	4	Bolt-Flange
631	121-0520	1	Bolt-Flange
680	121-0609	1	Rocker Cover ASM
690	121-0610	1	Gasket-Cover, Rocker
700	121-0608	2	Pipe-Knock
710	121-0514	4	Bolt-Flange
960	121-0606	1	Gasket Set ●

● Not illustrated



Crankshaft and Piston Assembly


Ref.	Part Number	Qty.	Description
10	121-0586	1	Crankshaft ASM
50	121-0529	1	Nut-Flange
70	121-0537	1	Key-Woodruff
310	121-0587	1	Connecting Rod ASM
310	121-0588	1	Connecting Rod ASM (Undersize)
320	121-0612	1	Bolt-Rod, Connecting
350	121-0589	1	Pin-Piston
360	121-6353	1	Piston (Oversize 0.50 Mm)
360	121-0590	1	Piston (STD)
360	121-0591	1	Piston (Oversize 0.250 Mm)
370	121-0592	1	Piston Ring Set (STD)
370	121-0593	1	Piston Ring Set (Oversize 0.250 Mm)
370	121-0594	1	Piston Ring Set (Oversize 0.50 Mm)
380	121-0561	1	Clip



Intake and Exhaust Assembly


Ref.	Part Number	Qty.	Description
10	121-0613	1	Camshaft ASM
25	121-0625	1	Pin-Camshaft
27	121-0535	1	O-Ring
34	121-0639	1	Pin-Spring
35	121-0631	1	Lever-Release
37	121-0632	1	Clip
38	121-0640	1	Spring-Return
60	121-0673	2	Spring-Valve
70	121-0579	2	Retainer-Spring
80	121-0596	1	Valve-Intake
90	121-0597	1	Valve-Exhaust
95	121-0555	4	Collet-Valve
150	121-0599	1	Timing Chain ASM
160	121-0634	1	Tensioner
163	121-0637	1	Spring-Tensioner
166	121-0633	1	Pin-Tensioner
170	121-0635	1	Guide-Chain
200	121-0624	1	Rocker Pin ASM
202	121-0507	1	Clip
220	121-0629	1	Intake Rocker Arm ASM
225	121-0630	1	Exhaust Rocker Arm ASM

Ref.	Part Number	Qty.	Description
230	121-0524	1	Screw-Adjust
231	121-0524	1	Screw-Adjust
240	121-0528	1	Nut
241	121-0528	1	Nut
290	121-0514	1	Bolt-Flange
310	121-0595	1	Muffler ASM
315	121-0638	1	Arrestor-Spark
317	121-0525	1	Screw-Tapping
320	121-0598	1	Muffler Cover ASM
340	121-0626	1	Gasket-Muffler
350	121-6376	2	Nut-Flange
360	121-0527	2	Bolt-Flange
361	121-0513	1	Bolt-Flange
365	121-0521	1	Bolt-Flange
385	121-6354	1	Screen-Complete
387	121-0525	2	Screw-Tapping
540	121-0623	1	Insulator ASM
550	121-0628	1	Gasket-Insulator No.2
560	121-0627	1	Gasket-Insulator No.1
570	121-0506	2	Nut-Flange




Intake and Exhaust Assembly (continued)

Ref.	Part Number	Qty.	Description
580	121-0516	1	Bolt-Flange
850	121-6375	1	Pipe-Breather




Air Cleaner Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
200	121-0620	1	Base ASM
210	121-0617	1	Packing
220	121-0614	1	Packing
250	121-0621	1	Cover ASM
260	121-0616	1	Label
270	121-0622	1	Nut-Wing
272	121-0615	1	Nut-Wing
510	121-0619	1	Air Cleaner ASM
520	121-0618	1	Set-Element




Governor Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
10	121-0643	1	Lever-Governor	350	121-0651	1	Washer
20	121-0642	1	Shaft-Governor	355	121-0534	1	Washer-Friction
30	121-0674	1	Governor Rod ASM	360	121-0509	1	Screw
40	121-0645	1	Spring-Rod	365	121-0572	1	Spring-Adjust
50	121-0507	1	Clip	395	121-0650	1	Clamp
60	121-0522	1	Bolt And Washer ASM	396	121-0523	1	Screw And Washer ASM
70	121-0530	1	Nut	435	121-0654	1	Speed Control Bracket ASM
80	121-0644	1	Spring-Governor	440	121-0508	1	Screw
310	121-0646	1	Speed Control Lever ASM	450	121-0505	1	Nut-Self Lock
322	121-0648	1	Link Rod ASM	480	121-0653	1	Spring-Return
340	121-0647	1	Plate-Stop	485	121-0514	2	Bolt-Flange




Recoil and Shroud Assembly

Ref.	Part Number	Qty.	Description
10	121-0600	1	Blower Housing ASM
20	121-0550	1	Label-Trademark
40	121-0515	4	Bolt-Flange
60	121-0656	1	Case Baffle No.1 ASM
61	121-0655	1	Case Baffle No.2 ASM
80	121-0500	1	Bolt-Flange
81	121-0514	1	Bolt-Flange
220	121-6377	4	Bolt And Washer ASM




Recoil Assembly

Ref.	Part Number	Qty.	Description
1	121-6356	1	Spring-Spiral
2	121-6357	1	Reel
3	121-0676	1	Starter Rope
4	121-6358	1	Handle-Starter
5	121-6359	1	Ratchet
6	121-6360	1	Spring-Friction
8	121-6361	1	Plate-Friction
11	121-6362	1	Pulley-Starter
49	121-6363	1	Screw-Center
210	121-6355	1	Recoil Starter ASM



Fuel Tank Assembly


Ref.	Part Number	Qty.	Description
10	121-6364	1	Fuel Tank ASM (2.7L)
23	121-0605	1	Label-Model
30	121-0684	1	Fuel Tank Cap ASM
40	121-0685	1	Filter-Fuel
48	121-0542	1	Union
60	121-0506	2	Nut-Flange
63	121-0517	1	Bolt-Flange
80	121-6378	1	Pipe-Rubber
90	121-0543	2	Clamp-Hose
224	121-0649	1	Lever-Control, Choke



Carburetor Assembly


Ref.	Part Number	Qty.	Description
1	121-0553	1	Valve-Throttle
2	121-0558	1	Screw
3	121-0662	1	Valve-Choke
5	121-0574	1	Jet-Pilot
8	121-0661	1	Lever-Choke
11	121-0602	1	Throttle Shaft ASM
12	121-0568	1	Bolt
14	121-6366	1	Needle
15	121-0660	1	Pin
16	121-0659	1	Float Body ASM
17	121-0559	1	Packing
18	121-0560	1	Packing-Chamber
19	121-0562	1	Float
20	121-0601	1	Nozzle-Main
22	121-0575	1	Jet-Main

Ref.	Part Number	Qty.	Description
24	121-0563	1	Clip
40	121-0554	1	Screw
41	121-0677	1	Spring
44	121-0557	1	Jet-Air
45	121-0552	1	Jet-Air, Pilot
62	121-0570	1	Seal
102	121-0573	1	Seal
144	121-0664	1	Nut
210	121-6365	1	Carburetor ASM
300	121-0675	1	Fuel Strainer ASM
302	121-0658	1	Packing
303	121-0657	1	Cup
325	121-0663	1	O-Ring
327	121-0556	2	Screw



Flywheel and Coil Assembly

Ref.	Part Number	Qty.	Description
10	121-0604	1	Flywheel ASM
11	121-0668	1	Ignition Coil ASM
12	121-6368	1	Lamp Coil ASM
23	121-0669	1	Spacer
30	121-0504	2	Bolt And Washer ASM
35	121-6369	2	Bolt And Washer ASM
50	121-6370	1	Wire-Coil
100	121-0547	1	Plug-Spark
110	121-0548	1	Cap-Spark Plug



Gear Reduction Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
55	121-0536	1	Key
330	121-0501	1	Bolt-Flange
350	121-6371	1	Washer
550	121-0671	1	Gasket-Cover, Reduction
600	121-0670	1	Reduction Cover ASM
605	121-0541	1	Seal-Oil
610	121-6372	1	Shaft-Driving
620	121-0545	1	Bearing-Ball
640	121-0518	6	Bolt-Flange
650	121-6373	1	Shaft-Driven

Attachments and Accessories

For 04040 Greensmaster Flex 2100 Traction Unit

Product Name	Model/Part
Wheel Kit	04123
Trans Pro 80 Tow-Behind Trailer.....	04238
Trans Pro 100 Tow-Behind Trailer.....	04240
Flat Ramp	04245
Rail Ramp Kit (Update).....	04247
Rail Ramp Conversion Kit (Update).....	04248
11-Blade Cutting Unit.....	04251
14-Blade Cutting Unit.....	04252
Narrow Wiehle Roller (Qty 1)	04255
Wide Wiehle Roller (Qty 1)	04256
Front Full Smooth Roller (Qty 1)	04257
Extended Narrow Wiehle Roller (Qty 1)	04258
Flex Groomer Drive, Forward Rotating	04259
Flex Groomer Drive, Counter Rotating.....	04260
LED Light Kit.....	04265
Out-Front Brush Kit.....	04266
Paspalum Wiehle Roller (Qty 1).....	04267
21in Soft Grooming Brush, DPA.....	04274
21in Stiff Grooming Brush, DPA.....	04275
Turf Evaluator	04399
Steel Roller (Qty 1)	04628
Left-Hand Carbide Grooming Reel	04708
Carbide Grooming Reel	04711
Steel Grooming Reel	04712
Groomer Brush	04713
Bedbar	106-2648-01
Roller Seal Replacement (Qty 1)	107-1594
Steel Roller Asm	107-3509
Wide Wiehle Steel Roller Asm	107-3514
Bedknife-Tournament, Extended	108-4302
Bedknife-Microcut, Extended.....	108-4303
Blade-Groomer, Helix	110-2333
Bedknife-EDGEMAX, Microcut.....	115-1880
Bedknife-EDGEMAX, Tournament Cut	115-1881
Wireless Hourmeter	115-4754
Rear Full Roller Kit (Aluminum).....	115-7356
Narrow Wiehle Roller Kit.....	115-7360
Roller Extension Kit	115-7361
Front Brush for Narrow Wiehle Roller (Qty 1).....	115-7377
Front Brush for Wide Wiehle Roller (Qty 1)	115-7378
Front Brush for Full Roller (Qty 1)	115-7379
Front Comb for Narrow Wiehle Roller (Qty 1).....	115-7380
Front Comb for Wide Wiehle Roller (Qty 1)	115-7381
Front Comb for Full Roller (Qty 1)	115-7382
Rear Roller Scraper Kit with Roller.....	115-7383
Wide Wiehle Roller Kit	115-7386

Attachments and Accessories (continued)

Front Full Smooth Roller Kit	115-7388
High Altitude Jet-Subaru	117-0073
21in 8 Blade Reel ASM	119-4103
21in 11 Blade Reel ASM	119-4104
21in 14 Blade Reel ASM	119-4105
Steel Rear Full Roller (Qty 1)	120-9595
High Height-of-Cut Arms (Qty 1)	120-9600
Rear Roller Adjustment (Qty 1)	120-9602
Wire Harness-Wireless Hour Meter	120-9690
Spark Plug	121-0547
Element Set	121-0618
Filter-Fuel	121-0685
Rear Roller Scraper (Qty 1)	121-2260
MVP Kit-Cutting Unit Re-Build	121-2637
Extended Wiehle Roller Kit	121-4675
MVP Kit, Forward Rotating Groomer Re-Build	121-9517
Blade-Groomer, Thin (Carbide)	121-9531
Paspalum Wiehle Roller	121-9535
Front Scraper for Narrow Wiehle Roller (Qty 1)	125-3503
Front Scraper for Wide Wiehle Roller (Qty 1)	125-3504
Front Scraper for Full Roller (Qty 1)	125-3505
Toro Reel Paper (10 Pack)	125-5610
Toro Reel Shim (0.002in)	125-5611
21in Soft Grooming Brush Kit	127-1547
21in Stiff Grooming Brush Kit	127-1548
Groomer Quick Up Kit	127-6119
MVP Filter and Spark Plug Kit, 2012 and After Walk-Behind Greensmaster Mower	30097
Cast Iron Wiehle Roller (Qty 1)	71-1550
Bedknife-Microcut	93-4262
Bedknife-Tournament Cut	93-4263
Bedknife-Low Cut	93-4264
Height-of-Cut Bar	94-9010
Bedbar-Aggressive	99-3794-03

Notes:



Count on it.