



Form No. 3418-528 Rev B

Count on it.

Parts Catalog

Cab Kit

Workman® HDX and HDX-Auto Utility Vehicle

Model No. 07392—Serial No. 401400001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame, Mount and Seal Assembly 4

Roof, Wiper Motor and Console Assembly 6


Window and Latch Assembly 8

Rain Gutter and Dash Support Assembly 10

Inner Fender Assembly 12

Attachments and Accessories 14

Frame, Mount and Seal Assembly




Frame, Mount and Seal Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	125-9805-03	1	Mount-Cab, RH
3	125-9802-03	1	Mount-Cab, LH
4	110-5954	2	Mount-Center, Bonded
5	3234-40	2	Screw-HF
6	98-4799	2	Spacer
7	114-0019	4	Washer-Plain
8	3296-25	4	Nut-Lock, NI
9	125-9633-03	2	Bracket-Mount, Front
10	136-2147-03	1	Mount-LH
11	3234-42	4	Screw-HHF
12	104-7201	2	Nut-HF
13	86-1990	2	Washer-Thrust
14	325-4	2	Screw-HH
15	99-5107	2	Nut-Lock
16	104-8301	4	Nut-HF, NI
17	136-2146-03	1	Mount-RH
18	137-1032-03	1	Plate-Floor, LH
19	32104-95	8	Screw-HWH
20	137-1026-03	1	Cover-Panel, Lower LH
21	125-9841-01	1	Plate-Panel, LH (Seal)
22	137-1025-03	1	Cover-Panel, Lower RH
23	137-1031-03	1	Plate-Floor, RH
24	125-9840-01	1	Plate-Panel, RH (Seal)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
25	132-7769-03	1	Plate-Panel,Rear
26	125-9842	2	Foam-Seal, Side
27	125-9843	1	Foam-Seal, Rear (Center)
28	125-9844	2	Foam-Seal, Rear
29	125-9622	22	Rivet-Blind
30	127-9945	1	Foam-Upholstrey, Center
31	127-9946	2	Foam-Upholstrey, Side
32	130-0450	2	Foam-Interior, Side
33	130-0449	1	Foam-Interior, Rear
34	137-1315	1	Seal-Trim, Cam
35	93-9850	1	Decal-ROPS, CE
36	117-4955	2	Decal-Danger, ROPS (CE)
37	137-1033	2	Seal-Cover
40	130-5964	2	Decal-Window, Pin
41	121-9777	2	Spring-Compression
42	130-5583	1	Strap-Mount, Manual
43	3229-3	2	Screw-CARR
46	107069	1	Clip
47	66-9302	2	Screw-HHF, Whiz
49	119-8615	2	Isolator-Rubber
50	136-2151	2	Spacer-Mount
51	3234-46	2	Screw-HHF
52	3217-7	2	Nut-Hex


Roof, Wiper Motor and Console Assembly



Roof, Wiper Motor and Console Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-2733	1	Roof-Cab, Workman	15	107-1013	4	Nut-Speed
2	107069	12	Clip	16	125-9603-03	1	Plate-Cover, Fuse
3	119-0872	14	Washer-Sealing, Bonded	17	125-7438	2	Knob-Screw, Thumb
4	120-4654	12	Screw-HHF	18	106-8737	2	Nut-Retainer
5	130-6087	1	Wiper Motor ASM	19	126-3739	8	Nut-Retainer
6	127-9878	1	Arm-Wiper	20	42862	1	Block-Terminal, Ground
7	130-5430	1	Blade-Wiper	21	42863	1	Strip-Jumper
8	136-1969	1	Console-Roof Top	22	137-1316	1	Seal-Trim
9	125-7437	1	Light-Dome	23	122-0308	1	Harness-Wire, Headliner
10	119-8355	1	Switch-Rocker	24	114-4899	12	Rivet-Push
11	99-7420	3	Plug-Hole	25	137-1018-03	1	Mount-Console
12	130-5444	1	Console Panel ASM	26	137-1313-03	1	Support-Roof
12:1	130-5439	1	Decal-Console	27	3290-379	4	Tie-Cable
13	104-2408	8	Screw-HSBH	28	109103	1	Fuse-Blade, 30 Amp
14	120-4578	4	Nut-HF				


Window and Latch Assembly



Window and Latch Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	125-9521	6	Screw-Shoulder, HSH	12	125-9793	2	Link-Window
2	125-9537	6	Bushing-Flange	13	125-9792	2	Handle-Window
3	125-9849	1	Window-Rear	14	3274-14	2	Screw-HSH
3:1	125-9848	1	Trim-Window, Rear	15	120-9681	8	Nut-Lock, NI
4	125-9982	18	Bushing-Flange	16	3274-59	2	Screw-HSH
5	130-5815	6	Washer-Backup	17	125-9987	2	Mount-Latch
6	104-8300	10	Nut-HF, NI	18	127-9850	2	Pin-Release, Quick
7	121-8441	2	Washer-Spacer	19	119-9812	2	Bolt-Shoulder
8	121-8535-03	2	Hinge-Window	20	104-7201	2	Nut-HF
9	125-9520	4	Screw-Shoulder, HSH	21	125-9676	2	Washer-Backup
10	125-9850	1	Window-Front, Upper	22	130-0590	2	Mount-Tab
10:1	127-9962	1	Seal-Trim, Windshield	23	1-807513	4	Bolt-CARR
11	127-9933	2	Plate-Backer, Windshield	24	130-5578	2	Tubing-Seal, Rubber

Rain Gutter and Dash Support Assembly




Rain Gutter and Dash Support Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	137-1021-03	1	Back-Plate
2	137-1024-03	1	Plate-Adjust
3	116-0559	1	Bolt-TAP
4	32128-56	1	Nut-HF
5	137-1023	1	Plate-Stop
6	3229-5	4	Screw-CARR
7	104-7201	4	Nut-HF

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8	137-1314-03	1	Gutter
9	32180-139	3	Mount-Tie Wrap, Magnetic
10	138-2751	1	Fitting-Tee, Barb
11	138-2704	1	Tube-Clear, 48 Inch
12	138-2705	1	Tube-Clear, 17 Inch
13	138-2706	1	Tube-Clear, 13 Inch
14	3290-378	3	Tie-Cable

Inner Fender Assembly



Inner Fender Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-2659	1	Fender-Inner
2	138-2660	2	Strap-Fender
3	3234-4	6	Screw-HHF
4	104-7201	8	Nut-HF

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	138-2662	2	Bumper-Rubber
6	119-8952	2	Washer
7	3290-379	2	Tie-Cable

Attachments and Accessories

For 07392 Cab Kit Workman HDX and HDX-Auto Utility Vehicle

Product Name	Model/Part
Door Kit with Sliding Window	07393
Exterior Mirror Kit.....	130-5448
Interior Mirror Kit.....	130-5449
Beacon Kit	130-5484
Work Light Kit	130-5485
Windshield Washer Fluid Kit, 2015 and after Workman MD/HD Series Utility Vehicle	130-5615

Notes:



Count on it.