



Topdresser 1800

for Workman[®] 3000/4000 Series

Model No. 44225—90001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

Contents

| Description | Page | Description | Page |
|--|------|---|------|
| Frame Assembly | 3 | Hopper Assembly | 7 |
| Slider Bed and Roller Assembly | 4 | Gate Slide and Brush Guard Assembly | 8 |
| Gate Assembly | 5 | Chain, Sprocket, and Guard Assembly | 9 |
| Brush and Motor Assembly and Hydraulic Schematic | 6 | | |

Accessories


| Description | Model / Parts No. | Description | Model / Parts No. |
|-----------------------------|-------------------|-------------|-------------------|
| Lift Bracket Assembly | 92-4452 | | |

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

| Abbreviation | Meaning | Abbreviation | Meaning |
|--------------|-----------------------------------|--------------|-------------------------|
| AR | as required | INC | incorporated |
| ASM | assembly | LH | left hand |
| CARR | carriage | NI | nylon insert |
| DEG | degrees | PPH | Phillips pan head |
| FH | flat head | PTH | Phillips truss head |
| GA | gauge | PTO | power take off |
| HF | hex flange | RH | right hand |
| HH | hex head | SFH | slotted fillister head |
| HHF | hex head flange | SHH | slotted hex head |
| HLH | hex lag head | SQH | square head |
| HJ | hex jam | SHWH | slotted hex washer head |
| HOC | height-of-cut | SPH | slotted pan head |
| HS | hex socket | SRH | slotted round head |
| HSBH | hex socket button head | STD | standard |
| HSFH | hex socket flat head | TAP | self tapping |
| HSH | hex socket head | TTH | Torx truss head |
| HWH | hex washer head | WH | wing head |
| HWHTF | hex washer head thread forming | | |

PROTOTYPE




Sheet No.: 5
T-3279

Brush and Motor Assembly and Hydraulic Schematic

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|---------------------|
| 1 | 3296-45 | 2 | Nut-Lock, NI |
| 2 | 99-0156 | 1 | Motor-Hydraulic |
| *2:1 | 100-1446 | 1 | Kit-Seal |
| 2:2 | 3257-43 | 1 | Key-Woodruff |
| 3 | 340-89 | 1 | Fitting-45° |
| 3:1 | 237-30 | 1 | O-Ring |
| 3:2 | 237-80 | 1 | O-Ring |
| 4 | 99-0191 | 1 | Hose-Pressure |
| 5 | 340-12 | 2 | Fitting-Straight |
| 5:1 | 237-30 | 1 | O-Ring |
| 6 | 92-2672 | 2 | Coupling-Hydraulic |
| 7 | 99-0177 | 1 | Hose-Hydraulic |
| 8 | 100-1431 | 1 | RH Motor Brace ASM |
| 8:2 | 98-3114 | 1 | Decal-Warning, Ce |
| 9 | 99-0162 | 1 | Brush |
| 10 | 99-0192 | 1 | Hose-Return |
| 11 | 100-1430 | 1 | LH Motor Brace ASM |
| 11:2 | 99-0015 | 1 | Decal-Danger |
| 11:3 | 93-9867 | 1 | Decal-No Riders |
| 11:4 | 58-6520 | 1 | Decal-Grease |
| 12 | 99-0041 | 1 | Shaft-Brush |
| 13 | 99-0160 | 1 | Bearing |
| 13:1 | 251-246 | 1 | Collar w/Set Screws |
| 13:2 | 3245-35 | 1 | Screw-HS |
| 13:3 | 302-2 | 1 | Fitting-Grease |
| 14 | 3256-25 | 4 | Washer-Flat |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|---------------------------------|
| 15 | 3296-48 | 2 | Nut-Lock NI |
| 16 | 323-4 | 4 | Screw-HH |
| 17 | 340-105 | 2 | Fitting-90° |
| 17:1 | 237-30 | 1 | O-Ring |
| 17:2 | 237-80 | 1 | O-Ring |
| 18 | 324-6 | 2 | Screw-HH |
| 19 | 99-0155 | 1 | Hydraulic Motor Conveyor ASM |
| *19:1 | 100-1447 | 1 | Kit-Seal |
| 19:2 | 10-7070 | 1 | Key-Square |
| 20 | 325-6 | 4 | Screw-HH |
| 21 | 3256-26 | 4 | Washer-Flat |
| 22 | 99-0116 | 1 | Plate-Spacer |
| 24 | 3253-7 | 2 | Washer-Lock/Sp |
| 25 | 340-6 | 1 | Fitting-Straight |
| 25:1 | 237-30 | 1 | O-Ring |
| 25:2 | 237-80 | 1 | O-Ring |
| 29 | 3246-3 | 4 | Screw-HS |
| 30 | 3256-24 | 4 | Washer-Flat |
| 31 | 3253-21 | 4 | Washer-Lock |

* Not illustrated




Sheet No.: 6

Hopper Assembly

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|------------------------|
| 1 | 100-1434 | 1 | RH Hopper Panel ASM |
| 1:2 | 99-0013 | 1 | Decal-Topdresser, 1800 |
| 1:3 | 94-1235 | 1 | Decal - Capacity |
| 2 | 32128-33 | 44 | Nut-HF |
| 3 | 99-0142 | 2 | Seal-Sand, Side |
| 4 | 3229-25 | 40 | Screw-CARR |
| 5 | 100-1433 | 1 | LH Hopper Panel ASM |
| 5:2 | 99-0013 | 1 | Decal-Topdresser, 1800 |
| 5:3 | 94-1235 | 1 | Decal - Capacity |
| 6 | 99-0143 | 1 | Seal-Sand, Front |
| 7 | 100-1428 | 2 | Front Lift Eye ASM |
| 7:2 | 93-9084 | 1 | Decal-Point, Lift |
| 7:3 | 93-9529 | 1 | Decal-Value, Kg |
| 8 | 99-0020 | 1 | Panel - Hopper, Front |
| 9 | 321-4 | 4 | Screw-HH |
| 10 | 74-0720 | 1 | Tube-Manual |
| 11 | 2412-133 | 2 | R-Clamp |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |



Sheet No.: 8

Chain, Sprocket, and Guard Assembly

| Ref. No. | Part No. | Qty. | Description |
|----------|-------------|------|-------------------------|
| 4 | 99-0171 | 1 | Guard-Chain & Sprockets |
| 5 | 100-1442 | 1 | Spacer-Guard |
| 6 | 100-1450-03 | 1 | Finger Guard ASM |
| 7 | 3296-39 | 1 | Nut-Lock, NI |
| 8 | 323-14 | 1 | Screw-HH |
| 9 | 99-0165-03 | 1 | Sprocket-Drive |
| 10 | 3246-3 | 2 | Screw-HS |
| 11 | 99-0164 | 1 | Chain-Roller |
| 11:1 | 2710-16 | 1 | Link-chain |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

PROTOTYPE



PROTOTYPE