



48" Special Edition Mower Wheel Horse® Garden Tractor Attachment

Model No. 78363DI – 200000001 and Up



Parts Catalog

Only standard Toro
replacement parts are
available for order.

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.


Contents

Description	Page	Description	Page
Reinforcement Plate Assembly	1	Pulley Box Assembly	4
Spindle and Blade Assembly	2	Miscellaneous Deck Hardware	5
Deck Suspension Assembly	3	Decal Assembly	6

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	INC	incorporated
ASM	assembly	LH	left hand
CARR	carriage	NI	nylon insert
DEG	degrees	PPH	Phillips pan head
FH	flat head	PTH	Phillips truss head
GA	gauge	PTO	power take off
HF	hex flange	RH	right hand
HH	hex head	SFH	slotted fillister head
HHF	hex head flange	SHH	slotted hex head
HLH	hex lag head	SQH	square head
HJ	hex jam	SHWH	slotted hex washer head
HOC	height-of-cut	SPH	slotted pan head
HS	hex socket	SRH	slotted round head
HSBH	hex socket button head	STD	standard
HSFH	hex socket flat head	TAP	self tapping
HSH	hex socket head	TTH	Torx truss head
HWH	hex washer head	WH	wing head
HWHTF	hex washer head thread forming		




Sheet No.:2

Reinforcement Plate Assembly

Ref. No.	Part No.	Qty.	Description
1	3230-1	1	Screw-CARR
2	113603	1	Roller Shaft
3	113349	1	Roller-Anti Scalp
4	3296-29	1	Nut-Lock
5	95-3879-01	1	Plate-Reinforce
6	95-3949-03	1	Cover-Belt, RH
7	46-8560	8	Screw-HHF
8	95-3950-03	1	Cover-Belt, LH
9	3296-39	7	Nut-Lock, NI
10	94-7642-03	2	Bracket-Guide
11	3256-41	1	Washer-Flat
12	95-3953	1	Guide - Belt
13	9335054	2	Pin-Hair
14	283-2	2	Pin-Clevis
15	3256-24	2	Washer-Flat
16	68-2730	2	Wheel-Gage
17	68-2350	2	Wheel-Gage
18	3272-21	1	Pin-Cotter
19	29-4820	1	Roller
20	3231-25	4	Screw-CARR
21	118960-03	1	Shaft-Roller
22	99-8082	1	Deck ASM
22:2	92-7108	2	Decal-Danger
22:3	3296-16	2	Nut-Lock, NI
22:4	3256-1	2	Washer-Flat
22:5	95-2747	1	Fitting-Washout

Ref. No.	Part No.	Qty.	Description
22:6	46-6290	1	O-Ring
22:7	3229-1	2	Screw-CARR
22:8	95-3270	1	Connector-Hose
23	9152366	1	Nut-HJ
24	93-1633	2	Washer
25	99-3708	1	Chute ASM
25:2	93-1122	1	Decal-Danger
26	116080	1	Bushing-Pivot
27	93-1630	1	Spring - Deflector
28	3256-26	1	Washer-Flat
29	3272-10	1	Pin-Cotter
35	321-4	1	Screw-HH
36	3296-42	1	Nut-Lock
37	46-8560	2	Screw-HHF
38	98-5032	1	Spring-Gage Wheel, LH
39	98-5033	1	Spring-Gage Wheel, RH
40	3231-22	1	Screw-CARR




Sheet No.:3

Spindle and Blade Assembly

Ref. No.	Part No.	Qty.	Description
1	95-3876	1	Bar – Idler Support
2	100071	1	Spring–Extension
3	3256-24	2	Washer–Flat
4	3253-21	1	Washer–Lock
5	323-7	2	Screw–HH
6	3296-39	3	Nut–Lock, NI
7	107675	2	Washer
8	93-1622	1	Pulley–Idler
9	107674	2	Spacer–Bushing
10	302-5	3	Fitting – Grease
11	3220-6	3	Nut–Jam
12	3253-8	3	Washer–Lock
13	95-3958	1	Pulley–Double
14	109966	6	Bearing–Ball
15	114568	3	Housing–Spindle
16	116085	3	Tube
17	32120-42	3	Ring–Retaining
18	106068	3	Spacer–Blade
19	106067	3	Cup–Spindle
20	78-6710	1	Shaft–Spindle
21	3256-28	3	Washer–Flat
22	106078	3	Blade
23	9202574	3	Washer–Flat
24	3220-7	3	Nut–Jam
25	52-2861	2	Washer
26	323-9	1	Screw–HH


Ref. No.	Part No.	Qty.	Description
27	112674	2	Shaft–Spindle
28	9080326	12	Screw–HH
29	110146	2	Pulley–Blade, Drive
30	95-3878	1	V–Belt



Sheet No.:4

Deck Suspension Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	98-5041	1	LH Leveler ASM	25	3272-12	1	Pin-Cotter
1	98-5043	1	RH Leveler ASM	26	3256-26	1	Washer-Flat
1:1	98-3478	2	Decal - Warning	27	323-9	4	Screw-HH
2	323-7	2	Screw-HH	28	3296-23	1	Nut-Lock, NI
3	94-7801-03	2	Draftbar	29	94-7802	1	Trunnion
4	102809	6	Locknut-Flange	30	94-7953	1	Collar
5	94-7804-03	2	Draftbar Adj.	31	3245-2	2	Screw-Set, HSH
6	94-7943-03	1	Shaft-Leveler	32	94-7543-03	1	Clamp
7	95-4102	2	Wheel	33	32128-40	2	Nut-Flange
8	3256-69	4	Washer-Flat	34	94-7954	1	Rod-Level Adjustment
9	933216	4	Pin-Roll, Spirol	35	3231-4	2	Screw-CARR
10	115706	4	Spacer	36	98-3479	1	Washer-Support
11	3231-38	4	Screw-CARR				
12	32152-2	4	Nut-Conelock				
13	94-2130-03	1	Shaft-Draft Bar				
14	3231-2	2	Screw-CARR				
15	114127	2	Spacer				
16	95-3875-03	1	Support-Wheel				
17	94-7544-03	1	Quad-Deck				
18	102597	1	Grip				
19	94-7965-03	1	Lever-HOC				
20	101853	1	Spring-Compression				
21	92-1057	2	Bolt-Shoulder				
22	32146-2	2	Nut-Lock, NI				
23	110837-03	1	Bracket-Pivot				
24	3296-39	2	Nut-Lock, NI				




Sheet No.:5

Pulley Box Assembly

Ref. No.	Part No.	Qty.	Description
1	3296-39	2	Nut-Lock, NI
2	94-2447	2	Pulley-Idler
3	94-2284-01	1	Lever-Idler
4	323-10	2	Screw-HH
5	94-2423	1	Rod-Pivot
6	32144-70	1	Screw-HH
7	94-2449	1	Ferrule - Adjuster
8	94-2287-03	1	Box-Pulley
9	3256-24	1	Washer-Flat
10	108571	1	Washer-Spring
11	933156	1	Pin-Spirol, Roll
12	101851	1	Knob-Adj
13	94-7764	1	Tensioner-Idler
14	3296-29	1	Nut-Lock
15	32152-9	1	Locknut
16	100-1196	1	Spring - Extension
17	19-1471	1	Screw-Shoulder
18	94-2288	1	Rod - Tension
19	302-5	2	Fitting - Grease
20	94-2462-01	1	Arm-Idler
21	95-4095	1	V-Belt

Ref. No.	Part No.	Qty.	Description



Sheet No.:7

Decal Assembly

Ref. No.	Part No.	Qty.	Description
1	98-3481	1	Decal-Belt Routing
6	111655	1	Decal-HOC
7	98-3480	1	Decal-Belt Routing
10	93-7282	1	Decal-wheel Adjustment

Ref. No.	Part No.	Qty.	Description

Maintenance Record

[illegible]

