



Mid-Size Mower

ProLine Gear 15 HP with 36 in. Side Discharge Mower

Model No. 30253—210000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

Contents

Description	Page	Description	Page
Engine and Clutch Assembly	3	Cylinder Head, Valves And Breather Assembly	
Clutch Assembly No. 54-3200	4	Kohler Model CV15T-41604	19
Fuel Tank Assembly	5	Ignition and Electrical Assembly	
Lower Controls Assembly	6	Kohler Model CV15T-41604	20
Transmission and Drive System Assembly	7	Blower Housing And Baffles Assembly	
Wheel Drive and Brake System Assembly	8	Kohler Model CV15T-41604	21
Handle Assembly	9	Starter Assembly	
Control Panel Assembly	10	Kohler Model CV15T-41604	22
Deck Assembly	11	Fuel System Assembly	
Spindles, Pulleys and Belts Assembly	12	Kohler Model CV15T-41604	23
Spindle Housing Assembly No. 104-6315	13	Engine Controls Assembly	
Spindle Housing Assembly No. 104-6317	14	Kohler Model CV15T-41604	24
Carrier Frame Assembly	15	Air Cleaner Assembly	
Electrical Schematic	16	Kohler Model CV15T-41604	25
Crankcase Assembly		Exhaust Assembly	
Kohler Model CV15T-41604	17	Kohler Model CV15T-41604	26
Oil Pan and Lubrication Assembly			
Kohler Model CV15T-41604	18		


Accessories

Description	Model / Part No.	Description	Model / Part No.
Bagging Unit	Model No. 30125		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	HYD	hydraulic
ASM	assembly	INC	incorporated
CARR	carriage	LH	left hand
DEG	degrees	NI	nylon insert
FH	flat head	PPH	Phillips pan head
GA	gauge	PTH	Phillips truss head
HF	hex flange	PTO	power take off
HH	hex head	RH	right hand
HHF	hex head flange	SFH	slotted fillister head
HLH	hex lag head	SHH	slotted hex head
HJ	hex jam	SQH	square head
HOC	height-of-cut	SHWH	slotted hex washer head
HS	hex socket	SPH	slotted pan head
HSBH	hex socket button head	SRH	slotted round head
HSFH	hex socket flat head	STD	standard
HSH	hex socket head	TAP	self tapping
HWH	hex washer head	TTH	Torx truss head
HWHTF	hex washer head thread forming	WH	wing head



Sheet No.:3

Engine and Clutch Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	288-10	1	Cap-Pipe	25	112843	1	Washer
2	105-2624	1	Pipe Nipple	26	54-3200	1	Clutch/Brake
3	63-8440	1	Decal-Hot Surface	27	105-0827	1	Pulley-Drive
4		1	Engine-Kohler, Cv15t-41604	28	608006	1	Key
5	32144-19	1	Screw-Thread Forming	29	94-5847-01	1	Cover - Pulley
6	2412-87	1	Clamp-Cable	30	56-6360	1	Filter-Fuel
7	2412-98	2	Clamp				
8	47-2982	1	Hose-Gas				
9	104-8136	1	Wire Harness				
10	12-3270	1	Screw				
11	3255-7	1	Washer-Lock/Ext				
12	32128-20	2	Nut-HF				
13	237-124	1	Grommet				
14	104-6373	1	Tube - Retainer				
15	1-613235	4	Washer				
16	1-633630	2	Grommet-Brake				
17	1-633545	2	Spacer-Grommet				
18	1-633543	1	Strap,Clutch/Brake				
19	322-11	1	Screw-HH				
20	3256-23	2	Washer-Flat				
21	33114-025	4	Screw-HH				
22	3256-3	2	Washer-Flat				
23	322-7	1	Screw-HH				
24	3212-9	1	Screw-HH				




Sheet No.:A1

T-3726

Clutch Assembly No. 54-3200

Ref. No.	Part No.	Qty.	Description
1	251-291	1	Bearing-Pulley
2	251-292	1	Bearing-Field
3	44-8310	2	Ring-Retaining
4	44-8320	3	Spring
5	3296-6	3	Nut-Lock, NI
6	44-8330	1	Spacer-Pulley Bearing
7	44-8340	1	Collar-Bearing
8	44-8360	1	Field Coil-Rotor / Bearing ASM
9	44-8370	1	Armature / Pulley / Bearing ASM
10	54-0230	1	Field Bearing ASM


Ref. No.	Part No.	Qty.	Description



Sheet No.:5

Fuel Tank Assembly


Ref. No.	Part No.	Qty.	Description
1	55-3570	1	Gas Cap ASM
2	1-323551	1	Tank-Fuel
3	104-8121	2	Stud-Threaded
4	98-3256	1	Decal-Ground Speed
5	104-8102-01	1	Plate-Shift Gate
6	3256-23	4	Washer-Flat
7	1-633349	2	Spring-Tank, Fuel
8	3296-47	2	Nut-Lock, NI
9	104-8100-01	1	Traction Frame ASM
10	2412-98	4	Clamp
11	47-2982	1	Hose-Gas
12	1-603770	1	Valve-Fuel
14	47-2966	1	Hose-Gas
15	322-4	2	Screw-HH
16	3253-4	2	Washer-Lock
17	95-2814	1	Decal-Fuel Shut Off
18	98-0776	1	Decal-Caution
19	1-543277	1	Elbow-Tank, Fuel
20	1-513645	1	Bushing-Valve, Fuel



Lower Controls Assembly

Ref. No.	Part No.	Qty.	Description
1	32103-25	2	Nut-Wing
2	3256-23	6	Washer-Flat
3	3290-307	4	Pin-Hair
4	52-2890	2	Bushing-Nylon
5	74-0521	2	Fitting-Rod
6	283-6	2	Pin-Clevis
7	74-0040	4	Spacer-Idler Pivot
8	67-6380-01	1	Bracket-LH Support
9	67-6370-01	1	Bracket-RH Support
10	323-16	2	Screw-HH
11	323-6	4	Screw-HH
12	3296-23	2	Nut-Lock, NI
13	95-2800	2	Pulley-Idler
14	95-2801	2	Spacer-Pulley
15	74-0220-01	1	Bracket-LH Idler
16	74-0230-01	1	Bracket-RH Idler
17	51-4450	2	Screw-Leveler
18	68-9690	2	Fitting-Rod
19	51-4380	1	Spring-LH Torsion
20	51-4370	1	Spring-RH Torsion
21	3296-39	6	Nut-Lock, NI
31	3234-32	6	Screw-HHF
32	32128-23	6	Nut-HF


Ref. No.	Part No.	Qty.	Description



Sheet No.:7

Transmission and Drive System Assembly


Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	47-1970	1	Grip-Engagement	26	323-9	1	Screw-HH
2	98-3274-03	1	Lever-Shift	27	16-7509	1	Lever-Idler
3	3296-6	1	Nut-Lock, NI	28	62-4540	1	Pulley
4	98-5975	1	Washer-Belleville	29	3296-39	1	Nut-Lock, NI
5	1-323379	1	Washer-Shifter Lever	30	322-2	4	Screw-HH
6	1-323500	1	Transmission, Peerless	31	3253-4	4	Washer-Lock
7	302-5	2	Fitting-Grease	32	3296-42	4	Nut-Lock, NI
8	98-0789	2	Coupler	33	3296-6	1	Nut-Lock, NI
9	51-4220	2	Guard-Coupler				
10	1-323254	2	Flange-Output				
11	321-4	4	Screw-HH				
12	3257-5	3	Key-Woodruff				
13	3245-9	2	Screw-Set				
14	32151-62	2	Ring-Retaining				
15	105-0828	2	Pulley-Transmission				
16	104-1102	2	Shaft-Output				
17	1-323252	2	Bearing-Shaft, Transmission				
18	95-1529	1	Rod-Shield				
19	95-1526	1	Shield-Trailing				
20	51-4190	1	Pulley-Driven				
21	3245-1	1	Screw-Set, HSH				
22	32120-64	1	Ring-Snap, External				
23	26-9671	1	V-Belt				
24	68-2190	1	Spring-Extension				
25	27-6230	1	Bolt-Wheel				



Wheel Drive and Brake System Assembly

Ref. No.	Part No.	Qty.	Description
1	3218-3	2	Nut-Jam
2	1-323307	2	Pin - Clevis
3	51-4610-01	1	Arm-LH Brake
4	51-4600-01	1	Arm-RH Brake
5	3290-307	2	Pin-Hair
6	51-4580	2	Rod-Brake
7	32151-40	2	Ring-Retaining
8	32151-56	2	Ring-Retaining, External
9	323-9	2	Screw-HH
10	1-323261	2	Drum, Brake
11	104-8152	2	Belt-Traction Drive
12	51-4170	8	Spacer-Pulley
13	51-4160-03	4	Pulley-Wheel
14	1-413333	2	Hub, Wheel W/Cups
15	3296-29	8	Nut-Lock
16	254-72	4	Bearing-Taper, Cup
17	254-94	4	Bearing-Taper, Cone
19	242-50	8	Nut-Lug
20	241-119	2	Cap-Dust
21	1-809082	2	Nut, SHH
22	1-523157	2	Washer-Spacer
23	1-633926	8	Stud-Wheel
24	302-19	2	Fitting-Grease
25	1-323262	2	Band, Brake
26	322-8	8	Screw-HH


Ref. No.	Part No.	Qty.	Description
27	1-543511	2	Seal-Grease
28	104-1197	2	Spacer-Wheel
29	1-806800	2	Pin-Cotter
30	3234-11	6	Screw-HHF
31	104-1196-01	1	Axle ASM
32	32128-21	6	Nut-HF
33	104-6321	2	Wheel And Tire ASM
34	104-1198	2	Wheel And Tire ASM
35	3290-357	2	Nut-Flange, Lock



Sheet No.:9

Handle Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	82-7631	2	Rod-Control				
2	3290-307	2	Pin-Hair				
3	237-141	2	Grommet-Rubber				
4	82-2290	1	Decal-Control Bar				
5	82-7680-03	1	Bail				
6	51-4850-03	1	Lever-Parking Brake				
7	32105-1	1	Screw-SHH				
8	82-7690-03	1	Bar-Control				
9	82-2280	1	Decal-Reverse Handle				
10	3272-11	2	Pin-Cotter				
11	99-8501-03	1	Control-Pivot				
12	283-55	2	Pin-Clevis				
13	67-6440-03	1	Handle-Upper				
14	3290-378	1	Tie-Cable				
15	3234-11	4	Screw-HHF				
16	32128-21	4	Nut-HF				
17	98-4387	1	Decal-Protection, Ear				
18	52-2010	1	Decal-Parking Lever				
19	218-595	1	Connector-Body				
20	32153-1	1	Nut-Lock				
21	82-2190	1	Switch-Bail				




Sheet No.:10

Control Panel Assembly

Ref. No.	Part No.	Qty.	Description
1	105-0884	1	Decal-Danger
2	63-8360	2	Key-Ignition
4	74-0630	1	Control-Throttle
6	3296-42	1	Nut-Lock, NI
7	74-0720	1	Tube-Manual
8	104-8141	1	Module-Delay
9	2412-120	2	R-Clamp
10	93-1187-03	1	Panel-Bottom
11	321-2	1	Screw-HH
14	3296-2	4	Nut-Lock
15	29-5560	1	Switch-On Off
15:1	218-461	1	Nut-HH
15:2	3254-5	1	Washer-Lock, Internal
17	32104-76	4	Screw
19	104-8140	1	Switch-PTO
20	104-8177-03	1	Panel-Control
21	104-8180	1	Decal-Control Panel
22	32105-14	4	Screw


Ref. No.	Part No.	Qty.	Description



Sheet No.:2

Deck Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	104-8170-01	1	Cover-36	19	322-50	2	Screw-Cap
2	104-8587	2	Knob	20	104-7753	1	Deflector ASM
3	3256-24	2	Washer-Flat	20:2	54-9220	1	Decal-Danger
4	32148-9	2	Nut-Insert	21	104-8555	1	Spacer-Mounting, Deflector
5	105-0832	2	Link-Support	22	104-8554	1	Spring-Torsion
6	3290-256	6	Pin-Hair				
7	3296-39	4	Nut-Lock, NI				
8	3220-3	2	Nut-Jam				
9	1-613204	2	Balljoint				
10	104-1156	4	Spacer				
11	323-10	4	Screw-HH				
12	105-0831	2	Rod ASM				
14	104-6390	1	Deck ASM				
14:2	104-8185	1	Decal-Belt Routing				
14:3	68-8340	1	Decal-Torque				
14:4	43-8480	1	Decal-Danger				
14:5	105-0840	1	Decal-Anti Scalp				
14:6	66-1340	1	Decal-Danger				
14:7	67-5360	1	Decal-Danger				
14:8	98-8038	1	Decal-36"				
14:9	104-8569	1	Decal-Deflector Warning				
15	3296-29	2	Nut-Lock				
16	3256-23	2	Washer-Flat				
17	68-2730	2	Gage-Wheel				
18	98-5967	1	Spacer - Wheel				




Sheet No.:3

Spindles, Pulleys and Belts Assembly

Ref. No.	Part No.	Qty.	Description
1	323-12	1	Screw-HH
2	3296-5	1	Nut-Lock NI
3	3256-24	3	Washer-Flat
4	105-2673	1	Spring - Extension
5	105-0889	1	Idler Arm ASM
6	51-3660	1	Pulley-Idler
7	3211-5	1	Screw-HH
8	323-6	2	Screw-HH
9	98-5975	2	Washer-Belleville
10	1-633166	1	Idler Pulley
11	3231-22	11	Screw-CARR
12	51-3530	1	V-Belt, Deck Drive
13	51-3641	1	Idler-Pivot Sleeve
14	323-42	1	Screw-HH
15	105-0886	1	Belt-Drive, PTO
16	1-809107	2	Washer-Hardened
17	104-6370	1	Idler Arm ASM
17:1	1-513034	2	Sleeve-Bearing
17:2	302-5	1	Fitting-Grease
18	104-6377	1	Tube - Idler
19	3296-39	1	Nut-Lock, NI
20	104-8161	1	Spring-Extension
21	1-413099	1	Pulley-Idler
22	104-6315	1	Spindle Housing ASM
23	27-0990	2	Blade
24	92-9820	2	Stiffener - Blade


Ref. No.	Part No.	Qty.	Description
25	44-2200	2	Screw - Blade
26	32128-21	12	Nut-HF
27	104-6317	1	Spindle Housing ASM
28	3256-4	1	Washer-Flat
29	3256-6	2	Washer-Flat



Sheet No.:A1
C-3011

Spindle Housing Assembly No. 104-6315


Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	3219-7	1	Nut-Hex				
2	7-4150	1	Washer-Pinion				
3	104-1117	1	Pulley And Hub ASM				
4	104-6325	2	Bearing				
5	104-6307	1	Spindle Housing				
6	104-6313	1	Spacer-Bearing				
7	104-6311	1	Shaft-Spindle				
8	88-7540	1	Washer - Backup				
9	79-1920	1	Shield-Bearing				



Sheet No.:A2
C-3012

Spindle Housing Assembly No. 104-6317

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	3219-7	1	Nut-Hex				
2	7-4150	1	Washer-Pinion				
3	104-1118	1	Pulley And Hub ASM				
4	104-6325	2	Bearing				
5	104-6307	1	Spindle Housing				
6	104-6313	1	Spacer-Bearing				
7	104-6310	1	Shaft-Spindle				
8	88-7540	1	Washer - Backup				
9	79-1920	1	Shield-Bearing				




Sheet No.:4


Carrier Frame Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	104-8587	3	Knob	21	104-1183-01	2	Castor Fork ASM
3	74-2080	1	Decal-Proline	22	325-33	2	Screw-HH
4	32151-72	1	Ring-Retaining	23	283-71	2	Pin-Lynch
5	104-8174	1	Decal-Service, 36"	24	3-6781	8	Washer-Thrust
			Hydro	25	94-1291	4	Bushing-Special
5	104-8176	1	Decal-Service, 36"				
			Gear				
6	32148-9	3	Nut-Insert				
7	104-8167-01	1	Cover-Carrier Frame				
8	105-0846-01	1	Shield-Heat				
9	12-3270	2	Screw				
10	104-1105	6	Spacer-Deck Support				
11	49-2040	2	Screw-Tapping				
12	1-513336	2	Bushing - Deck				
13	32120-33	2	Ring-Retaining				
14	104-8171	2	Decal-HOC				
15	105-0842	4	Spacer				
16	104-1108-01	1	Carrier Frame ASM				
17	302-5	2	Fitting-Grease				
18	32153-5	2	Nut-Lock				
19	104-1170	2	Castor Wheel ASM				
19:1	104-1169	1	Tire And Tube ASM				
19:3	62-5570	2	Bearing-Roller				
19:4	62-5580	2	Bearing-Outside				
19:5	302-11	1	Fitting-Lube, 45°				
20	104-1189	2	Bushing-Spanner				

Electrical Schematic

Name	AWG	COLOR	Component	Pin
W1	GPT16PK	PINK	P3	2
W2	GPT16PK	PINK	P3	1
W3	GPT16W	WHITE	P2	2
W4	GPT16BK	BLACK	P1	1
W5	GPT16BK	BLACK	P4	2
W6	GPT16GN	GREEN	P5	3
W8	GPT16PK	PINK	P6	4
W10	GPT18BN	BROWN	J4	1
W11	GPT18OR	ORANGE	P5	1
W12	GPT18OR	ORANGE	P5	1
W13	GPT16BK	BLACK	P1	1
W14	GPT18BK	BLACK	P5	4






Crankcase Assembly - Kohler Model CV15T-41604

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	12 032 03-S	1	Seal-Crankshaft	14	12 380 01-S	1	Pin-Governor Regulating
2	12 522 18-S	1	Shortblock	15	12 043 05-S	1	Gear-Governor
3	12 445 02-S	1	Strap-Lifting	16	M-631005-S	1	Washer-Plain, 6mm
4	M-839025-S	1	Screw-HF M8x1.25x22	17	12 144 02-S	1	Shaft-Governor Gear
5	24 380 13-S	4	Dowel-Locating	18	52 139 09-S	1	Plug-Cup
6	12 755 49-S	1	Kit-Camshaft (Incl. 7-8)	19	12 755 64-S	1	Kit-Governor Cross Shaft (Incl. 23)
7	12 089 31-S	1	Spring-Actuating	20	X-25-102-S	1	Washer-Plain, 1/4
8	12 422 07-S	A/R	Shim-Camshaft, White	21	12 032 01-S	1	Seal-Governor Cross Shaft
8	12 422 08-S	1	Shim-Camshaft, Blue	22	M-631015-S	1	Washer-Plain, 6mm
8	12 422 09-S	A/R	Shim-Camshaft, Red	23	12 154 05-S	1	Clip-Hitch Pin
8	12 422 10-S	A/R	Shim-Camshaft, Yellow	24	12 014 30-S	1	Crankshaft ASM (Incl. 25)
8	12 422 11-S	A/R	Shim-Camshaft, Green	25	12 139 01-S	1	Plug-Cup
8	12 422 12-S	A/R	Shim-Camshaft, Gray	*	12 755 93-S	1	Set-Gasket
8	12 422 13-S	A/R	Shim-Camshaft, Black				
9	12 144 27-S	1	Shaft-Balance				
10	12 874 07-S	1	Piston w/Ring Set STD (Incl. 11,12)				
10	12 874 08-S	1	Set-Piston w/Ring .25				
10	12 874 09-S	1	Set-Piston w/Ring .50				
10	12 874 11-S	1	Set-Piston w/Ring .08				
11	12 018 02-S	2	Retainer-Piston Pin				
12	12 108 07-S	1	Ring Set STD				
12	12 108 08-S	1	Ring Set .25				
12	12 108 09-S	1	Ring Set .50				
13	12 067 05-S	1	Rod-Connecting, STD				
13	12 067 06-S	1	Rod-Connecting .25				

* Not illustrated
Order Parts from Kohler




Oil Pan and Lubrication Assembly Kohler Model CV15T-41604

Ref. No.	Part No.	Qty.	Description
1	12 038 01-S	1	Dipstick ASM(Incl. 2-3)
2	25 755 13-S	1	Kit-Oil Fill Cap (Incl. 3)
3	12 153 03-S	1	O Ring-Dipstick
4	12 153 02-S	1	O Ring-Upper Oil Fill Tube
5	12 123 04-S	1	Tube-Oil Fill
6	M-545020-S	1	Screw-HF, M5x0.8x20
7	12 153 01-S	1	O Ring-Lower Oil Fill Tube
8	25 162 07-S	1	Screen-Oil Pickup
9	12 096 03-S	1	Cover-Oil Pickup Screen
10	M-545016-S	1	Screw-HF, M5x0.8x16
11	52 050 02-S	1	Filter-Oil
12	12 199 50-S	1	Pan ASM - Oil (Incl. 13, 17-20)
13	25 462 09-S	1	Valve-Oil Pressure Relief
14	25 139 57-S	1	Plug-Pipe, 3/8 SH
15	25 139 52-S	1	Plug-Pipe, 1/8
16	25 139 62-S	1	Plug-Pipe, 3/8 HSH
17	12 393 01-S	1	Pump-Oil
18	12 153 06-S	1	O Ring-Oil Pump Cover

Ref. No.	Part No.	Qty.	Description
19	12 096 34-S	1	Cover-Oil Pump
20	M-545016-S	3	Screw-HF, M5x0.8x16
21	12 032 03-S	1	Seal-Oil (PTO End)
22	24 086 16-S	11	Screw-HF, M8x1.25x45
23	24 086 17-S	1	Screw-HF, M8x1.25x45

Order Parts From Kohler




Cylinder Head, Valves And Breather Assembly Kohler Model CV15T-41604

Ref. No.	Part No.	Qty.	Description
1	12 351 01-S	2	Lifter-Valve
2	12 755 81-S	1	Kit-Cylinder Head (Incl. 3-13, 18-21, 25, Carburator Gasket 12 041 01-S(2), Exhaust Manifold Gasket 12 041 03-S, Air Cleaner Gasket 12 041 02-S)
3	12 411 01-S	2	Rod-Push
4	12 041 10-S	1	Gasket-Cylinder Head
5	12 017 01-S	1	Valve-Intake STD
5	12 017 02-S	1	Valve-Intake .25
6	12 016 01-S	1	Valve-Exhaust STD
6	12 016 02-S	1	Valve-Exhaust, .25
7	12 318 19-S	1	Head - Cylinder
8	12 468 05-S	1	Washer-Plain 13/32
9	12 112 13-S	1	Spacer-Head Bolt Exhaust Port
10	12 086 15-S	5	Screw-HF M10x1.5x81
11	12 089 01-S	2	Spring-Valve
12	12 173 01-S	2	Cap-Valve Spring
13	12 755 03-S	2	Kit-Retainer
14	25 237 14-S	2	Clamp-Hose

Ref. No.	Part No.	Qty.	Description
15	12 326 03-S	1	Hose-Breather
16	M-645020-S	3	Screw-HF M6x1.0x20
17	12 096 07-S	1	Cover-Valve w/Nipple
18	24 032 05-S	1	Seal-Valve Stem
19	M-640034-S	2	Screw-HF M6x1.0x34
20	12 599 03-S	2	Pivot-Rocker Arm
21	25 186 01-S	2	Arm-Rocker
22	M-545010-S	1	Screw-HF M5x0.8x10
23	12 018 01-S	1	Retainer-Breather Reed
24	12 402 02-S	1	Reed-Breather
25	25 139 60-S	1	Plug-Pipe, HSH 1/8

Order Parts From Kohler




Ignition and Electrical Assembly Kohler Model CV15T-41604

Ref. No.	Part No.	Qty.	Description
1	12 086 14-S	1	Screw-HF,M10x1.5x46
2	12 468 03-S	1	Washer-Plain, 3/8
3	12 162 03-S	1	Screen-Grass
4	25 086 47-S	4	Bolt-Shoulder
5	12 157 03-S	4	Fan
6	X-42-15-S	1	Key
7	236602-S	1	Connector-Rectifier, Regulator(3 contact)
8	12 403 01-S	1	Rectifier-Unregulated, 15 amp
9	X-22-11-S	2	Washer - Lock
10	M-639016-S	2	Screw-HF, M6x1.0x16
11	41 155 03-S	1	Connector
12	12 025 33-S	1	Flywheel
13	M-548025-S	2	Screw-HH M5x0.8x25
14	237878-S	1	Kit-Stator, 15 Amp
15	12 132 06-S	1	Spark Plug
16	X-728-1-S	2	Clip-Cable
17	M-545010-S	2	Screw-HF, M5x0.8x10
18	12 584 05-S	1	Module-Ignition
19	M-545020-S	2	Screw-HF, M5x0.8x20
*	25 518 05-S	1	Lead-Black, Rectifier/Regulator, (5"-14Gauge Uninsulated Push On

Ref. No.	Part No.	Qty.	Description
*	12 518 01-S	1	Tab Terminals) Lead-White, Ground To Kill, (19"-18 Gauge Fully Insulated Push On Tab and Uninsulated Push On Tab Terminals
*	25 518 12-S	1	Lead-Black,Ground, (5"-12Gauge-Insulated Grip Barrel Eyelet Terminals


* Not illustrated
Order Parts From Kohler



Blower Housing And Baffles Assembly
Kohler Model CV15T-41604

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	M-550010-S	6	Screw-HF, M5x0.8x10				
2	12 096 29-S	1	Cover-Starter				
3	12 027 68-S	1	Housing-Blower				
4	12 063 10-S	1	Baffle-Intake, Side				
5	12 063 08-S	1	Baffle-Cylinder Head				
6	M-545010-S	9	Screw-HF, M5x0.8x10				
7	12 313 03-S	1	Grommet-Spark Plug leads				
8	12 063 19-S	1	Baffle-Cylinder				
9	12 146 07-S	1	Plate-Blower Housing				
*	12 146 21-S	1	Decal-Horsepower				


* Not illustrated
Order Parts From Kohler



Starter Assembly
Kohler Model CV15T-41604

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	M-550010-S	5	Screw-HF, M5x0.8x10				
2	12 165 01-S	1	Starter ASM				
			Retractable (Incl. 3-9)				
3	12 081 01-S	1	Housing-Starter				
4	12 160 01-S	1	Rope-Starter				
5	25 166 01-S	1	Handle-Recoil				
6	12 089 06-S	1	Spring & Keeper				
7	12 093 01-S	1	Pulley				
8	12 757 06-S	1	Kit-Dog Repair (incl. 9)				
9	41 086 09-S	1	Screw-Posidrive				
10	15 109 01-S	1	Cup-Drive				
*	12 113 07-S	1	Decal-Starting				

* Not illustrated
Order Parts From Kohler




Fuel System Assembly

Kohler Model CV15T-41604

Ref. No.	Part No.	Qty.	Description
1	M-641060-S	2	Nut-HF M6x1.0
2	M-629116-S	2	Stud M6x1.0x116
3	12 853 80-S	1	Kit-Carburetor w/Gaskets (Incl. 4-6)
4	12 041 02-S	1	Gasket-Air Cleaner
5	12 053 80	1	Carburetor ASM (For Information Only Not Available Separately) (Service With Kits 12 757 02-S Float Kit 12 757 03-S Carb. Repair Kit and 12 757 08-S Choke Repair Kit)
6	12 041 01-S	2	Gasket-Carburetor
7	12 265 04-S	1	Deflector-Heat
8	47 154 01-S	1	Clip-Cable
*	12 757 02-S	1	Kit-Float
*	12 757 08-S	1	Kit-Choke Repair
*	12 757 03-S	1	Kit-Carburetor Repair

Ref. No.	Part No.	Qty.	Description

* Not illustrated
Order Parts From Kohler




Engine Controls Assembly Kohler Model CV15T-41604

Ref. No.	Part No.	Qty.	Description
1	12 079 07-S	1	Linkage-Choke
2	12 237 01-S	1	Clamp-Cable
3	M-664020-S	2	Screw-Lobed Socket M6x1.0x20
4	M-545016-S	1	Screw-HF M5x .08x16
5	12 536 01-S	1	Control-Speed ASM (Incl. 6-8)
6	M-443025-S	1	Screw-SPH, M4x0.7x25
7	12 089 11-S	1	Spring-Choke Adjustment
8	12 089 23-S	1	Spring-Choke Return
9	12 089 19-S	1	Spring-Governor
10	12 755 83-S	1	Kit - Governor Lever (Incl. 11-13)
11	12 100 07-S	1	Nut-HF
12	52 211 04-S	1	Bolt - Round HD
13	12 090 28-S	1	Lever-Governor
14	25 158 08-S	1	Bushing-Linkage Retaining
15	12 079 01-S	1	Linkage-Throttle
16	25 158 11-S	1	Bushing-Throttle Linkage

Ref. No.	Part No.	Qty.	Description


Order Parts From Kohler



Air Cleaner Assembly Kohler Model CV15T-41604

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	12 743 02-S	1	Kit-Air Cleaner (Incl. 2-12)				
2	25 341 03-S	1	Knob-Air Cleaner Cover				
3	12 096 38-S	1	Cover-Air Cleaner				
4	12 083 12-S	1	Element-Precleaner				
5	12 083 10-S	1	Element-Air Cleaner (Incl. 6-8)				
6	12 743 12-S	1	Kit-Seal (Incl. 7-8)				
7	12 100 08-S	1	Nut-Wing				
8	12 032 11-S	1	Seal				
9	12 094 07-S	1	Base-Air Cleaner (Incl. 10,11)				
10	12 072 04-S	1	Stud-M6x1.0x66				
11	12 086 01-S	2	Screw-#10 Hi-Lo Thread Forming				
12	12 041 02-S	1	Gasket-Air Cleaner				
*	12 113 04-S	1	Decal-Air Cleaner				

* Not illustrated
Order Parts From Kohler



**Exhaust Assembly
Kohler Model CV15T-41604**

Ref. No.	Part No.	Qty.	Description
1	12 068 44-S	1	Muffler
2	25 072 04-S	2	Stud M8x1.25x33
3	12 041 03-S	1	Gasket-Exhaust Manifold
4	X-25-78-S	1	Washer-Plain, 1/4
5	M-545016-S	1	Screw-HF, M5x0.8x16
6	M-841080-S	2	Nut-HF, M8x1.25
7	M-645016-S	2	Screw-HF, M6x1.0x16
8	M-645025-S	2	Screw-HF, M6x1.0x25
9	12 126 71-S	1	Bracket-Muffler

Ref. No.	Part No.	Qty.	Description

Obtain Parts From Kohler

Maintenance Record

[illegible]

