Form No. 3325–347

Dethatcher Kit

Reelmaster® 5000–D Series

Model No. 03516—210000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.


Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.


© The TORO Company — 2000
All Rights Reserved



Dethatcher Assembly

Ref. No.	Part No.	Qty.	Description
2	82–6630–01	1	Bracket–HOC, RH
3	100–6193	1	Carrier Frame ASM
3:2	67–1750	2	Bushing
3:3	75–2160	2	Bushing
3:4	302–60	1	Fitting–Lube
4	82–6680	1	Full Roller ASM
4:1	75–1290	2	Bearing–Roller
4:3	302–5	2	Fitting–Grease
5	75–1840	1	Front Grass Shield ASM
5:5	67–7960	1	Decal–Warning
5:5	93–6688	1	Decal–Warning, Europe
5:5	94–4584	1	Decal–Warning, Japan
6	321–4	2	Screw–HH
7	3256–1	2	Washer–Flat
8	82–6740	1	Rear Scraper ASM
8:1	82–6770–01	2	Spring–Scraper
8:3	3269–3	4	Rivet–Pop
9	323–49	2	Bolt–TAP
10	3296–39	8	Nut–Lock, NI
11	3218–3	4	Nut–Jam
12	3256–24	8	Washer–Flat
13	323–53	2	Bolt–TAP
14	3242–2	4	Screw–SQH
15	82–6650–01	1	Bracket–HOC, LH

Ref. No.	Part No.	Qty.	Description
16	3231–3	2	Screw–CARR
17	82–6710	1	Dethatcher Frame ASM
17:2	75–1710	1	Support
17:3	3253–21	2	Washer–Lock
17:4	323–6	2	Screw–HH
18	82–6780–01	1	Deflector–Rear
19	10–5080–01	1	Cap–End
20	323–6	4	Screw–HH
21	3253–21	4	Washer–Lock
22	3296–42	2	Nut–Lock, NI
23	82–6880–01	1	Scraper, LH
24	76–2460	2	Bearing ASM
24:1	94–3405	1	Bearing–Ball
24:1:1	3245–35	1	Screw–HS
24:1:2	251–77	1	Bearing–Lockcollar
25	3256–23	8	Washer–Flat
26	3253–4	7	Washer–Lock
27	322–7	6	Screw–HH
28	82–6530–01	1	Support–HOC, LH
29	82–6560	1	Dethatcher Shaft ASM
29:1	82–6570	1	Shaft–Reel
29:2	17–1600	2	Spacer
29:3	17–1590	24	Blade–11 Tooth
29:4	82–6600	23	Spacer
29:5	67–5840	1	Nut–Jam



Dethatcher Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
30	82–6830–01	1	Bracket–Scraper
31	75–1520	1	Wiehle Roller ASM
31:1	75–1290	2	Bearing–Roller
31:2	302–5	2	Fitting–Grease
32	322–3	2	Screw–HH
33	82–6510–01	1	Support–HOC, RH
34	323–7	4	Screw–HH
35	3296–29	2	Nut–Lock
36	82–6810–01	2	Plate–Bearing
37	82–6820	2	Spacer
38	77–0340	1	Nut–Spline
39	322–5	1	Screw–HH
40	82–6870–01	1	Scraper, RH
41	12–0460	1	Caplug
42	32121–12	2	Pin–Roll
54	302–11	2	Fitting–lube, 45°

Ref. No.	Part No.	Qty.	Description


TORO®