Form No. 3325-359

Cushman® GA 60 Aerator Adapter Kit

Workman® Vehicles

Model No. 44232

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.


Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 2000
All Rights Reserved



Sheet No.:0
T-3698

Aerator Adapter Kit Assembly

Ref. No.	Part No.	Qty.	Description
1	3256-2	2	Washer-Flat
2	3253-3	2	Washer-Lock
3	321-9	2	Screw-HH
4	92-4549-03	1	Mount-Controller
5	32128-43	1	Nut-Flange
6	323-8	1	Screw-HH
7	3231-25	1	Screw-CARR
8	92-4547-03	1	Clamp-Controller
9	92-4543	1	Splice-Wire
10	92-4542	1	Disconnect-Dc

Ref. No.	Part No.	Qty.	Description