



ELECTRIC STARTS FOR SINGLE STAGE SNOWTHROWERS

DÉMARREURS ÉLECTRIQUES POUR DÉNEIGEUSES À UN ÉTAGE

MODEL NO. 38176 - 6900001 & UP

MODEL NO. 38186 - 6900001 & UP

MODEL NO. 38196 - 6900001 & UP

ADDENDUM
SUPPLÈMENT

English

This unit is equipped with a 120 volt starter system. To use the electrical starter on a European 230 volt electric source, a 230 VAC to 120 VAC transformer (voltage converter) must be used. A transformer certified to CE electrical standards is recommended for proper use of the electrical system.

Français

Le démarreur électrique de cette machine utilise un courant alternatif de 120 V. En Europe, un transformateur (convertisseur de tension) doit être utilisé pour convertir la tension de secteur de 230 VAC en 120 VAC. L'utilisation d'un transformateur certifié conforme aux normes électriques CE est recommandée pour un usage correct du système électrique.