Parts Catalog

42in Bagger Zero-Turn-Radius Riding Mower

Model No. 79411—Serial No. 407200000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Twin Bag Assembly	4
Bag Assembly No. 140-5026	6
Bagger Top Assembly No. 140-5096	
Weight Assembly	
Chute Assembly	
Chute Assemby No. 139-3261	

Twin Bag Assembly




Twin Bag Assembly (continued)

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description		
1	144-1829-03	1	Frame ASM, Pivot [black]	11	139-2562	3	Pin-Hair		
2	131-3967-03	1	Bracket-Stabilizer	12	116-4992	1	Latch-Rubber		
3	140-5093	2	Rod-Support, Cz	13	137-3073	2	Washer-Plain		
4	140-5026	2	Bag ASM	14	132-6919	2	Screw-Plastic, PTH		
5	131-4189	1	Rod-Hood, Down	15	110-3144	4	Bolt-CARR		
6	140-5016	2	Bracket-Hopper Pivot	16	119-4041	8	Nut-HF		
7	140-5096	1	Top ASM-Bagger	17	139-2596	2	Screw-HHF		
8	112-3993	1	Screen-Bagger	18	32144-70	2	Screw-HWHTF		
9	112-3995	1	Tube-Bagger	19	139-2630	2	Bolt-CARR		
10	139-2611	2	Washer-Flat						

3443-158A


Bag Assembly No. 140-5026



Bag Assembly No. 140-5026 (continued)

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	114972-03	1	Frame-Bag	4	139-2630	2	Bolt-CARR
2	114973-03	1	Hanger-Bag	5	119-4038	2	Nut-Hex
3	114974-03	1	Clamp	6	110-6674	1	Bag

Bagger Top Assembly No. 140-5096




Bagger Top Assembly No. 140-5096 (continued)

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
2	116-1242-03	1	Stiffener-Bagger Top	6	137-3073	4	Washer-Plain
3	112-4001	1	Gasket	7	109-6809	1	Decal-Caution, Bagger
4	112-4000-03	1	Ring-Retainer	8	133-8061	1	Decal-Warning
5	114439	12	Rivet-Blind				_

3443-158A

Weight Assembly




10

Weight Assembly (continued)

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	139-5817-03	1	Bracket-Weight, LH	5	139-7482-03	6	Weight-Bagger
2	139-5815-03	1	Bracket-Weight, RH	6	139-2597	4	Screw-HHF
3	140-5097	2	Screw-Spcl	7	119-4042	6	Nut-HF, NI
4	87-5330	2	Washer .				

3443-158A

Chute Assembly




12

Chute Assembly (continued)

Ref.	Part Number	Qty.	Description
1	139-3261	1	42 In Bagger Boot Assembly

Chute Assemby No. 139-3261



Chute Assemby No. 139-3261 (continued)

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	140-3464	1	42 In Bagger Boot ASM	8	137-3088	3	Nut-Hex
1:2	110-6691	1	Decal-Danger	9	139-1730	1	Screw-Shoulder, HHF
2	138-7572	1	Hook-Boot	10	139-2351	1	Plate-Latch
3	3290-412	2	Rivet-Blind	11	139-1723	1	Washer-Flat
4	117344	1	Handle ASM	12	139-1716	1	Screw-HH
5	3269-31	2	Rivet-Pop	13	82-5690	1	Retainer-Duct
6	140-5094	1	Plate-Pivot, Cz	14	114-9015	1	Nut-Impeller
7	3274-69	2	Screw-HSBH				·

5 3443-158A

