Form No. 3325–489

LAWN-BOY®

Silver Series®

Walk–Behind Mower

Model No. 10270–210000001 and Up
Model No. 10270C–210000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© Lawn-Boy, Inc. — 2001
All Rights Reserved

Contents

Description	Page
Housing & Handle Bracket Assembly	3
Engine & Blade Assembly	5
Handles & Controls Assembly	6
Carburetor No. 640273	7
Engine–LEV115–350181E	8
Engine–LEV115–350181E	9
Engine–LEV115–350181E	10
Recoil Starter No. 590737	11
Recoil Starter No. 590694 (Optional)	12


Accessories

Description	Model / Part No.
Side bagging Kit	Model No. 89817
Rear Bagging Kit	Model No. 89800
Leaf Bag	Model No. 89804
Leaf Shredder Kit	Model No. 89860
Leaf Bag Kit w/Chute	Model No. 89811

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning
AR	as required
ASM	assembly
CARR	carriage
DEG	degrees
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HLH	hex lag head
HJ	hex jam
HOC	height-of-cut
HS	hex socket
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
INC	incorporated
LH	left hand
NI	nylon insert
PPH	Phillips pan head
PTH	Phillips truss head
PTO	power take off
RH	right hand
SFH	slotted fillister head
SHH	slotted hex head
SQH	square head
SHWH	slotted hex washer head
SPH	slotted pan head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	Torx truss head
WH	wing head




Sheet No.:2

Housing & Handle Bracket Assembly

Ref. No.	Part No.	Qty.	Description
1	40–1940	4	Washer
2	95–7403–03	4	Bracket–Height Adjustment, Wheel
3	92–7731	2	Plate – Baffle
4	92–4890	4	Washer – Wheel
5	92–4881–03	2	Plate – Height Adjustment
13	614677	2	Screw–Sems
15	92–8630	1	Plate–Mulch
16	98–8332	1	Knob
18	92–7742	1	RH Handle Brkt ASM
20	98–4471	1	Housing ASM (only on: 10270)
20	105–1264	1	Housing–Service (only on: 10270c)
20:2	43–8480	1	Decal–Danger (only on: 10270)
20:2	56–6270	1	Danger Decal(Fr/E) (only on: 10270c)
20:3	99–6018	1	Decal – Warning (only on: 10270)
20:3	104–7629	1	Decal–Warning (only on: 10270c)
20:4	92–2914	1	Decal – HOC, RH (only on: 10270)

Ref. No.	Part No.	Qty.	Description
20:4	104–7616	1	Decal–HOC,RH (only on: 10270c)
20:5	93–7250	1	Decal–Warning (only on: 10270)
20:5	104–7627	1	Decal–Warning (only on: 10270c)
20:6	92–7719	1	Insert – Housing
20:7	94–1610	2	Grommet – Plastic
20:8	613765	1	Nut–Cage
20:10	3269–26	1	Washer–Flat
20:11	92–2915	1	Decal – HOC, LH (only on: 10270)
20:11	104–7617	1	Decal–HOC,LH (only on: 10270c)
20:12	104–7634	1	Decal–Manual,Lb (only on: 10270c)
21	92–7743	1	LH Handle Brkt ASM
22	92–1005	2	Spring Arm ASM – Rear
23	95–7437	2	Tire–8”
24	92–1099	4	Bolt–Shoulder
25	322–3	4	Screw–HH
26	92–8647	1	Shield – Trailing
27	3296–39	2	Nut–Lock, NI
28	3296–29	4	Nut–Lock




Housing & Handle Bracket Assembly

Ref. No.	Part No.	Qty.	Description
30	92–1008	4	Knob–Lever, Height Adjustment
31	614687	2	Arm–Front Spring
32	614672	4	Bolt–Shoulder
33	95–7436	2	Tire–6”
*	95–7052	1	Plate–Opening, Chute

Ref. No.	Part No.	Qty.	Description

* Not illustrated




Sheet No.:3

Engine & Blade Assembly

Ref. No.	Part No.	Qty.	Description
1	612543–03	1	Blade
2	104–7958	1	Decal–Deck
3	105–1278	1	ASM–Guard,Muffler (only on: 10270c)
3	95–5569	1	ASM – Muffler Guard (only on: 10270)
3:1	104–8065	1	Decal–Surface, Hot–International (only on: 10270c)
3:1	65–2690	1	Decal–Surface, Hot (only on: 10270)
3:2	94–6066–03	1	Guard – Muffler
5	32144–85	1	Screw–HH
6	98–1593	1	Applique
7	104–7684	1	Decal–Recoil,5hp
8	92–1701	1	Stop–Rope
9	100–5998	1	Engine (Tecumseh Lev115–350181e)
10	95–1726	3	Screw–Taptite W/Patch
11	105–1256	1	Blade Retainer ASM
12	603164	1	Nut–Blade

Ref. No.	Part No.	Qty.	Description




Sheet No.:4

Handles & Controls Assembly

Ref. No.	Part No.	Qty.	Description
1	104–1013	1	Guard–Cable
2	614643–05	1	Handle – Lower
3	100–5989	1	Brake Cable ASM
4	93–7383	1	Guide–Rope
5	321–50	1	Screw–HH
6	100–2888–05	1	Handle–Upper
7	92–5412	1	Stop–Pivot
8	93–4184–03	1	Bail – Brake
10	3296–73	1	Nut–Lock, NI
11	98–7134	2	Knob–Handle
12	614697	2	Screw

Ref. No.	Part No.	Qty.	Description




Carburetor No. 640273


Ref. No.	Part No.	Qty.	Description
0	640273	1	Carburetor
1	631615	1	Throttle Shaft & Lever Assembly
2	631767	1	Throttle Return Spring
4	631184	1	Dust Seal Washer
5	631183	1	Dust Seal (Throttle)
6	640070	1	Throttle Shutter
7	650506	1	Shutter Screw
16	631807	1	Fuel Fitting
17	651025	1	Throttle Crack Screw/Idle Speed Screw
18	630766	1	Tension Spring
20	640027	1	Idle Restrictor Screw
20A	640200	1	Idle Restrictor Screw Cap
25	631867	1	Float Bowl
27	631024	1	Float Shaft
28	632019	1	Float
29	631028	1	Float Bowl ”O” Ring
30	631021	1	Inlet Needle, Seat, & Clip (Incl. 31)
31	631022	1	Spring Clip
35	640259	1	Primer Bulb/Retainer Ring
36	640080	1	Main Nozzle Tube

Ref. No.	Part No.	Qty.	Description
37	632547	2	O–Ring, Main Nozzle Tube
40	632746	1	High Speed Bowl Nut
44	27110A	1	Bowl Nut Washer
47	630748	1	Welch Plug, Idle Mixture Well
48	631027	1	Welch Plug, Atmospheric Vent
60	632760B	1	Repair Kit

Obtain parts from local Tecumseh dealer

Engine–LEV115–350181E





Engine–LEV115–350181E

Ref. No.	Part No.	Qty.	Description
1	37266	1	Cylinder (Incl. 2,20 & 150)
2	26727	2	Dowel Pin
6	33734	1	Breather Element
7	36557	1	Breather Body ASM (Incl. 6 & 12A)
12A	36558	1	Breather Cover & Tube
14	28277	1	Washer
15	30589	1	Governor Rod (Incl. 14)
16	34839A	1	Governor Lever
17	31335	1	Governor Lever Clamp
18	651018	1	Screw, Torx T–15
19	36281	1	Extension Spring
20	32600	1	Oil Seal
30	37616	1	Crankshaft
40	40004	1	Piston, Pin & Ring Set (Std.)
40	40005	1	Piston, Pin & Ring Set (.010” OS)
41	36070	1	Piston & Pin ASM (Std.) (Incl. 43)
41	36071	1	Piston & Pin ASM (.010” OS) (Incl. 43)
42	40006	1	Ring Set (Std.)
42	40007	1	Ring Set (.010” OS)
43	20381	2	Piston Pin Retaining Ring
45	36777	1	Connecting Rod ASM (Incl. 46)
46	32610A	2	Connecting Rod Bolt
48	27241	2	Valve Lifter
50	37460	1	Camshaft Exhaust (MCR) (Incl. 104)
52	29914	1	Oil Pump ASM
69	37130	1	Mounting Flange Gasket
70	34311E	1	Mounting Flange (Incl. 72 thru 83, 306)
72	36083	1	Oil Drain Plug
75	27897	1	Oil Seal
80	30574A	1	Governor Shaft
81	30590A	1	Washer
82	30591	1	Governor Gear ASM (Incl. 81)
83	30588A	1	Governor Spool
86	650488	6	Screw
89	611004	1	Flywheel Key
90	611112	1	Flywheel
92	650815	1	Belleville Washer
93	650816	1	Flywheel Nut
100	34443C	1	Solid State Ignition
101	610118	1	Spark Plug Cover
103	651007	2	Screw, Torx T–15
104	37480	1	Cam Bushing
110	37047	1	Ground Wire
119	36787	1	Cylinder Head Gasket
120	36825	1	Cylinder Head
125	37288	1	Exhaust Valve (Std.) (Incl. 151)
126	37289	1	Intake Valve (Std.) (Incl. 151)
130	6021A	6	Screw
135	35395	1	Resistor Spark Plug (RJ19LM)
150	31672	2	Valve Spring
151	31673	2	Valve Spring Cap
151A	40017	1	Intake Valve Seal
169	36783	1	Valve Cover Gasket
172	36784	1	Valve Cover
174	30200	2	Screw
178	29752	2	Nut & Lock Washer
182	6201	2	Nut & Lock Washer
184	26756	1	Carburetor To Intake Pipe Gasket
185	36785	1	Intake Pipe
186	32653	1	Governor Link
189	650839	2	Screw
191	36559A	1	S.E. Brake Bracket (Incl. 195)
195	610973	1	Terminal
207	34336	1	Throttle Link
216	33086	1	R.P.M. Adjusting Lever
223	650451	2	Screw
224	36786	1	Intake Pipe Gasket
238	650806	2	Screw
239	34338	1	Air Cleaner Gasket
240	36743	1	Air Cleaner Body
245	36745	1	Air Cleaner Filter
250	36744	1	Air Cleaner Cover
260	36800	1	Blower Housing
261	30200	2	Screw
262	650831	2	Screw
263A	36758	1	Starter Grill
275	37462	1	Muffler
277	650988	2	Screw
285	35000A	1	Starter Cup
287	650926	2	Screw
290	34357	1	Fuel Line
292	26460	2	Fuel Line Clamp
298	28763	3	Screw
300	36757	1	Fuel Tank (Incl. 292 & 301)
301	36246	1	Fuel Cap
305	35577	1	Oil Fill Tube
306	36996	1	”O”–Ring
307	35499	1	”O”–Ring
309	650562	1	Screw
310	36801	1	Dipstick
313	34080	1	Spacer
370A	36261	1	Lubrication Decal
370C	37318	1	Primer Decal (3X)
370D	35977	1	Caution Decal
370K	36695	1	Starter Decal
370Q	37548	1	Emissions Decal
380	640273	1	Carburetor (Incl. 184)
390	590737	1	Rewind Starter
400	36792B	1	Gasket Set
416	36085	1	Spark Arrestor Kit

Obtain parts from local Tecumseh dealer


Engine–LEV115–350181E

Ref. No.	Part No.	Qty.	Description
417	650821	1	Screw
420	730225A	1	SAE30 4–Cycle Engine Oil (Quart)
*99	750680	1	Shortblock

Ref. No.	Part No.	Qty.	Description

Obtain parts from local Tecumseh dealer

* Not illustrated




Recoil Starter No. 590737

Ref. No.	Part No.	Qty.	Description
0	590737	1	Rewind Starter
3	590740	1	Retainer
6	590616	2	Starter Dog
7	590617	2	Dog Spring
8	590618A	1	Pulley & Rewind Spring ASM
11	590687A	1	Starter Housing ASM (40 degree grommet)
12	590535	1	Starter Rope (Length 98” x 9/64” dia.)
13	590701	1	Starter Handle
14	590760	1	Spring Clip

Ref. No.	Part No.	Qty.	Description

Obtain parts from local Tecumseh dealer



Recoil Starter No. 590694 (Optional)

Ref. No.	Part No.	Qty.	Description
0	590694	1	Recoil Starter
1	590599A	1	Spring Pin (Incl. 4)
2	590600	1	Washer
3	590696	1	Retainer
4	590601	2	Washer
5	590697	1	Brake Spring
6	590698	2	Starter Dog
7	590699	2	Dog Spring
8	590700	1	Pulley & Rewind Spring ASM
11	590695	1	Starter Housing ASM (40 degree grommet)
12	590535	1	Starter Rope (98” X 9/64” dia.)
13	590701	1	Starter Handle

Ref. No.	Part No.	Qty.	Description

Obtain parts from local Tecumseh dealer

Maintenance Record

Date								

Maintenance Record

Date								

Maintenance Record

Date								

LAWN-BOY®