

LAWN-BOY®

Silver Series® Lawnmower

Model No. 10362—21000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

Contents

Description	Page	Description	Page
Housing, Handle Bracket And Wheel Assembly	3	Carburetor No. 640271	9
Gear Case Assembly No. 104-7671	4	Engine-LEV120-361516A	10
Rear Axle Assembly	5	Engine-LEV120-361516A	11
Engine And Blade Assembly	6	Engine-LEV120-361516A	12
Handle And Controls Assembly	7	Recoil Starter No. 590739	13
Grass Bagging Assembly	8	Recoil Starter No. 590702 (Optional)	14


Accessories

Description	Model / Part No.	Description	Model / Part No.
Side Bagging Kit	89817	Leaf Shredder Kit	89860
Leaf Bag	89804	Leaf Bag Kit with Chute	89811

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	INC	incorporated
ASM	assembly	LH	left hand
CARR	carriage	NI	nylon insert
DEG	degrees	PPH	Phillips pan head
FH	flat head	PTH	Phillips truss head
GA	gauge	PTO	power take off
HF	hex flange	RH	right hand
HH	hex head	SFH	slotted fillister head
HHF	hex head flange	SHH	slotted hex head
HLH	hex lag head	SQH	square head
HJ	hex jam	SHWH	slotted hex washer head
HOC	height-of-cut	SPH	slotted pan head
HS	hex socket	SRH	slotted round head
HSBH	hex socket button head	STD	standard
HSFH	hex socket flat head	TAP	self tapping
HSH	hex socket head	TTH	Torx truss head
HWH	hex washer head	WH	wing head
HWHTF	hex washer head thread forming		




Sheet No.:2

Housing, Handle Bracket And Wheel Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	40-1940	2	Washer	25	605120	1	Grommet
2	95-7403-03	2	Bracket-Wheel Height Adjustment	26	104-7671	1	Gear Case ASM
3	92-7731	2	Plate - Baffle	27	92-7724	1	Handle Bracket ASM-LH
4	92-4890	2	Washer - Wheel	28	322-3	6	Screw-HH
5	92-4881-03	2	Plate - Height Adjustment	29	92-8647	1	Shield - Trailing
10	98-4477	1	Deck ASM	30	3296-29	6	Nut-Lock
10:1	3269-26	1	Washer-Flat	32	92-1008	2	Knob-Lever, Height Adjustment
10:3	43-8480	1	Decal-Danger	33	614687	2	Arm-Front Spring
10:4	613765	1	Nut-Cage	34	614672	2	Bolt-Shoulder
10:6	99-6018	1	Decal - Warning	35	92-1099	2	Bolt-Shoulder
10:7	92-2914	1	Decal - HOC, RH	36	684776	2	Wheel & Tire ASM
10:8	92-2915	1	Decal - HOC, LH	*	95-7052	1	Plate - Chute Opening
10:9	93-7250	1	Decal-Warning				
10:10	94-1610	2	Grommet - Plastic				
10:12	92-7719	2	Insert - Housing				
10:13	614677	2	Screw- Sems				
17	92-8630	1	Plate-Mulch				
18	98-8332	1	Knob				
19	92-7723	1	Handle Bracket ASM-RH				
21	95-7068	1	Cover - Drive				
22	92-9665	1	Screw				
23	65-5221	2	Screw-HWHTF				
24	92-7728-03	1	Guide - Transmission				

* Not illustrated




Sheet No.:3

Rear Axle Assembly

Ref. No.	Part No.	Qty.	Description
1	92-1057	2	Bolt-Shoulder
2	92-1042	2	Wheel & Tire ASM
2:1	27-6250	2	Bushing
3	65-2720	4	Ring-Klip
4	65-4740	4	Washer-Thrust, Keyed
5	66-6050	1	Key-Rocking, LH
*6	66-6040	1	Key-Rocking, RH
7	65-4710	2	Ring-Friction
8	92-7746	2	Arm ASM-Rear Height Adjustment
8:1	302-56	1	Fitting-Zerk
8:2	47-2900	1	Bushing
8:3	70-9760	1	Bushing
9	92-1008	2	Knob-Lever, Height Adjustment
10	614447	2	Spacer-Axle Shaft
11	32144-85	2	Screw-HH
12	92-1004	2	Rear Spring Arm ASM
13	603773	2	Nut
14	65-4730	2	Washer-Arm, Pivot
15	65-4760	2	Washer-Clutch
16	65-4750	2	Gear-Pinion
17	65-4720	2	Spring-Compression
18	94-1609	2	Cover-Wheel

Ref. No.	Part No.	Qty.	Description
19	614426	2	Washer-Stepped
20	93-7381	1	V-Belt

* Not illustrated




Sheet No.:10

Grass Bagging Assembly

Ref. No.	Part No.	Qty.	Description
1	100-6361	1	Bag & Adapter ASM.
1:1	614700	1	Tie Strap
1:2	100-6362	1	Replacement Bag ASM.
1:3	684727-03	1	Adapter
2	613455	1	Wire Hanger,
3	613462-03	2	Clamp-Hanger
4	684729	1	Chute & Support
4:1	614589	1	Nut - Cap
4:2	614591	1	Support- Chute

Ref. No.	Part No.	Qty.	Description



Carburetor No. 640271


Ref. No.	Part No.	Qty.	Description
0	640273	1	Carburetor
1	631615	1	Throttle Shaft & Lever Assembly
2	631767	1	Throttle Return Spring
4	631184	1	Dust Seal Washer
5	631183	1	Dust Seal (Throttle)
6	640070	1	Throttle Shutter
7	650506	1	Shutter Screw
16	631807	1	Fuel Fitting
17	651025	1	Throttle Crack Screw/Idle Speed Screw
18	630766	1	Tension Spring
20	640027	1	Idle Restrictor Screw
20A	640200	1	Idle Restrictor Screw Cap
25	631867	1	Float Bowl
27	631024	1	Float Shaft
28	632802	1	Float (Plastic)
29	631028	1	Float Bowl "O" Ring
30	631021	1	Inlet Needle, Seat, & Clip (Incl. 31)
31	631022	1	Spring Clip
35	640259	1	Primer Bulb/Retainer Ring
36	640080	1	Main Nozzle Tube

Ref. No.	Part No.	Qty.	Description
36A	632766	1	Carburetor Tube
37	632547	2	O-Ring, Main Nozzle Tube
40	640030	1	High Speed Bowl Nut
44	27110A	1	Bowl Nut Washer
47	630748	1	Welch Plug, Idle Mixture Well
48	631027	1	Welch Plug, Atmospheric Vent
60	632760B	1	Repair Kit
*61	26756	1	Carburetor To Intake Pipe Gasket

Obtain parts from local Tecumseh dealer

* Not illustrated

Engine-LEV120-361516A



Engine-LEV120-361516A

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	37265	1	Cylinder (Incl. 2,20 & 150)	119	36787	1	Cylinder Head Gasket
2	26727	2	Dowel Pin	120	36825	1	Cylinder Head
6	33734	1	Breather Element	125	37288	1	Exhaust Valve (Std.) (Incl. 151)
7	36557	1	Breather Body ASM (Incl. 6 & 12A)	126	37289	1	Intake Valve (Std.) (Incl. 151)
12	36775	1	Breather Tube	130	6021A	6	Screw
12A	36558	1	Breather Cover & Tube	135	35395	1	Resistor Spark Plug (RJ19LM)
12B	36694	1	Breather Tube Elbow	150	31672	2	Valve Spring
14	28277	1	Washer	151	31673	2	Valve Spring Cap
15	30589	1	Governor Rod (Incl. 14)	151A	40017	1	Intake Valve Seal
16	34839A	1	Governor Lever	169	36783	1	Valve Cover Gasket
17	31335	1	Governor Lever Clamp	172	36784	1	Valve Cover
18	651018	1	Screw, Torx T-15	174	30200	2	Screw
19	36281	1	Extension Spring	178	29752	2	Nut & Lock Washer
20	32600	1	Oil Seal	182	6201	2	Screw
30	37624	1	Crankshaft	184	26756	1	Carburetor To Intake Pipe Gasket
40	40028	1	Piston, Pin & Ring Set (Std.)	185	37466	1	Intake Pipe
40	40028	1	Piston, Pin & Ring Set (.010" OS)	186	32653	1	Governor Link
41	36070	1	Piston & Pin ASM (Std.) (Incl. 43)	189	650839	2	Screw
41	35542	1	Piston & Pin ASM (.010" OS) (Incl. 43)	191	36559A	1	S.E. Brake Bracket (Incl. 195)
41	36071	1	Piston & Pin ASM (.020" OS) (Incl. 43)	195	610973	1	Terminal
42	40006	1	Ring Set (Std.)	207	34336	1	Throttle Link
42	40007	1	Ring Set (.010" OS)	216	33086	1	R.P.M. Adjusting Lever
43	20381	2	Piston Pin Retaining Ring	223	650451	2	Screw
45	36777	1	Connecting Rod ASM (Incl. 46)	224	36786	1	Intake Pipe Gasket
46	32610A	2	Connecting Rod Bolt	238	650932	2	Screw
48	27241	2	Valve Lifter	239	34338	1	Air Cleaner Gasket
50	37460	1	Camshaft Exhaust(MCR)	241	35797	1	Air Cleaner Vollar
52	29914	1	Oil Pump ASM	245	35066	1	Air Cleaner Filter
69	37130	1	Mounting Flange Gasket	250	35986	1	Air Cleaner Cover
70	34311E	1	Mounting Flange (Incl. 72 thru 83, 306)	260	36999	1	Blower Housing
72	36083	1	Oil Drain Plug	261	30200	2	Screw
75	27897	1	Oil Seal	262	650831	2	Screw
80	30574A	1	Governor Shaft	263A	36758	1	Starter Grill
81	30590A	1	Washer	275	37498	1	Muffler
82	30591	1	Governor Gear ASM (Incl. 81)	277	650988	2	Screw
83	30588A	1	Governor Spool	285	35000A	1	Starter Cup
86	650488	6	Screw	287	650926	2	Screw
89	611004	1	Flywheel Key	290	34357	1	Fuel Line
90	611112	1	Flywheel	292	26460	2	Fuel Line Clamp
92	650815	1	Belleville Washer	298	28763	3	Screw
93	650816	1	Flywheel Nut	300	35586	1	Fuel Tank (Incl. 292 & 301)
100	34443C	1	Solid State Ignition	301	36246	1	Fuel Cap
101	610118	1	Spark Plug Cover	305	35819A	1	Oil Fill Tube
103	651007	2	Screw, Torx T-15	306	36996	1	"O"-Ring
104	37480	1	Cam Bearing Bushing	307	35499	1	"O"-Ring
110	37047	1	Ground Wire	309	651014	1	Screw
				310	36801	1	Dipstick
				313	34080	1	Spacer
				370A	36261	1	Lubrication Decal
				370C	37318	1	Primer Decal (3X)
				370D	35977	1	Caution Decal
				370K	36695	1	Starter Decal

Obtain parts from local Tecumseh dealer

Engine-LEV120-361516A

Ref. No.	Part No.	Qty.	Description
380	640271	1	Carburetor (Incl. 184)
390	590739	1	Rewind Starter
400	36792B	1	Gasket Set
416	36085	1	Spark Arrestor Kit (Incl. 417) (Optional)
417	650821	1	Screw
420	730225A	1	SAE30 4-Cycle Engine Oil (Quart)
*	750865	1	Shortblock

Ref. No.	Part No.	Qty.	Description

Obtain parts from local Tecumseh dealer

* Not illustrated

LAWN-BOY®