



**Recycler<sup>®</sup>**  
**Walk Behind Mower**  
Model No. 20011-21000001 and Up

## Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

## Contents

<b>Description</b>	<b>Page</b>	<b>Description</b>	<b>Page</b>
Housing & Handle Bracket Assembly .....	3	Handle Assembly .....	7
Gear Case Assembly .....	4	Engine Briggs & Stratton Model	
Gear Case & Wheel Assembly .....	5	122602-0150-E1 .....	8-17
Engine Assembly .....	6	Maintenance .....	18-19


## Accessories

<b>Description</b>	<b>Model / Part No.</b>	<b>Description</b>	<b>Model / Part No.</b>
Recycler Bagging Kit .....	Model No. 59299		
Chute Plug Kit .....	Model No. 59134		

## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

<b>Abbreviation</b>	<b>Meaning</b>	<b>Abbreviation</b>	<b>Meaning</b>
AR .....	as required	HYD .....	hydraulic
ASM .....	assembly	INC .....	incorporated
CARR .....	carriage	LH .....	left hand
DEG .....	degrees	NI .....	nylon insert
FH .....	flat head	PPH .....	Phillips pan head
GA .....	gauge	PTH .....	Phillips truss head
HF .....	hex flange	PTO .....	power take off
HH .....	hex head	RH .....	right hand
HHF .....	hex head flange	SFH .....	slotted fillister head
HLH .....	hex lag head	SHH .....	slotted hex head
HJ .....	hex jam	SQH .....	square head
HOC .....	height-of-cut	SHWH .....	slotted hex washer head
HS .....	hex socket	SPH .....	slotted pan head
HSBH .....	hex socket button head	SRH .....	slotted round head
HSFH .....	hex socket flat head	STD .....	standard
HSH .....	hex socket head	TAP .....	self tapping
HWH .....	hex washer head	TTH .....	Torx truss head
HWHTF .....	hex washer head thread forming	WH .....	wing head




Sheet No.:2

## Housing & Handle Bracket Assembly

Ref. No.	Part No.	Qty.	Description
1	40-1940	2	Washer
2	95-7403-03	2	Bracket-Wheel Height Adjustment
3	92-4890	2	Washer - Wheel
4	3296-39	2	Nut-Lock, NI
5	93-0231	1	Screw - PPH
6	93-0222-03	1	Baffle - Front
7	93-0216	1	Kicker - Front
8	92-4881-03	2	Plate - Height Adjustment
9	93-0230-01	1	Cover - Recycling
10	93-0242	4	Grommet
11	32144-4	3	Screw-HH
12	32105-27	1	Screw
13	3296-2	1	Nut-Lock
15	93-0234	1	ASM - RH Handle Bracket
16	93-0209	1	Cover - Transmission
17	32144-119	1	Screw-Pth
18	49-2040	1	Screw-Tapping
19	93-0228-03	1	Guide - Transmission
20	92-1616	1	Screw-HWHTF
21	605120	1	Grommet
22	614673	1	Bushing-Plate, Actuator
23	104-7678	1	Gear Case ASM, Ts

Ref. No.	Part No.	Qty.	Description
24	92-2915	1	Decal - HOC, LH
25	92-2914	1	Decal - HOC, RH
26	93-0233	1	ASM - LH Handle Bracket
27	322-3	6	Screw-HH
28	92-8647	1	Shield - Trailing
29	3296-29	6	Nut-Lock
31	92-1008	2	Knob-Lever, Height Adjustment
32	614687	2	Arm-Front Spring
33	614650	2	Bolt-Shoulder
34	92-9591	2	Wheel ASM
35	614672	2	Bolt-Shoulder






Sheet No.:3

## Gear Case & Wheel Assembly

Ref. No.	Part No.	Qty.	Description
1	92-1057	2	Bolt-Shoulder
2	92-9590	2	Wheel ASM
2:3:1	27-6250	2	Bushing
3	65-2720	4	Ring-Klip
4	65-4740	4	Washer-Thrust, Keyed
5	66-6040	1	Key-Rocking, RH
6	66-6050	1	Key-Rocking, LH
7	65-4710	2	Ring-Friction
8	92-7746	2	Arm ASM-Rear Height Adjustment
8:1	302-56	1	Fitting-Zerk
8:2	47-2900	1	Bushing
8:3	70-9760	1	Bushing
9	92-1008	2	Knob-Lever, Height Adjustment
10	614447	2	Spacer-Axle Shaft
11	32144-85	2	Screw-HH
12	92-1004	2	Rear Spring Arm ASM
13	603773	2	Nut
14	65-4730	2	Washer-Arm, Pivot
15	65-4760	2	Washer-Clutch
16	65-4750	2	Gear-Pinion
17	65-4720	2	Spring-Compression
18	94-1609	2	Cover-Wheel

Ref. No.	Part No.	Qty.	Description
19	614426	2	Washer-Stepped
20	93-0232	1	V-Belt



Sheet No.:5


## Engine Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	95-1748	1	Screw-Blade	22	99-6015	1	Decal - Recoil
2	3253-22	1	Washer-Lock	23	99-6014	1	Decal - Recoil
3	93-0219-03	1	Accelerator	24	2210-316	1	Stop-Rope
4	93-0241-03	1	Blade - Steel Deck	26	93-0231	1	Screw - PPH
5	99-5287	1	ASM-Blade Driver	27	93-0223-03	1	Baffle - Rear
6	95-1878	1	Pulley	28	93-0217	1	Kicker - Rear
7	92-1024-03	1	Guide-Belt	29	95-1726	3	Screw-Taptite W/Patch
8	32128-32	2	Nut-HHF	30	104-0214	1	Screw-Set,Cone Point
9	99-6349	1	Baffle	31	93-4196-03	1	Shield - Grass
10	99-5236	1	Housing Sp Steel				
10:2	99-6011	1	Decal - Deck				
10:3	99-6018	1	Decal - Warning				
10:4	93-0248	1	Decal - Warning				
10:5	43-8480	1	Decal-Danger				
12	99-5291	1	Rod-Cover				
13	99-5292	1	Bracket-Cover				
14	99-5293	1	Spring-Torsion				
15	99-5294	1	Cover-Side				
16	99-5295	1	Chute-Side				
18	100-1589-03	1	Clamp-Door				
19	3229-11	2	Screw-CARR				
20	98-8332	1	Knob				
☆21		1	Engine - 6 HP Zs Intek Briggs & Stratton Model 122602-0150-E1				

☆ Not serviced







Assemblies include all parts shown in frames.

Sheet No.:


## ENGINE BRIGGS & STRATTON MODEL 122602-0150-E1

Ref. No.	Part No.	Qty.	Description
5	692801	1	Cylinder Head
7	★Δ273240	1	Cylinder Head Gasket
13	691137	1	Screw (Cylinder Head)
33	499642	1	Exhaust Valve
34	499641	1	Intake Valve
35	691304	1	Valve Spring (Intake)
36	263149	1	Valve Spring (Exhaust)
40	93312	1	Valve Retainer
45	262679	1	Valve Tappet
51	692668	1	Intake Gasket
122	★●◆Δ692799	1	Carburetor Spacer
155	691231	1	Cylinder Head Plate
189	691295	1	Rocker Arm Ball
238	691300	1	Valve Cap(Cylinder Head Plate)
914	691127	1	Screw (Rocker Cover)
337	499608	1	Sparkplug
383	19374	1	Sparkplug Wrench
635	662558	1	Sparkplug Boot
830	499756	1	Rocker Arm Stud
868	★Δ498592	1	Valve Seal
883	★Δ273348	1	Exhaust Gasket
993	★Δ691892	1	Plate Gasket
1022	★Δ272198	1	Rocker Cover Gasket
1023	692694	1	Rocker Cover
1026	498597	1	Push Rod

Ref. No.	Part No.	Qty.	Description
1029	691230	1	Rocker Arm
1034	691343	1	Push Rod Guide

★ Included in Gasket Set-See Ref. 358.  
● Included in Carburetor Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.  
Δ Included in Valve Overhaul Gasket Set-See Ref. 1033.



Assemblies include all parts shown in frames.

Sheet No.:

## ENGINE BRIGGS & STRATTON MODEL 122602-0150-E1

Ref. No.	Part No.	Qty.	Description
4	499619	1	Engine Sump
12	★272198	1	Crankcase Gasket
15	94880	1	Oil Drain Plug
16	694153	1	Crankshaft
20	★399781	1	Oil Seal
22	691092	1	Screw (Engine Sump)
	94612	1	Screw (Engine Sump) (Used in Hole Nearest Breather)
24	222698	1	Flywheel Key
25	499627	1	Piston Assembly (Standard)
	692788	1	Piston Assembly (.010 O/S)
	692789	1	Piston Assembly (.020 O/S)
	692790	1	Piston Assembly (.030 O/S)
26	499631	1	Ring Set (Standard)
	692785	1	-----Set(.010 O/S)
	692786	1	Ring Set(.020 O/S)
	692787	1	Ring Set(.030 O/S)
27	263190	1	Piston Pin Lock

Ref. No.	Part No.	Qty.	Description
28	499423	1	Piston Pin
29	499424	1	Connecting Rod
32	94699	1	Screw (Connecting Rod)
43	493737	1	Governor/Oil Slinger
46	692453	1	Camshaft
146	94388	1	Timing Key
741	262598	1	Timing Gear


★ Included in Gasket Set-See Ref. 358.  
● Included in Carburetor Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.  
△ Included in Valve Overhaul Gasket Set-See Ref. 1033.









Assemblies include all parts shown in frames.

Sheet No.:

## ENGINE BRIGGS & STRATTON MODEL 122602-0150-E1

Ref. No.	Part No.	Qty.	Description
182	692441		Bracket (Tank Mounting)
187	298049		Fuel Line (Cut to Required Length)
190	94511		Screw (Fuel Tank)
601	95126		Hose Clamp
670	280512		Fuel Tank Spacer
957	498697		Fuel Tank Cap
674	94929		Screw (Tank Bracket Mtg.)
972	499618		Fuel Tank
1059	398540		Screw/Washer Kit





Ref. No.	Part No.	Qty.	Description

★ Included in Gasket Set-See Ref. 358.  
 ● Included in Carburetor Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.  
 △ Included in Valve Overhaul Gasket Set-See Ref. 1033.







Sheet No.:

## ENGINE BRIGGS & STRATTON MODEL 122602-0150-E1

Ref. No.	Part No.	Qty.	Description
3	★299819		Oil Seal
7	★Δ273240		Cylinder Head Gasket
9	★Δ272481		Breather Gasket
12	★272198		Crankcase Gasket
20	★399781		Oil Seal
51	★◆●Δ272248		Intake Gasket
104	●231371		Float Hinge Pin
177	★280393		O-Ring Seal
121	692703		Carburetor Kit
122	★◆●Δ692799		Carburetor Spacer
127	●		Welch Plug (Sold in Kit Only)
134	●398188		Needle Valve
137	●◆		Float Bowl Gasket (Sold in Kit Only)
163	★◆●273364		Air Cleaner Gasket
276	●◆		Washer (Sold in Kit Only)
358	692702		Gasket Set
585	★272238		Breather Passage Gasket
708	●◆		Choke Shaft Seal (Sold in Kit Only)
868	★Δ498592		Valve Seal
883	★Δ273348		Exhaust Gasket
977	692704		Carburetor Gasket Set

Ref. No.	Part No.	Qty.	Description
987	●◆		Throttle Shaft Seal (Sold in Kit Only)
993	★Δ273346		Gasket
1022	★Δ273787		Rocker Cover Gasket
1033	692705		Valve Overhaul Kit
1081	★280966		O-Ring Seal

★ Included in Gasket Set-See Ref. 358.  
● Included in Carburetor Kit-See Ref. 121.

◆ Included in Carburetor Gasket Set-See Ref. 977.  
Δ Included in Valve Overhaul Gasket Set-See Ref. 1033.





