Form No. 3443-726 Rev A

TORO®

Count on it.

Parts Catalog

60in Completion Kit

Z Master® 4000 Series Riding Mower

Model No. 78466—Serial No. 400000000 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3443-726 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Blower and Drive Assembly 4
Blower Assembly No. 126-7697 5

© 2021—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved



Blower and Drive Assembly

Ref.	Part Number	Qty.	Description
1	126-7697	1	Blower ASM
2	1-353050	1	Shaft-Catcher, Grass
3	1-806323	1	Pin-Roll
4	135-0894	1	Sheave-HD60 Blower Drive
5	140-4906	1	Pulley Mount ASM
6	3296-39	3	Nut-Lock, NI
7	135-0154-01	1	Baffle-Bagger
8	3230-16	1	Screw-CARR
9	104-8300	1	Nut-HF, NI
10	3231-27	2	Screw-CARR

Ref.	Part Number	Qty.	Description
11	104-8301	2	Nut-HF, NI
12	144-6578	1	Cover-Belt
13	117-0342-01	1	Bracket-Cover, Belt
14	3229-1	2	Screw-CARR
15	3296-42	2	Nut-Lock, NI
16	135-0708	1	Belt-V, Hitemp
17	609900	1	Nut-Speed
18	98-8332	1	Knob
20	133-8061	1	Decal-Warning



Blower Assembly No. 126-7697

Ref.	Part Number	Qty.	Description
1	126-7613-03	1	Mount-Blower
2	1-513013	4	Housing-Flange
3	1-653346	2	Bearing
4	103-3815	1	Impeller
5	3257-32	1	Key-Woodruff
6	3230-18	6	Screw-CARR
7	32128-20	6	Nut-HF
8	126-9450	1	Upper-Housing W/Decals
8:2	126-9451	1	Decal-Warning
8:3	144-2629	1	Decal - E-Z Vac
9	1-513208	1	Washer-Spring
10	3219-6	1	Nut-Hex
11	126-9785	1	Cover-Bearing W/Decal
11:2	126-9595	1	Decal-Warning
12	3256-3	2	Washer-Flat
13	3296-47	2	Nut-Lock, NI
14	321-3	8	Screw-HH
15	116-4356	1	Pin-Latch
16	3290-307	1	Pin-Cotter
17	3256-4	5	Washer-Flat
18	121-3249	1	Spring-Compression

Ref.	Part Number	Qty.	Description
19	1-653365	1	Spacer
20	112-2345	1	Pulley
21	3256-26	1	Washer-Flat
22	3296-28	1	Nut-Lock, NI
23	1-653366	1	Hub
24	1-653322	1	Idler-Inside
25	3256-24	1	Washer-Flat
26	323-12	2	Screw-HH
27	3290-357	8	Nut-HHF, Whiz
28	103-0130	1	Bushing-Pivot, Idler
29	117-0345	1	Idler Arm ASM W/Bushings
29:2	1-653600	2	Bushing
29:3	302-19	1	Fitting-Grease
29:4	126-4659	1	Decal-Warning
30	3274-107	1	Screw-HSBH
31	116-6487	1	Blower Chute ASM
31:2	103-4752-03	1	Plate-Reinforcing
31:3	114439	5	Rivet-Blind
31:4	116-6486-03	1	Plate-Filler
31:5	126-4853	1	Decal-Warning
32	1-653596-03	1	Plate-Backing, Blower



Blower Assembly No. 126-7697 (continued)

Ref.	Part Number	Qty.	Description
33	32128-33	8	Nut-HF
34	3256-22	2	Washer-Flat
35	3274-69	2	Screw-HSBH
36	3229-1	2	Screw-CARR
37	3229-11	3	Screw-CARR
38	104-7201	7	Nut-HF
39	103-4080	2	Latch-Rubber
40	3256-16	7	Washer-Flat
41	3274-39	4	Screw-HSBH
42	323-10	1	Screw-HH

Ref.	Part Number	Qty.	Description
43	103-1103	1	Idler-Flat
44	109-1122-01	1	Bumper
45	323-11	2	Screw-HH
46	323-7	1	Screw-HH
47	104-2408	3	Screw-HSBH
48	3296-2	3	Nut-Lock, NI
49	1-603693	1	Spring-Extension
52	135-0456	1	Spacer
53	135-0457	1	Spacer

Notes:

Count on it.