



Parts Catalog

FieldFill 660

Model No. 46423—Serial No. 321000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Decal Assembly 4


Frame Assembly..... 6

Brush Covers Assembly 8

Brush Assembly 10

Hydraulic Drive Assembly..... 12


Decal Assembly



Decal Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	144-8878	2	Decal-Safety	5	136-3666	1	Decal-Fieldfill 660
2	144-8879	1	Decal Tighten Chain	6	133-8061	1	Decal-Warning
3	144-7905	1	Decal-Safety	7	105-0698	1	Decal-Caution
4	144-8880	1	Decal-Safety Hot Surface				


Frame Assembly



Frame Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	144-8881	2	Pull Rod	16	144-7939	12	Washer M10 - ISO 7089
2	144-8882	1	Holder For Wheel Fork	17	144-8109	2	Bolt M10 X 20 - ISO 4017
3	144-8883	1	Bracket For Brush - Right	18	144-7991	18	Washer M20 - ISO 7089
4	144-8884	1	Bracket For Brush - Left	19	144-8061	6	Grease Nipple M8 Din 71412A
5	144-8885	3	Wheel Fork	20	144-8746	3	Bolt M8 X 12 - ISO 4017
6	144-8886	3	Locking Pin	21	144-8271	1	Bolt M14 X 100 - ISO 4014
7	144-8887	3	Wheel Bolt	22	144-8270	2	Washer M14 - ISO 7089
8	144-8888	3	Wheel 260X85	23	144-8287	1	Spring Washer M14 - Din 127
9	144-8889	2	Locking Pin	24	144-8896	1	Nut M14 - Din 934
10	144-8890	1	Chain Suspension	25	144-8139	26	Nut M10 - Din 934
11	144-8891	12	Lock Washer	26	144-7942	6	Bolt M10 X 40 - ISO 4014 - 10.9
12	144-8892	2	Chain Link				
13	144-8893	1	Chain For Top Link				
14	144-8894	24	Spacer Disk				
15	144-8895	2	Bolt M10 X 100 - ISO 4014				


Brush Covers Assembly



Brush Covers Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	144-8897	1	Torque Support Bracket	11	144-7930	1	Spring Washer M8 - Din 127
2	144-8898	1	Shaft Cover	12	144-8273	1	Nut M8 - Din 934
3	144-8891	2	Lock Washer	13	144-8128	1	Toolbox Complete
4	144-8899	1	Cover Brush	14	144-8129	2	Toolbox Contraplate
5	144-8900	2	Acorn Nut M8	15	144-8130	2	Bolt M8 X 35 - ISO 4017
6	144-8901	2	Protection Bar	16	144-8013	2	Washer-Large M8 - Din 9021
7	144-8902	2	Bolt M10 X 16 - ISO 4017	17	144-7944	2	Self Lock Nut M8 - ISO 10511
8	144-7945	13	Bolt M8 X 20 - ISO 4017	18	144-8245	4	Nut M12 - Din 934
9	144-7929	13	Washer M8 - ISO 7089				
10	144-7944	12	Self Lock Nut M8 - ISO 10511				



Brush Assembly



Brush Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	144-8903	1	Main Frame Brush	17	144-8918	1	Drive Chain
2	144-8904	10	Bearing Bushing	18	144-8919	5	Brush Center 400Mm
3	144-8905	1	Brush Holder, HYD. Motor	19	144-8920	5	Disc Ø11/50 X 5Mm
4	144-8906	5	Sprocket 3/4" Z-20	20	144-7737	2	Brush
5	144-8907	5	Adjusting Washer 30X40X1	21	144-8921	10	Acorn Nut M5
6	144-8908	1	Bushing 25Mm	22	144-8819	1	HYD. Motor Omp 25
7	144-8909	2	Grub Screw M8X6	23	144-8152	5	Circlip D-30 - Din 471
8	144-8910	1	Torque Bolt - Left	24	144-8922	10	Carriage Bolt M5X45
9	144-8911	1	Torque Bolt - Right	25	144-7920	6	Bolt M10 X 25 - ISO 4017
10	144-8891	5	Lock Washer	26	144-8923	10	Large Washer M5 - Din 9021
11	144-8912	4	Brush Holder	27	144-8283	1	Bolt M12 X 35 - ISO 4017
12	144-8913	10	Grease Nipple M6 H1	28	144-8215	1	Bolt M12 X 40 - ISO 4017
13	144-8914	1	Holder	29	144-7922	7	Washer M12 - ISO 7089
14	144-8915	2	Chain Tensioner Wheel 10T	30	144-8924	5	Key 8X7X20 - Din 6885
15	144-8916	2	Bearing	31	144-8023	2	Key 8X7X30 - Din 6885
16	144-8917	1	Spacer				

Hydraulic Drive Assembly



Hydraulic Drive Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	144-8925	1	Flow Regulator 25 L	9	144-8933	2	Plug-In Coupling (Male Fitting)
2	144-8926	1	HYD. Fitting	10	144-8934	2	HYD. Connector Dust Cap
3	144-8927	2	HYD. Fitting	11	144-8819	1	HYD. Motor Omp 25
4	144-8928	2	HYD. Fitting	12	144-8935	1	T-Connector Pm, Pipe 12-M18
5	144-8929	1	HYD. Connector	13	144-8936	2	L-Connector Pm. Pipe 12-M18
6	144-8930	2	HYD. Hose				
7	144-8931	1	Return Valve				
8	144-8932	1	HYD. Fitting				

Notes:

Notes:

