



Form No. 3411-464 Rev E

**Count on it.**

# Parts Catalog

## **GrandStand® Mower**

**With 60in TURBO FORCE® Cutting Unit**

Model No. 74513—Serial No. 400000000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

60 Inch Deck Assembly ..... 4

Deck Decal Assembly No. 127-1941 ..... 6

Spindle Assembly No. 127-0560 ..... 8

Deflector Assembly No. 120-2451 ..... 10

Ground Drive Assembly ..... 12

LH Transaxle Assembly No. 136-4101 ..... 14

RH Transaxle Assembly No. 136-4102 ..... 16

Motion Control Assembly ..... 18

Control Handle Assembly No. 132-5157 ..... 20

Control Handle Assembly No. 132-5158 ..... 22

Parking Brake Assembly ..... 24

Deck Lift Assembly ..... 26

HOC Lever Assembly No. 130-1755 ..... 28

60 Inch Frame Assembly ..... 30

Wheel, Tire and Bearing Assembly No. 130-4558 ..... 32

Platform Assembly ..... 34


Engine Assembly ..... 36

Fuel Tank Assembly ..... 38

Wire Harness Assembly ..... 40

Attachments and Accessories ..... 42


# 60 Inch Deck Assembly



## 60 Inch Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 127-1941           | 1           | Deck ASM              | 21          | 109-6658           | 2           | Nut-Flange, NI           |
| 2           | 127-0560           | 3           | Spindle ASM           | 22          | 103-0865           | 3           | Washer-Blade Bolt, Heavy |
| 3           | 120-6434           | 3           | Pulley                | 23          | 51-4060            | 3           | Screw-Blade              |
| 4           | 109-6982           | 4           | Wireform-Cover        | 24          | 105-4622           | 1           | Spacer                   |
| 5           | 109-6936           | 2           | Cover-Belt, LH        | 25          | 322-50             | 2           | Screw-HH                 |
| 6           | 114-5204-01        | 1           | Bracket-Wheel, LH     | 26          | 104-8300           | 2           | Nut-HF, NI               |
| 7           | 114-5208-01        | 1           | Bracket-Wheel, Center | 27          | 108-4052           | 1           | Spring-Torsion           |
| 8           | 114-5213-01        | 1           | Bracket-Wheel, RH     | 28          | 98-7912            | 2           | Tube-Spanner             |
| 9           | 1-603299           | 4           | Roller-Scalp, Anti    | 29          | 104-0892           | 2           | Spacer-Axle, Rear        |
| 10          | 117-5758-03        | 3           | Bracket-Cover         | 30          | 98-5967            | 1           | Spacer-Wheel             |
| 11          | 117-9701-01        | 1           | Baffle ASM            | 31          | 323-23             | 2           | Screw-HH                 |
| 12          | 121-1788-01        | 1           | Baffle ASM            | 32          | 130-1812           | 1           | Torsion Idler ASM        |
| 13          | 130-6594-01        | 1           | Baffle-Discharge      | 33          | 127-1971           | 1           | Pulley-Idler             |
| 14          | 3231-2             | 9           | Bolt-CARR             | 34          | 323-14             | 1           | Screw-HH                 |
| 15          | 104-8301           | 56          | Nut-HF, NI            | 35          | 114-1908-01        | 1           | Skid                     |
| 16          | 120-2451           | 1           | Deflector ASM         | 36          | 130-6647-01        | 1           | Bracket-Skid             |
| 17          | 105-7718-03        | 3           | Blade-Hi Flow         | 37          | 109-2872           | 1           | Spacer-Pulley            |
| 18          | 131-1123           | 1           | Belt-V                | 38          | 3231-44            | 1           | Screw-CARR               |
| 19          | 32144-70           | 3           | Screw-HWHTF           | 39          | 132-5155           | 1           | Idler-Pulley, Flat       |
| 20          | 92-1624            | 7           | Screw-HWH             | 40          | 132-5153           | 1           | Shield-Dust              |


Deck Decal Assembly No. 127-1941



## Deck Decal Assembly No. 127-1941 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------------|
| 2           | 133-4604           | 2           | Decal-Danger             | 6           | 131-3507           | 1           | Decal-Belt, Tension (CE) |
| 4           | 107-1619           | 1           | Decal                    | 7           | 131-1180           | 1           | Decal-Adjustment, Baffle |
| 5           | 93-7818            | 1           | Decal-Torque, Blade Bolt | 8           | 112-3858           | 1           | Decal-Scalp, Anti        |

# Spindle Assembly No. 127-0560




## Spindle Assembly No. 127-0560 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               |
|-------------|--------------------|-------------|----------------------------------|
| 1           |                    | 1           | Spindle Housing ASM<br>W/Studs ● |
| 1:2         | 114-8195           | 6           | Bolt-Neck, Ribbed                |
| 2           | 116-0720           | 2           | Bearing-Ball                     |
| 3           | 127-0554           | 1           | Spacer-Bearing                   |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------------|
| 4           | 127-0556           | 1           | Shaft-Spindle, Ball Bearing |
| 5           | 127-0557           | 1           | Hub-Spindle (W/Studs)       |
| 6           | 92-5836            | 1           | Washer                      |
| 7           | 3296-67            | 1           | Nut-Lock, NI                |

● Not serviced separately

**Deflector Assembly No. 120-2451**




## Deflector Assembly No. 120-2451 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 3231-4             | 4           | Screw-CARR         |
| 2           | 106-3246-01        | 1           | Deflector          |
| 3           | 106-3248-03        | 1           | Strap-Discharge    |
| 4           | 110-0759           | 1           | Deflector-Rubber   |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 108-4059-01        | 1           | Plate-Hinge, Rear  |
| 6           | 106-3253-01        | 1           | Plate-Hinge, Front |
| 7           | 104-8301           | 4           | Nut-HF, NI         |


# Ground Drive Assembly



## Ground Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 136-4101           | 1           | LH Transmission ASM              | 19:1        | 133-8677           | 1           | Cap-Vented         |
| 2           | 136-4102           | 1           | RH Transmission ASM              | 20          | 3229-25            | 3           | Screw-CARR         |
| 3           | 131-1131-03        | 1           | Support-Transaxle                | 21          | 104-7201           | 3           | Nut-HF             |
| 4           | 93-2569            | 4           | Screw-HHF                        | 22          | 131-7427           | 1           | HYD Hose ASM       |
| 5           | 116-4701           | 16          | Screw-HHF                        | 23          | 109-0309           | 1           | Hose-Fuel          |
| 6           | 104-8301           | 18          | Nut-HF, NI                       | 24          | 92-2379            | 1           | Clamp-Hose         |
| 7           | 131-7405-03        | 1           | Plate-Skid, Transmission<br>(RH) | 25          | 131-7469           | 1           | Rod-Bypass, RH     |
| 8           | 131-7404-03        | 1           | Plate-Skid, Transmission<br>(LH) | 26          | 131-7470           | 1           | Rod-Bypass, LH     |
| 9           | 117-5351           | 1           | Spacer                           | 27          | 108-2992           | 2           | Pin-Hair           |
| 10          | 1-413088           | 1           | Bushing-Lever, Lift              | 28          | 32180-030          | 1           | Clip-Tie           |
| 11          | 131-1175           | 1           | Arm-Idler                        | 29          | 130-4561           | 2           | Wheel And Tire ASM |
| 12          | 114-0463           | 2           | Washer-Friction, Composite       | 29:1        | 130-4564           | 1           | Rim-8 Inch, Gray   |
| 13          | 110-9981           | 1           | Washer-Plain                     | 29:2        | 120-6466           | 1           | Tire               |
| 14          | 3234-39            | 1           | Screw-HHF                        | 29:3        | 232-27             | 1           | Stem-Valve         |
| 15          | 93-1622            | 1           | Pulley-Idler                     | 30          | 242-50             | 8           | Nut-Lug            |
| 16          | 3231-4             | 1           | Screw-CARR                       | 31          | 132-7584           | 2           | Spacer-Hex         |
| 17          | 132-1184           | 1           | Spring-Extension                 | 32          | 104-8300           | 2           | Nut-HF, NI         |
| 18          | 131-1124           | 1           | Belt-V                           | 33          | 3290-250           | 2           | Pin-Cotter         |
| 19          | 132-1135           | 1           | Tank-HYD                         | 34          | 2412-141           | 2           | Clamp-Drive, Worm  |
|             |                    |             |                                  | 35          | 3290-378           | 1           | Tie-Cable          |

# LH Transaxle Assembly No. 136-4101




# LH Transaxle Assembly No. 136-4101 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-4737           | 1           | Nut-Lock                | 8:2         |                    | 1           | Arm-Brake ●        |
| 2           | 132-4738           | 1           | Fan                     | 8:3         |                    | 1           | Pin-Roll ●         |
| 3           | 132-4739           | 1           | Pulley                  | 8:4         |                    | 1           | Shaft-Brake ●      |
| 4           | 136-5402           | 1           | Seal Kit                | 8:5         |                    | 1           | Actuator-Brake ●   |
| 4:1         | 100-6926           | 1           | Cap-Sealing             | 8:6         |                    | 1           | Disc-Brake ●       |
| 4:2         | 132-4736           | 1           | O-Ring                  | 8:7         |                    | 1           | Shoe-Brake ●       |
| 4:3         |                    | 1           | Cap-Seal ●              | 8:8         |                    | 1           | Shim Kit ●         |
| 4:4         |                    | 2           | Seal-Washer ●           | 9           | 132-4735           | 1           | Cap-Oil            |
| 4:5         |                    | 1           | Packing ●               | 10          | 132-4746           | 1           | Drain Bolt Kit     |
| 4:6         | 132-4744           | 1           | Seal-Shaft              | 10:1        |                    | 1           | Seal-Washer ●      |
| 4:7         |                    | 2           | O-Ring ●                | 11          | 136-5401           | 1           | Lever-Control, RH  |
| 4:8         |                    | 1           | Seal-Oil ●              | 12          | 132-4747           | 1           | Sleeve             |
| 4:9         | 121-0959           | 1           | Sealant                 | 13          | 132-4748           | 1           | Washer             |
| 4:10        | 132-4745           | 1           | Seal-Axle               | 14          | 136-5406           | 1           | Axle Flange Kit    |
| 4:11        |                    | 1           | Packing ●               | 14:1        |                    | 1           | Flange ●           |
| 5           | 104-3265           | 1           | Pin                     | 14:2        |                    | 1           | Key-Woodruff ●     |
| 6           | 132-4700           | 1           | Lever-Bypass            | 14:3        |                    | 1           | Washer ●           |
| 7           | 133-1461           | 1           | Expansion Fitting Kit   | 14:4        |                    | 1           | Nut-Lock ●         |
| 7:1         | 136-4051           | 2           | Seal-Fitting, Expansion | 14:5        |                    | 1           | Nut-Cap ●          |
| 7:2         |                    | 1           | Fitting ●               | 15          | 132-4743           | 1           | Hydro Filter Kit   |
| 7:3         |                    | 1           | Bolt-Flange ●           | 15:1        | 136-5409           | 2           | Filter             |
| 8           | 133-1468           | 1           | Brake Kit, Left         | 15:2        | 136-5410           | 2           | O-Ring             |
| 8:1         |                    | 1           | O-Ring ●                |             |                    |             |                    |

● Not serviced separately

# RH Transaxle Assembly No. 136-4102





## RH Transaxle Assembly No. 136-4102 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-4737           | 1           | Nut-Lock                | 8:2         |                    | 1           | Arm-Brake ●        |
| 2           | 132-4738           | 1           | Fan                     | 8:3         |                    | 1           | Pin-Roll ●         |
| 3           | 132-4739           | 1           | Pulley                  | 8:4         |                    | 1           | Shaft-Brake ●      |
| 4           | 136-5402           | 1           | Seal Kit                | 8:5         |                    | 1           | Actuator-Brake ●   |
| 4:1         | 100-6926           | 1           | Cap-Sealing             | 8:6         |                    | 1           | Disc-Brake ●       |
| 4:2         | 132-4736           | 1           | O-Ring                  | 8:7         |                    | 1           | Shoe-Brake ●       |
| 4:3         |                    | 1           | Cap-Seal ●              | 8:8         |                    | 1           | Shim Kit ●         |
| 4:4         |                    | 2           | Seal-Washer ●           | 9           | 132-4735           | 1           | Cap-Oil            |
| 4:5         |                    | 1           | Packing ●               | 10          | 132-4746           | 1           | Drain Bolt Kit     |
| 4:6         | 132-4744           | 1           | Seal-Shaft              | 10:1        |                    | 1           | Seal-Washer ●      |
| 4:7         |                    | 2           | O-Ring ●                | 11          | 136-5401           | 1           | Lever-Control, RH  |
| 4:8         |                    | 1           | Seal-Oil ●              | 12          | 132-4747           | 1           | Sleeve             |
| 4:9         | 121-0959           | 1           | Sealant                 | 13          | 132-4748           | 1           | Washer             |
| 4:10        | 132-4745           | 1           | Seal-Axle               | 14          | 136-5406           | 1           | Axle Flange Kit    |
| 4:11        |                    | 1           | Packing ●               | 14:1        |                    | 1           | Flange ●           |
| 5           | 104-3265           | 1           | Pin                     | 14:2        |                    | 1           | Key-Woodruff ●     |
| 6           | 132-4700           | 1           | Lever-Bypass            | 14:3        |                    | 1           | Washer ●           |
| 7           | 133-1461           | 1           | Expansion Fitting Kit   | 14:4        |                    | 1           | Nut-Lock ●         |
| 7:1         | 136-4051           | 2           | Seal-Fitting, Expansion | 14:5        |                    | 1           | Nut-Cap ●          |
| 7:2         |                    | 1           | Fitting ●               | 15          | 132-4743           | 1           | Hydro Filter Kit   |
| 7:3         |                    | 1           | Bolt-Flange ●           | 15:1        | 136-5409           | 2           | Filter             |
| 8           | 133-1462           | 1           | RH Brake Kit            | 15:2        | 136-5410           | 2           | O-Ring             |
| 8:1         |                    | 1           | O-Ring ●                |             |                    |             |                    |

● Not serviced separately


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 132-5157           | 1           | LH Control Handle ASM  | 9:3         | 103-1167           | 1           | Joint-Ball End, LH        |
| 1:2         | 131-3562           | 1           | Bearing-Sleeve         | 9:4         | 132-7515           | 1           | Rod-Control               |
| 2           | 132-5158           | 1           | RH Control Handle ASM  | 9:5         | 3256-45            | 2           | Washer-Flat               |
| 2:8         | 131-3562           | 1           | Bearing-Sleeve         | 10          | 130-1807           | 1           | RH Control Rod ASM        |
| 3           | 119-0222           | 2           | Grip                   | 10:1        | 92-7008            | 1           | End-Rod, Female           |
| 4           | 103-9928           | 2           | Bearing                | 10:2        | 103-1167           | 1           | Joint-Ball End, LH        |
| 5           | 120-3288           | 1           | Tab-Pivot, LH          | 10:3        | 132-7515           | 1           | Rod-Control               |
| 6           | 3229-1             | 4           | Screw-CARR             | 11          | 3231-28            | 2           | Screw-CARR                |
| 7           | 104-7201           | 6           | Nut-HF                 | 12          | 104-8301           | 4           | Nut-HF, NI                |
| 8           | 120-3287           | 1           | Tab-Pivot, RH          | 13          | 3256-24            | 2           | Washer-Flat               |
| 9           | 130-1803           | 1           | LH Control Rod ASM     | 14          | 132-7538           | 1           | Bracket-Adjustment, Speed |
| 9:1         | 1-603807           | 1           | Spring-Return, Neutral | 15          | 126-1499           | 2           | Cam                       |
| 9:2         | 92-7008            | 1           | End-Rod, Female        | 16          | 323-7              | 2           | Screw-HH                  |



**Control Handle Assembly No. 132-5157**



## Control Handle Assembly No. 132-5157 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-5115           | 1           | Pivot-Control, Motion (LH) | 6           | 110-7191           | 2           | Washer-Thrust      |
| 2           | 131-3562           | 1           | Bearing-Sleeve             | 7           | 116-2670           | 1           | Screw-Shoulder     |
| 3           | 132-5114-03        | 1           | Lever-LH                   | 8           | 104-8300           | 1           | Nut-HF, NI         |
| 4           | 323-10             | 1           | Screw-HH                   | 9           | 132-5146           | 1           | Spring-Extension   |
| 5           | 104-8301           | 1           | Nut-HF, NI                 |             |                    |             |                    |

Control Handle Assembly No. 132-5158




## Control Handle Assembly No. 132-5158 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|----------------------------|
| 1           | 120-8490           | 1           | Pivot-Control, Motion (RH) |
| 2           | 130-1825-03        | 1           | Lever-RH                   |
| 3           | 104-8301           | 1           | Nut-HF, NI                 |
| 4           | 323-10             | 1           | Screw-HH                   |
| 5           | 110-7191           | 2           | Washer-Thrust              |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 116-2670           | 1           | Screw-Shoulder     |
| 7           | 104-8300           | 1           | Nut-HF, NI         |
| 8           | 131-3562           | 1           | Bearing-Sleeve     |
| 9           | 132-5146           | 1           | Spring-Extension   |


# Parking Brake Assembly



## Parking Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-5170           | 1           | Brake Handle ASM     | 7           | 32144-4            | 2           | Screw-HWH          |
| 2           | 3230-23            | 5           | Bolt-CARR            | 8           | 132-1187           | 1           | Clamp-Cable        |
| 3           | 104-8300           | 6           | Nut-HF, NI           | 9           | 132-7582           | 1           | Mount-Cable, Brake |
| 4           | 132-5168           | 1           | RH Brake Caliper ASM | 10          | 1-633268           | 1           | Grip-Lever         |
| 5           | 132-5169           | 1           | LH Brake Caliper ASM | 11          | 131-1195           | 2           | Cable-Brake        |
| 6           | 104-8301           | 2           | Nut-HF, NI           |             |                    |             |                    |


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-----------------------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 120-8405-01        | 1           | Shaft-Cross, Front                      | 24:3        | 108-6544           | 4           | Spacer                  |
| 2           | 109-9409           | 2           | Support-Bearing, Cross<br>Shaft (Front) | 25          | 3231-7             | 4           | Screw-CARR              |
| 3           | 109-9410           | 2           | Bearing-Cross Shaft, Front              | 26          | 104-8301           | 7           | Nut-HF, NI              |
| 4           | 116-1700           | 4           | Bolt-CARR                               | 27          | 32128-19           | 4           | Nut-HF Lock, Large Flg  |
| 5           | 99-5107            | 8           | Nut-Lock                                | 28          | 109-9066           | 4           | Yoke-Adjust, Deck       |
| 6           | 127-0369           | 6           | Bushing                                 | 29          | 322-47             | 4           | Screw-HH                |
| 7           | 10-8110            | 3           | Washer-Thrust                           | 30          | 3218-2             | 8           | Nut-Jam                 |
| 8           | 3256-62            | 3           | Washer-Flat                             | 31          | 130-6589           | 2           | Link-Lift               |
| 9           | 120-8411-01        | 1           | Arm-Lift, RH                            | 32          | 109-9840           | 2           | Screw-Shoulder, HHF     |
| 10          | 32151-29           | 3           | Ring-Retaining                          | 33          | 109-9065           | 2           | Screw-HH                |
| 11          | 120-8410-01        | 1           | Arm-Lift, LH                            | 34          | 116-2428           | 2           | Bushing-Flanged         |
| 12          | 130-1755           | 1           | HOC Lever ASM                           | 35          | 3256-4             | 2           | Washer-Flat             |
| 13          | 119-6223           | 2           | Washer                                  | 36          | 114-8417           | 4           | Nut-HF, NI              |
| 14          | 3296-53            | 3           | Nut-Lock, NI                            | 37          | 104-0151           | 2           | Spacer                  |
| 15          | 327-7              | 3           | Screw-HH                                | 38          | 84-2350            | 1           | Spacer-Long             |
| 16          | 130-6615           | 1           | HOC Link ASM                            | 39          | 132-7581           | 1           | HOC Plate And Decal ASM |
| 17          | 3218-6             | 1           | Nut-Jam                                 | 40          | 131-1103-01        | 1           | Plate-HOC, Inner        |
| 18          | 98-5975            | 1           | Washer-Belleville                       | 41          | 116-4701           | 3           | Screw-HHF               |
| 19          | 323-58             | 1           | Bolt-TAP, HH                            | 42          | 80-7590            | 2           | Spacer                  |
| 20          | 116-0886           | 1           | Spring-Extension                        | 43          | 116-5584           | 1           | Pin-HOC                 |
| 21          | 116-0780           | 4           | Screw-Shoulder, HHF                     | 44          | 116-0756           | 2           | Deck Lift Chain ASM     |
| 22          | 3256-28            | 4           | Washer-Flat                             | 44:1        | 1-633447           | 1           | Chain-Lift, Deck        |
| 23          | 127-1948-03        | 2           | Link-Lift                               | 44:2        | 109-9065           | 1           | Screw-HH                |
| 24          | 136-5675           | 1           | Deck Strut ASM                          | 44:3        | 32128-37           | 1           | Nut-HF                  |
| 24:2        | 126-8360           | 4           | Bushing-Rubber,<br>Suspension           | 45          | 130-0742           | 2           | Bolt-Shoulder           |
|             |                    |             |                                         | 46          | 43-0940            | 2           | Spacer                  |
|             |                    |             |                                         | 47          | 133-1431           | 1           | Spacer-Split            |


HOC Lever Assembly No. 130-1755



## HOC Lever Assembly No. 130-1755 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------|
| 1           | 130-1775-01        | 1           | Lever-Lift         | 8           | 103-1363           | 4           | Rivet               |
| 2           | 136-0530           | 1           | Rod-Latch, Release | 9           | 614672             | 1           | Screw-Shoulder, HWH |
| 3           | 114-8187           | 1           | Spring-Compression | 10          | 98-1629            | 1           | Washer              |
| 4           | 114-1207           | 1           | Washer-Special     | 11          | 104-7201           | 1           | Nut-HF              |
| 5           | 115-2750           | 1           | Knob               | 12          | 104-8301           | 1           | Nut-HF, NI          |
| 6           | 115-3592           | 1           | Grip               | 13          | 131-7452           | 1           | Latch-HOC           |
| 7           | 119-2309           | 1           | Bolt-Shoulder      |             |                    |             |                     |


# 60 Inch Frame Assembly



## 60 Inch Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 131-7431-01        | 1           | Frame                         | 22          | 114-1925           | 2           | Bumper-Rubber            |
| 8           | 132-7537           | 1           | Tower Decal ASM               | 23          | 114-1926           | 2           | Bumper-Rubber            |
| 8:2         | 131-3524           | 1           | Decal-Level, Oil              | 24          | 121-7988-01        | 2           | Fork-Caster              |
| 8:4         | 116-8775           | 1           | Decal-Fill, Fuel              | 25          | 1-811010           | 2           | Plug                     |
| 8:5         | 131-3527           | 1           | Decal-Caution                 | 26          | 1-543509           | 4           | Bearing-Roller, Tapered  |
| 8:6         | 131-3526           | 1           | Decal-Controls                | 27          | 116-5647           | 2           | Seal-Grease              |
| 8:7         | 131-3528           | 1           | Decal-Fuse                    | 28          | 1-633508           | 6           | Washer-Bellville         |
| 9           | 3234-42            | 4           | Screw-HHF                     | 29          | 103-4882           | 2           | Cap-Grease               |
| 10          | 104-8301           | 8           | Nut-HF, NI                    | 30          | 132-5150-03        | 1           | Guard-Engine             |
| 11          | 131-7455           | 1           | Plate-Striker                 | 31          | 1-513658           | 4           | Bumper                   |
| 12          | 3229-11            | 1           | Screw-CARR                    | 33          | 3230-10            | 2           | Bolt-CARR                |
| 13          | 104-7201           | 1           | Nut-HF                        | 34          | 3296-51            | 2           | Nut-Lock, NI             |
| 14          | 105-4886           | 4           | Nut-Tinnerman                 | 35          | 3290-271           | 2           | Rivet-Pop                |
| 15          | 3230-5             | 3           | Bolt-CARR                     | 38          | 130-1790           | 1           | Decal-Panel, Control     |
| 16          | 104-8300           | 9           | Nut-HF, NI                    | 48          | 107-3002           | 2           | Washer-Nylon             |
| 17          | 107-3844           | 3           | Washer                        | 49          | 105-8278           | 1           | Decal                    |
| 18          | 130-4558           | 2           | Wheel/Tire And Bearing<br>ASM | 52          | 132-7578-01        | 1           | Guard-Fan, RH            |
| 19          | 132-5161-01        | 1           | Tube-Mount, Fuel Tank         | 53          | 132-7598-01        | 1           | Guard-Fan, LH            |
| 20          | 132-1145-03        | 1           | Bracket-Cross                 | 63          | 133-4641           | 2           | Decal-Warning, No Riders |
| 21          | 117-3591           | 2           | Decal-Commercial              | 77          | 131-3529           | 1           | Decal-Service Aid        |

# Wheel, Tire and Bearing Assembly No. 130-4558




# Wheel, Tire and Bearing Assembly No. 130-4558 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Wheel And Bearing ASM ● | 1:5         | 130-4563           | 1           | Wheel And Tire ASM |
| 1:1         | 1-633585           | 2           | Bearing-Cone, Taper     | 2           | 103-2768           | 2           | Guard-Seal         |
| 1:2         | 103-0063           | 2           | Seal-Caster             | 3           | 3296-45            | 1           | Nut-Hex            |
| 1:3         | 103-3051           | 1           | Spacer-Nut ■            | 4           | 325-20             | 1           | Screw-HH           |
| 1:4         | 126-5359           | 1           | Caster Axle ASM         |             |                    |             |                    |

● Not serviced separately

■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on spacer nut


# Platform Assembly



## Platform Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 120-8499-03        | 1           | Hinge-Pad                  | 14          | 3231-2             | 2           | Bolt-CARR          |
| 2           | 117-9739           | 1           | Pad-Cushion                | 15          | 3231-27            | 2           | Screw-CARR         |
| 3           | 3256-23            | 4           | Washer-Plain               | 16          | 120-8475-01        | 1           | Platform           |
| 4           | 121-7999           | 4           | Screw-HH                   | 17          | 126-7157           | 1           | Mat-Platform       |
| 5           | 114-0463           | 4           | Washer-Friction, Composite | 18          | 136-5669-01        | 1           | Clamp-Shield       |
| 6           | 133-1426           | 2           | Knob                       | 19          | 32144-70           | 2           | Screw-HWHTF        |
| 7           | 116-2886           | 2           | Slide-Bushing              | 20          | 119-8650           | 1           | Pin-Latch          |
| 8           | 3253-4             | 2           | Washer-Lock                | 21          | 114-5348           | 1           | Spring             |
| 9           | 131-4535           | 2           | Nut-Acorn                  | 22          | 1-603175           | 1           | Knob-Ball          |
| 10          | 111044             | 4           | Spacer                     | 23          | 132-7583           | 2           | Bushing-Flanged    |
| 11          | 114-1915-01        | 2           | Link-Pad                   | 24          | 104-8301           | 2           | Nut-HF, NI         |
| 12          | 3256-4             | 6           | Washer-Flat                | 25          | 323-11             | 2           | Screw-HH           |
| 13          | 3296-59            | 4           | Nut-Lock, NI               |             |                    |             |                    |


# Engine Assembly



## Engine Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 131-1157           | 1           | Engine-Kohler, Ecv740 | 20          | 131-3586-03        | 1           | Stop-Clutch             |
| 1:4         | 116-5395           | 1           | Sensor-Oxygen         | 21          | 32144-70           | 4           | Screw-HWHTF             |
| 2           | 98-5975            | 4           | Washer-Belleville     | 22          | 132-5152           | 1           | Throttle ASM            |
| 3           | 126-0983           | 4           | Screw-BHTF            | 23          | 1-807533           | 2           | Bolt-CARR               |
| 5           | 132-1168           | 1           | Bracket-Muffler       | 24          | 32128-17           | 2           | Nut-Lock, Flange        |
| 6           | 3234-42            | 2           | Screw-HHF             | 25          | 1-603175           | 1           | Knob-Ball               |
| 8           | 104-8301           | 2           | Nut-HF, NI            | 26          | 131-3550           | 1           | Muffler Guard ASM       |
| 9           | 133-4634           | 1           | Muffler-Kohler        | 29          | 94-2579            | 1           | Decal                   |
| 12          | 3234-17            | 4           | Screw-HHF             | 30          | 131-3530-03        | 1           | Bracket-Mounting, Guard |
| 13          | 32128-25           | 4           | Nut-HF                | 31          | 106-9758           | 1           | Screw-CARR              |
| 14          | 1-807259           | 1           | Key                   | 32          | 3230-23            | 4           | Bolt-CARR               |
| 15          | 120-8498           | 1           | Pulley                | 33          | 104-8300           | 5           | Nut-HF, NI              |
| 16          | 131-1100           | 1           | Clutch                | 34          | 3290-378           | 1           | Tie-Cable               |
| 17          | 107-4136           | 1           | Washer                | 35          | 133-4657           | 1           | Hose ASM                |
| 18          | 1-603610           | 1           | Washer-Spring         | 35:2        | 353-508            | 1           | Plug-HH                 |
| 19          | 3212-6             | 1           | Screw-HH              | 35:2:1      | 237-42             | 1           | O-Ring                  |


# Fuel Tank Assembly



## Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-7560           | 1           | Fuel Tank ASM         | 2           | 110-8255           | 1           | Hose-Fuel          |
| 1:2         | 46-6560            | 2           | Bushing               | 3           | 98-2952            | 1           | Fitting-Straight   |
| 1:3         | 115-7788           | 1           | Cap-Fuel              | 4           | 132-7576           | 1           | Hose-Fuel          |
| 1:4         | 104-5228           | 1           | Fitting-Elbow, 90 DEG | 5           | 132-7545           | 1           | Fuel Line ASM      |
| 1:5         | 132-7559           | 1           | Fuel Tube ASM         |             |                    |             |                    |

# Wire Harness Assembly



## Wire Harness Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 136-5422           | 1           | Harness-Wire               | 13          | 114-0279           | 1           | Switch-PTO, On-On  |
| 2           | 82-2190            | 3           | Switch-Bail                | 14          | 117-2222           | 1           | Switch-Ignition    |
| 3           | 104-8162           | 1           | Battery                    | 15          | 63-8360            | 1           | Key-Ignition       |
| 4           | 130-6635-01        | 1           | Bracket-Hold Down, Battery | 16          | 3253-3             | 1           | Washer-Lock        |
| 5           | 104-7201           | 2           | Nut-HF                     | 17          | 3217-5             | 1           | Nut-Hex            |
| 6           | 1-633651           | 2           | Bolt-Holddown              | 18          | 3290-500           | 1           | Screw-PPH          |
| 7           | 112-7063           | 1           | Cable-Battery, Black       | 19          | 3256-14            | 1           | Washer-Flat        |
| 8           | 130-6570           | 1           | Module-Meter, Hour         | 20          | 3296-2             | 1           | Nut-Lock, NI       |
| 9           | 3256-23            | 2           | Washer-Plain               | 21          | 1-643275           | 1           | Relay              |
| 10          | 322-3              | 2           | Screw-HH                   | 22          | 67-1300            | 1           | Decal              |
| 11          | 115-3864           | 1           | Cable-Battery, Positive    | 23          | 1-643267           | 1           | Indicator-LED, Red |
| 12          | 109-5715           | 2           | Nut-HHF, Smooth            | 99          | 3290-378           | 4           | Tie-Cable          |

# Attachments and Accessories

## For 74513 GrandStand Mower With 60in TURBO FORCE Cutting Unit

| Product Name                                                             | Model/Part  |
|--------------------------------------------------------------------------|-------------|
| E-Z Vac Bagger .....                                                     | 78570       |
| 60in EZ Vac Blower.....                                                  | 78576       |
| Brake Hub Puller.....                                                    | 116-6518    |
| Speed Setting Tool.....                                                  | 132-7595    |
| Light Kit.....                                                           | 133-1437    |
| Electric Accessory Port.....                                             | 133-1438    |
| Hydraulic Cap Lock Kit.....                                              | 136-5420    |
| Twin Bagger Kit.....                                                     | 78524       |
| Trash Bag Assembly.....                                                  | 133-1435    |
| HOC Set Blocks.....                                                      | 133-1439    |
| Strobe Light Kit.....                                                    | 133-1495    |
| 15-Pound Cast Weight.....                                                | 112-7059-01 |
| Recycler Kit .....                                                       | 115-7468    |
| Harness Wire Splitter.....                                               | 121-5988    |
| Trimmer Rack .....                                                       | 133-1441    |
| 5 Gallon Bucket .....                                                    | 133-2533    |
| Filter-Oil.....                                                          | 98020       |
| Spark Plug .....                                                         | 130-8380    |
| Stand-On Weight Kit .....                                                | 133-1428    |
| Chute Gate Kit W/ Bag.....                                               | 133-1434    |
| Bucket Mount Kit.....                                                    | 136-5681    |
| Pneumatic Castor Wheel Kit .....                                         | 137-4136    |
| Blower Drive 60-in .....                                                 | 78527       |
| Roller Striper Kit.....                                                  | 133-1436    |
| Starter Fuse Kit, GrandStand Mower .....                                 | 139-5555    |
| 18x8.5n10 X-Tweel Turf.....                                              | 139-7890    |
| Soft Bag (3 Bushel).....                                                 | 30104       |
| Air Cleaner Filter.....                                                  | 100-4556    |
| Turbo Baffle Kit .....                                                   | 107-1634    |
| Filter Air Safety .....                                                  | 103-1326    |
| Bagger Enhancement Kit.....                                              | 139-1529    |
| 6in Hose Kit, E-Z Vac Twin Bagger, 2016 and After Grandstand Mower ..... | 139-7930    |
| Blower Upgrade Kit, Twin Bagger, 2016 and After Grandstand Mower .....   | 139-7940    |
| Fuel Filter.....                                                         | 130-8381    |
| 6 Pack-Blade, 20.5in Lo Flow .....                                       | 108-1128    |
| Blade-Lo Flow, 20.5in .....                                              | 105-7716-03 |
| 6 Pack Blade, 20.5in Mid-Flow .....                                      | 108-1123    |
| Blade-Mid Flow, 20.5in .....                                             | 105-7715-03 |
| 6 Pack Blade, 20.5in Hi-Flow .....                                       | 108-1114    |
| Blade-Hi Flow, 20.5in.....                                               | 105-7718-03 |
| 6 Pack-Blade, 20.5in Recycler.....                                       | 110-0405    |
| Blade-Recycler, 20.5in.....                                              | 105-7777-03 |
| 6 Pack-Blade, 20.5in Atomic.....                                         | 108-1115    |
| Blade-Atomic, 20.5in .....                                               | 105-8777-03 |
| 60 In Blade And Belt Kit .....                                           | 132-4742    |
| Hypr-Oil 500 (quart).....                                                | 114-4713    |

Attachments and Accessories (continued)

Hypr-Oil 500 (gallon)..... 114-4714

Hypr-Oil 500-5 (5 gallon)..... 114-4715

Toro Premium Fuel Treatment 12 Oz Bottle ..... 131-6572

Hydro Filter Kit ..... 132-4743

Hydro Oil Change Kit ..... 133-1457

10w30 4-Cycle Engine Oil (32oz Bottle)..... 38280

Toro 4-Cycle SAE 30 Oil (32oz Bottle) ..... 38903

Spark Arrestor ..... 98-9099



**Count on it.**