



**Count on it.**

Form No. 3445-126 Rev A

# Parts Catalog

## Super Recycler® Lawn Mower

Model No. 21386—Serial No. 409176091 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Housing Assembly ..... 4

Rear Door and Mulch Plug Assembly ..... 6

Bag Assembly ..... 8

Engine and Blade Assembly ..... 10


Front Wheel and Height-of-Cut Assembly ..... 12

Transmission and Rear Wheel Height-of-Cut Assembly ..... 14

Handle Assembly ..... 16

Attachments and Accessories ..... 18


# Housing Assembly



## Housing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 140-3768           | 1           | Housing ASM           | 10:2        | 138-3221           | 1           | Latch-Door                  |
| 1:4         | 94-8072            | 1           | Decal-Danger          | 10:3        | 138-3242           | 1           | Cap-Door                    |
| 1:7         | 125-5092           | 1           | Decal-Placement, Foot | 10:4        | 137-9137           | 1           | Screw-PPH                   |
| 1:8         | 137-9196           | 1           | Decal-Quick Wash      | 11          | 108-3753           | 1           | Chute-Discharge, Side       |
| 4           | 107-7494           | 1           | Cover-Belt            | 12          | 138-3224           | 1           | Bracket-Cable, Traction     |
| 5           | 49-2040            | 2           | Screw-HWHTF           | 14          | 112-6401           | 1           | Coupling-Hose, Washout Port |
| 6           | 112-6416           | 1           | Bracket-Cover         | 15          | 112-6400           | 1           | Port-Washout                |
| 7           | 137-4795           | 2           | Screw                 | 17          | 112-6438           | 1           | Washer-Seal, Washout Port   |
| 8           | 99-5291            | 1           | Rod-Cover             | 18          | 3254-5             | 1           | Washer-Lock                 |
| 9           | 99-5293            | 1           | Spring-Torsion        | 19          | 3218-6             | 1           | Nut-Jam                     |
| 10          | 107-3717           | 1           | Discharge Door ASM    |             |                    |             |                             |


# Rear Door and Mulch Plug Assembly



## Rear Door and Mulch Plug Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 107-7495           | 1           | Tunnel-Discharge   | 16          | 32144-70           | 2           | Screw-HWHTF           |
| 2           | 49-2040            | 5           | Screw-HWHTF        | 18          | 120-7011           | 1           | Shield-Trailing       |
| 3           | 114-2668           | 1           | Chute              | 19          | 117-1092           | 2           | Screw-PTH             |
| 4           | 115-8413           | 1           | Mulch Plug ASM     | 20          | 137-9108           | 1           | Plate-Handle, LH      |
| 5           | 137-9139           | 1           | Rear Door ASM      | 21          | 137-9107           | 1           | Plate-Handle, RH      |
| 5:2         | 131-4514           | 1           | Decal-Warning      | 22          | 140-3916-03        | 1           | Bracket-Smartstow, RH |
| 8           | 115-2859           | 1           | Spring-Torsion     | 23          | 140-3917-03        | 1           | Bracket-Smartstow, LH |
| 9           | 114-7924           | 1           | Spring-Torsion     | 24          | 106-9799           | 2           | Wheel-Sweep           |
| 10          | 94-8196            | 2           | Washer-Nylon       | 25          | 140-1292           | 2           | Screw-Shoulder        |
| 12          | 105-1316-01        | 1           | Lip-Housing        | 26          | 138-0719           | 2           | Nut-HF                |
| 13          | 63-8590            | 3           | Screw              |             |                    |             |                       |


# Bag Assembly



## Bag Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 132-4529-03        | 1           | Bag Frame ASM      |
| 2           | 114-2664           | 1           | Grass Bag ASM      |

# Engine and Blade Assembly



## Engine and Blade Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 6           | 108-8110-03        | 1           | Guide-Belt            |
| 7           | 107-7489-03        | 1           | Shield-Grass          |
| 8           | 95-1727            | 3           | Screw-Taptite         |
| 10          | 139-1816           | 1           | Driver-Blade          |
| 12          | 133-8183-03        | 1           | Blade-Recycling, 21In |
| 13          | 105-6848-01        | 1           | Accelerator-Blade     |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                |
|-------------|--------------------|-------------|-----------------------------------|
| 14          | 125-2466           | 1           | Bolt-Blade                        |
| 20          | 133-8062           | 1           | Decal-Arrestor, Spark             |
| 21          | 2210-316           | 1           | Stop-Rope                         |
| 22          | 140-3773           | 1           | Decal-Engine                      |
| 26          |                    | 1           | Engine-Briggs<br>104M020254F1 ● ■ |

● Not serviced separately

■ Obtain parts from [www.briggsandstratton.com](http://www.briggsandstratton.com)


# Front Wheel and Height-of-Cut Assembly



## Front Wheel and Height-of-Cut Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 114-3467           | 2           | Screw-Shoulder     | 8           | 603773             | 4           | Locknut            |
| 2           | 107-7492           | 2           | Arm-Pivot          | 9           | 92-1057            | 2           | Bolt-Shoulder      |
| 3           | 52-2480            | 2           | Spacer-Wheel       | 10          | 140-1294           | 2           | Wheel ASM          |
| 4           | 107-7491           | 2           | Arm-Spring         | 10:1        | 27-6250            | 2           | Bushing            |
| 5           | 105-3042           | 2           | Knob-Lever, HOC    | 11          | 40-1940            | 2           | Washer             |
| 6           | 49-2040            | 6           | Screw-HWHTF        | 12          | 139-1669-01        | 2           | Plate-HOC          |
| 7           | 3256-24            | 2           | Washer-Flat        |             |                    |             |                    |

## Transmission and Rear Wheel Height-of-Cut Assembly




## Transmission and Rear Wheel Height-of-Cut Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|---------------------|
| 1           | 121-9184           | 1           | Transmission ASM     | 13          | 65-4710            | 2           | Ring-Friction       |
| 2           | 115-4669           | 1           | Belt-V               | 14          | 65-4760            | 2           | Washer-Clutch       |
| 3           | 114-7977-03        | 1           | Bracket-Transmission | 15          | 139-6644           | 1           | Key-Rocking, L.H.   |
| 4           | 108-7476           | 3           | Screw-Plastite       | 16          | 139-6643           | 1           | Key-Rocking, R.H.   |
| 5           | 138-3235           | 2           | Cap-End              | 17          | 65-4750            | 2           | Gear-Pinion         |
| 6           | 107-7491           | 2           | Arm-Spring           | 18          | 65-4720            | 2           | Spring-Compression  |
| 7           | 105-3042           | 2           | Knob-Lever, HOC      | 19          | 92-1057            | 2           | Bolt-Shoulder       |
| 8           | 49-2040            | 6           | Screw-HWHTF          | 20          | 140-1295           | 2           | Wheel Gear ASM      |
| 9           | 100-8774           | 2           | Pivot Arm ASM        | 20:3        |                    | 1           | Wheel ASM ●         |
| 9:2         | 47-2900            | 1           | Bushing              | 20:3:1      | 27-6250            | 2           | Bushing             |
| 9:3         | 70-9760            | 1           | Bushing              | 21          | 74-1671            | 2           | Spacer-Cover, Wheel |
| 9:4         | 302-56             | 1           | Fitting-Grease       | 22          | 74-1660            | 2           | Cover-Wheel         |
| 10          | 65-4730            | 2           | Washer-Arm, Pivot    | 23          | 603773             | 2           | Locknut             |
| 11          | 65-4740            | 4           | Washer-Thrust, Keyed | 26          | 139-1669-01        | 2           | Plate-HOC           |
| 12          | 65-2720            | 4           | Ring-Retaining, Clip |             |                    |             |                     |

● Not serviced separately

# Handle Assembly



## Handle Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 140-3831-03        | 1           | Bracket-Float, LH  | 16          | 140-3821           | 1           | Decal                 |
| 2           | 137-4838-03        | 1           | Bracket-Float, RH  | 17          | 136-7150           | 1           | Bar-Control, Traction |
| 3           | 137-4844           | 2           | Knob-Handle        | 18          | 3256-23            | 1           | Washer-Plain          |
| 4           | 140-3824-05        | 1           | Handle-Upper       | 19          | 99-1589            | 1           | Lever-Traction        |
| 5           | 130-2344           | 2           | Bolt-Shoulder      | 20          | 136-7166           | 1           | Spring-Torsion        |
| 6           | 3296-47            | 4           | Nut-Lock, NI       | 21          | 131-0880-03        | 1           | Bail-Brake            |
| 7           | 138-3249           | 2           | Quick Release ASM  | 22          | 95-4453            | 1           | Screw                 |
| 7:1         | 140-4157           | 1           | Nut-Push           | 23          | 136-5864           | 1           | Anchor-Cable          |
| 7:2         | 138-3248           | 1           | Lever-Release      | 24          | 117-9389           | 1           | Cable-Traction        |
| 7:3         | 138-3253           | 1           | Anchor-Spring      | 25          | 117-5900           | 1           | Cable-Brake           |
| 7:4         | 115-2858           | 1           | Spring-Compression | 26          | 614249             | 3           | Tie-Cable             |
| 7:5         | 140-4158           | 1           | Rod-Release        | 29          | 131-4551           | 1           | Cover-Handle          |
| 8           | 86-9671            | 1           | Guide-Rope         | 30          | 137-4803           | 2           | Bumper-Rubber         |
| 9           | 3296-73            | 2           | Nut-Lock, NI       | 31          | 137-9100           | 2           | Cover-Bumper          |
| 10          | 114-7988           | 1           | Guide-Cable        | 32          | 140-3827           | 2           | Decal-Flex            |
| 11          | 105-6842           | 1           | Guide-LH           | 33          | 3256-1             | 1           | Washer-Flat           |
| 12          | 105-6841           | 1           | Guide-RH           | 34          | 130-6721           | 2           | Clip-Tree             |
| 15          | 104-8678           | 1           | Handle-Control     |             |                    |             |                       |

# Attachments and Accessories

## For 21386 Super Recycler Lawn Mower

| Product Name                                   | Model/Part  |
|------------------------------------------------|-------------|
| Bagging Blade .....                            | 108-3759-03 |
| Lawnmower Cover.....                           | 490-7462    |
| Traction Assist Handle Kit.....                | 131-4590    |
| Bag-Walk Behind (Toro).....                    | 490-7318    |
| Summer Oil-Case of 24 (20oz Bottles).....      | 38916       |
| Briggs Maint Kit.....                          | 130-8148    |
| 4-Cycle Fuel, Snow And Lawn 32oz Can .....     | 131-3823    |
| Toro Premium Fuel Treatment 12 Oz Bottle ..... | 131-6572    |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle) .....    | 38903       |
| Oil-30/10W-30 Synthetic (Quart).....           | 138-6053    |

**Notes:**



**Count on it.**