



## French Decal Kit

### Timecutter™ Z Riding Mowers

Part No. 105-1930

Part No. 105-1931

Part No. 105-1932

Part No. 105-1933

## Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

## Contents

<b>Description</b>	<b>Page</b>	<b>Description</b>	<b>Page</b>
Deck Height Decal Assembly .....	3	Kohler Engine Decal Assembly	
Console Decal Assembly .....	4	Only on No. 105-1932, 105-1932 .....	7
Transport Decal Assembly .....	5	Cutting Unit Decal Assembly .....	8
Briggs and Stratton Engine Decal Assembly .....			
Only on No. 105-1930, 105-1931, and 105-1932 .....	6		


## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

<b>Abbreviation</b>	<b>Meaning</b>	<b>Abbreviation</b>	<b>Meaning</b>
AR .....	as required	HYD .....	hydraulic
ASM .....	assembly	INC .....	incorporated
CARR .....	carriage	LH .....	left hand
DEG .....	degrees	NI .....	nylon insert
FH .....	flat head	PPH .....	Phillips pan head
GA .....	gauge	PTH .....	Phillips truss head
HF .....	hex flange	PTO .....	power take off
HH .....	hex head	RH .....	right hand
HHF .....	hex head flange	SFH .....	slotted fillister head
HLH .....	hex lag head	SHH .....	slotted hex head
HJ .....	hex jam	SQH .....	square head
HOC .....	height-of-cut	SHWH .....	slotted hex washer head
HS .....	hex socket	SPH .....	slotted pan head
HSBH .....	hex socket button head	SRH .....	slotted round head
HSFH .....	hex socket flat head	STD .....	standard
HSH .....	hex socket head	TAP .....	self tapping
HWH .....	hex washer head	TTH .....	Torx truss head
HWHTF .....	hex washer head thread forming	WH .....	wing head








Sheet No.:8

## Transport Decal Assembly

Ref. No.	Part No.	Qty.	Description
1	104-8061	1	Decal-Transport International


Ref. No.	Part No.	Qty.	Description



Sheet No.:9

## Briggs and Stratton Engine Decal Assembly (No. 105-1930, 105-1931, and 105-1932 Only)

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	104-8065	1	Decal-Surface, Hot International (only on: 105-1930, 105-1931, 105-1932)				
2	105-1860	1	Decal-Engine B&s International (only on: 105-1930)				



Sheet No.:10

## Kohler Engine Decal Assembly (No. 105-1931, 105-1932 Only)

Ref. No.	Part No.	Qty.	Description
1	105-1861	1	Decal-Engine Kohler International (only on: 105-1931, 105-1932)

Ref. No.	Part No.	Qty.	Description









