



44 inch Vac Bagger

TimeCutter™ Z Riding Mower Attachment

Model No. 79161—210000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.


Contents

Description	Page	Description	Page
Drive Components Assembly	3	Bag and Frame Assembly	7
Blower Housing Assembly	4	Baffle Assembly	8
Bag Top Assembly	5	Front Weight Assembly	9
44 Inch Deck Components Assembly	6	Maintenance	10–11

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	HYD	hydraulic
ASM	assembly	INC	incorporated
CARR	carriage	LH	left hand
DEG	degrees	NI	nylon insert
FH	flat head	PPH	Phillips pan head
GA	gauge	PTH	Phillips truss head
HF	hex flange	PTO	power take off
HH	hex head	RH	right hand
HHF	hex head flange	SFH	slotted fillister head
HLH	hex lag head	SHH	slotted hex head
HJ	hex jam	SQH	square head
HOC	height-of-cut	SHWH	slotted hex washer head
HS	hex socket	SPH	slotted pan head
HSBH	hex socket button head	SRH	slotted round head
HSFH	hex socket flat head	STD	standard
HSR	hex socket head	TAP	self tapping
HWH	hex washer head	TTH	Torx truss head
HWHTF	hex washer head thread forming	WH	wing head




Sheet No.:2

Drive Components Assembly

Ref. No.	Part No.	Qty.	Description
1	79-7110	1	Spring-Compression
2	79-2020	1	Spring-Rod
3	79-1970	1	Idler Arm ASM
4	3296-39	2	Nut-Lock, NI
5	92-7099	1	Pulley-Idler
6	3256-4	4	Washer-Flat
7	107213	1	Spacer
8	3256-24	1	Washer-Flat
9	323-10	2	Screw-HH
10	93-8013	1	Bushing
11	93-1622	1	Pulley-Idler
12	3230-16	4	Screw-CARR
13	93-8007	1	V-Belt
14	79-7280-03	1	Support-Shield, Belt
15	100284	2	Bushing
16	3256-26	1	Washer-Flat
17	3272-7	1	Pin-Cotter
18	79-7440	1	Bracket-Support, Housing
19	32128-20	4	Nut-HF
20	3256-3	1	Washer-Flat
21	79-7390	1	Spring-Extension
22	93-8012-03	1	Latch-Blower
23	93-8016-03	1	Mounting-Blower
24	3256-23	1	Washer-Flat
25	3272-10	1	Pin-Cotter

Ref. No.	Part No.	Qty.	Description
26	3296-29	1	Nut-Lock
27	98-3499	1	Washer - Flat
28	3230-2	1	Screw-CARR




Sheet No.:3

Blower Housing Assembly

Ref. No.	Part No.	Qty.	Description
1	32128-20	6	Nut-HF
2	3290-479	1	Fastener-Panel
3	82-5690	1	Retainer-Duct
4	22-9741	1	Spacer-Interlock
5	3220-6	2	Nut-Jam
6	3253-8	2	Washer-Lock
7	251-341	4	Flange
8	251-288	2	Bearing-Ball
9	3230-16	6	Screw-CARR
10	94-4378	1	Housing - Blower
11	3229-11	6	Screw-CARR
12	79-4300-03	1	Impeller
13	79-7170-03	1	Cover-Blower, Bottom
14	3256-22	6	Washer-Flat
15	3296-56	6	Nut-Lock, NI
16	3257-40	1	Key-Hi Pro
17	79-1470	1	Shaft-Blower
18	7038	1	Spacer
19	79-1460	1	Pulley-Blower


Ref. No.	Part No.	Qty.	Description



Sheet No.:4

Bag Top Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	115880	2	Grip	26	114955-03	1	Frame ASM
2	115481-03	2	Latch-Bagger, Top	27	323-6	2	Screw-HH
3	114439	24	Rivet-Pop	28	114961-03	1	Hinge-Bag, Top
4	9202704	4	Washer	30	93-7329	1	Decal - Easy Twin
5	92-1734	1	Top-Bagger				
6	321-4	2	Screw-HH				
7	3296-42	4	Nut-Lock, NI				
8	2412-91	2	Clamp				
9	321-4	2	Screw-HH				
10	94-4379	1	Bag Stiffener ASM				
10:2	93-7320	1	Decal - Caution				
11	3296-39	2	Nut-Lock, NI				
12	114966	1	Clamp-Seal				
13	117239	1	Seal-Chute				
14	92-1736-03	1	Support-Screen				
15	114969	1	Feeler-Fill, Bag				
16	3218-1	1	Nut-Jam				
17	32144-8	1	Screw-HH				
18	3256-49	1	Washer-Flat				
19	233-68	1	Knob				
20	104-8030	1	Chute-Discharge				
21	118320	1	Handle-Tapered				
22	114960	1	Pin-Spring				
23	114962	2	Spring-Extension				
24	9790944	2	Spacer				
25	114967	1	Screen-Bagger				




Sheet No.:5

44 Inch Deck Components Assembly

Ref. No.	Part No.	Qty.	Description
1	3230-8	1	Screw-CARR
2	93-8008	1	Pulley
3	3230-16	4	Screw-CARR
4	100-4184	1	Screw-CARR
5	93-9344-03	1	Bracket-Pivot
6	321-4	2	Screw-HH
7	94-4380	1	Belt Shield ASM
7:1	93-8022	1	Bracket-Support, Shield
7:2	79-0470	4	Poprivet
7:3	88-1870	1	Bracket-Support, Shield
8	93-8009	1	Tube-Latch
9	3296-42	2	Nut-Lock, NI
10	100-4188-03	1	Baffle-Rear
12	93-8023	1	Tube-Spacer
13	93-8020-03	1	Pivot-Bracket
14	3296-29	10	Nut-Lock
15	3256-23	6	Washer-Flat
16	100-4189-03	1	Ring-Bagging, RH
17	55-4940-03	3	Blade-Sail, High
18	104-8036-01	1	Cover-Belt, Bagger
19	46-8560	1	Screw-HHF


Ref. No.	Part No.	Qty.	Description



Sheet No.:6

Bag and Frame Assembly

Ref. No.	Part No.	Qty.	Description
1	114972-03	2	Frame-Bag
2	104-3692-03	1	Bagger Bracket ASM
3	9335064	1	Pin-Hair Cotter
4	3296-42	8	Nut-Lock, NI
5	321-4	4	Screw-HH
6	104-8006-03	2	Plate-Bagger
7	105-1941-03	4	Spacer-Black
8	3296-29	4	Nut-Lock
9	114974-03	2	Clamp
10	114973-03	2	Hanger-Bag
11	3230-1	4	Screw-CARR
12	93-1623	2	Bag-Depth
13	105-1940-03	2	Gusset-Bagger
14	3256-22	12	Washer-Flat
15	322-10	4	Screw-HH
16	321-10	4	Screw-HH



Sheet No.:9

Front Weight Assembly

Ref. No.	Part No.	Qty.	Description
1	104-8029	1	Weight-Bagger
2	104-8016	1	Decal
3	3234-18	4	Screw-HHF

Ref. No.	Part No.	Qty.	Description

Maintenance Record

[illegible]

Maintenance Record

[illegible]

