Form No. 3326–171

Glass Door

Workman® 3000/4000 Series Vehicles Attachment

Model No. 07226

Model No. 07251

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.


Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.


© The TORO Company — 2001
All Rights Reserved



Glass Door Assembly

Ref. No.	Part No.	Qty.	Description
1	95–7346–01	1	Glass Door ASM – RH (only on: 07251)
1	95–7346–06	1	Glass Door ASM – RH (only on: 07226)
1:1	95–7347–06	1	Door Frame – RH (only on: 07226)
1:1	95–7347–01	1	Door Frame – RH (only on: 07251)
1:2	99–1100	1	Window–RH, Synthetic
1:2	95–7308	1	Glass – Door
1:3	95–7348	1	Safety Lock – RH
1:4	95–7350	1	Cover – RH
1:5	95–7353	1	Seal ASM
1:6	98–2941	1	Door Latch W/O Lock
1:7	99–1228–01	1	Hinge – Upper RH (only on: 07251)
1:7	99–1228–06	1	Hinge – Upper RH (only on: 07226)
1:8	99–9399–01	1	Hinge – Lower RH (only on: 07251)
1:8	99–9399–06	1	Hinge – Lower RH (only on: 07226)
1:9	33114–016	4	Screw–HH
1:10	3256–23	4	Washer–Flat
1:11	95–7302	1	Seal – Door

Ref. No.	Part No.	Qty.	Description
2	95–7355–06	1	Glass Door ASM –LH (only on: 07226)
2	95–7355–01	1	Glass Door ASM –LH (only on: 07251)
2:1	95–7356–06	1	Door Frame – LH (only on: 07226)
2:1	95–7356–01	1	Door Frame – LH (only on: 07251)
2:2	99–1103	1	Window–Lower, LH, Synthetic
2:2	95–7305	1	Glass – Door, Lower
2:3	95–7349	1	Safety Lock – LH
2:4	95–7351	1	Cover – LH
2:5	95–7353	1	Seal ASM
2:6	98–2917	1	Door – Latch
2:7	99–1227–06	1	Hinge – Upper LH (only on: 07226)
2:7	99–1227–01	1	Hinge – Upper LH (only on: 07251)
2:8	99–9398–06	1	Hinge – Lower LH (only on: 07226)
2:8	99–9398–01	1	Hinge – Lower LH (only on: 07251)
2:9	33114–016	4	Screw–HH
2:10	3256–23	4	Washer–Flat



Sheet No.: 2

Glass Door Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
2:11	95–7302	1	Seal – Door
2:12	98–2916	1	Lock & Key Set (Optional)
2:13	95–7357–01	1	Slide Window – LH (only on: 07251)
2:13	95–7357–06	1	Slide Window – LH (only on: 07226)
2:13:1		1	Slide Window – LH
2:13:1:1	95–7311	1	Glass – Door, Upper
2:13:1:2	95–7312	1	Glass – Door, Upper
2:13:1:3	95–7358	1	Closure
3	95–7352	2	Hydropneumatic Spring
4	99–1104	2	Spring Bracket Kit
5	99–1105	2	Ballstud
6	105–1744	2	Cap–End

Ref. No.	Part No.	Qty.	Description


TORO®