Form No. 3412-208 Rev C

TORO®

Count on it.

Parts Catalog

High Flow Hydraulics Kit

GrandStand® Multi Force® Mower

Model No. 78601—Serial No. 400000000 and Up

Register at www.Toro.com.
Original Instructions (EN)

3412-208 C

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

High Flow Hydraulic Assembly 4
Pump and Cooler Assembly 6
Pump Assembly No. 136-1242 8
Pulley Assembly 10

© 2021—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


High Flow Hydraulic Assembly



High Flow Hydraulic Assembly (continued)

Ref.	Part Number	Qty.	Description
1	136-8305-03	1	Pump Mount ASM
2	136-7429-03	1	Pump Guard Bracket ASM
3	136-5738-03	1	Cooler Cover ASM
4	137-0796	1	Cap-Filler, Breather
4:1	237-101	1	O-Ring
6	3269-8	2	Rivet-Blind
7	3234-42	6	Screw-HHF
8	104-8301	13	Nut-HF, NI
9	104-1412	3	Bumper-Rubber
10	136-5740-01	1	Mount-Frame, Rear
11	63-7880	1	Pin-Latch, Brake
12	3290-250	1	Pin-Cotter
13	3231-25	3	Bolt-CARR
14	3231-11	2	Screw-CARR
15	116-5809	2	Spacer-Hydro
16	115-4212	1	Decal-Warning
17	136-7413-03	1	Plate
18	115-4855	1	Decal-Caution
19	93-7814	1	Decal-Danger
20	136-8361-01	1	Mount-Frame, Front
21	136-8362-01	1	Backplate
22	3231-9	2	Screw-CARR
23	137-2069	2	Spacer
24	1-806005	1	Pin-Cotter


Pump and Cooler Assembly



Pump and Cooler Assembly (continued)

Ref.	Part Number	Qty.	Description
1	136-5733	1	Cooler-Hydraulic
2	AU218-5063	2	Fitting-Straight
3	136-7412	1	Hydraulic Tube ASM
4	136-1242	1	Pump-Hydro
5	353-388	1	Fitting-Straight
5:1	237-79	1	O-Ring
6	94-7166	1	Adapter
6:1	237-79	1	O-Ring
7	136-8308	1	Fitting-Straight
7:1	237-42	1	O-Ring
8	100-4887	1	Fitting-Elbow, 90
8:1	237-42	1	O-Ring
9	2412-36	2	Clamp-Hose
10	133-2082	1	Hose-HYD
11	115-2231	1	Fitting-STR
11:1	237-79	1	O-Ring
12	136-5732	1	Fitting-Screen
12:1	237-79	1	O-Ring
13	353-620	1	Fitting-Straight
13:1	237-81	1	O-Ring
14	136-8346	1	Filter Head ASM
15	137-4102	1	Filter-Oil,Transmission
16	AU218-5119	1	Adaptor-Elbow
17	107069	4	Clip
18	110-6767	4	Washer-Thrust
19	136-5728	2	Fitting-Bulkhead ASM
20	144-1597	1	Quick Coupler-Male
21	136-5706	1	Disconnect-Quick, Female
22	136-7403	1	Fitting-Elbow
22:1	237-79	1	O-Ring
23	136-7402	1	Tube, Return
24	136-7415	1	Hydraulic Tube ASM
25	136-7383	1	Tube, Suction
26	3234-4	4	Screw-HHF


Pump Assembly No. 136-1242



Pump Assembly No. 136-1242 (continued)

Ref.	Part Number	Qty.	Description
1	136-5414	1	Ring-Retaining
2	136-5416	1	Seal-Lip
3	136-5415	1	Washer-Flat
4	109-2863	1	Bearing, Input Shaft Pr
5	114-8155	1	Trunnion Seal Kit
6	106-8753	2	Pin-Headless, Straight
7	136-5417	1	O-Ring
8	112-4152	1	Arm-Trunnion
9	112-4153	1	Swashplate
10	120-1092	1	Cylinder Block Kit
11	94-1910	1	Guide-Slot
12	106-8759	1	Bypass Valve Kit
13	108-2109	2	Shock Valve Kit
14	112-4164	1	Charge Relief Kit
15	136-5419	1	Bracket-Fan
16	112-4161	2	Bolt
17	136-5418	1	Fan Hub Kit
18	116-0917	1	Guard-Fan, Pump
19	104-2189	1	Plug-Thread, Straight
21	144-7018	1	Shaft Seal
22	144-7019	1	0-Ring Seal

Pulley Assembly



Pulley Assembly (continued)

Ref.	Part Number	Qty.	Description
1	103-2739	1	Key
2	133-2039	1	Pulley W/Hub
4	104-8120	1	V-Belt, PTO
5	114-0463	2	Washer-Friction, Composite
6	133-2033-03	1	Arm-Idler
7	93-1622	1	Pulley-Idler
8	66-4180	1	Spring-Brake, Main
9	1-413088	1	Bushing-Lever, Lift
10	110-9981	1	Washer-Plain
11	3231-5	1	Screw-CARR
12	104-8301	4	Nut-HF, NI
13	18-9810	1	Washer-Thrust
14	114-4681	1	Screw-HHF
15	136-7409	1	Control Arm ASM
16	104-6560	1	Screw-HH
17	3234-18	2	Screw-HHF
18	120-6474	3	Screw-Set, SQH



Count on it.