



GTS[®] 150–200 Conversion Kit
1995–1997 Super Recycler Walk Behind Mower
Part No. 105–1293

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.


Contents

Description	Page	Description	Page
Engine and Throttle Assembly	3	Flywheel Assembly Engine GTS-200	10
Cylinder Assembly Engine GTS-200	4	Starter Assembly Engine GTS-200	11
Cylinder Head Assembly Engine GTS-200	5	Carburetor Overhaul Kit Assembly	
Crankshaft Assembly Engine GTS-200	6	Engine GTS-200	12
Carburetor Assembly Engine GTS-200	7	Maintenance	13-15
Air Cleaner Assembly Engine GTS-200	8		
Muffler and Fuel Tank Assembly			
Engine GTS-200	9		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	HYD	hydraulic
ASM	assembly	INC	incorporated
CARR	carriage	LH	left hand
DEG	degrees	NI	nylon insert
FH	flat head	PPH	Phillips pan head
GA	gauge	PTH	Phillips truss head
HF	hex flange	PTO	power take off
HH	hex head	RH	right hand
HHF	hex head flange	SFH	slotted fillister head
HLH	hex lag head	SHH	slotted hex head
HJ	hex jam	SQH	square head
HOC	height-of-cut	SHWH	slotted hex washer head
HS	hex socket	SPH	slotted pan head
HSBH	hex socket button head	SRH	slotted round head
HSFH	hex socket flat head	STD	standard
HSH	hex socket head	TAP	self tapping
HWH	hex washer head	TTH	Torx truss head
HWHTF	hex washer head thread forming	WH	wing head




Sheet No.:1

Engine and Throttle Assembly

Ref. No.	Part No.	Qty.	Description
1	32144-102	3	Screw-HWH
2	55-3570	1	Gas Cap ASM
3	98-1501	1	Control - Throttle
4	98-1514	1	Decal - Recoil
5	98-3206	1	Nameplate-Toro
8	98-1425	1	Engine - Gts Ohv 200
8:1	2210-316	1	Stop-Rope
8:2	2210-249	1	Clamp-Casing
8:3	93-8470	1	Screw-Clamp

Ref. No.	Part No.	Qty.	Description



★ **REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.**

Assemblies include all parts shown in frames.

Sheet No.:


Cylinder Assembly Engine GTS-200

Ref. No.	Part No.	Qty.	Description
1	99-0900	1	Cylinder Assembly
2	99-0911	1	Bushing
★3	99-0912	1	Seal - Oil
8	77-9260	1	Breather Assy.
†★9	99-0913	1	Gasket - Breather
10	99-0914	1	Screw - Hex.
11	99-0915	1	Tube - Breather
★116	99-0916	1	Seal - O Ring
227	99-0917	1	Lever Assembly - Gov.
230	99-0918	1	Washer - Gov. Crank
306	99-0919	1	Shield - Cylinder
307	99-0920	1	Screw - Hex.
523	77-7260	1	Dipstick
525	99-0906	1	Tube - Oil Filler
562	99-0921	1	Screw - Hex.
584	99-0922	1	Baffle - Cylinder
★585	99-0923	1	Gasket - Breather
592	99-0924	1	Nut - Hex.
615	99-0925	1	Fastener
616	99-0926	1	Crank - Governor
663	99-0927	1	Screw - Hex

Ref. No.	Part No.	Qty.	Description
718	99-0928	1	Dowel - Sleeve
	99-2529	1	Short Block

★Included in Gasket Set-Part No. 100-5035

†Included in Valve Overhaul Gasket Set Part No. 100-5033



Assemblies include all parts shown in frames.


Sheet No.:

Cylinder Head Assembly Engine GTS-200

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
5	99-0929	1	Head - Cylinder	†*883	99-0947	1	Gasket - Exhaust
†*7	99-0930	1	Gasket - Cylinder Head	†*993	99-0948	1	Gasket - Plate
13	99-0931	1	Screw - Hex	†*1022	99-0907	1	Gasket - Rocker Cover
33	99-0932	1	Valve - Exhaust	1023	98-9211	1	Cover - Rocker
34	99-0933	1	Valve - Intake	1026	99-0949	1	Rod - Push
35	99-0934	1	Spring - Valve	1029	99-0950	1	Arm - Rocker
40	99-0935	1	Retainer - Valve Spring	1034	99-0951	1	Guide - Push Rod
45	99-0936	1	Tappet - Valve				
155	99-0938	1	Plate - Cylinder Head				
189	99-0939	1	Ball - Rocker Arm				
238	99-0940	1	Cap - Valve				
305	99-0942	1	Screw - Hex				
337	77-7330	1	Plug - Spark				
354		1	Nut - Hex (Sold in Kit Only)				
383	99-0944	1	Wrench - Spark Plug				
635	77-9190	1	Elbow - Spark Plug				
830	99-0945	1	Stud - Rocker Arm				
836	99-0941		Screw - Hex				
†*868	99-0946		Seal - Valve				

*Included in Gasket Set-Part No. 100-5035

†Included in Valve Overhaul Gasket Set Part No. 100-5033



Assemblies include all parts shown in frames.








Sheet No.:

Muffler and Fuel Tank Assembly Engine GTS-200

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
182	98-9205	1	Bracket - Tank Mounting				
187	99-0922	1	Line - Fuel (Cut to Required Length)				
188	99-0993	1	Screw - Shoulder				
188A	98-9202	1	Screw - Hex				
284	99-0994	1	Screw - Hex				
300	99-0995	1	Muffler - Exhaust				
305A	98-9204	1	Screw - Torx®				
305B	99-0998	1	Screw - Hex				
346	99-1047	1	Screw - Hex				
346A	99-0999	1	Screw - Hex				
601	99-0996	1	Clamp - Hose				
670	99-0997	1	Spacer - Fuel Tank				
832	98-9206	1	Guard - Muffler				
836	99-0941	1	Screw - Hex				
†★883	99-0947	1	Gasket - Exhaust				
930	98-9203	1	Guard - Rewind				
972	99-1000	1	Tank - Fuel				

★Included in Gasket Set-Part No. 100-5035

†Included in Valve Overhaul Gasket Set Part No. 100-5033



1036 LABEL KIT-EMISSION


Assemblies include all parts shown in frames.

Sheet No.:

Flywheel Assembly Engine GTS-200

Ref. No.	Part No.	Qty.	Description
23	99-1001	1	Flywheel
37	99-0905	1	Guard - Flywheel
65	99-1002	1	Screw - Hex.
304	99-1003	1	Housing - Blower
332	99-1004	1	Nut - Flywheel
333	99-1005	1	Armature - Magneto
334	99-1006	1	Screw - Hex
356	99-1007	1	Wire - Stop
363	99-1008	1	Puller - Flywheel
373	99-1009	1	Nut - Hex
455	99-1010	1	Cup - Flywheel
836	99-0941	1	Screw - Hex
851	77-9450	1	Terminal - Cable
1005	99-1015	1	Fan - Flywheel
1036	99-1016	1	Label Kit - Emission

Ref. No.	Part No.	Qty.	Description







Assemblies include all parts shown in frames.

Sheet No.:

Starter Assembly Engine GTS-200

Ref. No.	Part No.	Qty.	Description
55	99-1048	1	Housing – Rewind Starter
56	94-1657	1	Pulley – Starter
58	94-1668	1	Rope – Starter
59	77-7210	1	Insert – Starter Grip
60	77-8520	1	Grip – Starter Rope
65	99-1002	1	Screw – Hex.
373	99-1009	1	Nut – Hex.
456	94-1659	1	Retainer – Spring
459	94-1654	1	Pawl – Ratchet
461	94-1660	1	Screw – Shoulder
515	94-1655	1	Spring – Friction
608	98-9215	1	Starter – Rewind

Ref. No.	Part No.	Qty.	Description



Assemblies include all parts shown in frames.

Sheet No.:

Carburetor Overhaul Kit Assembly Engine GTS-200

Ref. No.	Part No.	Qty.	Description
★3	99-0912	1	Seal - Oil
†★7	99-0930	1	Gasket - Cylinder Head
†★9	99-0913	1	Gasket - Breather
★12	99-0953	1	Gasket - Crankcase
★20	77-7570	1	Seal - Oil
●104	99-0970	1	Pin - Float Hinge
◆110		1	Washer - Bowl (Sold in Kit Only)
★116	99-0916	1	Seal - O Ring
121	99-0901	1	Carburetor Kit
●127		1	Plug - Welch (Sold in Kit Only)
●134	77-8110	1	Valve - Needle
◆137		1	Gasket - Bowl (Sold in Kit Only)
◆★163	99-0971	1	Gasket - Air Cleaner
358	99-0902	1	Gasket Set
★585	99-0923	1	Gasket - Breather
◆634		1	Washer - Foam (Sold in Kit Only)
†★868	99-0946	1	Seal - Valve

Ref. No.	Part No.	Qty.	Description
†★883	99-0947	1	Gasket - Exhaust
977	99-0903	1	Gasket Set - Carburetor
†★993	99-0948	1	Gasket - Plate
†★1022	99-0907	1	Gasket - Rocker Cover
1033	99-0904	1	Gasket Set - Valve Overhaul

●Included in Carburetor Kit-Part No. 100-5036

★Included in Gasket Set-Part No. 100-5035

◆Included in Carburetor Gasket Set-Part No. 100-5034 †Included in Valve Overhaul Gasket Set Part No. 100-5033

