



Count on it.

Form No. 3449-336 Rev A

Parts Catalog

Road Light Kit

Groundsmaster® 4500-D or 4700-D Traction Unit

Model No. 30670



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Head Light, Tail Light and Wire Harness Assembly..... 4

Light Mount Kit Assembly No. 140-6698 6


Wire Harness Assembly No. 122-2398..... 8

Switches and Flasher Assembly 10

License Plate Mounting Bracket and Light Assembly 12

Speed Plates Assembly 14


Head Light, Tail Light and Wire Harness Assembly



Head Light, Tail Light and Wire Harness Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	136-3596-03	1	Bracket-Tail Light, RH	16	3218-6	4	Nut-Jam
2	136-3595-03	1	Bracket-Tail Light, LH	17	115-4841	4	Screw-HH
3	139-2071	2	Light-Rear Tail/Stop/Turn	18	323-12	6	Screw-HH
4	136-3592-03	1	Bracket-Headlight, RH	19	145-5251	1	Bracket-Pdm
5	136-3591-03	1	Bracket-Headlight, LH	20	32144-87	1	Screw-HWHTF
6	140-6773	1	LH Light ASM	21	33103-012	1	Screw-HHF
6:2	140-6698	1	Light Mount Kit	22	145-5256	1	Decal-Fuse
7	140-6772	1	RH Light ASM	23	140-6828-03	1	Housing-Light, LH
7:2	140-6698	1	Light Mount Kit	24	140-6829-03	1	Housing-Light, RH
8	125-4645-03	1	Bracket-Horn	25	140-6835	2	Inner Mount ASM
9	116749	1	Horn	25:2	107-1013	2	Nut-Speed
10	323-34	1	Screw-HH	25:3	138-2760	4	Nut-Clinch, Hex
11	104-8301	7	Nut-HF, NI	26	3229-11	4	Screw-CARR
12	321-11	2	Screw-HH	27	3250-23	4	Screw-PPH
13	104-7201	6	Nut-HF, NI	28	3274-69	8	Screw-HSBH
14	122-2398	1	Harness-Wire, Primary	29	3290-378	9	Tie-Cable
			Homologation	30	136-3821-0P	1	Mount-Fuse Block
15	99-7667	4	Washer-Flat	31	121-8861	1	Fuse-Mini Blade, 2 Amp

Light Mount Kit Assembly No. 140-6698




Light Mount Kit Assembly No. 140-6698 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-2092	1	Mount-Light
2	107-7983	1	Screw-HH
3	33116-030	1	Screw-HH

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	48-8070	2	Washer-Lock
5	33026-00	2	Nut-Hex

Wire Harness Assembly No. 122-2398




Wire Harness Assembly No. 122-2398 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
12	116-0053	1	Cap-Plug
13	100-4918	2	Diode
14	32181-015	1	Cover-Fuseblock
15	121-8861	2	Fuse-Mini Blade, 2 Amp

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
16	121-8864	3	Fuse-Mini Blade, 5 Amp
17	121-8866	1	Fuse-Mini Blade, 10 Amp
18	121-8867	1	Fuse-Mini Blade, 15 Amp
19	126-3991	2	Relay-Micro


Switches and Flasher Assembly



Switches and Flasher Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-6606	1	Switch Mount ASM	15	139-1950	1	Switch-Multifunction
1:2	140-1623	1	Decal-Control, LH	16	99-7420	3	Plug-Hole
1:3	140-1531	1	Decal-Control, RH	17	119-7769	1	Switch-Rocker, On/None/On
2	107069	6	Clip	18	139-2291	1	Control-Cover
3	140-1505-03	2	Bracket-Mount	19	32105-15	6	Screw-HWH
4	140-1506-03	1	Mount-Fuse, Plate	20	114-4899	2	Rivet-Push
5	3230-33	4	Screw-CARR	21	139-2247	1	Clip-Switch
6	104-7201	4	Nut-HF, NI	22	139-2248	1	Clip-Switch
7	107-1013	3	Nut-Speed	23	32105-13	2	Screw-HWH
8	609900	2	Nut-Speed	25	93-5023	4	Spacer
9	139-2080	1	Flasher-Dual Rate	26	95-5622	2	Hanger-Rubber
10	3290-379	1	Tie-Cable	27	3256-3	8	Washer-Flat
11	140-1502-03	1	Cover-Fuse	28	322-8	4	Screw-HH
12	125-7438	2	Knob-Screw, Thumb	29	132-3262-03	2	Plate-Bent, Bracket
13	32115-15	2	Nut-Push	30	104-8300	4	Nut-HF, NI
14	104-2065	1	Screw-HWH				

License Plate Mounting Bracket and Light Assembly




License Plate Mounting Bracket and Light Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	136-3616-03	1	Bracket-License Plate
2	9266934	2	Screw
3	139-2074	1	Light-Plate, License (Ece)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	104-2408	2	Screw-HSBH
5	107-1013	2	Nut-Speed
6	122-0146	1	Harness-Wire

Speed Plates Assembly



Speed Plates Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-7771-03	2	Mount-Decal, Bent Plate
2	111-4247	4	Sign-20K

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	3234-34	4	Screw-HHF
4	32128-33	4	Nut-HF



Count on it.