



Form No. 3449-336 Rev A

Count on it.

Parts Catalog

Road Light Kit

Groundsmaster® 4500-D or 4700-D Traction Unit

Model No. 30670



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Head Light, Tail Light and Wire Harness Assembly..... 4

Light Mount Kit Assembly No. 140-6698 6


Wire Harness Assembly No. 122-2398..... 8

Switches and Flasher Assembly 10

License Plate Mounting Bracket and Light Assembly 12

Speed Plates Assembly 14

Head Light, Tail Light and Wire Harness Assembly




Head Light, Tail Light and Wire Harness Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	136-3596-03	1	Bracket-Tail Light, RH
2	136-3595-03	1	Bracket-Tail Light, LH
3	139-2071	2	Light-Rear Tail/Stop/Turn
4	136-3592-03	1	Bracket-Headlight, RH
5	136-3591-03	1	Bracket-Headlight, LH
6	140-6773	1	LH Light ASM
6:2	140-6698	1	Light Mount Kit
7	140-6772	1	RH Light ASM
7:2	140-6698	1	Light Mount Kit
8	125-4645-03	1	Bracket-Horn
9	116749	1	Horn
10	323-34	1	Screw-HH
11	104-8301	7	Nut-HF, NI
12	321-11	2	Screw-HH
13	104-7201	6	Nut-HF, NI
14	122-2398	1	Harness-Wire, Primary Homologation
15	99-7667	4	Washer-Flat

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
16	3218-6	4	Nut-Jam
17	115-4841	4	Screw-HH
18	323-12	6	Screw-HH
19	145-5251	1	Bracket-Pdm
20	32144-87	1	Screw-HWHTF
21	33103-012	1	Screw-HHF
22	145-5256	1	Decal-Fuse
23	140-6828-03	1	Housing-Light, LH
24	140-6829-03	1	Housing-Light, RH
25	140-6835	2	Inner Mount ASM
25:2	107-1013	2	Nut-Speed
25:3	138-2760	4	Nut-Clinch, Hex
26	3229-11	4	Screw-CARR
27	3250-23	4	Screw-PPH
28	3274-69	8	Screw-HSBH
29	3290-378	9	Tie-Cable
30	136-3821-0P	1	Mount-Fuse Block
31	121-8861	1	Fuse-Mini Blade, 2 Amp

Light Mount Kit Assembly No. 140-6698




Light Mount Kit Assembly No. 140-6698 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-2092	1	Mount-Light
2	107-7983	1	Screw-HH
3	33116-030	1	Screw-HH

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	48-8070	2	Washer-Lock
5	33026-00	2	Nut-Hex

Wire Harness Assembly No. 122-2398




Wire Harness Assembly No. 122-2398 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
12	116-0053	1	Cap-Plug
13	100-4918	2	Diode
14	32181-015	1	Cover-Fuseblock
15	121-8861	2	Fuse-Mini Blade, 2 Amp

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
16	121-8864	3	Fuse-Mini Blade, 5 Amp
17	121-8866	1	Fuse-Mini Blade, 10 Amp
18	121-8867	1	Fuse-Mini Blade, 15 Amp
19	126-3991	2	Relay-Micro


Switches and Flasher Assembly



Switches and Flasher Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-6606	1	Switch Mount ASM	15	139-1950	1	Switch-Multifunction
1:2	140-1623	1	Decal-Control, LH	16	99-7420	3	Plug-Hole
1:3	140-1531	1	Decal-Control, RH	17	119-7769	1	Switch-Rocker, On/None/On
2	107069	6	Clip	18	139-2291	1	Control-Cover
3	140-1505-03	2	Bracket-Mount	19	32105-15	6	Screw-HWH
4	140-1506-03	1	Mount-Fuse, Plate	20	114-4899	2	Rivet-Push
5	3230-33	4	Screw-CARR	21	139-2247	1	Clip-Switch
6	104-7201	4	Nut-HF, NI	22	139-2248	1	Clip-Switch
7	107-1013	3	Nut-Speed	23	32105-13	2	Screw-HWH
8	609900	2	Nut-Speed	25	93-5023	4	Spacer
9	139-2080	1	Flasher-Dual Rate	26	95-5622	2	Hanger-Rubber
10	3290-379	1	Tie-Cable	27	3256-3	8	Washer-Flat
11	140-1502-03	1	Cover-Fuse	28	322-8	4	Screw-HH
12	125-7438	2	Knob-Screw, Thumb	29	132-3262-03	2	Plate-Bent, Bracket
13	32115-15	2	Nut-Push	30	104-8300	4	Nut-HF, NI
14	104-2065	1	Screw-HWH				


License Plate Mounting Bracket and Light Assembly



License Plate Mounting Bracket and Light Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	136-3616-03	1	Bracket-License Plate	4	104-2408	2	Screw-HSBH
2	9266934	2	Screw	5	107-1013	2	Nut-Speed
3	139-2074	1	Light-Plate, License (Ece)	6	122-0146	1	Harness-Wire

Speed Plates Assembly



Speed Plates Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	131-7771-03	2	Mount-Decal, Bent Plate
2	111-4247	4	Sign-20K

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	3234-34	4	Screw-HHF
4	32128-33	4	Nut-HF



Count on it.