Form No. 3450-278 Rev A

TORO®

Count on it.

Parts Catalog

Hydraulic Switch Kit

Sand Pro® 5040 Traction Unit

Model No. 08783—Serial No. 410000000 and Up

Register at www.Toro.com.
Original Instructions (EN)

3450-278 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Hydraulic Routing and Couplers Assembly 4
Hydraulic Pump and Manifold Assembly 6
Hydraulic Pump Assembly No. 114-0603 8
Hydraulic Manifold Assembly No. 137-3360 10
Control Panel and Wire Harness Assembly 12
Attachments and Accessories 14

© 2021—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


Hydraulic Routing and Couplers Assembly



Hydraulic Routing and Couplers Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-3366	1	Clamp-Saddle
2	137-3371	1	Coupler ASM
2:2	110-1303	1	Decal-Coupler
3	3256-23	2	Washer-Plain
4	322-10	2	Screw-HH
5	340-101	3	Fitting-HYD, 45 DEG
5:1	237-30	1	O-Ring
5:2	237-79	1	O-Ring
6	100-7671	3	Adapter-HYD
6:1	237-79	1	O-Ring
7	105-4170	4	Coupler-Male
8	105-4169	2	Coupler-Female
9	105-7962	2	Plug-Dust
10	105-7963	4	Cap-Dust
11	112-7159	1	Coupler ASM
11:2	112-7160	1	Decal-Quick Coupler
12	108-8464	2	Fitting-Straight
12:2	237-79	1	O-Ring
12:3	237-30	1	O-Ring
13	340-98	1	Fitting-Elbow, 90 DEG
13:1	237-79	1	O-Ring
13:2	237-30	1	O-Ring
14	322-12	2	Screw-HH
15	3296-29	2	Nut-Lock, NI
16	32120-2	1	Ring-Retaining
17	32151-29	2	Ring-Retaining
18	340-104	1	Fitting-Tee
18:1	237-30	2	O-Ring
19	110-1324	1	Tube ASM
20	340-4	2	Fitting-Straight
20:1	237-30	1	O-Ring
20:2	237-79	1	O-Ring
21	120-3409	1	Fitting-Tee
21:1	237-79	1	O-Ring
21:2	237-30	1	O-Ring
22	119-2074	1	Hose-HYD
23	137-3375	1	Hose-HYD
24	2412-36	1	Clamp-Hose
25	137-3374	1	Hose-HYD
27	3290-378	3	Tie-Cable


Hydraulic Pump and Manifold Assembly



Hydraulic Pump and Manifold Assembly (continued)

Ref.	Part Number	Qty.	Description
1	108-2825	1	Hub
2	5-7280	1	Key
3	3246-4	4	Screw-Set
4	137-3377	1	Bracket W/Bushing ASM
4:2	23-2270	1	Bushing-Rubber
7	114-0603	1	HYD Pump ASM
8	137-3365-01	1	Arm-Torque
9	353-987	1	Fitting-Elbow, 90
9:1	237-81	1	O-Ring
10	340-98	2	Fitting-Elbow, 90 DEG
10:1	237-79	1	O-Ring
10:2	237-30	1	O-Ring
11	137-3364-01	1	Bracket-Block, Valve
12	2412-81	1	Clamp-R
13	3256-23	3	Washer-Plain
14	322-12	1	Screw-HH
15	104-8300	1	Nut-HF, NI
16	137-3360	1	Manifold ASM (On-Off-On)
17	3234-5	2	Screw-HHF
18	119-2074	1	Hose-HYD
19	137-3356	1	Hydraulic Tube ASM
20	137-3363	1	Hose-Suction
21	2412-129	2	Clamp-Hose
22	323-7	2	Screw-HH
23	104-8301	2	Nut-HF, NI
24	3235-6	2	Screw-HH
25	87-3990	1	Strainer-Transaxle
25:1	237-101	1	O-Ring
27	340-142	1	Fitting-Elbow, 90 DEG
27:1	237-58	1	O-Ring
27:2	237-81	1	O-Ring

Hydraulic Pump Assembly No. 114-0603




Hydraulic Pump Assembly No. 114-0603 (continued)

Ref.	Part Number	Qty.	Description
1	114-0606	1	Seal Kit
1:1		1	Seal-Lip ●
1:2		2	Seal-Backup ●
1:3		2	Seal-Channel ●
1:4		2	Seal-Gasket ●

● Not serviced separately


Hydraulic Manifold Assembly No. 137-3360



Hydraulic Manifold Assembly No. 137-3360 (continued)

Ref.	Part Number	Qty.	Description
2	112-9212	5	Plug
3	107-7517	1	Valve-Solenoid
3:1	105-9156	1	Seal Kit
3:2	107-7812	1	Nut-Solenoid
4	107-7516	2	Solenoid Valve ASM
4:1	105-9156	1	Seal Kit
4:2	110-2634	1	Nut-Coil
5	120-2553	1	Valve-Relief
5:1	105-9156	1	Seal Kit
6	119-8036	3	Coil

Control Panel and Wire Harness Assembly



Control Panel and Wire Harness Assembly (continued)

Ref.	Part Number	Qty.	Description
2	99-7430	1	Relay-Mini
5	3296-42	1	Nut-Lock, NI
6	137-3361	1	Lift Panel ASM
6:2	137-3362	1	Decal-Lift
7	93-9999	1	Switch-PTO
8	100-8590	1	Switch-Rocker, Dpdt (On-Off-On)
9	122-1465	1	Harness-Wire
10	218-578	1	Fuse-Blade, 10 Amp

Attachments and Accessories

For 08783 Hydraulic Switch Kit Sand Pro 5040 Traction Unit

Product Name	Model/Part
QAS Bunker Pump	08765
Vibratory Edger	08766

Notes:



Count on it.