



BY APPOINTMENT TO
HER MAJESTY THE QUEEN
MANUFACTURERS OF HAYTER
HORTICULTURAL MACHINERY
TORD UNLIMITED, SPELLBROOK,
BISHOPS STORTFORD, HERTS

HAYTER

MAKERS OF THE FINEST MOWERS

Parts Catalogue

46cm Lawn Mower

Code CODE610B

Serial No.320000001

Manual Part No. 134-7531 Rev A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

- Suspension, Traction and HOC Assembly 4
- Handle Bar and Controls Assembly 6
- Engine and Blade Assembly 8
- Deck and Grass Bag Assembly 10


Suspension, Traction and HOC Assembly



Suspension, Traction and HOC Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-0156	2	Screw-Tooth	14	134-0185	1	Bracket-Connecting, HOC
2	134-0117	6	Nut-Lock, Flange	15	134-0186	1	Board-Adjuster, HOC
3	134-0175	2	Cap-Hub (7)	16	134-0187	2	Cap-Hub (8)
4	134-0118	4	Nut-Lock, Flange	17	134-0188	2	Wheel ASM (8)
5	134-0176	8	Bearing	18	134-0196	2	Cover-Wheel, Dustproof
6	134-0177	2	Wheel ASM (7)	19	134-0131	6	Screw-Self Driving
7	134-0178	2	Cover-Wheel, Dustproof	20	134-0189	2	Screw-Pan, Cross
8	134-0179	4	Washer-Wave	21	134-0193	1	Rear Axle Shaft ASM
9	134-0180	2	Clamp-Axle, Fixed	22	134-0194	1	Handle ASM
10	134-0181	4	Screw-Tooth	23	134-0190	4	Nut-Lock
11	134-0182	1	Front Wheel Axis ASM	24	134-0195	4	Sleeve-Shaft, Axle
12	134-0183	2	Ring-Fixed	25	134-0191	2	Ring-Fixed
13	134-0184	1	Spring-Tension	26	134-0192	1	Handle-Lever, HOC


Handle Bar and Controls Assembly



Handle Bar and Controls Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-0219	4	Bolt	12	134-0230	1	Bolt-HH, Flange
2	09475	4	Washer	13	134-0231	1	Hook-Cable
3	03469	4	Washer-Spring	14	09472	2	Washer-Plain
4	134-0222	4	Nut-Lid	15	09474	1	Washer-Spring
5	134-0223	2	Handlebar-Lower	16	134-0234	2	Nut-Lid
6	134-0224	2	Nut-Hex	17	134-0235	2	Plug-Tube
7	134-0225	2	Knob-Rotary	18	134-0236	1	Cable-Brake, Engine
8	134-0226	2	Bolt-Flat Head	19	134-0237	1	Cable-Block, Fixed
9	134-0227	2	Washer-Curve	20	134-0238	2	Grip-Handle
10	134-0228	1	Cable Clamp	21	134-0239	1	Lever-Engine
11	134-0229	1	Handlebar-Upper	24	H295159	1	Decal-Stop


Engine and Blade Assembly



Engine and Blade Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-0150	1	Bolt-Blade	9	134-0157	1	Cover-Pulley, Belt
2	134-0151	1	Washer-Dished	10	134-0117	1	Nut-Lock, Flange
3	134-0073	1	Blade-Mulch	11	134-0118	3	Nut-Lock, Flange
4	134-0152	1	Support-Blade	12	134-3581	1	Briggs & Stratton 450E Stage 5
5	134-0153	1	Sheath-Blade	13	134-0158	3	Washer-Square
6	134-0154	1	Key-Flat	14	09369	3	Screw-HH
7	134-0155	2	Screw-Self Driving	34	111-9994	1	Decal-Engine
8	134-0156	1	Screw-Tooth				

Deck and Grass Bag Assembly



Deck and Grass Bag Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	134-0117	2	Nut-Lock, Flange	15	134-0131	2	Screw-Self Driving
2	134-0118	4	Nut-Lock, Flange	16	134-0132	1	Deflector-Rear
3	134-0119	2	Screw-Tooth	17	134-0133	1	Pressing Board-Lock Button, Mulch
4	134-0120	1	Bumper-Front	18	134-0134	1	Spring-Button, Mulch
5	134-0121	2	Nut-Lock	19	134-0135	1	Lock-Button, Mulch
6	134-2000	1	Deck	20	134-0136	1	Plug-Mulch
7	134-0123	1	Spring-Twist, RH	21	134-0137	1	Bag-Grass
8	134-0124	1	Rod-Spring, Rear Deflector	22	134-0138	1	Frame-Bag, Grass
9	134-0125	1	Spring-Twist, LH	23	134-0139	1	Cap-End
10	134-0126	1	O-Ring	39	134-0084	1	Decal-Safety
11	134-0127	1	Port-Wash	40	134-0051	1	Logo-Hayter
12	134-0128	4	Bolt-HH, Flange	43	111-9937	1	Decal-Easy Wash
13	134-0129	1	Bracket-Handle, RH				
14	134-0130	1	Bracket-Handle, LH				

