BY APPOINTMENT TO
HER MAJESTY THE QUEEN
MANUFACTURERS OF HAYTER
HORTICULTURAL MACHINERY
TORO U.K. LIMITED, SPELLBROOK,
BISHOPS STORTFORD, HERTS

HAYTER

MAKERS OF THE FINEST MOWERS

Parts Catalogue

46cm Lawn Mower

Code CODE610B

Serial No.320000001

Manual Part No. 134-7531 Rev A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Suspension, Traction and HOC Assembly 4
Handle Bar and Controls Assembly. 6
Engine and Blade Assembly. 8
Deck and Grass Bag Assembly 10

© 2021—

Contact us at .
Printed in the USA.
All Rights Reserved


Suspension, Traction and HOC Assembly



Suspension, Traction and HOC Assembly (continued)

Ref.	Part Number	Qty.	Description
1	134-0156	2	Screw-Tooth
2	134-0117	6	Nut-Lock, Flange
3	134-0175	2	Cap-Hub (7)
4	134-0118	4	Nut-Lock, Flange
5	134-0176	8	Bearing
6	134-0177	2	Wheel ASM (7)
7	134-0178	2	Cover-Wheel, Dustproof
8	134-0179	4	Washer-Wave
9	134-0180	2	Clamp-Axle, Fixed
10	134-0181	4	Screw-Tooth
11	134-0182	1	Front Wheel Axis ASM
12	134-0183	2	Ring-Fixed
13	134-0184	1	Spring-Tension
14	134-0185	1	Bracket-Connecting, HOC
15	134-0186	1	Board-Adjuster, HOC
16	134-0187	2	Cap-Hub (8)
17	134-0188	2	Wheel ASM (8)
18	134-0196	2	Cover-Wheel, Dustproof
19	134-0131	6	Screw-Self Driving
20	134-0189	2	Screw-Pan, Cross
21	134-0193	1	Rear Axle Shaft ASM
22	134-0194	1	Handle ASM
23	134-0190	4	Nut-Lock
24	134-0195	4	Sleeve-Shaft, Axle
25	134-0191	2	Ring-Fixed
26	134-0192	1	Handle-Lever, HOC


Handle Bar and Controls Assembly



Handle Bar and Controls Assembly (continued)

Ref.	Part Number	Qty.	Description
1	134-0219	4	Bolt
2	09475	4	Washer
3	03469	4	Washer-Spring
4	134-0222	4	Nut-Lid
5	134-0223	2	Handlebar-Lower
6	134-0224	2	Nut-Hex
7	134-0225	2	Knob-Rotary
8	134-0226	2	Bolt-Flat Head
9	134-0227	2	Washer-Curve
10	134-0228	1	Cable Clamp
11	134-0229	1	Handlebar-Upper
12	134-0230	1	Bolt-HH, Flange
13	134-0231	1	Hook-Cable
14	09472	2	Washer-Plain
15	09474	1	Washer-Spring
16	134-0234	2	Nut-Lid
17	134-0235	2	Plug-Tube
18	134-0236	1	Cable-Brake, Engine
19	134-0237	1	Cable-Block, Fixed
20	134-0238	2	Grip-Handle
21	134-0239	1	Lever-Engine
24	H295159	1	Decal-Stop


Engine and Blade Assembly



Engine and Blade Assembly (continued)

Ref.	Part Number	Qty.	Description
1	134-0150	1	Bolt-Blade
2	134-0151	1	Washer-Dished
3	134-0073	1	Blade-Mulch
4	134-0152	1	Support-Blade
5	134-0153	1	Sheath-Blade
6	134-0154	1	Key-Flat
7	134-0155	2	Screw-Self Driving
8	134-0156	1	Screw-Tooth
9	134-0157	1	Cover-Pulley, Belt
10	134-0117	1	Nut-Lock, Flange
11	134-0118	3	Nut-Lock, Flange
12	134-3581	1	Briggs & Stratton 450E Stage 5
13	134-0158	3	Washer-Square
14	09369	3	Screw-HH
34	111-9994	1	Decal-Engine

Deck and Grass Bag Assembly



Deck and Grass Bag Assembly (continued)

Ref.	Part Number	Qty.	Description
1	134-0117	2	Nut-Lock, Flange
2	134-0118	4	Nut-Lock, Flange
3	134-0119	2	Screw-Tooth
4	134-0120	1	Bumper-Front
5	134-0121	2	Nut-Lock
6	134-2000	1	Deck
7	134-0123	1	Spring-Twist, RH
8	134-0124	1	Rod-Spring, Rear Deflector
9	134-0125	1	Spring-Twist, LH
10	134-0126	1	O-Ring
11	134-0127	1	Port-Wash
12	134-0128	4	Bolt-HH, Flange
13	134-0129	1	Bracket-Handle, RH
14	134-0130	1	Bracket-Handle, LH
15	134-0131	2	Screw-Self Driving
16	134-0132	1	Deflector-Rear
17	134-0133	1	Pressing Board-Lock Button, Mulch
18	134-0134	1	Spring-Button, Mulch
19	134-0135	1	Lock-Button, Mulch
20	134-0136	1	Plug-Mulch
21	134-0137	1	Bag-Grass
22	134-0138	1	Frame-Bag, Grass
23	134-0139	1	Cap-End
39	134-0084	1	Decal-Safety
40	134-0051	1	Logo-Hayter
43	111-9937	1	Decal-Easy Wash

Toro U.K LIMITED, SPELLBROOK, BISHOP'S STORTFORD HERTS. CM23 4BU, ENGLAND