



Form No. 3450-384 Rev A

Count on it.

Parts Catalog

122cm (48in) Mid-Size Rear-Discharge Deck

Model No. 02712—Serial No. 410000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

48 Inch Deck and Cover Assembly 4


48 Inch Deck Spindle and Pulley Assembly 6

Idler Arm Assembly 8

Caster Assembly 10

Guard and Drag Shield Assembly 12


48 Inch Deck and Cover Assembly



48 Inch Deck and Cover Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	111-1360-01	1	48 Inch Deck ASM	16	1-303536	2	Stud-Shield, Belt (Long)
2	111-3922-01	1	Cover-Deck	17	1-303537	4	Stud-Shield, Belt (Short)
3	111-4929-01	1	Guard-Pipe, Exhaust	18	111-2479	1	Belt-V
4	111-1544-01	2	Bracket-Deflector, Side	19	ZNN3E000U	11	Nut-Nyloc
5	111-1545-01	1	Bracket-Deflector, Center	20	ZDH3E016U	11	Screw-HH
6	111-1409-01	1	Guard-Discharge, RH	21	09475	22	Washer
7	111-1410-01	1	Guard-Discharge, LH	22	09320	4	Rivet
8	111-1547	1	Deflector-Centre, Rubber	23	922854	1	Decal-Noise
9	111-1546	2	Deflector-Side	24	117-8339	1	Lanyard-3 Inch
10	139-5557	2	Decal-Danger, CE	25	111-2470-03	1	Guide-Belt
11	111-1764	1	Decal-Midsized	26	03162	1	Screw-HH
12	32128-20	6	Nut-HF	27	09257	1	Washer
13	09267	1	Washer-Plain	28	111-3882	6	Cap-End, Rubber
14	111-3697	1	Nut-Retainer	29	111-3887	1	Bracket-Guard
15	1-323417	6	Washer	29:2	111-7683	1	Nut-Rivet


48 Inch Deck Spindle and Pulley Assembly



48 Inch Deck Spindle and Pulley Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	108-6697	3	Spindle Housing ASM	11	1-800861	3	Screw-Cap, HH
1:1	119-7857	2	Bearing-Ball, 1 Inch	12	103-1330	3	Guard-Bearing, Top
1:2	110-2116	1	Spacer-Bearing	13	1-403183	3	Sheave
1:3	108-6694	1	Housing-Spindle	14	1-323339	3	Washer-Retainer, Sheave
1:4	32120-8	1	Ring-Snap	15	3219-6	3	Nut-Hex
2	95-1726	18	Screw-Taptite	16	1-803310	3	Screw-Set
3	3290-357	18	Nut-HSF	17	1-413113	2	Bushing-Idler
4	110-4888	3	Washer-Spacer	18	136-5405	1	Pulley-Idler, Flat
5	103-2535	3	Spacer-Guard, Bottom	19	1-613098	1	Pulley-Idler
6	1-807267	3	Key	20	5-0652	2	Spacer
7	1-323529	3	Tube-Spindle, Short	21	98-5975	3	Washer-Belleville
8	1-323539	12	Spacer	22	1-403188	1	Spacer
9	107-3195-03	3	Blade-Rotary, 16.5 Inch (Atomic)	23	09353	2	Screw-HH
10	1-513208	3	Washer-Spring	24	323-15	1	Screw-HH
				25	3296-39	3	Nut-Lock, NI

Idler Arm Assembly




Idler Arm Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	1-324372	1	Pad And Spring ASM	17	132-4718	1	Pulley-Idler, Flat
1:1	1-323709	1	Pad-Brake ●	18	1-303434	1	Bushing-Engagement
1:2	1-323710	1	Spring ●	19	103-3600	1	Idler Arm ASM
1:3	103-0138	2	Rivet-Pop ●	19:2	1-323729	2	Sleeve-Bearing
2	09821	2	Screw-HH	20	32151-103	1	Ring-Retaining, EXT
3	3296-42	2	Nut-Lock, NI	21	ZDH3E016U	1	Screw-HH
4	322-10	1	Screw-HH	22	1-303352	1	Washer-Spindle
5	1-403179	1	Tube-Pivot	23	1-806003	2	Pin-Cotter
6	32120-35	1	Ring-Retaining, EXT	24	111-1355	1	Rod-Brake
7	ZWP1H000U	1	Washer-Plain	25	1-323748	1	Ring-Push On
8	1-322235	1	Arm-Assist, 32/36	26	1-323747	1	Spring-Compression
9	09267	1	Washer-Plain	27	1-323746	1	Spacer-Flanged
10	ZNN3E000U	1	Nut-Nyloc	28	3296-42	1	Nut-Lock, NI
11	1-303238	1	Eyebolt-Thread, RH	29	1-323071	1	Spring-Extension
12	32128-20	3	Nut-HF	30	1-303334	1	Washer-Spring
13	1-303236	1	Body-Turnbuckle	31	10-11-017	1	Fitting-Straight
14	1-303348	1	Eyebolt-Thread, LH	32	111-1629	1	Rod-Linkage, Drive
15	702809	1	Screw-HH	33	09207	1	Nut
16	98-5975	1	Washer-Belleville				

● Not illustrated

Caster Assembly




Caster Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	110-5023	2	Wheel And Tire ASM	7	1-303314	8	Spacer-Caster
1:1		1	Tire ●	8	110-2130	2	Support ASM
1:2	1-513809	1	Bearing	8:2	1-303514	2	Bearing-Flanged
1:3	1-513810	2	Bushing	8:3	302-52	1	Fitting-Grease
1:4	302-61	1	Fitting-Grease	9	1-513338	2	Washer-Flat
1:5		1	Wheel ●	10	1-809020	2	Pin
2	1-513547	2	Spacer	11	3290-357	8	Nut-HSF
3	325-20	2	Screw-HH	12	ZWQ1J000U	8	Washer-Plain
4	116-7942-01	2	Fork-Caster	13	323-7	8	Screw-HH
5	3217-9	2	Nut-HH	14	111-1900-01	2	Spacer-Caster
6	3253-7	2	Washer-Lock				

● Not serviced separately

Guard and Drag Shield Assembly



Guard and Drag Shield Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	111-1408-01	1	Guard-Discharge, Center	11:2	111-7683	2	Nut-Rivet
2	15-11-003	2	Bolt-CARR	12	HY103653	8	Screw-HH
3	09475	4	Washer	13	ZWQ1J000U	2	Washer-Plain
4	09441	2	Nut-Hex, NI	14	09449	2	Nut
5	3290-357	8	Nut-HSF	15	98-5975	8	Washer-Belleville
6	111-1655-01	1	Guard-Underside	16	103-2056	1	Shield-Drag
7	09267	2	Washer-Plain	17	09480	2	Washer-Lock
8	09320	2	Rivet	18	111-3697	2	Nut-Retainer
9	03162	4	Screw-HH	19	117-8339	2	Lanyard-3 Inch
11	111-1986	1	Guard-Drive	20	09257	2	Washer

Notes:

Notes:



Count on it.