



**Count on it.**

Form No. 3419-747 Rev C

# Parts Catalog

## Workman® HDX-Auto Utility Vehicle

Model No. 07390TC—Serial No. 403430001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.


## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents


|                                                |    |
|------------------------------------------------|----|
| Front Frame Assembly .....                     | 4  |
| Rear Frame and Suspension Assembly .....       | 5  |
| Rear Axle and Tire Assembly .....              | 6  |
| Brake Caliper Assembly No. 127-7424 .....      | 7  |
| Front and Rear Brake Line Assembly .....       | 8  |
| Front Suspension Assembly .....                | 9  |
| Steering and Front Wheel Assembly .....        | 10 |
| Steering Linkage Assembly .....                | 11 |
| Hydraulic Cylinder Assembly No. 112-3217 ..... | 12 |
| Front Control Arm Assembly .....               | 13 |
| Master Cylinder and Brake Pedal Assembly ..... | 14 |
| Master Cylinder Assembly No. 104-6782 .....    | 15 |
| Accelerator Pedal Assembly .....               | 16 |
| Center Console Assembly .....                  | 17 |
| Bumper, Hood and Seat Base Assembly .....      | 19 |
| Dash Assembly .....                            | 20 |
| Steering Hydraulic Assembly .....              | 21 |
| Steering Valve Assembly No. 120-4813 .....     | 22 |
| Seat Assembly .....                            | 23 |
| Roll-Over Protection System Assembly .....     | 24 |
| Full Bed and Side Panel Assembly .....         | 25 |
| Engine and Transmission Support Assembly ..... | 26 |
| Engine and Exhaust Assembly .....              | 27 |
| Cooling System Assembly .....                  | 29 |
| Radiator and Fan Assembly .....                | 30 |
| Clutch Assembly .....                          | 31 |
| Primary Clutch Assembly No. 132-6780 .....     | 33 |
| Secondary Clutch Assembly No. 132-6785 .....   | 34 |
| Speed Limiter Cover Assembly .....             | 35 |
| Transmission Assembly .....                    | 36 |
| Transmission Assembly No. 121-9603 .....       | 37 |
| Rear Drive Assembly .....                      | 39 |
| Differential Assembly No. 121-9604 .....       | 40 |
| Driveshaft Assembly No. 121-9832 .....         | 41 |
| Battery Installation Assembly .....            | 42 |
| Rear Tail Light and Fender Assembly .....      | 43 |
| Fuel System Assembly .....                     | 44 |
| Hydraulic Lift Valve Assembly .....            | 45 |
| Control Valve Assembly No. 43-1950 .....       | 47 |
| Hydraulic Cylinder Assembly No. 133-0620 ..... | 48 |
| Hydraulic Tank and Filter Assembly .....       | 49 |
| Air Cleaner Assembly .....                     | 50 |
| Air Cleaner Assembly No. 138-3448 .....        | 51 |
| High Flow Hydraulic Assembly .....             | 52 |
| Hydraulic Manifold Assembly No. 115-2252 ..... | 54 |
| Hydraulic Pump Assembly No. 115-7787 .....     | 55 |
| Electrical Assembly .....                      | 56 |
| Attachments and Accessories .....              | 57 |



## Front Frame Assembly

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 121-9745-03 | 1    | Frame-Front    |
| 2    | 87-2440     | 2    | Bumper-Rubber  |
| 3    | 26-0071     | 2    | Snubber-Rubber |
| 7    | 110-2594    | 1    | Horn           |
| 8    | 3234-1      | 1    | Screw-HHF      |
| 12   | 106-2427-03 | 1    | Cover          |
| 13   | 114-8272-03 | 1    | Bracket-Bumper |
| 14   | 3234-5      | 4    | Screw-HHF      |
| 15   | 32144-70    | 4    | Screw-HWHTF    |


| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 17   | 94-2413     | 7    | Nut-U            |
| 18   | 3231-21     | 4    | Screw-CARR       |
| 19   | 3290-357    | 7    | Nut-HSF          |
| 21   | 114-8418    | 7    | Screw-HWH, Sems  |
| 23   | 107-8042    | 2    | Bumper-Rubber    |
| 25   | 3290-379    | 7    | Tie-Cable        |
| 26   | 127-8626    | 1    | Decal-Electrical |
| 31   | 32180-030   | 2    | Clip-Tie         |
| 32   | 133-8061    | 1    | Decal-Warning    |



## Rear Frame and Suspension Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 115-7911    | 1    | Rear Frame ASM     |
| 1:2  | 115-2047    | 2    | Decal-Surface, Hot |
| 2    | 131-3474    | 1    | Mount-Spring, LH   |
| 3    | 131-3472    | 1    | Mount-Spring, RH   |
| 4    | 104-8301    | 6    | Nut-HF, NI         |
| 5    | 87-4760     | 12   | Bushing-Rubber     |
| 6    | 87-1490     | 2    | Spring-Leaf, Rear  |
| 7    | 131-3476    | 4    | Shackle            |
| 8    | 3234-38     | 18   | Screw-HHF          |


| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 9    | 99-5107     | 18   | Nut-Lock          |
| 10   | 32148-9     | 4    | Nut-Clinch        |
| 11   | 108-3109    | 2    | Retainer-Cylinder |
| 12   | 3229-1      | 2    | Screw-CARR        |
| 13   | 104-7201    | 3    | Nut-HF, NI        |
| 14   | 87-3470     | 2    | Bumper            |
| 15   | 103-9511    | 2    | Nut-Lock, NI      |
| 17   | 3255-8      | 1    | Washer-Lock       |
| 18   | 32105-15    | 1    | Screw-HWH         |



## Rear Axle and Tire Assembly


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 119-9515    | 1    | Axle-Rear              |
| 2    | 121-9751    | 2    | Hub-Bearing, Wheel     |
| 2:2  | 121-9752    | 5    | Stud-Wheel             |
| 3    | 3234-11     | 16   | Screw-HHF              |
| 4    | 127-7424    | 2    | Brake Caliper ASM      |
| 5    | 119-9509    | 2    | Screw-Bleed            |
| 6    | 115-7742    | 1    | Hitch ASM              |
| 6:1  | 92-5951-03  | 1    | Angle-Hitch            |
| 6:2  | 136-1163    | 1    | Decal-Load, Towing     |
| 7    | 114-8351    | 2    | Rotor-Brake            |
| 8    | 131-8428    | 2    | Tire/Wheel ASM         |
| 8:1  | 131-6673    | 1    | Tire-Rear              |
| 8:2  | 131-8429    | 1    | Wheel                  |
| 8:3  | 232-27      | 1    | Stem-Valve             |
| 9    | 87-7470-03  | 2    | Plate-Spring, Clamp    |
| 10   | 87-7480     | 8    | Washer                 |
| 11   | 87-3600     | 2    | Spacer-Absorber, Shock |

| Ref.  | Part Number | Qty. | Description    |
|-------|-------------|------|----------------|
| 12    | 87-5330     | 2    | Washer         |
| 13    | 87-3920     | 8    | Bushing        |
| 14    | 121-9774    | 2    | Absorber-Shock |
| 15    | 242-50      | 10   | Nut-Lug        |
| 16    | 3256-27     | 2    | Washer-Flat    |
| 17    | 3256-6      | 2    | Washer-Flat    |
| 18    | 99-5107     | 2    | Nut-Lock       |
| 19    | 115-2398    | 8    | Bolt-HH        |
| 20    | 114-8417    | 2    | Nut-HF, NI     |
| 21    | 114-8424    | 2    | Screw-HH       |
| 22    | 115-2164    | 2    | Nut-Spindle    |
| 23    | 121-9744    | 2    | Axle ASM       |
| 23:3  | 107-2894    | 1    | Clamp-Boot     |
| 23:4  | 107-2896    | 2    | Boot           |
| 23:5  | 107-2895    | 2    | Clamp-Boot     |
| 23:10 | 107-2893    | 1    | Clamp-Boot     |
| 24    | 340-64      | 2    | O-Ring         |



## Brake Caliper Assembly No. 127-7424


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 119-9510           | 1           | *obs* Pads-Brake   |
| 2           | 119-9511           | 1           | Bracket Kit        |
| 3           | 133-0614           | 1           | Piston Kit         |



## Front and Rear Brake Line Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 119-9682    | 1    | Front Brake Line ASM |
| 2    | 119-9681    | 1    | Rear Brake Line ASM  |
| 3    | 32144-70    | 1    | Screw-HWHTF          |
| 4    | 321-6       | 3    | Screw-HH             |
| 5    | 104-7201    | 3    | Nut-HF, NI           |
| 6    | 3234-21     | 3    | Screw-HHF            |
| 7    | 32128-33    | 3    | Nut-HF               |
| 8    | 115-2341    | 8    | Washer-Banjo         |
| 9    | 120-4875    | 4    | Bolt-Flange, Banjo   |






## Front Suspension Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 87-0160     | 1    | Tower-Control Arm, LH  |
| 2    | 87-0150     | 1    | Tower-Control Arm, RH  |
| 3    | 33-3090     | 4    | Bushing                |
| 4    | 3234-39     | 8    | Screw-HHF              |
| 5    | 87-2500     | 2    | Sleeve-Spring, Pivot   |
| 6    | 105-7958    | 2    | Spring Cradle ASM      |
| 6:2  | 93-9879     | 1    | Decal-Warning          |
| 7    | 325-13      | 2    | Screw-HH               |
| 8    | 99-5107     | 4    | Nut-Lock               |
| 9    | 87-3600     | 10   | Spacer-Absorber, Shock |
| 10   | 87-5330     | 12   | Washer                 |
| 11   | 119-6725    | 2    | Link, Anti-Sway Bar    |
| 12   | 87-3920     | 24   | Bushing                |
| 13   | 133-0633-03 | 1    | Bar-Anti-Sway, HD      |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 14   | 302-11      | 2    | Fitting-Lube, 45 DEG |
| 15   | 87-3910     | 2    | Bushing-Rubber       |
| 16   | 87-4010-03  | 2    | Clamp-Bar, Sway      |
| 17   | 87-3890-03  | 2    | Bracket-Bar, Sway    |
| 18   | 3231-25     | 4    | Bolt-CARR            |
| 19   | 104-8301    | 12   | Nut-HF, NI           |
| 20   | 119-6724    | 2    | Link-Stabilizer      |
| 21   | 324-10      | 8    | Screw-HH             |
| 22   | 105-4183-01 | 2    | Spring-Compression   |
| 24   | 121-9774    | 2    | Absorber-Shock       |
| 25   | 324-13      | 2    | Screw-HH             |
| 26   | 3256-6      | 2    | Washer-Flat          |
| 27   | 3256-27     | 2    | Washer-Flat          |
| 28   | 114-8417    | 10   | Nut-HF, NI           |




## Steering and Front Wheel Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 104-8301    | 2    | Nut-HF, NI             |
| 2    | 324-10      | 2    | Screw-HH               |
| 3    |             | 1    | Steering Linkage ASM ● |
| 4    | 119-9548    | 2    | Bearing-Ball           |
| 5    | 114-8296    | 1    | Link-Center            |
| 6    | 32120-22    | 2    | Ring-Snap, Internal    |
| 7    | 112843      | 2    | Washer                 |
| 8    | 114-8417    | 2    | Nut-HF, NI             |
| 9    | 119-9513    | 1    | Knuckle-LH             |
| 10   | 119-9514    | 1    | Knuckle-RH             |
| 11   | 114-8356    | 2    | Tie Rod ASM            |
| 12   | 121-9751    | 2    | Hub-Bearing, Wheel     |
| 12:2 | 121-9752    | 5    | Stud-Wheel             |
| 13   | 3234-11     | 12   | Screw-HHF              |
| 14   | 114-8351    | 2    | Rotor-Brake            |
| 15   | 127-7424    | 2    | Brake Caliper ASM      |
| 16   | 112-3217    | 1    | HYD Cylinder ASM       |


| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 17   | 106-6774    | 2    | Joint-Ball               |
| 19   | 302-5       | 2    | Fitting-Grease           |
| 21   | 131-8430    | 2    | Tire/Wheel ASM           |
| 21:1 | 131-8431    | 1    | Wheel                    |
| 21:2 | 131-6670    | 1    | Tire                     |
| 21:3 | 232-27      | 1    | Stem-Valve               |
| 22   | 242-50      | 10   | Nut-Lug                  |
| 23   | 114-4681    | 2    | Screw-HHF                |
| 24   | 32151-104   | 2    | Ring-Retaining, External |
| 25   | 32136-14    | 2    | Nut-Hst                  |
| 26   | 32136-3     | 2    | Nut-SHH                  |
| 27   | 3272-12     | 4    | Pin-Cotter               |
| 28   | 104-0719    | 2    | Washer-Hardened          |
| 29   | 3256-62     | 2    | Washer-Flat              |
| 30   | 115-2173    | 2    | Screw-HH                 |
| 31   | 3296-49     | 2    | Nut-Lock, NI             |
| 32   | 119-9509    | 2    | Screw-Bleed              |

● Not serviced separately



## Steering Linkage Assembly


| Ref. | Part Number | Qty. | Description                      |
|------|-------------|------|----------------------------------|
| 1    | 132-6767    | 1    | Mount-Pivot, W/Bushings          |
| 7    | 115-2164    | 2    | Nut-Spindle                      |
| 9    | 302-60      | 2    | Fitting-Grease                   |
| 10   | 132-0794    | 1    | Idler Arm ASM                    |
| 10:1 | 132-0792    | 1    | Idler Arm And Thrust Washer ASM  |
| 10:2 | 93-7510     | 1    | Ring-Quad                        |
| 10:3 | 131-3499    | 1    | O-Ring                           |
| 11   | 132-0795    | 1    | Pitman Arm ASM                   |
| 11:1 | 132-0793    | 1    | Pitman Arm And Thrust Washer ASM |
| 11:2 | 93-7510     | 1    | Ring-Quad                        |
| 11:3 | 131-3499    | 1    | O-Ring                           |



## Hydraulic Cylinder Assembly No. 112-3217

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    |             | 1    | Rod-Cylinder ●      |
| 2    |             | 1    | Body-Cylinder ●     |
| 3    | 115-2160    | 1    | Cylinder Repair Kit |


● Not serviced separately



## Front Control Arm Assembly


| Ref.  | Part Number | Qty. | Description              |
|-------|-------------|------|--------------------------|
| 1     | 115-2405    | 1    | Lower LH Control Arm ASM |
| 1:2   | 87-1450     | 2    | Bushing-Flange           |
| 1:3   | 115-2165    | 1    | Ball Joint               |
| 1:3:1 | 302-5       | 1    | Fitting-Grease           |
| 1:4   | 87-2420     | 1    | Seal-Joint, Ball         |
| 1:5   | 32151-104   | 1    | Ring-Retaining, External |
| 2     | 115-2407    | 1    | Lower RH Control Arm ASM |
| 2:2   | 87-1450     | 2    | Bushing-Flange           |
| 2:3   | 115-2165    | 1    | Ball Joint               |
| 2:3:1 | 302-5       | 1    | Fitting-Grease           |
| 2:4   | 87-2420     | 1    | Seal-Joint, Ball         |
| 2:5   | 32151-104   | 1    | Ring-Retaining, External |
| 3     | 115-2404    | 1    | Upper LH Control Arm ASM |
| 3:2   | 87-1450     | 2    | Bushing-Flange           |
| 3:3   | 115-2165    | 1    | Ball Joint               |

| Ref.  | Part Number | Qty. | Description              |
|-------|-------------|------|--------------------------|
| 3:3:1 | 302-5       | 1    | Fitting-Grease           |
| 3:4   | 87-2420     | 1    | Seal-Joint, Ball         |
| 3:5   | 32151-104   | 1    | Ring-Retaining, External |
| 4     | 115-2406    | 1    | Upper RH Control Arm ASM |
| 4:2   | 87-1450     | 2    | Bushing-Flange           |
| 4:3   | 115-2165    | 1    | Ball Joint               |
| 4:3:1 | 302-5       | 1    | Fitting-Grease           |
| 4:4   | 87-2420     | 1    | Seal-Joint, Ball         |
| 4:5   | 32151-104   | 1    | Ring-Retaining, External |
| 5     | 99-5107     | 8    | Nut-Lock                 |
| 6     | 114-8419    | 6    | Screw-HHF                |
| 7     | 324-10      | 4    | Screw-HH                 |
| 8     | 325-17      | 2    | Screw-HH                 |
| 9     | 114-8417    | 4    | Nut-HF, NI               |




## Master Cylinder and Brake Pedal Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 120-5023-03 | 1    | Pedal-Brake         |
| 2    | 256-156     | 2    | Bushing-Flange      |
| 3    | 104-6782    | 1    | Master Cylinder ASM |
| 4    | 3234-11     | 2    | Screw-HHF           |
| 5    | 3290-357    | 2    | Nut-HSF             |
| 6    | 283-2       | 1    | Pin-Clevis          |
| 7    | 3272-10     | 1    | Pin-Cotter          |
| 8    | 106-2475    | 1    | Shaft-Brake         |
| 9    | 63-3410     | 1    | Screw-Shoulder      |
| 10   | 32128-33    | 1    | Nut-HF              |
| 11   | 95-1653     | 1    | Switch-Pole, Single |
| 12   | 302-60      | 1    | Fitting-Grease      |
| 13   | 3256-21     | 2    | Washer-Flat         |
| 14   | 3269-25     | 2    | Rivet-Pop           |



## Master Cylinder Assembly No. 104-6782

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 104-6845    | 1    | Reservoir ASM        |
| 1:1  | 92-4112     | 1    | Cap ASM              |
| 2    | 93-8971     | 2    | Seal-Port, Flange    |
| 3    | 92-4103     | 1    | Pin-Stop             |
| 4    | 92-4102     | 1    | Secondary Piston ASM |
| 5    | 92-4110     | 1    | Clevis               |
| 6    | 21-0360     | 1    | Nut-Hex              |
| 7    | 94-5209     | 1    | Cover-Dust           |
| 8    | 94-5210     | 1    | Rod-Push             |
| 9    | 92-4109     | 1    | Ring-Snap            |
| 10   | 92-4108     | 1    | Retainer-Washer      |
| 11   | 92-4101     | 1    | Primary Piston ASM   |




## Accelerator Pedal Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 120-4983-03 | 1    | Pedal-Accelerator        |
| 2    | 93-8969-03  | 1    | Pedal                    |
| 3    | 256-259     | 2    | Bushing-Flange           |
| 4    | 87-2880     | 1    | Shaft-Pedal, Accelerator |
| 5    | 32151-56    | 1    | Ring-Retaining, External |
| 6    | 119-4881    | 1    | Bolt-Shoulder            |
| 7    | 32128-33    | 1    | Nut-HF                   |
| 8    | 120-4982    | 1    | Bracket-Mount, Cable     |
| 9    | 3230-1      | 2    | Bolt-CARR                |
| 10   | 32128-20    | 2    | Nut-HF                   |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 11   | 302-5       | 1    | Fitting-Grease       |
| 12   | 283-85      | 1    | Pin-Clevis           |
| 13   | 3272-6      | 1    | Pin-Cotter           |
| 14   | 127-8625-03 | 1    | Bracket-Mount, Pedal |
| 15   | 46-6811     | 4    | Screw-HWH            |
| 16   | 67-1450     | 1    | Spring-Idler         |
| 17   | 321-6       | 1    | Screw-HH             |
| 18   | 3218-1      | 1    | Nut-Jam              |
| 19   | 121-9876    | 1    | Cable-Accelerator    |






## Center Console Assembly

| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 1    | 121-9870-03 | 1    | Support-Lever                 |
| 2    | 114402      | 2    | Spacer                        |
| 3    | 321-9       | 2    | Screw-HH                      |
| 4    | 3296-56     | 2    | Nut-Lock, NI                  |
| 5    | 3290-477    | 1    | Washer-Curved                 |
| 6    | 127-8863    | 1    | Lever-Brake, Park             |
| 6:1  | 127-8864    | 1    | Grip-Handle                   |
| 7    | 127-8603    | 2    | Bellcrank-Brake, Park         |
| 8    | 323-36      | 1    | Screw-HH                      |
| 9    | 104-8301    | 1    | Nut-HF, NI                    |
| 10   | 106-7833    | 1    | Spacer                        |
| 11   | 116-1545    | 1    | Clamp                         |
| 12   | 121-9872    | 1    | Lever-Pivot                   |
| 13   | 121-9873    | 1    | Lever-Control, Speed          |
| 14   | 121-9895    | 1    | Lever-HYD                     |
| 16   | 121-9851    | 1    | Lever-Control, Speed (Detent) |
| 17   | 3274-55     | 2    | Screw-HSBH                    |
| 19   | 52-2890     | 2    | Bushing-Nylon                 |
| 20   | 121-9869    | 1    | Shaft-Lever, Shift            |
| 21   | 121-9868    | 1    | Lever-Shift                   |


| Ref. | Part Number | Qty. | Description                    |
|------|-------------|------|--------------------------------|
| 22   | 87-2310     | 1    | Clevis-Cable                   |
| 23   | 32151-56    | 1    | Ring-Retaining, External       |
| 24   | 87-2900     | 1    | Spring-Compression             |
| 25   | 100-1270    | 1    | Switch-Proximity               |
| 26   | 100-4872    | 1    | Plate-Switch, Neutral          |
| 27   | 3229-34     | 1    | Screw-CARR                     |
| 28   | 3296-12     | 1    | Nut-Lock, NI                   |
| 29   | 115-2250    | 1    | Link                           |
| 30   | 115-2350    | 1    | Pin-Retainer                   |
| 31   | 283-62      | 3    | Pin-Clevis                     |
| 32   | 3290-307    | 4    | Pin-Cotter                     |
| 33   | 94-3829     | 1    | Pin-Clevis                     |
| 34   | 3256-23     | 1    | Washer-Plain                   |
| 35   | 65-5220     | 2    | Screw-HSH, Thread Forming      |
| 36   | 106-7903    | 1    | Knob-Control                   |
| 38   | 233-48      | 2    | Knob                           |
| 40   | 3290-221    | 1    | Washer-Spring                  |
| 41   | 32121-48    | 1    | Pin-Spring                     |
| 42   | 104-1414    | 1    | Sensor-Proximity, Ferrous (NC) |



## Center Console Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 43   | 32104-60    | 2    | Screw-HWH   |
| 44   | 3234-12     | 2    | Screw-HHF   |
| 45   | 3231-21     | 2    | Screw-CARR  |

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 46   | 3290-357    | 2    | Nut-HSF     |
| 47   | 3290-379    | 3    | Tie-Cable   |




## Bumper, Hood and Seat Base Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 133-0566    | 1    | Seatbase ASM        |
| 1:2  | 114-8407    | 1    | Fender-Front, RH    |
| 1:3  | 114-8408    | 1    | Fender-Front, LH    |
| 1:4  | 117-5036    | 14   | Screw-Plastic, HWH  |
| 2    | 106-2378    | 2    | Mudflap             |
| 3    |             | 1    | Control Plate ASM ● |
| 3:1  | 121-9737-03 | 1    | Plate-Control       |
| 3:2  | 121-9890    | 1    | Decal-Console       |
| 4    | 3256-55     | 8    | Washer-Flat         |
| 5    | 3234-4      | 4    | Screw-HHF           |
| 6    | 104-7201    | 4    | Nut-HF, NI          |
| 7    | 138-3387    | 1    | Shift Indicator ASM |
| 8    | 98-1375     | 10   | Screw-HWH           |
| 9    | 106-7984    | 1    | Lever-Detent        |

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 10   | 3274-55     | 1    | Screw-HSBH             |
| 11   | 82-4240     | 1    | Spacer-Bearing         |
| 12   | 94-8196     | 1    | Washer-Nylon           |
| 13   | 3290-221    | 1    | Washer-Spring          |
| 14   | 3256-23     | 1    | Washer-Plain           |
| 15   | 104-8300    | 1    | Nut-HF, NI             |
| 16   | 112-3185    | 1    | Bumper                 |
| 17   | 139-3382    | 1    | Hood ASM               |
| 17:2 | 117-4950    | 1    | Decal                  |
| 19   | 136-6318    | 2    | Housing-Headlight, 12V |
| 20   | 114-8341    | 6    | Clip-Speed             |
| 21   | 138-3371    | 1    | Decal-Indicator, Shift |
| 22   | 133-0574    | 2    | Bulb-LED               |
| 23   | 112-6957    | 6    | Washer-Hardened        |


● Not serviced separately



## Dash Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 127-8621    | 1    | Dash ASM                   |
| 1:2  | 127-8620    | 1    | Decal-Dash                 |
| 1:3  | 121-9776    | 1    | Decal-Danger, Vehicle (CE) |
| 1:4  | 115-2282    | 1    | Decal-Warning, Dash        |
| 1:5  | 106-2353    | 1    | Decal-Powerpoint           |
| 2    | 117-4948    | 1    | Handle-Grab                |
| 3    | 104-7201    | 2    | Nut-HF, NI                 |
| 4    | 103995      | 2    | Washer                     |
| 5    | 95-8999     | 1    | Switch                     |
| 6    | 99-7420     | 1    | Plug-Hole                  |
| 7    | 33103-012   | 2    | Screw-HHF                  |
| 8    | 3234-5      | 3    | Screw-HHF                  |


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 9    | 106-5269    | 1    | Ignition Switch ASM |
| 9:2  | 108-8660    | 1    | Nut-Mounting        |
| 9:3  | 106-5270    | 1    | Ignition Key Set    |
| 9:4  | 108-8659    | 1    | Washer-Backup       |
| 10   | 104-8300    | 3    | Nut-HF, NI          |
| 11   | 99-7411     | 1    | Point-Power         |
| 12   | 99-7416     | 1    | Cap                 |
| 16   | 138-9289    | 1    | Cluster-Instrument  |
| 18   | 105-4232    | 1    | Switch              |
| 19   | 112-3324    | 1    | Switch-Horn         |
| 20   | 112-3313    | 1    | Nut-Weatherproof    |



## Steering Hydraulic Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 120-4813    | 1    | Pump-Steering              |
| 2    | 98-1471     | 1    | Wheel-Steering             |
| 2:1  | 98-1468     | 1    | Cover-Wheel, Steering      |
| 3    | 94-1444     | 3    | Union-Bulkhead             |
| 3:1  | 237-21      | 2    | O-Ring                     |
| 4    | 106-7974    | 3    | Hose-HYD                   |
| 5    | 106-7975    | 2    | Hose-HYD                   |
| 6    | 340-71      | 2    | Fitting-Straight, Bulkhead |
| 6:1  | 237-22      | 2    | O-Ring                     |
| 8    | 340-70      | 4    | Nut-Lock                   |
| 9    | 106-7804    | 1    | Tube-HYD                   |
| 9:1  | 237-21      | 1    | O-Ring                     |
| 10   | 3219-10     | 6    | Nut-Hex                    |
| 11   | 106-7806    | 1    | Tube-HYD                   |
| 11:1 | 237-21      | 1    | O-Ring                     |
| 13   | 340-132     | 1    | Fitting-Elbow, 90 DEG      |
| 13:1 | 237-78      | 1    | O-Ring                     |
| 13:2 | 237-21      | 1    | O-Ring                     |
| 14   | 98-7977     | 4    | Screw-HHF                  |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 15   | 106-7839    | 2    | Clamp-Tube            |
| 16   | 3234-21     | 2    | Screw-HHF             |
| 18   | 104-7201    | 2    | Nut-HF, NI            |
| 19   | 3256-27     | 1    | Washer-Flat           |
| 20   | 3296-33     | 1    | Nut-Lock, NI          |
| 21   | 106-6713    | 1    | Cover-Lines, Steering |
| 22   | 3290-379    | 4    | Tie-Cable             |
| 23   | 108-6505    | 1    | Hose-HYD              |
| 24   | 340-92      | 1    | Fitting-Straight      |
| 24:1 | 237-78      | 1    | O-Ring                |
| 24:2 | 237-21      | 1    | O-Ring                |
| 25   | 115-7701    | 1    | Tube-HYD              |
| 25:1 | 237-22      | 1    | O-Ring                |
| 26   | 115-7702    | 1    | Tube-HYD              |
| 26:1 | 237-22      | 1    | O-Ring                |
| 27   | 115-7703    | 1    | Tube-HYD              |
| 27:1 | 237-21      | 1    | O-Ring                |
| 28   | 56-7973     | 2    | Clamp-Tube            |
| 29   | 117-4861    | 1    | Hose-HYD              |



## Steering Valve Assembly No. 120-4813

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 106-6716    | 1    | Seal Kit          |
| 1:1  |             | 1    | Ring-Seal, Dust ● |
| 1:2  |             | 1    | Seal-Shaft ●      |
| 1:3  |             | 1    | O-Ring ●          |
| 1:4  |             | 2    | O-Ring ●          |
| 1:5  |             | 5    | O-Ring ●          |


● Not serviced separately



## Seat Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 115-2435-03 | 4    | Bracket-Seat               |
| 2    | 119-0655    | 2    | Adjuster-Seat, Non Locking |
| 3    | 3230-1      | 8    | Bolt-CARR                  |
| 4    | 104-8300    | 8    | Nut-HF, NI                 |
| 5    | 3274-22     | 8    | Screw-HSH                  |
| 6    | 115-7721    | 8    | Nut-Clip, U                |
| 7    | 121-9763    | 2    | Adjuster-Seat, Locking     |
| 7:1  | 2410-49     | 1    | Cap-Vinyl                  |
| 8    | 104-7658    | 2    | Spacer                     |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 9    | 119-0727-03 | 2    | Bracket-Belt, Seat   |
| 10   | 119-0731-03 | 1    | Armrest-LH           |
| 11   | 119-0732-03 | 1    | Armrest-RH           |
| 12   | 133-0577    | 2    | Seat ASM             |
| 13   | 33114-030   | 12   | Screw-HH             |
| 14   | 110-0413    | 2    | Seatbelt-Retractable |
| 15   | 3212-4      | 4    | Screw-HH             |
| 16   | 3296-7      | 4    | Nut-Lock             |




## Roll-Over Protection System Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 2    | 121-9857    | 1    | ROPS Cover ASM (W/Decal) |
| 2:2  | 105-4215    | 1    | Decal-Caution            |
| 3    | 3230-18     | 8    | Screw-CARR               |
| 4    | 2412-133    | 2    | Clamp-R                  |
| 5    | 32128-20    | 8    | Nut-HF                   |
| 6    | 105-7960    | 1    | Bed Support ASM          |
| 6:2  | 93-9852     | 1    | Decal-Warning            |
| 6:3  | 92-5972     | 4    | Grommet-Rubber           |


| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 7    | 104-7050    | 1    | Tube-Manual     |
| 8    | 104-7048    | 1    | Cap-Housing     |
| 11   | 3234-38     | 6    | Screw-HHF       |
| 13   | 115-7910    | 1    | ROPS ASM        |
| 13:2 | 106-7767    | 2    | Decal-ROPS      |
| 13:3 | 93-9850     | 1    | Decal-ROPS, CE  |
| 13:4 | 117-4969    | 1    | Decal-ROPS, ISO |
| 14   | 127-7382    | 2    | Seal-ROPS       |






## Full Bed and Side Panel Assembly

| Ref. | Part Number | Qty. | Description              | Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|------|-------------|------|--------------------------|
| 1    | 93-9724-03  | 1    | Flatbed-Full             | 15   | 93-9719     | 2    | Block-Wear               |
| 2    | 133-0645    | 1    | Front Panel ASM          | 16   | 93-9595     | 2    | Lanyard                  |
| 2:2  | 115-7739    | 1    | Decal-No Riders          | 17   | 3256-57     | 4    | Washer-Flat              |
| 3    | 133-0617    | 1    | Panel-Side, RH           | 18   | 92-1233     | 4    | Pin-Clevis               |
| 4    | 133-0616    | 1    | Panel-Side, LH           | 19   | 92-1298     | 8    | Pin-Lynch                |
| 5    | 92-1320-03  | 2    | Angle-Side               | 20   | 32148-7     | 4    | Nut-Clinch               |
| 6    | 92-1265-03  | 2    | Bracket-Pivot            | 21   | 32148-6     | 4    | Nut-Clinch               |
| 7    | 133-0644    | 1    | Tailgate                 | 22   | 3230-18     | 6    | Screw-CARR               |
| 7:2  | 105-4222    | 1    | Decal                    | 23   | 3234-7      | 21   | Screw-HHF                |
| 8    | 106-2423-03 | 1    | Bracket-Spacer, RH       | 24   | 3234-29     | 6    | Screw-HHF                |
| 9    | 106-2422-03 | 1    | Bracket-Spacer, LH       | 25   | 3250-45     | 4    | Screw-SPH                |
| 10   | 93-9720-03  | 2    | Bracket-Pivot, Long (LH) | 26   | 3296-42     | 4    | Nut-Lock, NI             |
| 11   | 93-9721-03  | 2    | Bracket-Pivot, Long (RH) | 27   | 323-42      | 8    | Screw-HH                 |
| 12   | 93-9575     | 2    | Tube-Pivot, Flatbed      | 28   | 3231-24     | 6    | Screw-CARR               |
| 13   | 99-1123     | 2    | Latch ASM                | 31   | 3296-44     | 14   | Nut-Lock, NI             |
| 13:1 | 92-1271     | 1    | Pivot-Latch              | 32   | 32128-20    | 27   | Nut-HF                   |
| 13:2 | 99-1113     | 1    | Handle-Latch             | 33   | 127-8624    | 2    | Decal-Workman, HD (Auto) |
| 13:3 | 99-1112     | 1    | Plate-Retainer           | 35   | 93-9868     | 2    | Decal-Caution            |
| 13:4 | 32121-78    | 1    | Pin-Roll                 | 36   | 93-9899     | 2    | Decal-Warning            |
| 13:5 | 32121-25    | 1    | Pin-Roll                 |      |             |      |                          |



## Engine and Transmission Support Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|---------------------------|
| 1           | 121-9750-03        | 1           | Support-Engine            |
| 2           | 121-9801-03        | 1           | Mount-Engine/Transmission |
| 3           | 3234-11            | 2           | Screw-HHF                 |
| 4           | 104-8301           | 2           | Nut-HF, NI                |
| 5           | 3290-379           | 7           | Tie-Cable                 |
| 6           | 3272-37            | 2           | Pin-Cotter                |
| 7           | 32180-030          | 1           | Clip-Tie                  |




## Engine and Exhaust Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 121-9743    | 1    | Engine-Kohler, LH775       |
| 1:1  | 108-3847    | 1    | Filter-Oil ●               |
| 2    | 127-8809-03 | 1    | Mount-Pump                 |
| 3    | 131-6680    | 1    | Bracket-Throttle           |
| 4    | 121-9831-03 | 1    | Bracket-Muffler            |
| 5    | 121-9830    | 1    | Muffler ASM                |
| 6    | 121-9850    | 1    | Mount-Sensor, Tach         |
| 7    | 121-9829    | 1    | Manifold-Exhaust           |
| 8    | 121-9828    | 1    | Pipe-Exhaust, Intermediate |
| 9    | 120-4800    | 1    | Sensor-Geartooth           |
| 10   | 32105-20    | 2    | Screw-HH                   |
| 11   | 94-7621     | 1    | Sender-Temperature         |
| 12   | 127-8714    | 1    | Adapter-Filter, Remote     |
| 13   | 121-9714    | 1    | Adapter-Coupler, Pump      |
| 14   | 100-8159    | 2    | Screw-HSFH                 |
| 15   | 119-0652    | 1    | Coupler-Rubber             |
| 16   | 3256-23     | 2    | Washer-Plain               |
| 17   | 322-7       | 2    | Screw-HH                   |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 18   | 322-21      | 2    | Screw-HH             |
| 19   | 115-2169    | 1    | Hub-Pump             |
| 20   | 3241-6      | 2    | Screw-SQH            |
| 21   | 104-8300    | 7    | Nut-HF, NI           |
| 22   | 117-5612    | 1    | Harness-Wire, Ground |
| 23   | 32144-112   | 3    | Screw-HWH            |
| 24   | 7-0030      | 1    | Screw-Shoulder, HH   |
| 25   | 329-6       | 1    | Screw-HH             |
| 26   | 131-6678    | 1    | Bellcrank ASM        |
| 27   | 119-4881    | 1    | Bolt-Shoulder        |
| 29   | 3220-1      | 1    | Nut-Jam              |
| 30   | 112-1542    | 1    | Spring-Extension     |
| 31   | 3234-19     | 4    | Screw-HHF            |
| 32   | 104-8301    | 4    | Nut-HF, NI           |
| 33   | 3255-9      | 1    | Washer-Lock          |
| 35   | 99-6810     | 1    | Screw-HHF            |
| 36   | 33104-020   | 2    | Screw-HHF            |
| 37   | 32144-70    | 2    | Screw-HWHTF          |

● Not illustrated




## Engine and Exhaust Assembly (continued)

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 38   | 2112-9      | 2    | Clamp                      |
| 38:1 | 32128-20    | 2    | Nut-HF                     |
| 39   | 3230-23     | 5    | Bolt-CARR                  |
| 40   | 99-3441     | 1    | Harness-Wire, Fusible Link |
| 41   | 120-9636    | 2    | Spacer                     |
| 42   | 94-2691     | 2    | Screw-HWH                  |
| 43   | 121-9894    | 1    | Fitting-Straight           |
| 44   | 302-40      | 1    | Fitting-Grease, 90 DEG     |
| 45   | 127-8706    | 1    | Fitting-STR                |
| 45:1 | 127-8710    | 1    | O-Ring                     |
| 45:2 | 127-8711    | 1    | O-Ring                     |
| 46   | 127-8709    | 1    | Fitting-90                 |
| 46:1 | 127-8712    | 1    | O-Ring                     |
| 46:2 | 127-8713    | 1    | O-Ring                     |
| 47   | 127-8707    | 1    | Fitting-STR                |

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 47:1 | 127-8712    | 1    | O-Ring         |
| 48   | 127-8708    | 1    | Fitting-STR    |
| 48:1 | 127-8710    | 1    | O-Ring         |
| 49   | 127-8619    | 1    | Tube-HYD       |
| 50   | 127-8618    | 1    | Tube-HYD       |
| 51   | 3290-381    | 3    | Tie-Cable      |
| 52   | 106-7839    | 2    | Clamp-Tube     |
| 53   | 87-6630     | 2    | Washer-Plain   |
| 54   | 3234-21     | 1    | Screw-HHF      |
| 55   | 104-7201    | 2    | Nut-HF, NI     |
| 56   | 120-6686    | 2    | Nut-Clip, U    |
| 57   | 131-6679    | 1    | Lever-Throttle |
| 58   | 75-8700     | 1    | Bushing-Idler  |
| 60   | 251-259     | 1    | Bearing-Ball   |
| 61   | 32128-13    | 1    | Nut-HF         |

● Not illustrated




## Cooling System Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 115-2434    | 1    | Mount-Radiator         |
| 2    | 107069      | 2    | Clip                   |
| 3    |             | 1    | Radiator And Fan ASM ● |
| 4    | 3234-11     | 1    | Screw-HHF              |
| 5    | 104-8301    | 4    | Nut-HF, NI             |
| 6    | 3256-3      | 2    | Washer-Flat            |
| 7    | 3234-4      | 4    | Screw-HHF              |
| 8    | 32128-33    | 2    | Nut-HF                 |
| 9    | 121-9818    | 1    | Hose-Coolant, Upper    |
| 10   | 121-9819    | 1    | Hot Coolant Pipe ASM   |
| 11   | 121-9820    | 1    | Cold Coolant Pipe ASM  |
| 12   | 127-8634    | 1    | Hose-Straight          |
| 13   | 119-9711    | 2    | Hose-Straight          |
| 14   | 121-9854-03 | 1    | Plate Mount-Tank       |
| 15   | 120-4856    | 1    | Tank-Surge             |
| 16   | 46-8091     | 2    | Screw-HWH              |
| 17   | 92-2379     | 6    | Clamp-Hose             |


| Ref. | Part Number | Qty. | Description                    |
|------|-------------|------|--------------------------------|
| 18   | 120-4867    | 1    | Cap-Coolant, Threaded (15 PSI) |
| 19   | 2412-34     | 8    | Clamp-Hose                     |
| 20   | 115-2428-03 | 1    | Screen-Radiator                |
| 21   | 74-5950     | 4    | Latch-Swell                    |
| 22   | 120-4866    | 1    | Cap-System, Cooling            |
| 23   | 106-6755    | 1    | Decal-Cap, Radiator            |
| 24   | 56-7974     | 2    | Clamp-Tube                     |
| 25   | 3256-23     | 1    | Washer-Plain                   |
| 26   | 322-11      | 1    | Screw-HH                       |
| 27   | 104-8300    | 1    | Nut-HF, NI                     |
| 28   | 127-8608    | 1    | Hose-Coolant                   |
| 29   | 120-5021    | 2    | Hose-Coolant                   |
| 30   | 3290-379    | 2    | Tie-Cable                      |
| 31   | 121-6286    | 1    | Decal-Fill, Radiator           |
| 32   | 121-6287    | 1    | Decal-Tank, Overflow           |

● Not serviced separately



## Radiator and Fan Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 114-8384    | 1    | Radiator           |
| 2    | 121-9812    | 1    | Fan-Electric       |
| 3    | 114-8386    | 1    | Shroud             |
| 4    | 114-8387    | 2    | Latch-Spring       |
| 5    | 3234-30     | 7    | Screw-HHF          |
| 6    | 703856      | 7    | Nut-Sq, Caged      |
| 7    | 60-6910     | 4    | Screw-HH           |
| 8    | 115-7765    | 1    | Plate-Mount, Lower |




## Clutch Assembly

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 121-9838    | 1    | Housing-Inlet, Air        |
| 2    | 121-9815-03 | 1    | Spanner Plate ASM         |
| 3    | 121-9836    | 1    | Cover-Enclosure           |
| 4    | 121-9837    | 1    | Cover-Limiter, Speed      |
| 5    | 121-9102    | 3    | Screw-HWH                 |
| 6    | 32144-86    | 14   | Screw-HWHTF               |
| 7    | 94-2691     | 2    | Screw-HWH                 |
| 8    | 132-6780    | 1    | Primary Clutch ASM        |
| 9    | 121-9853    | 1    | Hose-Intake               |
| 10   | 121-9612    | 1    | Belt                      |
| 11   | 132-6785    | 1    | Secondary Clutch ASM      |
| 12   | 121-9844    | 1    | Cylinder-Master           |
| 13   |             | 1    | Speed Limiter Cover ASM ● |
| 14   | 80-2570     | 1    | Pin-Clevis                |
| 15   | 3290-307    | 2    | Pin-Cotter                |
| 16   | 117-5094    | 1    | Pin-Clevis                |
| 17   | 41-8440     | 1    | Washer                    |
| 18   | 121-9848    | 1    | Screw-HSH                 |

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 19   | 121-9847    | 1    | Spring-Compression     |
| 20   | 2412-125    | 2    | Clamp-Hose             |
| 21   | 3234-1      | 4    | Screw-HHF              |
| 22   | 115-2341    | 6    | Washer-Banjo           |
| 23   | 115-2340    | 3    | Bolt-Banjo             |
| 24   | 121-9846    | 1    | Speed Control Hose ASM |
| 25   | 121-9899    | 1    | Reservoir Fitting ASM  |
| 26   | 121-9897    | 1    | Hose-Reservoir         |
| 27   | 3290-379    | 1    | Tie-Cable              |
| 28   | 237-58      | 1    | O-Ring                 |
| 29   | 32144-4     | 1    | Screw-HWH              |
| 30   | 104-6550    | 1    | Washer-Clutch          |
| 31   | 87-8640     | 1    | Washer-Flat            |
| 32   | 127-8716    | 1    | Screw-HH, Lock         |
| 33   | 127-8622    | 1    | Reservoir-Fluid        |
| 34   | 127-8623    | 1    | Cap-Reservoir          |
| 35   | 2412-141    | 1    | Clamp-Drive, Worm      |
| 36   | 121-9840    | 1    | Fan                    |

● Not serviced separately




## Clutch Assembly (continued)

| Ref. | Part Number | Qty. | Description   |
|------|-------------|------|---------------|
| 37   | 127-8640    | 1    | Stiffener-Fan |
| 38   | 32144-10    | 4    | Screw-HWH     |
| 39   | 94-5781     | 6    | Screw-HHF     |

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 40   | 132-6778    | 1    | Spring-Clutch, Primary     |
| 41   | 136-6322    | 1    | Collar-Shift Stop, Primary |


● Not serviced separately






## Primary Clutch Assembly No. 132-6780

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 3           | 130-4069           | 2           | Washer-Thrust         |
| 4           | 130-4067           | 1           | Sleeve-Idler, Primary |
| 5           | 130-4068           | 1           | Cap-Sleeve, Idler     |
| 7           | 132-6779           | 3           | Weight-Clutch         |
| 8           | 119-6016           | 3           | Screw-Shoulder        |
| 9           | 119-6015           | 3           | Nut-Hex, Lock         |



## Secondary Clutch Assembly No. 132-6785


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 130-4055    | 4    | Screw                   |
| 2    | 133-0571    | 1    | Cam ASM                 |
| 3    | 119-0811    | 1    | Ring-Retaining          |
| 4    | 130-4058    | 2    | E-Ring                  |
| 5    | 130-4059    | 2    | Washer-Thrust           |
| 6    | 130-4060    | 2    | Roller-Clutch, Torlon   |
| 7    | 132-6782    | 1    | Spider-Outer, Dampened  |
| 8    | 130-4061    | 1    | Dampener-Spider         |
| 9    | 132-6783    | 1    | Spider-Insert, Dampener |
| 10   | 132-6784    | 1    | Spring-Compression      |
| 12   | 130-4063    | 2    | Pin-Roller              |
| 13   | 130-4064    | 2    | Roller-Clutch, Stanyl   |
| 15   | 130-4065    | 2    | Pin-Spring, Slotted     |
| 17   | 130-4066    | 1    | Bearing-Ball            |
| 18   | 130-4612    | 1    | Ring-Retaining          |



## Speed Limiter Cover Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 127-8743    | 1    | Cover-Control, Speed |
| 2    | 127-8748    | 1    | Ring-Quad            |
| 3    | 127-8736    | 1    | Piston-HYD           |
| 4    | 121-9730    | 1    | Bushing-Sleeve       |
| 5    | 121-9845    | 1    | Union-Rotary         |
| 5:1  | 127-8861    | 2    | O-Ring               |
| 5:2  | 115-2341    | 1    | Washer-Banjo         |
| 6    | 121-9731    | 1    | Retainer             |
| 7    | 3274-39     | 3    | Screw-HSBH           |
| 8    | 127-8747    | 1    | U-Cup                |






## Transmission Assembly No. 121-9603

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 130-4600    | 1    | Plug               |
| 2    | 130-4601    | 1    | Plug-Magnetic      |
| 3    | 130-4602    | 1    | Screw              |
| 4    | 130-4603    | 14   | Screw              |
| 5    | 130-4604    | 5    | Screw              |
| 6    | 130-4605    | 3    | Screw              |
| 7    | 130-4606    | 1    | Nut                |
| 8    | 130-4607    | 2    | Washer-Cup         |
| 9    | 130-4608    | 3    | Washer             |
| 10   | 130-4609    | 2    | Pin-Dowel          |
| 11   | 130-4610    | 1    | Ring-Snap          |
| 12   | 130-4611    | 2    | Ring-Retaining     |
| 13   | 130-4612    | 2    | Ring-Retaining     |
| 14   | 130-4613    | 3    | Ring-Snap, EXT     |
| 15   | 130-4614    | 2    | Washer-Thrust      |
| 16   | 130-4615    | 1    | Washer-Thrust      |
| 17   | 130-4616    | 2    | Bearing-Needle     |
| 18   | 130-4617    | 5    | Bearing-Ball       |
| 19   | 130-4618    | 1    | Bearing-Needle     |
| 20   | 130-4619    | 2    | Bearing-Ball       |
| 22   | 130-4623    | 1    | Spring-Compression |


| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 23   | 130-4620    | 2    | Spring-Compression        |
| 24   | 130-4621    | 2    | Spring-Compression        |
| 25   | 130-4622    | 1    | Spring-Washer             |
| 26   | 130-4624    | 1    | Gearcase-Front            |
| 27   | 130-4625    | 1    | Gearcase-Rear             |
| 28   | 130-4626    | 1    | Cover-Gear, Sector        |
| 29   | 130-4627    | 1    | Drum-Shift                |
| 30   | 130-4628    | 1    | Gear-Sector, 31T          |
| 31   | 130-4629    | 1    | Star-Detent               |
| 32   | 130-4630    | 1    | Gear-Sector, 16T          |
| 33   | 130-4631    | 1    | Pawl-Detent               |
| 34   | 130-4632    | 1    | Plate-Park, 12-Face       |
| 35   | 130-4636    | 1    | Shaft-Output, Front (22T) |
| 36   | 130-4633    | 1    | Gear-Helical, 88T         |
| 37   | 130-4634    | 1    | Shaft-Reverse, 29T        |
| 38   | 130-4635    | 1    | Shaft-Output, Rear (22T)  |
| 39   | 130-4637    | 1    | Bellcrank-180 Degree      |
| 40   | 130-4638    | 1    | Shaft                     |
| 41   | 130-4639    | 1    | Tube-Vent                 |
| 42   | 130-4647    | 1    | Dog-Shift, Park           |
| 43   | 130-4640    | 1    | Shaft-Shift               |



## Transmission Assembly No. 121-9603 (continued)

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 44   | 130-4641    | 1    | Collar-Shift           |
| 45   | 130-4642    | 2    | Fork-Shift             |
| 46   | 130-4643    | 1    | Sprocket-48T, 6-Face   |
| 47   | 130-4644    | 1    | Gear-Low, 67T          |
| 48   | 130-4646    | 1    | Dog-Engagement, 6-Face |
| 49   | 130-4645    | 1    | Gear-53T               |
| 50   | 130-4648    | 1    | Subassembly-Input      |
| 52   | 130-4649    | 1    | Spacer                 |
| 53   | 130-4650    | 1    | Chain-Silent, 11W40P   |


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 54   | 130-4651    | 1    | Chain-Silent, Type 101 |
| 55   | 130-4652    | 1    | Sensor-Speed           |
| 56   | 130-4653    | 1    | Switch-Rotary, 6-Pin   |
| 60   | 130-4654    | 1    | O-Ring                 |
| 61   | 130-4655    | 1    | O-Ring                 |
| 62   | 130-4656    | 1    | Seal-Lip, Triple       |
| 63   | 130-4657    | 1    | O-Ring                 |
| 64   | 130-4658    | 1    | Seal-Lip, Triple       |



## Rear Drive Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 121-9604    | 1    | Differential ASM   |
| 2    | 121-9616-03 | 1    | Mount-Rear, RH     |
| 3    | 121-9617-03 | 1    | Mount-Rear, LH     |
| 5    | 104-8301    | 6    | Nut-HF, NI         |
| 6    | 121-9823    | 1    | Rotor-Brake, Park  |
| 7    | 137-2789    | 1    | Spacer-Brake, Park |
| 8    | 109-0958    | 1    | Plate-Mount, Brake |
| 9    | 109-2889    | 1    | Caliper-Brake      |
| 10   | 121-9842    | 1    | Cable-Brake, Park  |
| 11   | 1-808265    | 1    | Pin-Clevis         |
| 12   | 3290-307    | 1    | Pin-Cotter         |

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 13   | 121-9832    | 1    | Rear Driveshaft ASM      |
| 14   | 127-8633    | 4    | Screw-HSH, Lock          |
| 15   | 3234-11     | 14   | Screw-HHF                |
| 16   | 119-4061    | 2    | Screw-HHF                |
| 17   | 32120-47    | 2    | Ring-Retaining, External |
| 19   | 127-8859    | 1    | Bellows-Breather         |
| 20   | 122-0589    | 1    | Harness-Wire             |
| 21   | 127-8894    | 1    | Bracket                  |
| 22   | 131-8309    | 1    | Controller-Solenoid      |
| 23   | 100-4352    | 2    | Screw-HWH                |
| 24   | 32180-039   | 1    | Clip-Connector, Molex    |




## Differential Assembly No. 121-9604

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 130-4600    | 1    | Plug                   |
| 2    | 130-4691    | 2    | Plug-Expansion         |
| 3    | 130-4601    | 1    | Plug-Magnetic          |
| 4    | 130-4660    | 2    | Screw                  |
| 5    | 130-4603    | 8    | Screw                  |
| 6    | 130-4661    | 8    | Screw-Cap, HH          |
| 7    | 130-4662    | 1    | Nut-Hex                |
| 8    | 130-4663    | 1    | Washer-Locking         |
| 9    | 130-4609    | 2    | Pin-Dowel              |
| 10   | 130-4664    | 1    | Pin-Dowel              |
| 11   | 130-4665    | 1    | Shim                   |
| 12   | 130-4666    | 1    | Bearing-Ball           |
| 13   | 130-4667    | 1    | Bearing-Ball           |
| 14   | 130-4668    | 1    | Bearing-Ball           |
| 15   | 130-4669    | 1    | Bearing-Needle         |
| 16   | 130-4671    | 1    | Spring-Torsion, Return |
| 17   | 130-4670    | 1    | Spring-Compression     |
| 18   | 130-4672    | 1    | Cover-Output           |
| 19   | 130-4673    | 1    | Gearcase               |

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 20   | 130-4674    | 1    | Housing-Differential     |
| 21   | 130-4677    | 2    | Pinion-Differential, 12T |
| 22   | 130-4678    | 1    | Gear-Output, 16T         |
| 23   | 130-4679    | 1    | Gear-Output, 16T         |
| 24   | 130-4675    | 1    | Pinion-Spiral, 10T       |
| 25   | 130-4676    | 1    | Gear-Spiral, 37T         |
| 26   | 130-4639    | 1    | Tube-Vent                |
| 27   | 130-4680    | 1    | Pin-Pinion, Differential |
| 28   | 130-4681    | 1    | Dog-Engagement, 6 Pin    |
| 29   | 130-4683    | 1    | Collar-Lock              |
| 30   | 130-4682    | 1    | Coupler                  |
| 31   | 130-4684    | 2    | Retainer-Fork            |
| 32   | 130-4685    | 1    | Fork-Pivot, Shift        |
| 33   | 130-4686    | 1    | Solenoid                 |
| 34   | 130-4687    | 1    | Seal-Lip, Triple         |
| 35   | 130-4688    | 1    | Seal-Lip, Triple         |
| 36   | 130-4689    | 1    | O-Ring                   |
| 37   | 130-4690    | 1    | Seal-Lip, Triple         |






## Driveshaft Assembly No. 121-9832

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 121-9880           | 2           | U-Joint            |
| 3           | 121-9822           | 1           | Yoke-Flange        |
| 4           | 121-9879           | 1           | Yoke-Slip          |
| 4:1         | 106-1104           | 1           | Fitting-Grease     |




S2



## Rear Tail Light and Fender Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 132-6701    | 2    | Fender-Rear                |
| 2    | 93-8943-03  | 1    | Bracket-Fender, Rear (LH)  |
| 3    | 93-8944-03  | 1    | Bracket-Fender, Rear (RH)  |
| 4    | 93-8941-03  | 1    | Bracket-Fender, Front (LH) |
| 5    | 93-8942-03  | 1    | Bracket-Fender, Front (RH) |
| 6    | 121-6269-03 | 2    | Bracket-Light, Tail        |
| 7    | 120-4820    | 2    | Light-Tail, Brake          |
| 7:1  | 115-7858    | 1    | Bulb-7528                  |
| 7:2  | 121-6271    | 1    | Lens-Light, Tail           |


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 7:3  | 121-6272    | 2    | Screw-PPH           |
| 8    | 2412-93     | 2    | Clamp-R             |
| 9    | 3234-17     | 4    | Screw-HHF           |
| 10   | 104-8300    | 4    | Nut-HF, NI          |
| 11   | 32105-15    | 12   | Screw-HWH           |
| 12   | 105-6245    | 6    | Screw-Tapping       |
| 13   | 104-7201    | 12   | Nut-HF, NI          |
| 14   | 121-6320    | 4    | Screw-HH            |
| 15   | 43-5920     | 4    | Washer-Lock, Spring |



## Fuel System Assembly

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 115-7767-03 | 1    | Tube-Support      |
| 2    | 94-5780     | 2    | Screw-HWH         |
| 3    | 104-8300    | 2    | Nut-HF, NI        |
| 4    | 115-7700    | 1    | Tank-Fuel         |
| 5    | 114-0284    | 1    | Grommet           |
| 6    | 114-0285    | 1    | Valve-Rollover    |
| 7    | 114-8404    | 1    | Plate-Retainer    |
| 8    | 32144-70    | 2    | Screw-HWHTF       |
| 9    | 137-4127    | 1    | Cap-Fuel          |
| 10   | 127-8801    | 1    | Fuel Pump ASM     |
| 10:1 | 115-2163    | 1    | Gasket-Pump, Fuel |
| 10:2 | 115-2162    | 1    | Cap-Pump, Fuel    |


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 10:3 | 115-7818    | 1    | Fuel Filter ASM     |
| 10:4 | 120-4812    | 1    | Float               |
| 11   | 127-8685    | 1    | Canister-Carbon     |
| 12   | 92-2379     | 2    | Clamp-Hose          |
| 13   | 106-5317    | 1    | Hose-Fuel           |
| 14   | 115-7854    | 1    | Filter-Fuel, Inline |
| 15   | 133-8499    | 1    | Valve-Check, Vacuum |
| 16   | 2412-146    | 1    | Clamp-Hose          |
| 17   | 109-0279    | 1    | Hose-Fuel           |
| 18   | 121-0780    | 1    | Hose-Fuel           |
| 19   | 115-7871    | 2    | Hose-Fuel           |



## Hydraulic Lift Valve Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 43-1950     | 1    | HYD Control Valve ASM |
| 2    | 340-77      | 1    | Fitting-Elbow, 90 DEG |
| 2:1  | 237-22      | 1    | O-Ring                |
| 2:2  | 237-42      | 1    | O-Ring                |
| 3    | 340-97      | 1    | Fitting-Elbow, 90 DEG |
| 3:1  | 237-22      | 1    | O-Ring                |
| 3:2  | 237-78      | 1    | O-Ring                |
| 4    | 340-88      | 1    | Fitting-Straight      |
| 4:1  | 237-22      | 1    | O-Ring                |
| 4:2  | 237-78      | 1    | O-Ring                |
| 5    | 340-94      | 1    | Adapter               |
| 5:1  | 237-22      | 2    | O-Ring                |
| 5:2  | 237-42      | 1    | O-Ring                |
| 6    | 127-8604    | 1    | Tube-HYD              |
| 6:1  | 237-22      | 1    | O-Ring                |
| 6:2  | 340-117     | 1    | Cap                   |
| 7    | 127-8605    | 1    | Tube-HYD              |
| 8    | 106-7969    | 2    | Coupler-Quick, Male   |
| 9    | 106-7968    | 2    | Coupler-Quick, Female |
| 10   | 340-2       | 2    | Fitting-Straight      |
| 10:1 | 237-22      | 1    | O-Ring                |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 10:2 | 237-42      | 1    | O-Ring                |
| 11   | 3234-4      | 2    | Screw-HHF             |
| 12   | 104-7201    | 2    | Nut-HF, NI            |
| 13   | 56-7976     | 8    | Clamp-Tube            |
| 14   | 56-7973     | 2    | Clamp-Tube            |
| 15   | 121-9859    | 1    | Tube-HYD              |
| 15:1 | 237-22      | 1    | O-Ring                |
| 15:2 | 340-117     | 1    | Cap                   |
| 16   | 340-21      | 2    | Fitting               |
| 16:1 | 237-21      | 3    | O-Ring                |
| 17   | 133-0620    | 2    | HYD Cylinder ASM      |
| 18   | 340-132     | 4    | Fitting-Elbow, 90 DEG |
| 18:1 | 237-78      | 1    | O-Ring                |
| 18:2 | 237-21      | 1    | O-Ring                |
| 19   | 340-82      | 2    | Fitting-Elbow, 90 DEG |
| 19:1 | 237-42      | 1    | O-Ring                |
| 19:2 | 237-21      | 1    | O-Ring                |
| 20   | 121-9862    | 1    | Tube-HYD              |
| 21   | 121-9863    | 1    | Tube-HYD              |
| 22   | 114-8410    | 2    | Screw-HHF             |
| 23   | 121-9875    | 2    | Hose ASM-HYD HP       |



## Hydraulic Lift Valve Assembly (continued)

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 24   | 115-7711    | 1    | Hose-HYD                  |
| 25   | 104-3751    | 1    | Hose ASM-CYL, Lift        |
| 26   | 108-6505    | 1    | Hose-HYD                  |
| 27   | 98-4587     | 1    | HYD Hose ASM              |
| 28   | 24-7922     | 1    | Conduit-Convoluted, Split |
| 29   | 24-7923     | 2    | Conduit-Convoluted, Split |
| 30   | 3290-379    | 9    | Tie-Cable                 |
| 31   | 106-7881    | 2    | Cap-Dust, HYD             |


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 32   | 106-7882    | 2    | Plug-Dust, HYD          |
| 33   | 32105-13    | 1    | Screw-HWH               |
| 34   | 3290-148    | 1    | Nut-HF                  |
| 35   | 115-7715    | 1    | Coupler Bracket ASM     |
| 35:2 | 115-7723    | 1    | Decal-Disconnect, Quick |
| 36   | 32151-83    | 2    | Ring-Snap               |
| 37   | 32144-57    | 5    | Screw                   |



## Control Valve Assembly No. 43-1950

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 1    | 22-8330     | 2    | Plug        |
| 2    | 237-42      | 2    | O-Ring      |
| 3    | 22-8340     | 2    | Spring      |
| 4    | 22-8350     | 2    | Ball        |
| 5    | 22-8370     | 2    | Seat-Valve  |
| 6    | 22-8360     | 2    | Pin         |
| 7    |             | 1    | Body ●      |
| 8    | 22-8420     | 1    | Spool       |
| 9    | 22-8500     | 2    | O-Ring      |
| 10   | 22-8380     | 2    | Retainer    |
| 11   | 22-8410     | 1    | Spring      |
| 12   | 23-3030     | 1    | Spacer      |
| 13   | 22-8480     | 1    | Ring-Snap   |
| 14   | 22-8490     | 1    | Ring-Snap   |


● Not serviced separately



## Hydraulic Cylinder Assembly No. 133-0620


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 133-0618           | 1           | Cylinder Seal Kit  |
| 2           | 93-9852            | 1           | Decal-Warning      |






## Hydraulic Tank and Filter Assembly

| Ref. | Part Number | Qty. | Description              | Ref. | Part Number | Qty. | Description  |
|------|-------------|------|--------------------------|------|-------------|------|--------------|
| 1    | 121-9814-03 | 1    | Mount-Tank, Hydraulic    | 17   | 114-8438    | 1    | Hose-HYD     |
| 2    | 121-9813    | 1    | Tank-HYD                 | 19   | 56-7970     | 4    | Clamp-Tube   |
| 4    | 115-2230    | 1    | Strainer-In Tank         | 22   | 115-5103    | 5    | Screw-HHF    |
| 4:1  | 340-136     | 1    | O-Ring                   | 23   | 32144-57    | 2    | Screw        |
| 6    | 107-4543    | 1    | Clamp                    | 25   | 104-7201    | 5    | Nut-HF, NI   |
| 7    | 104-0790    | 1    | Bushing                  | 26   | 121-9874    | 1    | HYD Hose ASM |
| 8    | 104-0791    | 1    | Pipe-Stand               | 27   | 3234-47     | 2    | Screw-HHF    |
| 9    | 115-7877    | 1    | Cap-Oil, HYD             | 28   | 104-8300    | 3    | Nut-HF, NI   |
| 10   | 87-8780     | 1    | Head-Filter              | 29   | 3256-23     | 1    | Washer-Plain |
| 11   | 54-0110     | 1    | Filter-Oil, Transmission | 30   | 322-10      | 1    | Screw-HH     |
| 13   | 3234-17     | 4    | Screw-HHF                | 33   | 2412-36     | 2    | Clamp-Hose   |
| 14   | 32128-20    | 4    | Nut-HF                   | 34   | 121-9885    | 1    | Dipstick     |
| 15   | 354-121     | 1    | Fitting-STR              | 35   | 2412-106    | 1    | Clamp-R      |
| 15:1 | 237-79      | 1    | O-Ring                   |      |             |      |              |




## Air Cleaner Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 2           | 138-3448           | 1           | Air Cleaner ASM     |
| 3           | 121-9852           | 1           | Hose-Intake, Engine |
| 5           | 2412-130           | 2           | Clamp-Hose          |
| 6           | 3234-36            | 2           | Screw-HHF           |
| 7           | 104-8300           | 2           | Nut-HF, NI          |



## Air Cleaner Assembly No. 138-3448


| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 1    | 136-7859    | 1    | Rain Cap Kit                  |
| 1:1  | 1-643009    | 1    | Clamp-Hose                    |
| 2    | 95-5806     | 1    | Bracket-Mounting, Air Cleaner |
| 3    | 104-0498    | 1    | Valve-Vacuator                |
| 4    | 108-3811    | 1    | Filter-Air                    |
| 5    | 281-7       | 1    | Cap-Pipe                      |
| 6    | 106-6748    | 1    | Gasket                        |
| 7    | 107-7971    | 1    | Cup                           |



## High Flow Hydraulic Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 340-109     | 3    | Fitting-Tee           |
| 1:1  | 237-79      | 1    | O-Ring                |
| 1:2  | 237-30      | 2    | O-Ring                |
| 2    | 115-2252    | 1    | HYD Manifold ASM      |
| 3    | 133-0611    | 1    | Cooler-Oil, HD        |
| 4    | 115-7787    | 1    | Hydraulic Pump ASM    |
| 5    | 105-7978    | 1    | Coupler Bracket ASM   |
| 5:2  | 139-3341    | 1    | Decal-Couplers, Quick |
| 6    | 105-4169    | 2    | Coupler-Female        |
| 7    | 32120-2     | 2    | Ring-Retaining        |
| 8    | 340-4       | 2    | Fitting-Straight      |
| 8:1  | 237-30      | 1    | O-Ring                |
| 8:2  | 237-79      | 1    | O-Ring                |
| 9    | 105-7962    | 2    | Plug-Dust             |
| 10   | 3234-4      | 2    | Screw-HHF             |
| 11   | 104-7201    | 2    | Nut-HF, NI            |
| 12   | 105-4170    | 1    | Coupler-Male          |
| 13   | 105-7963    | 1    | Cap-Dust              |
| 14   | 340-89      | 1    | Fitting-HYD, 45 DEG   |
| 14:1 | 237-30      | 1    | O-Ring                |
| 14:2 | 237-80      | 1    | O-Ring                |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 15   | 121-9864    | 1    | Tube-HYD             |
| 16   | 121-9865    | 1    | Tube-HYD             |
| 17   | 94-2691     | 2    | Screw-HWH            |
| 18   | 107-1136    | 1    | Hose ASM             |
| 19   | 99-6929     | 2    | Fitting-Elbow45      |
| 19:1 | 237-80      | 1    | O-Ring               |
| 20   | 2412-36     | 2    | Clamp-Hose           |
| 21   | 2412-129    | 4    | Clamp-Hose           |
| 22   | 121-9891    | 1    | Fitting-Tee          |
| 22:1 | 237-146     | 1    | O-Ring               |
| 23   | 87-8170     | 1    | Fitting-90           |
| 23:1 | 237-80      | 1    | O-Ring               |
| 24   | 105-4232    | 1    | Switch               |
| 25   | 105-8513    | 1    | Harness-Wire         |
| 26   | 115-7756    | 1    | Decal-HYD, High Flow |
| 27   | 127-8606    | 1    | HYD Hose ASM         |
| 28   | 127-8607    | 1    | HYD Hose ASM         |
| 29   | 127-8722    | 1    | Hose-HYD             |
| 30   | 127-8723    | 1    | Hose-HYD             |
| 31   | 340-138     | 1    | Fitting-HYD, 45 DEG  |



## High Flow Hydraulic Assembly (continued)


| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 31:1 | 237-79      | 1    | O-Ring      |
| 31:2 | 237-22      | 1    | O-Ring      |



## Hydraulic Manifold Assembly No. 115-2252


| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    |             | 1    | Housing ●                  |
| 2    | 110-8905    | 1    | Valve-Relief, Solenoid     |
| 2:1  | 110-6316    | 1    | Seal Kit                   |
| 2:2  | 130-8180    | 1    | Nut-Coil (9/16-24 Unef-2B) |
| 3    | 115-3021    | 1    | Coil-12V                   |

● Not serviced separately



## Hydraulic Pump Assembly No. 115-7787

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 115-8696    | 1    | Seal Kit         |
| 2    | 115-8697    | 1    | Seal Kit         |
| 7    | 136-1197    | 1    | Shaft-Drive      |
| 8    | 136-1198    | 1    | Gear-Drive       |
| 26   | 115-7855    | 1    | Key-Square       |
| 29   | 119-0653    | 1    | Coupling-Splined |



## Electrical Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 122-0089    | 1    | Harness-Wire, Rear      |
| 1:10 | 100-4918    | 1    | Diode                   |
| 1:13 | 121-8870    | 1    | Fuse-Mini Blade, 30 Amp |
| 1:19 | 121-8867    | 1    | Fuse-Mini Blade, 15 Amp |
| 1:20 | 32180-101   | 2    | Cover-Fuse, Single      |
| 2    | 122-1449    | 1    | Harness-Wire, Front     |
| 2:8  | 121-8866    | 4    | Fuse-Mini Blade, 10 Amp |
| 2:9  | 121-8867    | 3    | Fuse-Mini Blade, 15 Amp |
| 2:10 | 121-8870    | 1    | Fuse-Mini Blade, 30 Amp |
| 2:11 | 100-4918    | 6    | Diode                   |
| 2:19 | 32180-156   | 1    | Cap-Plug, 6 Way         |

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 3    | 121-9893    | 1    | Bracket-Relay          |
| 4    | 99-7435     | 1    | Relay                  |
| 5    | 99-7430     | 4    | Relay-Mini             |
| 6    | 32144-112   | 3    | Screw-HWH              |
| 7    | 3290-379    | 1    | Tie-Cable              |
| 9    | 32144-4     | 2    | Screw-HWH              |
| 10   | 42862       | 1    | Block-Terminal, Ground |
| 11   | 32105-13    | 4    | Screw-HWH              |
| 12   | 3290-148    | 4    | Nut-HF                 |
| 13   | 42863       | 1    | Strip-Jumper           |



# Attachments and Accessories

## For 07390TC Workman HDX-Auto Utility Vehicle

| Product Name                                                                  | Model/Part |
|-------------------------------------------------------------------------------|------------|
| Full Area Flatbed .....                                                       | 07301      |
| Full Area Flatbed Side Kit .....                                              | 07302      |
| Fold Down Side Kit .....                                                      | 07303      |
| 2/3 Area Flatbed .....                                                        | 07321      |
| 2/3 Area Flatbed Side Kit .....                                               | 07322      |
| Bed Liner .....                                                               | 07331      |
| 1/3 Area Flatbed .....                                                        | 07341      |
| 1/3 Area Platform Lift .....                                                  | 07347      |
| Heater Kit.....                                                               | 07349      |
| Canopy .....                                                                  | 07372      |
| Windshield .....                                                              | 07373      |
| 4 Post Roll-Over Protection System.....                                       | 07378      |
| 4-Wheel Drive Kit.....                                                        | 07391      |
| Cab Kit.....                                                                  | 07392      |
| Door Kit with Sliding Window .....                                            | 07393      |
| High Range Lockout Kit, 2015 and after Workman HDX-Auto Utility Vehicle ..... | 07394      |
| High-Flow Hydraulics Kit.....                                                 | 07395      |
| Hand Throttle Kit.....                                                        | 07420      |
| Aggressive Tire Kit.....                                                      | 07422      |
| Premium All Season Hydraulic Fluid (55 Gallon Drum) .....                     | 108-1177   |
| Premium All Season Hydraulic Fluid (5 Gallon Pail) .....                      | 108-1178   |
| Premium Transmission/Hydraulic Tractor Fluid (55 Gallon Drum).....            | 108-1183   |
| Premium Transmission/Hydraulic Tractor Fluid (5 Gallon Pail) .....            | 108-1184   |
| Premium All Purpose Grease (Tube) .....                                       | 108-1190   |
| Premium All Season Gear Lube (Quart) .....                                    | 108-1590   |
| Filter-Oil .....                                                              | 108-3847   |
| Remote Hydraulics Manifold Kit.....                                           | 110-2626   |
| Tire-Rear, 24x13-12 .....                                                     | 110-5132   |
| Wheel-12in x 8.0in .....                                                      | 114-8260   |
| Wireless Hourmeter .....                                                      | 115-4754   |
| Horn Kit.....                                                                 | 115-7825   |
| Side Mirror Kit.....                                                          | 115-7849   |
| Roll-Over Protection System Signal Kit.....                                   | 117-4825   |
| Worklight Kit .....                                                           | 117-4827   |
| Remote Hydraulic Float Kit .....                                              | 117-4828   |
| Receiver Hitch Kit .....                                                      | 117-4831   |
| Trailer Signal Kit .....                                                      | 117-4836   |
| Manual 4-Wheel Drive Control Kit.....                                         | 119-0817   |
| Canopy for Four-Post Roll-Over Protection System Kit.....                     | 119-9457   |
| Road Light and Homologation Kit .....                                         | 120-5030   |
| Brake and Signal Light Kit.....                                               | 120-5045   |
| Premium Engine Oil 10w30 (55 Gallon Drum) .....                               | 121-6392   |
| Premium Engine Oil 10w30 (5 Gallon Pail) .....                                | 121-6393   |
| Trailer Brake Kit .....                                                       | 125-0123   |
| Backup Alarm Kit .....                                                        | 127-8729   |
| 1/3 Area Cover Kit .....                                                      | 127-8739   |

## Attachments and Accessories (continued)

|                                                                                        |          |
|----------------------------------------------------------------------------------------|----------|
| High Air Intake Kit .....                                                              | 127-8740 |
| Exterior Mirror Kit .....                                                              | 130-5448 |
| Interior Mirror Kit .....                                                              | 130-5449 |
| Beacon Kit .....                                                                       | 130-5484 |
| Work Light Kit .....                                                                   | 130-5485 |
| Windshield Washer Fluid Kit, 2015 and after Workman MD/HD Series Utility Vehicle ..... | 130-5615 |
| MVP Kit 400 Hour Filter Kit .....                                                      | 131-8276 |
| Tire/Wheel ASM (24 X 13-12) .....                                                      | 131-8432 |
| LED Worklight Kit .....                                                                | 133-0554 |
| Alternator Kit, Workman HDX-Auto Utility Vehicle .....                                 | 133-0575 |
| ROPS Beacon Kit .....                                                                  | 133-0609 |
| Bracket-light, Canopy .....                                                            | 133-0627 |
| Wheel/Tire ASM, A502 (20X9-12)Semi-Aggressive .....                                    | 136-6308 |
| Wheel/Tire ASM, K502 (24X12-12)Semi-Aggressive .....                                   | 136-6309 |
| Wheel/Tire ASM, A404 (20X9-12)Smooth .....                                             | 136-6334 |
| Wheel/Tire ASM, A404 (24X12-12)Smooth .....                                            | 136-6335 |
| Wireless Hourmeter Kit .....                                                           | 138-5655 |
| Multi Pro WM Turf Sprayer .....                                                        | 41240    |
| Spreader Base Unit .....                                                               | 41253    |
| Vicon Spreader .....                                                                   | 41256    |
| Topdresser 1800 .....                                                                  | 44225    |
| Core Harvester Adapter Kit .....                                                       | 44242    |
| Pro Force Debris Blower .....                                                          | 44552    |
| Pro Force Debris Blower .....                                                          | 44553    |
| Pro Force Debris Blower .....                                                          | 44554    |
| ProPass 200 Top Dresser with Twin Spinner .....                                        | 44701    |
| ProPass 200 Top Dresser with Twin Spinner and Wireless Control .....                   | 44751    |
| 12 Inch Rear Wheel Weights .....                                                       | 81115    |
| Automatic Tailgate Release Kit .....                                                   | 92-1220  |
| Fuse Block .....                                                                       | 92-2641  |
| Topdresser 1800 Lift Kit .....                                                         | 92-4452  |
| Spark Arrestor Screen .....                                                            | 94-8157  |
| Tire-Rear, 23x8.50-12 .....                                                            | 98-2993  |
| Tire-Rear, Industrial .....                                                            | 99-1091  |

**Notes:**



**Count on it.**