



# 42 Inch Single Stage Snowthrower

## Wheel Horse® 300 Series

### Garden Tractor Attachment

Model No. 79362—220000001 and Up

## Parts Catalog

### Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.


Contents

| Description                               | Page | Description | Page |
|-------------------------------------------|------|-------------|------|
| Housing and Attachment Assembly . . . . . | 3    |             |      |
| Chute and Rotation Assembly . . . . .     | 4    |             |      |
| Auger and Drive Assembly . . . . .        | 5    |             |      |

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


| Abbreviation    | Meaning                           | Abbreviation   | Meaning                 |
|-----------------|-----------------------------------|----------------|-------------------------|
| AR . . . . .    | as required                       | HYD . . . . .  | hydraulic               |
| ASM . . . . .   | assembly                          | INC . . . . .  | incorporated            |
| CARR . . . . .  | carriage                          | LH . . . . .   | left hand               |
| DEG . . . . .   | degrees                           | NI . . . . .   | nylon insert            |
| FH . . . . .    | flat head                         | PPH . . . . .  | Phillips pan head       |
| GA . . . . .    | gauge                             | PTH . . . . .  | Phillips truss head     |
| HF . . . . .    | hex flange                        | PTO . . . . .  | power take off          |
| HH . . . . .    | hex head                          | RH . . . . .   | right hand              |
| HHF . . . . .   | hex head flange                   | SFH . . . . .  | slotted fillister head  |
| HLH . . . . .   | hex lag head                      | SHH . . . . .  | slotted hex head        |
| HJ . . . . .    | hex jam                           | SQH . . . . .  | square head             |
| HOC . . . . .   | height-of-cut                     | SHWH . . . . . | slotted hex washer head |
| HS . . . . .    | hex socket                        | SPH . . . . .  | slotted pan head        |
| HSBH . . . . .  | hex socket button head            | SRH . . . . .  | slotted round head      |
| HSFH . . . . .  | hex socket flat head              | STD . . . . .  | standard                |
| HSH . . . . .   | hex socket head                   | TAP . . . . .  | self tapping            |
| HWH . . . . .   | hex washer head                   | TTH . . . . .  | Torx truss head         |
| HWHTF . . . . . | hex washer head<br>thread forming | WH . . . . .   | wing head               |



Sheet No.:2

## Housing and Attachment Assembly

| Ref. No. | Part No.   | Qty. | Description           | Ref. No. | Part No. | Qty. | Description |
|----------|------------|------|-----------------------|----------|----------|------|-------------|
| 1        | 104604-01  | 1    | Frame-Mounting        | 25       | 323-6    | 4    | Screw-HH    |
| 2        | 3296-39    | 18   | Nut-Lock, NI          | 26       | 9335054  | 1    | Pin-Hair    |
| 4        | 3256-24    | 13   | Washer-Flat           |          |          |      |             |
| 5        | 92-8748    | 1    | Decal-Attachment      |          |          |      |             |
| 6        | 93-1616-01 | 1    | Plate-Extension       |          |          |      |             |
| 7        | 3231-2     | 13   | Screw-CARR            |          |          |      |             |
| 9        | 93-1617-01 | 2    | Plate-Extension, RH   |          |          |      |             |
| 10       | 3229-25    | 9    | Screw-CARR            |          |          |      |             |
| 11       | 79-6170-01 | 1    | Scraper-Reversible    |          |          |      |             |
| 12       | 3256-22    | 9    | Washer-Flat           |          |          |      |             |
| 13       | 3296-42    | 9    | Nut-Lock, NI          |          |          |      |             |
| 14       | 3256-27    | 1    | Washer-Flat           |          |          |      |             |
| 15       | 9335064    | 1    | Pin-Cotter, Hair      |          |          |      |             |
| 16       | 93-1620-01 | 2    | Skid                  |          |          |      |             |
| 17       | 105-1401   | 1    | Lift Tube W/Decal ASM |          |          |      |             |
| 17:2     | 86-5100    | 1    | Decal - Warning       |          |          |      |             |
| 18       | 3256-28    | 2    | Washer-Flat           |          |          |      |             |
| 19       | 101461-01  | 1    | Rod-Lift              |          |          |      |             |
| 20       | 100653     | 1    | Eyebolt               |          |          |      |             |
| 21       | 4629       | 1    | Spring                |          |          |      |             |
| 22       | 92-7299    | 1    | Auger W/Decals ASM    |          |          |      |             |
| 22:2     | 63-2380    | 2    | Decal-Danger          |          |          |      |             |
| 22:3     | 92-8652    | 1    | Decal-Warning         |          |          |      |             |
| 22:4     | 86-5100    | 1    | Decal - Warning       |          |          |      |             |




Sheet No.:3

## Chute and Rotation Assembly

| Ref. No. | Part No.   | Qty. | Description           |
|----------|------------|------|-----------------------|
| 1        | 3290-320   | 1    | Retainer-Push On      |
| 2        | 40-8230    | 1    | Grip-Chute Control    |
| 3        | 32121-50   | 1    | Pin-Spring            |
| 4        | 3230-2     | 1    | Screw-CARR            |
| 5        | 3256-24    | 5    | Washer-Flat           |
| 6        | 3296-39    | 6    | Nut-Lock, NI          |
| 7        | 3296-29    | 7    | Nut-Lock, NI          |
| 8        | 3256-23    | 6    | Washer-Flat           |
| 10       | 3230-1     | 3    | Screw-CARR            |
| 11       | 26-1110-01 | 1    | Extender-Chute, Upper |
| 12       | 322-2      | 3    | Screw-HH              |
| 13       | 94-1832    | 1    | Chute                 |
| 13:2     | 94-8079    | 1    | Decal-Danger          |
| 15       | 20-4320    | 2    | Washer-Rubber         |
| 16       | 3231-2     | 2    | Screw-CARR            |
| 17       | 3290-340   | 2    | Washer-Belleville     |
| 18       | 11-7120-01 | 1    | Deflector             |
| 19       | 94-9787-01 | 1    | Shield-Deflector      |
| 20       | 27-0220    | 6    | Screw-Special         |
| 21       | 78-0160-01 | 1    | Chute Swivel Ring     |
| 22       | 25-5450    | 3    | Retainer-Chute        |
| 23       | 78-0330-01 | 1    | Adapter               |
| 24       | 9202414    | 2    | Washer-Spacer         |
| 25       | 3272-10    | 1    | Pin-Cotter            |
| 26       | 3290-212   | 1    | Washer-Spring         |

| Ref. No. | Part No.    | Qty. | Description       |
|----------|-------------|------|-------------------|
| 27       | 79-3770-03  | 1    | Bracket-Worm      |
| 28       | 8-8600      | 1    | Gear-Worm, Chute  |
| 29       | 78-7430     | 1    | Rod               |
| 30       | 94-2686     | 1    | Joint-Universal   |
| 31       | 9335054     | 1    | Pin-Hair          |
| 32       | 104-4695-01 | 1    | Crank Support ASM |
| 33       | 51-2650     | 1    | Rod-Chute Control |
| 34       | 323-6       | 2    | Screw-HH          |
| 35       | 3290-238    | 1    | Washer-Lock       |
| 36       | 32121-47    | 1    | Pin-Spring        |



Sheet No.:4

## Auger and Drive Assembly

| Ref. No. | Part No.   | Qty. | Description        |
|----------|------------|------|--------------------|
| 1        | 9266714    | 2    | Screw-HWH          |
| 2        | 3256-22    | 3    | Washer-Flat        |
| 3        | 109218     | 1    | Guard-Chain        |
| 4        | 3296-29    | 12   | Nut-Lock, NI       |
| 5        | 110569     | 2    | Bearing & Collar   |
| 6        | 3230-1     | 6    | Screw-CARR         |
| 7        | 110567     | 2    | Flange-Zerk Relube |
| 8        | 110568     | 2    | Flange             |
| 11       | 321-3      | 1    | Screw-HH           |
| 12       | 325-8      | 2    | Screw-HH           |
| 13       | 3256-26    | 4    | Washer-Flat        |
| 14       | 32149-2    | 1    | Nut                |
| 15       | 109244-01  | 1    | Guard-Chain        |
| 16       | 6417       | 2    | Spacer             |
| 17       | 93-1614    | 2    | Sprocket-Idler     |
| 18       | 3296-23    | 2    | Nut-Lock, NI       |
| 19       | 6416       | 1    | Chain              |
| 20       | 3256-28    | 4    | Washer-Flat        |
| 22       | 105-1478   | 1    | Auger ASM          |
| 22:2     | 101480     | 2    | Bearing-Ball       |
| 23       | 93-1618-01 | 2    | Support            |
| 24       | 94-7842    | 1    | Pulley - V         |
| 25       | 3242-2     | 2    | Screw-SQH          |
| 26       | 1005       | 1    | Key-Straight       |
| 27       | 113320-01  | 1    | Shaft-Drive        |
| 28       | 937089     | 1    | Key                |

| Ref. No. | Part No.   | Qty. | Description             |
|----------|------------|------|-------------------------|
| 29       | 78-0850-01 | 1    | Sprocket-Drive,14 Tooth |
| 30       | 3246-2     | 1    | Setscrew-HSH            |
| 31       | 78-7480    | 1    | Spring-Extension        |
| 32       | 92-7101    | 1    | Pulley-Flat Idler       |
| 33       | 323-9      | 1    | Screw-HH                |
| 34       | 323-10     | 1    | Screw-HH                |
| 35       | 7450-01    | 1    | Bracket-Retainer,Belt   |
| 36       | 104662     | 1    | Spacer                  |
| 37       | 7451       | 1    | Pulley-Idler            |
| 38       | 78-0480-01 | 1    | Arm-Idler               |
| 39       | 3296-39    | 2    | Nut-Lock, NI            |
| 40       | 9750       | 1    | V-Belt                  |
| 41       | 3272-7     | 1    | Pin-Cotter              |

## Maintenance Record

[illegible]

## Maintenance Record

[illegible]

