



# Spool Carrier Kit

## Dingo<sup>®</sup> Compact Utility Loader

Part No. 104–2661

## Parts Catalog

---

### Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.



Sheet No.:0

Spool Carrier Assembly

| Ref. No. | Part No.    | Qty. | Description      |
|----------|-------------|------|------------------|
| 1        | 104-0637    | 4    | Washer-Thrust    |
| 2        | 100-1663    | 2    | Pin-Snapper      |
| 3        | 104-0697-03 | 1    | Tube ASM         |
| 4        | 93-4696     | 2    | Pin-Snapper      |
| 5        | 104-0686-03 | 1    | Shaft ASM        |
| 6        | 32128-49    | 2    | Nut-HHF          |
| 7        | 104-0693-03 | 1    | Clamp ASM        |
| 8        | 104-0699    | 1    | U-Bolt           |
| 9        | 104-2730    | 2    | Down-Tie, Rubber |
| 10       | 104-8410    | 2    | Sheath-Bungi     |

| Ref. No. | Part No. | Qty. | Description |
|----------|----------|------|-------------|
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |
|          |          |      |             |