



Count on it.

Form No. 3435-867 Rev B

Parts Catalog

Work Lights Kit

**Groundsmaster® and Reelmaster® Traction
Units with Universal Sunshade**

Model No. 140-1554



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Sunshade Work Light Assembly No. 140-1554 Reelmaster 3XXX Installation 4

Sunshade Work Light Assembly No. 140-1554 Reelmaster 5XXX Installation 6

Sunshade Work Light Assembly No. 140-1554 Groundsmaster 4000/4100 Installation 8

Sunshade Work Light Assembly No. 140-1554 Groundsmaster 4500/4700, 7000 Installation. 10

Sunshade Work Light Assembly No. 140-1554 Groundsmaster 3280 Installation 12

Sunshade Work Light Assembly No. 140-1554 Groundsmaster 7200 Installation 14


Sunshade Work Light Assembly No. 140-1554 Groundsmaster 360 Installation 16

Sunshade Work Light Assembly No. 140-1554 Groundsmaster 5900 Installation 18

Sunshade Work Light Assembly No. 140-1554 Groundsmaster 3200/3300 Installation 20

Sunshade Work Light Assembly No. 140-1554

Reelmaster 3XXX Installation



RM3XXX WORK LIGHTS INSTALLATION

Sunshade Work Light Assembly No. 140-1554


Reelmaster 3XXX Installation (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-2696-03	2	Mount
2	140-6990	4	Light-Work, LED
3	108-6544	4	Spacer
4	3231-7	4	Screw-CARR
5	3231-22	4	Screw-CARR
6	104-8301	8	Nut-HF, NI
7	95-8999	1	Switch

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8	122-1765	1	Harness-Wire, Worklights
9	109355	1	Fuse-Blade, 15 Amp
10	3234-47	4	Screw-HHF
11	104-8300	4	Nut-HF, NI
13	144-3386-03	2	Mount-Work Lights
14	3290-378	6	Tie-Cable

Sunshade Work Light Assembly No. 140-1554

Reelmaster 5XXX Installation



RM5XXX WORK LIGHTS INSTALLATION


Sunshade Work Light Assembly No. 140-1554

Reelmaster 5XXX Installation (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-2696-03	2	Mount	8	122-1765	1	Harness-Wire, Worklights
2	140-6990	4	Light-Work, LED	9	109355	1	Fuse-Blade, 15 Amp
3	108-6544	4	Spacer	10	3234-47	4	Screw-HHF
4	3231-7	4	Screw-CARR	11	104-8300	4	Nut-HF, NI
5	3231-22	4	Screw-CARR	13	144-3386-03	2	Mount-Work Lights
6	104-8301	8	Nut-HF, NI	14	3290-378	6	Tie-Cable
7	95-8999	1	Switch				

Sunshade Work Light Assembly No. 140-1554

Groundsmaster 4000/4100 Installation



GM4000/4100 WORK LIGHTS INSTALLATION

Sunshade Work Light Assembly No. 140-1554


Groundsmaster 4000/4100 Installation (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-2696-03	2	Mount
2	140-6990	4	Light-Work, LED
3	108-6544	4	Spacer
4	3231-7	4	Screw-CARR
5	3231-22	4	Screw-CARR
6	104-8301	8	Nut-HF, NI
7	95-8999	1	Switch

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8	122-1765	1	Harness-Wire, Worklights
9	109355	1	Fuse-Blade, 15 Amp
10	3234-47	4	Screw-HHF
11	104-8300	4	Nut-HF, NI
13	144-3386-03	2	Mount-Work Lights
14	3290-378	6	Tie-Cable

Sunshade Work Light Assembly No. 140-1554

Groundsmaster 4500/4700, 7000 Installation



GM4500/4700, 7000 WORK LIGHTS INSTALLATION

Sunshade Work Light Assembly No. 140-1554


Groundsmaster 4500/4700, 7000 Installation (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-2696-03	2	Mount
2	140-6990	4	Light-Work, LED
3	108-6544	4	Spacer
4	3231-7	4	Screw-CARR
5	3231-22	4	Screw-CARR
6	104-8301	8	Nut-HF, NI
7	95-8999	1	Switch

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8	122-1765	1	Harness-Wire, Worklights
9	109355	1	Fuse-Blade, 15 Amp
10	3234-47	4	Screw-HHF
11	104-8300	4	Nut-HF, NI
13	144-3386-03	2	Mount-Work Lights
14	3290-378	6	Tie-Cable

Sunshade Work Light Assembly No. 140-1554

Groundmaster 3280 Installation



GM3280 WORK LIGHTS INSTALLATION


Sunshade Work Light Assembly No. 140-1554

Groundsmaster 3280 Installation (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-2696-03	2	Mount	8	122-1765	1	Harness-Wire, Worklights
2	140-6990	4	Light-Work, LED	9	109355	1	Fuse-Blade, 15 Amp
3	108-6544	4	Spacer	10	3234-47	4	Screw-HHF
4	3231-7	4	Screw-CARR	11	104-8300	4	Nut-HF, NI
5	3231-22	4	Screw-CARR	13	144-3386-03	2	Mount-Work Lights
6	104-8301	8	Nut-HF, NI	14	3290-378	6	Tie-Cable
7	95-8999	1	Switch				

Sunshade Work Light Assembly No. 140-1554

Groundmaster 7200 Installation



GM7200 WORK LIGHTS INSTALLATION

Sunshade Work Light Assembly No. 140-1554


Groundsmaster 7200 Installation (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-2696-03	2	Mount
2	140-6990	4	Light-Work, LED
3	108-6544	4	Spacer
4	3231-7	4	Screw-CARR
5	3231-22	4	Screw-CARR
6	104-8301	8	Nut-HF, NI
7	95-8999	1	Switch

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8	122-1765	1	Harness-Wire, Worklights
9	109355	1	Fuse-Blade, 15 Amp
10	3234-47	4	Screw-HHF
11	104-8300	4	Nut-HF, NI
13	144-3386-03	2	Mount-Work Lights
14	3290-378	6	Tie-Cable

Sunshade Work Light Assembly No. 140-1554

Groundsmaster 360 Installation



GM360 WORK LIGHTS INSTALLATION

Sunshade Work Light Assembly No. 140-1554


Groundsmaster 360 Installation (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-2696-03	2	Mount
2	140-6990	4	Light-Work, LED
3	108-6544	4	Spacer
4	3231-7	4	Screw-CARR
5	3231-22	4	Screw-CARR
6	104-8301	8	Nut-HF, NI
7	95-8999	1	Switch

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8	122-1765	1	Harness-Wire, Worklights
9	109355	1	Fuse-Blade, 15 Amp
10	3234-47	4	Screw-HHF
11	104-8300	4	Nut-HF, NI
13	144-3386-03	2	Mount-Work Lights
14	3290-378	6	Tie-Cable

Sunshade Work Light Assembly No. 140-1554

Groundmaster 5900 Installation



GM5900 WORK LIGHTS INSTALLATION

Sunshade Work Light Assembly No. 140-1554


Groundsmaster 5900 Installation (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-2696-03	2	Mount
2	140-6990	4	Light-Work, LED
3	108-6544	4	Spacer
4	3231-7	4	Screw-CARR
5	3231-22	4	Screw-CARR
6	104-8301	8	Nut-HF, NI
7	95-8999	1	Switch

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8	122-1765	1	Harness-Wire, Worklights
9	109355	1	Fuse-Blade, 15 Amp
10	3234-47	4	Screw-HHF
11	104-8300	4	Nut-HF, NI
13	144-3386-03	2	Mount-Work Lights
14	3290-378	6	Tie-Cable

Sunshade Work Light Assembly No. 140-1554

Groundsmaster 3200/3300 Installation



GM3200/3300 WORK LIGHTS INSTALLATION

Sunshade Work Light Assembly No. 140-1554

Groundsmaster 3200/3300 Installation (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-2696-03	2	Mount	8	122-1765	1	Harness-Wire, Worklights
2	140-6990	4	Light-Work, LED	9	109355	1	Fuse-Blade, 15 Amp
3	108-6544	4	Spacer	10	3234-47	4	Screw-HHF
4	3231-7	4	Screw-CARR	11	104-8300	4	Nut-HF, NI
5	3231-22	4	Screw-CARR	13	144-3386-03	2	Mount-Work Lights
6	104-8301	8	Nut-HF, NI	14	3290-378	6	Tie-Cable
7	95-8999	1	Switch				

Notes:

Notes:



Count on it.