




RADIUS® S-SERIES

Model No. RZS651GKA48CA3—Serial No. 413950474 and Up

Picture below may not reflect actual product.



Parts Manual

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Touch Up Paint


Exmark black touch up spray paint – gloss black.

Exmark red touch up paint (spray paint – P/N 1-850337 - .6 oz liquid bottle – P/N 103-9140).

Contents

Complete Deck Assembly	4
Deck Assembly	6
Deck W/Decals Assembly	8
Idler Arm Assembly	10
Main Frame Assembly	12
Frame w/Decals Assembly	14
Roll-Over Protection System Assembly	16
Front Caster and Fork Assembly	18
Caster Wheel Assembly	20
Caster Tire Assembly	22
Deck Lift Assembly	24
Deck Strut Assembly No. 140-1179	26
Control Panel Assembly	28
Motion Control Assembly	30
LH Motion Control Assembly	32
RH Motion Control Assembly	34
Rear Wheel Assembly	36
Seat Assembly	38
Seat Assembly (Continued)	40
Fuel Assembly	42
Engine Assembly	44
Transaxle Assembly	46
LH Transaxle Assembly	48
RH Transaxle Assembly	50
Electrical Assembly	52
Electrical Harness Assembly	54


Complete Deck Assembly



Complete Deck Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-8593	1	Deck-ASM

Figure 1 shows a perspective view of a U-shaped track 5. A vertical post 27 is positioned at the center of the track's opening. A horizontal bar 24 is attached to the post 27, extending across the top of the track's opening.



Deck Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-6558	1	ASM, 48" Deck W/Decals	20	103-6384	2	Blade-Solid ●
2	116-3344	2	ASM-Cutter Hsg With Bearings	20	103-6389	2	Blade, Low Lift ●
2:2	116-0720	2	Bearing-Ball	20	103-6394	2	Blade, Mulching ● ♦
2:3	116-3312	1	Spacer-Bearing	20	103-6404	2	Blade-Notched
3	103-1330	2	Guard-Bearing Top	21	103-3037	2	Bushing, Splined
4	116-3342	2	ASM-Spindle And Seal	22	109-9220	2	Screw-Sems 1/2-20 X 2.19 ■ □
5	109-6658	24	Nut-Nyloc 3/8-16 Flg	23	116-4589	2	Sheave-Blade Drive, 8.40
6	142-9262-01	1	Baffle-Discharge 48 2Blade	24	109-2523	1	Belt 46"
7	142-6530	1	ASM-Idler Arm W/Bearings	25	103-2802	2	Washer-Spring Disc 3/4
8	116-6317	1	Spring-Extension	26	116-7306	2	Nut-Hex 3/4-16 W/Patch ▲
9	126-4781-03	1	Step-Deck	27	323-38	1	Screw-HH 3/8-16 X 4 3/4
10	3230-3	1	Bolt-Carriage 5/16-18 X 1 1/4	28	3231-22	2	Bolt-Carriage 3/8-16 X 1
11	104-8300	2	Nut-Nyloc 5/16-18 Flg	29	3230-18	1	Bolt-Carriage 5/16-18 X 5/8
12	109-2872	1	Spacer-Pulley	30	142-7103	1	Shield, Rt
13	126-9197	1	Idler-Pulley, Flat 5.00X1.31	31	142-7102	1	Shield, Lt
14	3231-44	1	Bolt-Carriage 3/8-16 X 2 1/2	32	109-6982	2	Wireform-Cover
15	126-8043	1	Shield-Dust	33	98-5975	3	Washer-Spring Disc 3/8
16	126-9195	1	Shield-Guard, Dust	34	116-8131	3	Axle, Roller
17	126-9196	1	Idler-Pulley, Flat	35	116-9362	3	Screw-HH 3/8-16 X 3 3/4 GR 8
18	142-8544	1	Pin, Chute	36	103-8415	3	Roller-Anti-Scalp
19	142-7025	1	Chute-Deck Discharge	38	116-9981	3	Kit, Anti-Scalp Roller
20	116-5171	2	Blade-Extreme 2, 24.50" ●	39	146-0943	1	Retainer, Chute

● Optional Equipment


■ Torque to 50-60 ft-lb

▲ Torque to 130-160 ft-lb

♦ Requires installation of mulch kit for proper mulching. See your Exmark dealer for details.

□ Apply lubricant to threads as needed to prevent seizing. Copper based anti-seize preferable. Grease is an acceptable substitute.


Deck W/Decals Assembly



Deck W/Decals Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	109-6014	1	Decal-Routing, Belt	6	126-6464	2	Decal-Danger Thrown Objects
3	109-6036	1	Decal-Roller, Anti-Scalp	7	126-6746	1	Decal-Ultracut 48 Series 3
4	112-9028	2	Decal-Cover, Missing				
5	116-8283	1	Decal-Torque, Bolt				

Idler Arm Assembly




Idler Arm Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	142-5935	2	Bushing, Igus
3	142-6529	2	Spacer, Idler Pivot
4	32144-11	1	Screw-HWH

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	3256-24	1	Washer-Flat
6	126-1696	1	Screw-HWHTF
7	3256-3	1	Washer-Flat


Main Frame Assembly



Main Frame Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-8340	1	ASM, Frame W/ Decals	5	109-9233	2	Bumper-Push-In, Rubber
2	142-8704	1	ASM, ROPS	6	126-5491	2	Isolator
3	126-7064-01	1	Pan-Floor	7	104-8300	2	Nut-Nyloc 5/16-18 Flg
4	126-7065	2	Grommet-Rubber	11	126-8819	1	Decal-Exmark Logo

Frame w/Decals Assembly




Frame w/Decals Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	109-6014	1	Decal-Routing, Belt
3	116-8588	1	Decal-Release, Drive
4	142-7754	1	Decal-Warning(Aurora)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	126-4363	2	Decal-Warning
6	127-6618	1	Strip-Seal


Roll-Over Protection System Assembly



Roll-Over Protection System Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-8492	1	ASM, ROPS Upper W/ Decal	7	142-8824	2	Bolt,CARR, Spcl
1:2	107-3069	1	Decal-Warning	8	142-5261	2	Spring, ROPS
4	116-0104	2	Pin-Spring	9	142-7097	2	Screw
5	126-9866	2	Washer, Wave	10	142-5250	4	Spacer, ROPS
6	126-9821	2	Nut, ROPS Pivot	11	142-9547	4	Bolt, Shoulder
				12	142-9550	4	Washer, Belleville

Front Caster and Fork Assembly




Front Caster and Fork Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	109-3678	4	Bearing-Ball
2	126-5897	2	Spring
3	142-8137	2	ASM-Front Caster W/Fork

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	3256-68	2	Washer-Flat
5	3234-5	2	Screw-HH Flg 5/16-18 X 3/4
6	144-0375	2	Cap, Grease


Caster Wheel Assembly



Caster Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	126-3289	1	ASM-Wheel And Tire 13X6.50-6	3	126-5389	1	Screw-HHF
2	142-7827-01	1	Fork-Caster	4	127-0068	1	Spanner-Wheel, Caster
				5	99-5107	1	Nut-Lock 1/2-13


Caster Tire Assembly



Caster Tire Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	126-5959	1	Tire	5	5108	1	Valve
3	130-0705	2	Bushing-Flange	6	120-7125	1	Fitting-Zerk
4	135-4489	2	Bearing-Roller, Wheel				


Deck Lift Assembly



Deck Lift Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-5872	4	Bearing-Flange	13	1-373034	2	Washer
2	116-2887	4	Gusset-Lift, Deck	14	109-6658	2	Nut-Nyloc 3/8-16 Flg
3	3230-22	8	Bolt-Carriage 5/16-18 X 1 Sp	15	126-5221	1	Spacer-Stepped
4	104-8300	8	Nut-Nyloc 5/16-18 Flg	16	142-8481	1	Latch, Transport
5	135-5083-03	1	Shaft-Decklift Front	17	126-5593	1	Grommet
6	135-5081-03	1	Shaft-Decklift Rear	18	142-8482	1	Linkage, Transport
7	135-5079-03	1	Link-Decklift	19	126-5401	1	Pin-HOC
8	126-4535	1	Bracket ASM	20	3218-1	1	Nut-Jam 1/4-20
8:1	126-4784	1	Decal-HOC	21	126-7019	1	Knob
9	142-8483-03	1	Plate, HOC Lower	22	126-8353	1	Tag-Retention, Magnetic
10	126-8877	4	Deck Chain ASM	23	104-8301	2	Nut-Nyloc 3/8-16 Flg
10:1	1-633447	1	Chain-Lift, Deck	24	135-0313	1	Screw-CARR
10:2	130-0742	2	Bolt-Shoulder	25	3231-42	1	Bolt-Carriage 3/8-16 X 3
10:3	104-8301	2	Nut-Nyloc 3/8-16 Flg	26	142-7110	2	Spacer, HOC
10:4	43-0940	2	Spacer	27	142-7785	2	Screw-Hex
11	126-8365	1	Deck Strut ASM	28	142-7784	2	Nut-HF, NI
12	3231-40	2	Bolt-Carriage 3/8-16 X 2 1/4	29	142-8484	1	Spring, Extension


Deck Strut Assembly No. 140-1179



Deck Strut Assembly No. 140-1179 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	126-8360	4	Bushing-Rubber, Suspension	4	3231-7	2	Screw-CARR
3	108-6544	4	Spacer	5	2844	2	Washer
				6	104-8301	2	Nut-HF, NI

Control Panel Assembly




Control Panel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-8529	1	Cable-Control, Throttle	14:2	142-8540	1	Decal-Control Panel
2	142-8530	1	Cable-Control, Choke	15	142-8471	1	Cover, Motion Control, Rt
3	142-8345	1	ASM, Rear Guard W/ Decals	16	142-8472	1	Cover, Motion Control, Lt
3:2	133-8062	1	Decal-Arrestor, Spark	17	142-8234	2	Decal-S-Series
3:3	106-5517	2	Decal-Warning	18	135-1929	4	Bolt-CARR
4	142-8271-03	1	Guard, Muffler	19	126-6268	2	Screw-Truss HD 5/16-18 X 3/4 Torx Plus
5	142-8477	4	Screw, Taptite	20	126-6266	4	Screw-1/4-20 X .65 Torx Plus
6	126-6267	4	Screw-Truss HD 5/16-18 X 2 3/4 Torx Plus	21	136-4195	2	Screw-Shoulder 1/4-20 X 1.15
7	104-8300	6	Nut-Nyloc 5/16-18 Flg	22	126-5544	4	Screw-HWH #10-14 X 1/2 Torx
8	142-8346-03	1	Bracket, Pod, Rt	23	3296-2	4	Nut-Nyloc #10-24
9	142-8347-03	1	Bracket, Pod, Lt	24	135-2015	2	Screw-Shoulder
10	142-8329	1	Guard, Upper, Lt	25	126-6877	1	Decal, Exmark Logo
11	142-8328	1	Guard, Upper, Rt	26	32180-030	1	Clip-Tie
12	142-8620	1	ASM, Pod Lt	27	146-0012	2	Screw-Plastic, HWH
12:2	142-8476	1	Fender, Lt	28	146-1840	1	ASM-Control Panel W/Decal ●
12:3	146-0013	3	Screw-Torx	28:2	146-1836	1	Decal-Control Panel ●
13	142-8621	1	ASM, Pod Rt				
13:2	142-8475	1	Fender, Rt				
13:3	146-0013	3	Screw-Torx				
14	142-8474	1	ASM-Control Panel W/Decal				

● Used with 103-5221 Switch-PTO

Motion Control Assembly




Motion Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	104-8300	4	Nut-Nyloc 5/16-18 Flg	18	142-7992	1	ASM, Motion Control W/ Grip, Rt
2	104-8301	3	Nut-Nyloc 3/8-16 Flg	18:2	126-7359	1	Grip
3	107-1045	1	Spring-Extension	19	142-7991	1	ASM, Motion Control W/ Grip, Lt
4	109-7694	2	Spring-Compression	19:2	126-7359	1	Grip
5	112-3306	2	Nut	20	126-7217	2	Linkage-Brake, Lower
6	115-5099	2	Bolt-Pivot	21	142-8325	1	ASM, Motion Control Lt
7	119-1415	4	Pin-Cotter, Locking	22	142-8326	1	ASM, Motion Control Rt
8	323-8	1	Screw-HH 3/8-16 X 1 1/2	23	1-303105	1	Yoke-Adjustable
9	119-4164	1	Washer-Wave	24	1-808280	1	Pin-Clevis 5/16 X 1 49/64
10	126-4299	2	Screw-HSBH	25	32120-47	1	Ring-Retaining
11	142-6851	2	Damper	26	110-5052	4	Screw-HHF
12	126-4424	4	Screw-HHF Shoulder 3/8-16 X 3/4 Tf	27	37-8771	2	Screw-Shoulder 5/16-18 X 5/8
13	126-5813	1	Shaft-Brake	28	126-6266	2	Screw-1/4-20 X .65 Torx Plus
14	126-5819	1	Linkage-Brake, Upper	29	126-5820	1	Bearing-Spherical
15	126-5989	1	Pivot-Flange	30	2844	1	Washer
16	126-9490	1	Lever-Brake (With Grip)				
17	126-6456	1	Bracket-Brake				
17:2	126-5820	1	Bearing-Spherical				

LH Motion Control Assembly

For Serial Nos. 413,950,474–414,538,454




LH Motion Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	126-3773	1	Control Arm ASM	10	104-8300	2	Nut-Nyloc 5/16-18 Flg
1:2	126-8909	2	Bushing	11	126-8195	1	Spring-Return, Neutral
1:3	1-413152	2	Bushing-Sleeve	12	3256-24	1	Washer-3/8 SAE
2	142-8478	1	Spacer, Anti-Rotation	13	117-1198	1	Bolt-Pivot
3	126-7296	2	Washer-Friction	14	119-8925	1	Washer-Belleville
4	142-8339	1	Lever, Motion Control	15	117-1240	1	Washer
5	119-8925	1	Washer-Belleville	16	126-7296	1	Washer-Friction
6	142-5951	1	Bolt-Pivot	17	3256-24	1	Washer-3/8 SAE
7	32152-2	1	Nut-Hex 3/8-16 Lock	18	32152-2	1	Nut-Hex 3/8-16 Lock
8	126-5435	1	Link-Control	19	3218-3	1	Nut-Jam 3/8-16
9	126-5434	1	Swivel				

RH Motion Control Assembly

For Serial Nos. 413,950,474–414,538,454




RH Motion Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	126-3773	1	Control Arm ASM
1:2	126-8909	2	Bushing
1:3	1-413152	2	Bushing-Sleeve
2	142-8478	1	Spacer, Anti-Rotation
3	126-7296	2	Washer-Friction
4	142-8339	1	Lever, Motion Control
5	119-8925	1	Washer-Belleville
6	142-5951	1	Bolt-Pivot
7	32152-2	1	Nut-Hex 3/8-16 Lock
8	126-5435	1	Link-Control
9	126-5434	1	Swivel

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
10	104-8300	2	Nut-Nyloc 5/16-18 Flg
11	126-8195	1	Spring-Return, Neutral
12	3256-24	1	Washer-3/8 SAE
13	117-1198	1	Bolt-Pivot
14	119-8925	1	Washer-Belleville
15	117-1240	1	Washer
16	126-7296	1	Washer-Friction
17	3256-24	1	Washer-3/8 SAE
18	32152-2	1	Nut-Hex 3/8-16 Lock
19	3218-3	1	Nut-Jam 3/8-16


Rear Wheel Assembly



Rear Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-8201	2	Wheel And Tire ASM	1:3	5108	1	Valve
1:1	142-4284	1	Tire	2	242-50	8	Nut-Lug
1:2	142-8188	1	Wheel				


Seat Assembly



Seat Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-9275-03	1	Support, Seat	6	135-0505	2	Bumper-Seat
2	146-0185	1	Seat, Susp.	7	3230-22	2	Bolt-Carriage 5/16-18 X 1 Sp
3	104-8300	6	Nut-Nyloc 5/16-18 Flg	8	126-9082	1	Decal-Radius Logo
4	135-7047	1	Bumper-Rubber	9	142-8229	1	Decal-Service Aid
5	3296-47	1	Nut-Nyloc 5/16-18 Thin				

Seat Assembly (Continued)




Seat Assembly (Continued) (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	126-8558	1	Tracks-4" Travel
2	146-0290	1	Cover, Lower
3	146-0291	1	Cover, Upper
4	121-3658	1	RH Arm Rest Kit
4:1	110-4163	1	Cushion-Rest, Arm
5	121-3660	1	LH Arm Rest Kit

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5:1	110-4163	1	Cushion-Rest, Arm
7	126-8560	1	Kit-Seat Belt
8	116-8911	1	Knob-Adjuster
9	82-2190	1	Switch
10	126-8559	1	Bellows-Seat
11	26-4840	4	Spacer-Pin, Mounting


Fuel Assembly



Fuel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-8619	1	ASM-Fuel Tank	4	126-8740	1	Fuel Hose ASM
2	135-4801	1	Cap-Fuel, Ratcheting	4:1	109-0302	1	Hose-Fuel
3	146-1015	1	Vent Hose ASM	4:2	109-0678	1	Hose-Fuel
3:1	115-7872	1	Hose-Fuel	4:3	1-603770	1	Valve-Fuel
3:2	108-6344	1	Hose-LP	4:4	2412-98	4	Clamp-Hose
3:3	120-2234	1	Fitting-Tee	5	126-5523	3	Clip
3:4	126-9067	1	Clamp Hose	6	1-303287	1	Tie-Cable 5 1/2 (Small)
3:5	130-7714	1	Hose-Fuel	7	116-4464	1	Plug-Port
3:6	2412-80	1	Clamp-Hose				

Engine Assembly




Engine Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1		1	Engine-Kawasaki, Fx651V ■	12	142-6547	1	ASM, Pump Idler
1:1		1	Kawasaki 49065-7007	12:2	142-8477	1	Screw, Taptite
			Engine Oil Filter ■▲	12:3	142-5935	2	Bushing, Igus
1:2		1	Kawasaki 49019-7005 Fuel	12:4	142-6529	1	Spacer, Idler Pivot
			Filter ■▲	13	116-2456	2	Pulley-Flat Idler
1:3		1	Kawasaki 11013-7045	14	3231-29	2	Bolt-Carriage 3/8-16 X 1 3/4
			Safety Filter ■▲	15	3231-9	1	Bolt-Carriage 3/8-16 X 2 3/4
1:4		1	Kawasaki 11013-7044	16	104-8301	3	Nut-Nyloc 3/8-16 Flg
			Engine Air Filter ■▲	17	1-603402	1	Spring-Extension
2	1-653313	2	Gasket-Exhaust	18	126-5993	1	Belt-V
3	142-8275	1	Sheave, Engine	19	116-4924	1	Asm-Hose Oil Drain W/Plug
4	1-807259	1	Key-Machine 1/4 X 1/4 X 1	19:1	353-508	1	Plug-W/O-Ring ●
5	146-0187-03	1	Anchor-Clutch	19:1:1	237-42	1	O-Ring
6	98-5975	4	Washer-Spring Disc 3/8	20	142-9154	1	Muffler, Kawasaki
7	323-7	4	Screw-HH 3/8-16 X 1 1/4	21	3256-22	1	Washer-1/4 SAE
8	126-8926	1	Clutch	22	3217-5	1	Nut-Hex 1/4-20
9	109-6919	1	Washer-Clutch	23	114-3550	4	Washer-Spring Lock M8
10	1-603610	2	Washer-Spring Disc 7/16	24	114-3549	4	Nut-M8
11	109-9762	1	Screw-HH 7/16-20 X 2				
			W/Loctite				

● Torque to 24-26 ft-lb
▲ Obtain parts from www.kawpower.com

■ Not serviced separately


Transaxle Assembly



Transaxle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-6317	1	Transaxle ASM	8	116-6833	1	Shaft-Spacer
2	142-6318	1	Transaxle ASM	9	1-303334	4	Washer-Spring Disc 5/16
3	104-8300	8	Nut-Nyloc 5/16-18 Flg	10	94-7972	2	Screw-HH W/Loctite
4	126-4687	4	Screw-HHF	11	109-5395	2	Arm-Bypass, Hydro
5	3230-7	2	Bolt-Carriage 5/16-18 X 2 1/4	12	3229-1	2	Bolt-Carriage 1/4-20 X 3/4
6	142-8480	2	Spacer, Hydro	13	108-6402	2	Knob-Handle
7	3230-30	2	Bolt-Carriage 5/16-18 X 4 1/2	14	1-806003	2	Hairpin-Cotter
				15	3256-4	2	Washer-3/8 Std

LH Transaxle Assembly




LH Transaxle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	114-8465	1	Charge Kit	8	116-6214	1	Cap-Axle, Long
1:3	109-3540	1	O-Ring-Charge Seal Cover	9	135-7347	1	Fan And Pulley Kit
2	109-3321	1	Filter-Hydraulic	9:1	116-9714	1	Nut-HJ
3	120-7979	1	Guard-Filter, LH	9:2	126-0226	1	Fan
4	109-3540	1	O-Ring-Charge Seal Cover	10	109-5592	1	Spring
5	116-6213	1	Tube-Axle	99	135-3604	1	Brake Shaft Seal Kit ●
6	116-3872	1	Hub-Offset	99	109-3537	1	Seal Kit ●
7	109-3536	1	Nut-Hub				

● Not illustrated

RH Transaxle Assembly




RH Transaxle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	114-8465	1	Charge Kit	8	116-6214	1	Cap-Axle, Long
1:3	109-3540	1	O Ring-Seal	9	135-7347	1	Fan And Pulley Kit
2	109-3321	1	Element-Oil Filter, HYD	9:1	116-9714	1	Nut-HJ
3	120-7981	1	Guard-Filter, RH	9:2	126-0226	1	Fan
4	109-3540	1	O Ring-Seal	10	109-5592	1	Spring-Extension
5	116-6213	1	Tube-Axle	99	135-3604	1	Brake Shaft Seal Kit ●
6	116-3872	1	Hub-Offset	99	109-3537	1	Seal Kit ●
7	109-3536	1	Nut-Hub				

● Not illustrated

Electrical Assembly



Electrical Assembly (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	142-9137	1	Harness-Main ▲	12	33114-020	1	Screw-HH M8-1.25 X 20Mm
2	126-6725-03	1	Tray-Battery	13	139-6368	1	Switch-Rocker, On-None-On
3	99-7421	1	Battery - Wet (300 CCA, 12 V)	14	137-4100	1	Switch-Ignition
4	142-8697	1	Strap, Bungee	15	1-603511	1	Key-Ignition
5	3256-22	2	Washer-1/4 SAE	15	103-2106	1	Key-Exmark Logo
6	321-4	2	Screw-HH 1/4-20 X 3/4	16	116-5609	1	Module ASM
7	32128-33	2	Nut-Whizlock 1/4-20	17	126-6267	2	Screw-Truss HD 5/16-18 X 2 3/4 Torx Plus
8	110-6765	1	Switch	18	104-8300	2	Nut-Nyloc 5/16-18 Flg
9	82-2190	2	Switch	25	103-5221	1	Switch-PTO ■
10	126-6266	1	Screw-1/4-20 X .65 Torx Plus	26	146-2055	1	Harness-Main ●▲■
11	33094-00	1	Washer				

● Not illustrated

■ Used with 103-5221 Switch-PTO

▲ Use dielectric grease on all unsealed connectors and terminals only. Do not apply in sealed connectors.

Electrical Harness Assembly



Electrical Harness Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	126-3991	1	Relay-Micro
6	121-8867	1	Fuse-Mini Blade, 15 Amp
7	121-8868	1	Fuse-Mini Blade, 20 Amp
8	103-3895	1	Diode
9	126-8876	1	Insulator-Battery

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
10	1-543393	1	Insulator-Solenoid
11	116-0053	1	Cap-Plug
13	32180-037	1	Clip-Harness
14	32180-176	1	Cover-Block, Fuse
15	32180-177	1	Clip-Mounting

Notes:

Notes:

Notes:



MAXIMIZE THE PERFORMANCE OF YOUR EXMARK MACHINE.



EXMARK® PREMIUM ENGINE OIL

Exmark now offers a family of engine oil viscosities to perform well in any environment. Each viscosity has the same synthetic formulation to give you what you need in punishing conditions. We designed each grade to the highest quality, making it ideal even for diesel applications. Coupled with Exmark Premium Fuel Treatment, we have the performance products to make your machine hum.

EXMARK PREMIUM ENGINE OIL SAE 30/10W-30

- Meets zero shear requirements of a straight grade SAE 30 as well as the cold temp properties of a 10W-30.
- Most versatile oil in the industry.
- Superior corrosion protection over conventional oil - even in corrosive, humid environments.

EXMARK PREMIUM ENGINE OIL SAE 20W-50

- Perfect for your big block engine, or any application in severe service.
- Same full synthetic formulation as all other Exmark Premium viscosities.
- Also effective for use in severe service small block engines.

EXMARK PREMIUM ENGINE OIL SAE 10W-50

- Full synthetic formulation gives you peak performance. Don't settle for less.
- Wide span multi-grade combines easy starting in cold weather with maximum protection in high temperature operation.
- Reduce friction & wear over standard mineral formulations.

EXMARK PREMIUM ENGINE OIL SAE 0W-40

- The perfect choice for when the weather turns cold or unpredictable, and your Exmark UTV has to perform.
- Commercial quality for severe service.
- Advanced additive package helps prevent corrosion from long-term storage.

EXMARK PREMIUM ENGINE OIL UTV FORMULATION

- 4-cycle high-temp formulation.
- Heavier viscosity, full synthetic, perfect for your UTV.

EXMARK PREMIUM UTV EXTREME CONDITIONS GEAR OIL

- SAE 80W-90, designed to keep your UTV performing at its peak.
- Shear stable, hypoid gear lube.
- Includes a premium additive system to combat wear, oxidation, rust & corrosion.

Available from your local Exmark dealer. Find your closest dealer at exmark.com

EXMARK ACCESSORIES AND OPTIONS*

MID-MOUNT RIDING ACCESSORIES AND OPTIONS

CUSTOM RIDE SEAT SUSPENSION SYSTEM	OPERATOR CONTROLLED DISCHARGE
FULL SUSPENSION SEAT	SUN SHADE
DECK LIFT ASSIST KIT	TRASH CONTAINER
HITCH KIT	TURF STRIPER
LIGHT KIT	ULTRA VAC COLLECTION SYSTEM
12V POWER PORT	ULTRA VAC QUICK DISPOSAL SYSTEM
MICRO-MULCH SYSTEM	

OUT-FRONT RIDING ACCESSORIES AND OPTIONS

CUSTOM RIDE SEAT SUSPENSION SYSTEM	SNOW BLADE
DUAL-TAIL WHEEL	SNOWBLOWER
FLOOR PAN EXTENDER	SUN SHADE
HITCH KIT	TRASH CONTAINER
LIGHT KIT	ULTRA VAC COLLECTION SYSTEM
MICRO-MULCH SYSTEM	ULTRA VAC QUICK DISPOSAL SYSTEM
ROLL OVER PROTECTION SYSTEM (ROPS)	WEATHER CAB

WALK-BEHIND ACCESSORIES AND OPTIONS

GRASS CATCHER	TURF STRIPER
MICRO-MULCH SYSTEM	STANDON

*Some accessories and options not available for some models.

Place Model No. and Serial No.
Label Here (Included in the Literature
Pack) or Fill in Below

Model No. _____

Serial No. _____

Date Purchased _____

Engine Model No. and Spec. No. _____

Engine Serial No. (E/No) _____

© 2023 Exmark Mfg. Co., Inc.
415 Industrial Row
Beatrice, NE 68310
All Rights Reserved

Part No. 4506-246 Rev. A
(402) 223-6300
Printed in the USA.



* 4 5 0 6 - 2 4 6 * A

www.exmark.com