



Form No. 3453-926 Rev A

Count on it.

Parts Catalog

Blower and Drive Kit 52in E-Z Vac™ for Z Master® Mower

Model No. 78552—Serial No. 412090000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Blower Assembly 4

Belt, Cover and Pulley Assembly..... 6




Blower Assembly

Ref.	Part Number	Qty.	Description
1	1-353054	1	Latch-Catcher, Grass
2	1-513013	4	Housing-Flange
3	1-513208	1	Washer-Spring
4	3256-26	1	Washer-Flat
5	147-2359	1	Housing W/Decal-Upper
5:2	127-2857	1	Decal - Vib, Pinch Warning
5:3	112-1770	1	Decal
5:4	126-9451	1	Decal-Warning
6	1-653322	1	Idler-Inside
7	1-653346	2	Bearing
8	109-1122-01	1	Bumper
9	1-653365	1	Spacer
10	1-653366	1	Hub
11	1-653596-03	1	Plate-Backing, Blower
13	3274-69	2	Screw-HSBH
14	103-0130	1	Bushing-Pivot, Idler
15	112-2345	1	Pulley
16	103-1103	1	Idler-Flat

Ref.	Part Number	Qty.	Description
17	145-1953	1	Cover-Bearing, W/Decal
17:2	126-9595	1	Decal-Warning
18	103-3815	1	Impeller
19	103-4080	2	Latch-Rubber
20	103-4171	1	Chute-Blower, Small
21	112-1761-03	1	Plate-Bottom
22	110-0334-03	1	Blower Mount ASM
22:1		1	Blower-Mount ●
22:1:2	1-353050	1	Shaft-Catcher, Grass
22:1:7	1-806323	1	Pin-Roll
23	117-0345	1	Idler Arm ASM W/Bushings
23:2	1-653600	2	Bushing
23:3	302-19	1	Fitting-Grease
23:4	126-4659	1	Decal-Warning
24	321-3	8	Screw-HH
25	323-11	2	Screw-HH
26	323-12	2	Screw-HH
27	323-7	1	Screw-HH

● Not serviced separately




Blower Assembly (continued)

Ref.	Part Number	Qty.	Description
28	323-8	3	Screw-HH
29	3219-6	1	Nut-Hex
30	3296-28	1	Nut-Lock, NI
31	3229-1	2	Screw-CARR
32	3229-11	3	Screw-CARR
33	3230-18	6	Screw-CARR
34	3256-16	12	Washer-Flat
35	3256-24	1	Washer-Flat
36	3256-3	2	Washer-Flat
37	3256-4	4	Washer-Flat
38	3257-32	1	Key-Woodruff
39	3274-107	1	Screw-HSBH

Ref.	Part Number	Qty.	Description
40	3256-22	2	Washer-Flat
41	3290-357	8	Nut-HSF
42	3274-39	12	Screw-HSBH
43	3296-39	2	Nut-Lock, NI
44	3296-47	2	Nut-Lock, NI
45	32128-20	6	Nut-HF
46	32128-33	15	Nut-HF
47	3296-2	8	Nut-Lock, NI
48	112-1762-03	1	Plate-Filler, Rear
57	112-1787	1	Latch-Stop
58	104-8426	1	Spacer

● Not serviced separately



Belt, Cover and Pulley Assembly

Ref.	Part Number	Qty.	Description
1	98-8332	1	Knob
2	115-3638	1	Belt Cover
3	609900	1	Nut-Speed
4	115-3637-01	1	Bracket-Cover, Belt
5	104-7201	2	Nut-HF, NI
6	112-2343	1	Belt-V
7	1-603693	1	Spring-Extension
8	112-8669-03	1	Pulley-Blower
9	1-807512	2	Bolt-CARR
11	140-4906	1	Pulley Mount ASM
12	104-8301	3	Nut-HF, NI

Notes:



Count on it.