



Form No. 3453-928 Rev A

Count on it.

Parts Catalog

Blower and Drive Kit

72in E-Z Vac™ for Z Master® Mower

Model No. 78554—Serial No. 410000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Blower Drive Assembly 4


Belt, Cover and Pulley Assembly..... 6



Blower Drive Assembly

Ref.	Part Number	Qty.	Description
1	1-353054	1	Latch-Catcher, Grass
2	1-513013	4	Housing-Flange
3	1-513208	1	Washer-Spring
4	3256-26	1	Washer-Flat
5	145-8454	1	Housing W/Decal-Upper
5:2	127-2857	1	Decal - Vib, Pinch Warning
5:3	112-1770	1	Decal
5:4	126-9451	1	Decal-Warning
7	1-653346	2	Bearing
8	103-0458-01	1	Bumper
9	103-0460	1	Spacer
11	103-0461-03	1	Plate-Backing, Blower
12	3274-39	6	Screw-HSBH
13	3274-69	4	Screw-HSBH
14	1-603044	1	Bushing
15	103-0456	1	Sheave
16	103-1103	1	Idler-Flat
17	145-8453	1	Cover-Bearing W/Decal
17:2	126-9595	1	Decal-Warning
18	103-0455	1	Impeller
19	103-2898	2	Latch-Rubber


Ref.	Part Number	Qty.	Description
20	109-1134	1	Chute-Blower
21	110-0328-03	1	Plate-Bottom
22	110-0329-03	1	Mount-Blower
23	145-8455	1	Idler Arm W/Bushings
23:1	302-19	1	Fitting-Grease
23:2	1-653600	2	Bushing
23:3	126-4659	1	Decal-Warning
24	321-3	10	Screw-HH
25	323-11	4	Screw-HH
28	323-8	3	Screw-HH
29	3219-6	1	Nut-Hex
30	3296-28	1	Nut-Lock, NI
31	3229-1	2	Screw-CARR
32	3229-11	3	Screw-CARR
33	3230-18	6	Screw-CARR
34	3256-16	6	Washer-Flat
36	3256-3	2	Washer-Flat
37	3256-4	4	Washer-Flat
38	3257-32	1	Key-Woodruff
40	3256-22	2	Washer-Flat
41	3290-357	8	Nut-HSF



Blower Drive Assembly (continued)

Ref.	Part Number	Qty.	Description
43	3296-39	2	Nut-Lock, NI
44	3296-47	2	Nut-Lock,NI
45	32128-20	6	Nut-HF
46	32128-33	17	Nut-HF
47	3296-2	6	Nut-Lock, NI
49	3296-42	2	Nut-Lock, NI

Ref.	Part Number	Qty.	Description
51	103-3093	2	Plate-Backing
54	103-0445-03	1	Pin-Mount
55	323-5	3	Screw-HH
57	112-1787	1	Latch-Stop
58	104-8426	1	Spacer



Belt, Cover and Pulley Assembly

Ref.	Part Number	Qty.	Description
1	98-8332	1	Knob
2	117-0340	1	Belt Cover
3	609900	1	Nut-Speed
4	117-0342-01	1	Bracket-Cover, Belt
5	104-7201	2	Nut-HF, NI
6	112-2384	1	Belt-V
7	1-603693	1	Spring-Extension
8	112-7202-03	1	Pulley-Blower
9	1-807512	2	Bolt-CARR
11	140-4906	1	Pulley Mount ASM
12	104-8301	3	Nut-HF, NI

Notes:



Count on it.