



Form No. 3418-796 Rev B

**Count on it.**

# Parts Catalog

## 22in Recycler®

### Lawn Mower with SmartStow®

Model No. 20340—Serial No. 401500000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Housing Assembly ..... 4

Rear Bag Assembly ..... 6

Engine and Blade Assembly ..... 8


Front Wheel and Height-of-Cut Assembly ..... 10

Rear Wheel and Height-of-Cut Assembly ..... 12

Handle and Control Assembly ..... 14

Attachments and Accessories ..... 16

# Housing Assembly



## Housing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 132-4510           | 1           | Housing ASM           | 18          | 32104-120          | 2           | Screw-PPH                   |
| 1:2         | 94-8072            | 1           | Decal-Danger          | 19          | 137-9139           | 1           | Rear Door ASM               |
| 1:3         | 137-9196           | 1           | Decal-Quick Wash      | 19:2        | 131-4514           | 1           | Decal-Warning               |
| 2           | 114-7963-01        | 1           | Baffle-Front          | 20          | 115-2859           | 1           | Spring-Torsion              |
| 5           | 114-7961           | 1           | Baffle-Rear           | 21          | 114-7924           | 1           | Spring-Torsion              |
| 6           | 136-5882           | 1           | Chute-Recycle         | 22          | 112-6400           | 1           | Port-Washout                |
| 7           | 46-8091            | 9           | Screw-HWH             | 23          | 112-6401           | 1           | Coupling-Hose, Washout Port |
| 8           | 112-6416           | 1           | Bracket-Cover         | 25          | 112-6438           | 1           | Washer-Seal, Washout Port   |
| 9           | 99-8445            | 2           | Screw-HWH             | 26          | 3254-5             | 1           | Washer-Lock                 |
| 10          | 99-5291            | 1           | Rod-Cover             | 27          | 3218-6             | 1           | Nut-Jam                     |
| 11          | 99-5293            | 1           | Spring-Torsion        | 29          | 114-7987           | 1           | Bumper                      |
| 12          | 115-8449           | 1           | Deflector-Side        | 30          | 105-6849           | 2           | Screw-Forming, Thread       |
| 13          | 115-8447           | 1           | Chute-Discharge, Side | 31          | 130-6660           | 2           | Cap-Plug                    |
| 14          | 114-7960           | 1           | Deflector-Recycle     | 40          | 132-4511           | 1           | Decal-Deck                  |
| 15          | 114-7958           | 1           | Knob-Recycle          | 43          | 125-5026           | 1           | Decal                       |
| 16          | 114-7959           | 1           | Latch-Recycle         | 47          | 108-7476           | 2           | Screw-Plastite              |
| 17          | 117-1031           | 1           | Spring-Compression    |             |                    |             |                             |


# Rear Bag Assembly



## Rear Bag Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 132-4529-03        | 1           | Bag Frame ASM      |
| 2           | 115-4673           | 1           | Grass Bag ASM      |

# Engine and Blade Assembly




## Engine and Blade Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------------------|-------------|--------------------|-------------|-----------------------|
| 2           |                    | 1           | Engine-Briggs,<br>104M020131F1 ●■ | 17          | 125-2466           | 1           | Bolt-Blade            |
| 10          | 105-3030-03        | 1           | Guide-Belt                        | 18          | 114-7937           | 1           | Cover-Belt            |
| 11          | 95-1726            | 3           | Screw-Taptite                     | 19          | 46-8091            | 2           | Screw-HWH             |
| 12          | 106-3999           | 1           | Spacer-Driver                     | 22          | 2210-316           | 1           | Stop-Rope             |
| 13          | 106-3987           | 1           | Driver-Blade                      | 42          | 133-8105           | 1           | Decal-Shroud          |
| 14          | 131-4547-03        | 1           | Blade-22 Inch                     | 46          | 117-2718           | 1           | Decal-Arrester, Spark |
| 15          | 108-3766-03        | 1           | Support-Blade                     | 47          | 133-8198           | 1           | Decal-Level, Fuel     |

● Not serviced separately

■ Obtain parts from [www.briggsandstratton.com](http://www.briggsandstratton.com)

# Front Wheel and Height-of-Cut Assembly




## Front Wheel and Height-of-Cut Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 115-1956-03        | 2           | Plate-HOC, Front   |
| 2           | 322-3              | 4           | Screw-HH           |
| 3           | 3296-29            | 6           | Nut-Lock, NI       |
| 4           | 105-1818           | 2           | Bushing-Mount, HOC |
| 5           | 137-9128           | 2           | Arm-Pivot, Front   |
| 6           | 105-1809           | 2           | Arm-Spring         |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 110-0549           | 2           | Knob-HOC           |
| 8           | 105-3048           | 2           | Washer-Flat        |
| 9           | 322-6              | 2           | Screw-HH           |
| 10          | 40-1940            | 2           | Washer             |
| 11          | 614650             | 2           | Bolt-Shoulder      |
| 12          | 137-4833           | 2           | 8In Wheel ASM      |


# Rear Wheel and Height-of-Cut Assembly



## Rear Wheel and Height-of-Cut Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 136-5887-03        | 1           | Plate-HOC, Rwd (LH)   | 14          | 108-7476           | 3           | Screw-Plastite        |
| 2           | 136-5888-03        | 1           | Plate-HOC, Rwd (RH)   | 15          | 110-7191           | 2           | Washer-Thrust         |
| 3           | 322-3              | 4           | Screw-HH              | 16          | 131-5399           | 2           | Gear-Pinion, 15T      |
| 4           | 3296-29            | 4           | Nut-Lock, NI          | 17          | 32151-61           | 2           | Ring-Retaining        |
| 5           | 108-9779           | 2           | Retainer-Bushing, HOC | 18          | 136-9059           | 2           | Gear Cover ASM        |
| 6           | 104-8699           | 2           | Bearing-Ball          | 18:2        | 614426             | 1           | Washer-Stepped        |
| 7           | 108-9782           | 2           | Bushing-Sleeve        | 19          | 614650             | 2           | Bolt-Shoulder         |
| 8           | 136-9090           | 2           | Arm-Pivot, Rear       | 20          | 137-4843           | 2           | Wheel Gear ASM (11In) |
| 9           | 132-4486           | 2           | Arm-Spring            | 23          | 120-7012           | 1           | Shield-Trailing       |
| 10          | 110-0549           | 2           | Knob-HOC              | 24          | 117-1092           | 2           | Screw-PTH             |
| 11          | 131-9696           | 1           | Transmission          | 25          | 3229-11            | 2           | Screw-CARR            |
| 12          | 91-2258            | 1           | Belt-V                | 26          | 3296-16            | 2           | Nut-Lock, NI          |
| 13          | 132-4481-01        | 1           | Bracket-Transmission  |             |                    |             |                       |

# Handle and Control Assembly



## Handle and Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|------------------------|
| 1           | 137-9109-03        | 1           | Plate-Handle, LH      | 16          | 99-1589            | 1           | Lever-Traction         |
| 2           | 137-9110-03        | 1           | Plate-Handle, RH      | 17          | 121-9118           | 1           | Spring-Torsion         |
| 3           | 3274-55            | 2           | Screw-HSBH            | 18          | 131-0880-03        | 1           | Bail-Brake             |
| 4           | 3296-47            | 4           | Nut-Lock,NI           | 19          | 120-9699           | 1           | Screw-CARR             |
| 5           | 132-4471-05        | 1           | Handle                | 20          | 136-5864           | 1           | Anchor-Cable           |
| 6           | 130-2344           | 2           | Bolt-Shoulder         | 21          | 115-8435           | 1           | Cable-Traction         |
| 8           | 115-2860           | 2           | Quick Release ASM     | 22          | 115-8437           | 1           | Cable-Brake            |
| 8:1         | 109-0917           | 1           | Nut-Push              | 23          | 131-0897           | 1           | Knob-Handle, Locking   |
| 8:2         | 114-7995           | 1           | Lever                 | 24          | 86-9671            | 1           | Guide-Rope             |
| 8:3         | 114-7996           | 1           | Anchor-Spring         | 25          | 3296-73            | 1           | Nut-Lock, NI           |
| 8:4         | 115-2858           | 1           | Spring-Compression    | 26          | 114-7988           | 1           | Guide-Cable            |
| 8:5         | 114-2675           | 1           | Rod-Release           | 27          | 131-4551           | 1           | Cover-Handle           |
| 9           | 105-6842           | 1           | Guide-LH              | 28          | 130-6721           | 2           | Clip-Tree              |
| 10          | 105-6841           | 1           | Guide-RH              | 40          | 132-4513           | 1           | Decal                  |
| 13          | 104-8678           | 1           | Handle-Control        | 41          | 132-4470           | 1           | Decal-Traction, Adjust |
| 14          | 136-7150           | 1           | Bar-Control, Traction | 42          | 136-9075           | 1           | Washer-Curved          |
| 15          | 3256-23            | 1           | Washer-Plain          |             |                    |             |                        |

# Attachments and Accessories

## For 20340 22in Recycler Lawn Mower with SmartStow

| Product Name                            | Model/Part |
|-----------------------------------------|------------|
| Fuel Stabilizer .05 oz .....            | 130-2393   |
| Briggs Maint Kit.....                   | 130-8148   |
| Traction Assist Handle Kit.....         | 131-4590   |
| Lawn Striping Kit with 22in Roller..... | 20601      |
| Lawnmower Cover.....                    | 490-7462   |
| 22 Inch Atomic Blade.....               | 59534P     |

**Notes:**

**Notes:**

**Notes:**



**Count on it.**