



Form No. 3454-104 Rev A

Count on it.

Parts Catalog

48in and 52in E-Z Vac™ DFS Collection System

Z Master® G3 Mower

Model No. 78566—Serial No. 411400000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents


Bagger Mount Assembly 4
 Hood and Frame Assembly 5
 Tube and Weight Assembly 6
 Bagger Mount Assembly 7



Bagger Mount Assembly


Ref.	Part Number	Qty.	Description
1	3274-1	1	Screw-HSH
2	103-8835-03	1	Link
3	109-8701-03	1	Frame ASM
5	1-323385	1	Knob-3 Prong
6	322-12	1	Screw-HH
7	3256-23	5	Washer-Plain
8	103-5114-03	1	Bellcrank
9	103-3202	2	Cap
10	3296-29	5	Nut-Lock, NI
11	116-2804	1	Exhaust Diverter ASM
12	109-6658	12	Nut-Flange, NI
13	3230-31	1	Screw-CARR
14	117-6164-03	1	Handle ASM
15	103-7115	1	Handle-Grip

Ref.	Part Number	Qty.	Description
16	3231-28	8	Screw-CARR
17	3233-34	2	Screw-CARR
18	1-513658	2	Bumper
19	103-4402	2	Bearing
20	103-4433	1	Shaft-Collar
21	116-0473-03	1	Mount-Bagger, Upper
22	109-9248	1	Mount-Bagger, Lower
24	116-0458	2	Pin-Mount, Bagger
25	3230-5	4	Bolt-CARR
26	116-0057-03	1	Bumper-RH
27	116-0180	1	LH Bumper ASM
27:2	106-5517	1	Decal-Warning
28	99-5107	2	Nut-Lock



Hood and Frame Assembly


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	1-653598-03	1	Clamp-Seal
2	1-653561	1	Seal-Chute
3	114-8249	1	Dfs Hood ASM
4	3250-27	4	Screw-PPH
5	3256-61	14	Washer-Flat
7	3256-22	8	Washer-Flat
8	321-4	11	Screw-HH
9	114439	18	Rivet-Blind
10	99-4693	1	Decal
11	114967	1	Screen-Bagger
12	32128-33	11	Nut-HF
13	103-4412-03	1	Plate-Rear
14	103-4832	1	Seal-Door
15	103-4834-03	1	Strap-Hold Down
16	103-5101-03	1	Support-Screen
17	3296-2	4	Nut-Lock, NI



Tube and Weight Assembly

Ref.	Part Number	Qty.	Description
1	109-2043	1	Lower Tube ASM
1:2	103-4081	2	Latch-Keeper ●
1:3	3290-500	2	Screw-PPH
1:4	3256-14	2	Washer-Flat
2	109-2036	1	Tube-Upper
3	32105-13	3	Screw-HWH
4	3256-61	3	Washer-Flat
5	3296-2	3	Nut-Lock, NI
6	147-2356	3	Weight ASM
6:1	147-2357	1	Weight W/Decal ASM
6:1:2	136-4053	1	Decal-Warning, Counterweight
6:2	115-3616-01	1	Tab-Support, Weight
6:3	323-4	2	Screw-HH
6:4	3253-5	2	Washer-Lock
7	115-3615-01	1	Bracket-Mount, Weight
8	104-8300	2	Nut-HF, NI
9	3230-23	2	Bolt-CARR
10	3256-4	6	Washer-Flat
11	323-6	6	Screw-HH
12	3253-5	6	Washer-Lock
13	104-8301	3	Nut-HF, NI
14	104-2442	2	Bumper-Rubber
15	104-7658	2	Spacer
16	3296-47	2	Nut-Lock, NI

● Kit No. 103-4188 - Contains catch, rubber latch, and mounting hardware



Bagger Mount Assembly

Ref.	Part Number	Qty.	Description
1	103-4819-03	1	Guard-RH
2	103-7829	1	Panel-Bagger, RH
3	114439	14	Rivet-Blind
4	103-5102	1	Panel-Bagger
5	103-4828	1	Screen-Door
6	3256-2	20	Washer-Flat
7	321-4	32	Screw-HH
8	103-4406-03	1	Door-Frame
9	3296-29	12	Nut-Lock, NI
10	3256-23	22	Washer-Plain
11	103-4820-03	2	Plate, Hinge
12	103-6294	2	Pin-Pivot, Hinge
13	103-6295	2	Bearing
14	3256-4	2	Washer-Flat
15	3296-59	2	Nut-Lock, NI
16	3230-22	4	Screw-CARR
17	94-8196	6	Washer-Nylon
18	103-4424	2	Arm-Linkage, Door
19	32151-61	6	Ring-Retaining
20	103-4431	2	Washer
21	3219-5	4	Nut-Hex

Ref.	Part Number	Qty.	Description
22	103-4835	2	Anchor-Spring
23	103-4848	2	Trunnion-Link
24	103-4822	2	Link-Door
25	103-4813	2	Spring
26	323-7	2	Screw-HH
27	103-4415	2	Bearing-Linkage, Pivot
29	32128-33	26	Nut-HF
30	322-5	4	Screw-HH
31	3231-4	2	Screw-CARR
32	3256-22	6	Washer-Flat
33	103-4437-03	1	Guard-LH
34	103-5112	1	Link-LH
35	107069	6	Clip
36	103-4408-03	2	Stop-Linkage
37	3296-39	2	Nut-Lock, NI
38	3230-2	4	Bolt-CARR
39	103-5111	1	Link-RH
40	3256-26	2	Washer-Flat
41	1-806003	2	Pin-Cotter
42	103-7828	1	Panel-Bagger, LH



Count on it.