



Form No. 3454-105 Rev A

Count on it.

Parts Catalog

60in E-Z Vac™ DFS Collection System

Z Master® G3 Mower

Model No. 78567—Serial No. 411400000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Bagger Frame Mount and Handle Assembly 4

Hood Assembly..... 5

Tube and Weight Assembly 6


Bagger Assembly..... 7



Bagger Frame Mount and Handle Assembly

Ref.	Part Number	Qty.	Description
1	3233-34	2	Screw-CARR
2	116-0473-03	1	Mount-Bagger, Upper
3	323-12	4	Screw-HH
4	3256-4	7	Washer-Flat
5	103-2409	4	Half-Block, Bearing
6	103-2412-03	1	Link-Intermediate
7	323-53	2	Screw-HH
8	3290-357	8	Nut-HSF
9	116-0458	2	Pin-Mount, Bagger
10	109-8709-03	1	Frame
11	103-3201	2	Cap
12	103-3202	4	Cap
13	116-2804	1	Exhaust Diverter ASM
15	1-633131	3	Yoke-Linkage, Brake
16	103-2399	3	Pin-Spring, Clevis
17	3219-3	3	Nut-Hex
18	103-2413	3	Link-Handle
20	3272-10	3	Pin-Cotter
21	109-6658	14	Nut-Flange, NI


Ref.	Part Number	Qty.	Description
22	109-6869	1	Pin-Handle
23	32151-48	1	E-Ring
24	115-3604-03	1	Bagger Handle ASM
25	109-8712-03	1	Mount-Pivot
26	3231-28	10	Screw-CARR
27	109-9248	1	Mount-Bagger, Lower
28	1-513658	2	Bumper
29	321-6	2	Screw-HH
30	3256-55	2	Washer-Flat
31	103-3191-03	2	Latch
32	1-633545	2	Spacer
33	3296-42	2	Nut-Lock, NI
34	103-7115	1	Handle-Grip
36	116-0057-03	1	Bumper-RH
37	116-0180	1	LH Bumper ASM
37:2	106-5517	1	Decal-Warning
38	99-5107	2	Nut-Lock
40	104-8301	2	Nut-HF, NI



Hood Assembly

Ref.	Part Number	Qty.	Description
1	103-0378	2	Clamp-Seal
2	103-0439	1	Seal-Tube
3	114-8246	1	Hood ASM
4	3256-61	23	Washer-Flat
5	3250-27	8	Screw-PPH
6	3256-22	13	Washer-Flat
7	321-4	18	Screw-HH
8	67-7310	1	Decal
9	103-0440	1	Screen-Bagger
10	114439	39	Rivet-Blind

Ref.	Part Number	Qty.	Description
11	103-0379	2	Bracket-Mount
12	103-0376	2	Plate-Latch, Reinforcement
13	103-2360	1	Seal-Door Hinge
14	103-3010-03	1	Strap-Hold Down
15	103-2710	1	Rear Crossmember ASM
15:2	32148-6	6	Nut-Clinch
16	103-2662-03	1	Support-Screen
17	32128-33	12	Nut-HF
18	3296-2	8	Nut-Lock, NI



Bagger Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	103-7827	1	Panel-Bagger, RH	17	323-6	4	Screw-HH
2	3256-2	32	Washer-Flat	18	32128-33	24	Nut-HF
3	321-3	32	Screw-HH	19	103-2383	1	Bag And Bottom Panel ASM
4	3256-24	12	Washer-Flat	20	103-2414-03	1	Support
5	322-3	6	Screw-HH	21	3272-10	2	Pin-Cotter
6	103-2404-03	1	Sheet, Wall	22	103-2365	2	Link-Hinge
7	103-7826	1	Panel, Bagger LH	23	3219-3	2	Nut-Hex
8	32128-20	6	Nut-HF	24	1-633131	2	Yoke-Linkage, Brake
9	3256-22	4	Washer-Flat	25	1-808285	2	Pin-Clevis
10	321-4	4	Screw-HH	26	1-806003	2	Pin-Cotter
11	103-2737	1	Door ASM	27	103-3331-03	1	Arm-Hinge, RH
11:2	32148-6	12	Nut-Clinch	28	103-2361	2	Pin-Pivot, Hinge
12	103-8018	2	Plug-Dome	29	103-2377	2	Bushing
13	3290-357	4	Nut-HSF	30	114439	21	Rivet-Blind
14	103-3332-03	1	Arm, Hinge LH	32	3296-39	2	Nut-Lock, NI
16	323-9	2	Screw-HH				



Count on it.