Form No. 3454-381 Rev A

TORO®

Count on it.

Parts Catalog

Road Light Kit, Z Master® Professional 7500-D Series Riding Mower

With 60in or 72in TURBO FORCE® Rear Discharge Mower

Model No. 02937

Register at www.Toro.com.
Original Instructions (EN)

CE

3454-381 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Headlight Mount Assembly 4
Light Mount Kit Assembly No. 140-6698 5
Rear Light Assembly 6
Control Panel and Speed Decal Assembly 7
Control Panel Assembly 8
Wire Harness, Horn and Beacon Assembly 9
LH Lever Assembly No. 140-6692 10


© 2022—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved




Headlight Mount Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	144-3550-03	1	Mount-Lights [black]
2	144-3206-03	2	Mount-Light
3	144-3205-03	2	Mount-Extension
4	140-6773	1	LH Light ASM
4:2	140-6698	1	Light Mount Kit
5	140-6772	1	RH Light ASM
5:2	140-6698	1	Light Mount Kit
6	120-9699	8	Screw-CARR
7	104-7201	8	Nut-HF, NI
8	325-5	2	Screw-HH
9	99-5107	2	Nut-Lock
10	134-8015	4	Spacer, Light Mount
11	32180-030	2	Clip-Tie



Light Mount Kit Assembly No. 140-6698


Ref.	*Part Number*	*Qty.*	*Description*
1	139-2092	1	Mount-Light
2	107-7983	1	Screw-HH
3	33116-030	1	Screw-HH
4	48-8070	2	Washer-Lock
5	33026-00	2	Nut-Hex



Rear Light Assembly

Ref.	Part Number	Qty.	Description
1	140-6859-03	1	Mount-Turn, LH
2	140-6860-03	1	Mount-Turn, RH
3	134-6518	2	Bracket-Pivot, ASM
3:1	134-6517-03	1	Pivot Bracket ASM [black]
3:2	140-6682-03	1	Pivot
3:3	32121-34	1	Pin-Roll
3:4	61-3270-03	1	Spring-Compression
3:5	134-8192	1	Washer 34 DIA X 7 DIA X 5 THK
3:6	32105-15	1	Screw-HWH
4	140-6861-03	1	Mount-Light, RH
5	140-6862-03	1	Mount-Light, LH
6	134-8127-03	1	Housing-Light, LH
7	134-8126-03	1	Housing-Light, RH

Ref.	Part Number	Qty.	Description
8	140-6835	2	Inner Mount ASM
8:2	107-1013	2	Nut-Speed
8:3	138-2760	4	Nut-Clinch, Hex
9	139-2071	2	Light-Rear Tail/Stop/Turn
10	140-6863-03	2	Cover-Mount
11	139-2429	4	Screw-HHF
12	104-8301	4	Nut-HF, NI
13	3234-4	6	Screw-HHF
14	104-7201	10	Nut-HF, NI
15	3229-11	4	Screw-CARR
16	3250-23	4	Screw-PPH
18	3274-69	8	Screw-HSBH
19	139-3205	8	Rivet-Plastic
20	111-5020	2	Reflector-Adhesive




Control Panel and Speed Decal Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1		1	Control Panel ASM ▲
2	140-6841-03	1	Mount-License, Speed
3	120-9693	2	Screw-PPH
4	139-2074	1	Light-Plate, License (Ece)
5	3229-11	7	Screw-CARR
6	104-7201	7	Nut-HF, NI
7	120-9684	2	Nut-Lock
8	140-1519	3	Decal-Speed (20Kpm)
99	134-7570	3	Decal-Speed, 10 Kph ■ ●


● Not illustrated
▲ Not serviced separately

■ Optional Equipment



Control Panel Assembly


Ref.	*Part Number*	*Qty.*	*Description*
1	134-7009-03	1	Panel-Control
2	134-6932-03	1	Control-Cover
3	107069	6	Clip
4	120-0334	1	Switch-Rocker
5	119-7769	1	Switch-Rocker, On/None/On
6	1-807533	1	Bolt-CARR
7	139-2080	1	Flasher-Dual Rate
8	120-4578	1	Nut-HF
9	32105-15	6	Screw-HWH
10	111-3472	1	Switch-Beacon



Wire Harness, Horn and Beacon Assembly

Ref.	Part Number	Qty.	Description
1	140-6692	1	LH Lever ASM
2	134-3747	1	Screw-HHF
4	110-2594	1	Horn
7	122-2482	1	Harness-Wire, EU Light Kit
7:13	116-0053	3	Cap-Plug
7:14	32181-015	1	Cover-Fuseblock
7:18	121-8861	2	Fuse-Mini Blade, 2 Amp
7:19	121-8864	3	Fuse-Mini Blade, 5 Amp
7:20	121-8866	1	Fuse-Mini Blade, 10 Amp
7:21	126-3991	2	Relay-Micro
8	134-5326	1	Light-Beacon ASM
9	119-8095	1	Socket-Beacon
10	134-6548-03	1	Bracket,Beacon
11	111-2195-03	1	Clamp-50MM
12	134-3748	2	Screw-HHF

Ref.	Part Number	Qty.	Description
13	09270	2	Washer-Plain
14	134-3762	3	Nut-Flange, NI
15	09784	2	Screw-Soc, HD
16	122-1222	1	Harness-Wire
17	134-5327	1	Ferrite, Emc Suppresion
18	134-7530-03	2	Plate - Speed Limiter
19	32144-10	2	Screw-HWH
20	104-7201	2	Nut-HF, NI
21	32180-139	2	Mount-Tie Wrap, Magnetic
22	32180-150	2	Clip-Harness. Edge, W/Tie-Wrap
99	32180-030	2	Clip-Tie
99	74-07-020	15	Tie-Cable
99	HY3966	10	Tie-Cable



LH Lever Assembly No. 140-6692

Ref.	*Part Number*	*Qty.*	*Description*
1	140-6693	1	Lever ASM-Foam, LH
1:1	134-8053-03	1	Lever ASM-LH [black]
1:2	134-8052	1	Grip, Control Lever
2	136-2162	1	Switch-Combination Assembly
3	132-1418	1	Cap-Switch
4	3245-42	1	Screw-Set
5	136-1921	1	Decal-Lights

Notes:



Count on it.