




# **142-1850**

## **40 INCH SPIKER**

Model No. 142-1850—Serial No. 413950474 and Up

Picture below may not reflect actual product.



# **Parts Manual**

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity


In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Spiker Head Assembly ..... 4

# Spiker Head Assembly



## Spiker Head Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 104-8300           | 110         | Nut-Nyloc 5/16-18 Flg  | 7           | 135-9351-05        | 36          | Star, Spiker Head        |
| 2           | 104-8301           | 12          | Nut-Nyloc 3/8-16 Flg   | 8           | 135-9370           | 1           | Mount-Aerator Head       |
| 3           | 114-4681           | 12          | Screw-HHF              | 9           | 135-9379           | 4           | Bearing-Pillow Block     |
| 4           | 115-7109           | 2           | Washer-Flat            | 10          | 135-9791-05        | 2           | Disc-Spyker Head         |
| 5           | 135-7099           | 2           | Swivel-Chain ASM       | 11          | 3234-17            | 2           | Screw-HH Flg 5/16-18 X 1 |
| 5:1         | 135-9373           | 1           | Z-Plug Drawbar Spring  | 12          | 3234-29            | 108         | Screw-HH Flg 5/16-18 X 1 |
| 6           | 135-8785-05        | 1           | Head-Aeration, 40 Inch | 14          | 133-8061           | 1           | Decal-Warning            |

**Notes:**

**Notes:**

Place Model No. and Serial No.  
Label Here (Included in the Literature  
Pack) or Fill in Below

Model No. \_\_\_\_\_

Serial No. \_\_\_\_\_

Date Purchased \_\_\_\_\_

Engine Model No. and Spec. No. \_\_\_\_\_

Engine Serial No. (E/No) \_\_\_\_\_



Z Turf Equipment is part of the Exmark® family of products.  
©2023 Exmark Mfg. Co., Inc. All Rights Reserved. Printed in the USA.  
415 Industrial Row • Beatrice, NE 68310 • (402) 223-6300

[www.zturfequipment.com](http://www.zturfequipment.com)

