Form No. 3454-915 Rev A

TORO®

Count on it.

Parts Catalog

Power Broom

Model No. 38701—Serial No. 411700000 and Up

Register at www.Toro.com.
Original Instructions (EN)

3454-915 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Main Frame and Belt Cover Assembly 4
Auger Drive Assembly 6
Broom and Deflector Assembly 8
Broom Frame Assembly 10
Broom Assembly 12
Engine Assembly 14
Handle Assembly 16
Control Assembly 18
Traction Drive Assembly 20
Attachments and Accessories 22

© 2022—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


Main Frame and Belt Cover Assembly



Main Frame and Belt Cover Assembly (continued)

Ref.	Part Number	Qty.	Description
1	136-6639-01	1	Frame-Traction
2	107069	8	Clip
3	136-6650-01	1	Cover-Bottom
4	136-6651-01	1	Cover-Rear
5	32144-85	10	Screw-HWH Thd Form
19	138-0731	1	Belt Cover, No Light


Auger Drive Assembly



Auger Drive Assembly (continued)

Ref.	Part Number	Qty.	Description
1	136-8654-03	1	Bracket-Clutch, Impeller
2	136-6654-03	1	Bracket- Bellcrank
3	92-9698	1	Screw-Shoulder
4	32144-85	15	Screw-HWH Thd Form
5	137-3111	1	Screw-HHF
6	136-6689	1	Plate-Friction, Wheel
7	137-6156	1	Bracket-Plate, Traction
8	137-6159-03	1	Bellcrank-Drive
9	137-3094	1	Nut-Hex
10	137-6157	1	Link-Drive
11	38-7820	2	Bearing-Ball
12	136-7124	1	Retainer-Bearing
13	137-6154	1	Pulley-Traction
14	115-1166	1	Washer-Flat
15	119-4042	1	Nut-HF, NI
16	256-257	2	Bushing-Nyliner
17	120-7156	2	Bushing-Plate, Traction
18	137-6189	1	Spring-Extension
19	137-3005	1	Nut-HF
20	145-0670	1	Arm-Clutch, Impeller
23	121-4600	2	Nut-Hex
24	136-8671-03	1	Bracket-Brake, Clutch
27	136-7116	1	Bolt-Shoulder
28	136-7186	2	Arm-Idler, Traction
29	120-3060	1	Spring-Torsion
30	139-2553	2	Screw-HHF
31	3-4244	2	Pulley-Idler


Broom and Deflector Assembly



Broom and Deflector Assembly (continued)

Ref.	Part Number	Qty.	Description
2	112-9028	1	Decal-Cover, Missing
3	115-2903	2	Decal-Grease
5	32144-14	6	Screw-HWHTF
7	66-6140	1	Decal
8	142-3051	2	Decal-Z-Logo
8	62-5550	2	Decal
9	116-8869-03	3	Strap-Support, Deflector
10	116-8880-03	2	Strap-Support, Broom Deflector
11	137-3042	6	Screw-HH
12	104-7201	9	Nut-HF, NI
13	116-8864	1	Deflector-Broom
14	3256-2	3	Washer-Flat
15	120-4654	3	Screw-HHF
43	139-9928-01	1	Plate-Cover
44	32144-85	2	Screw-HWH Thd Form


Broom Frame Assembly



Broom Frame Assembly (continued)

Ref.	Part Number	Qty.	Description
1	116-8544	1	Frame
2	116-8546	1	Arm-Right
3	116-8545	1	Arm-Left
4	116-8543	2	Caster-Bracket
5	116-8114	1	Shaft
6	120-9738	2	Screw-HH
7	119-4038	2	Nut-Hex
8	116-8115	1	Gearbox-Worm
9	83-2800	1	Key-Straight
10	116-8116	2	Bearing-Flange
11	139-2590	16	Screw-CARR
12	115-1166	16	Washer-Flat
13	137-3087	16	Nut-Hex
14	116-8223	2	Tube-Square, Height Adjust
15	116-8117	2	Caster-Wheel
16	137-3050	2	Screw-HH
17	137-3088	2	Nut-Hex
18	103-3202	2	Cap
19	116-8123	1	Broom Hood ASM
19:3	142-9656	2	Decal-Warning Fly Obj-Entangle
20	116-8224	2	Pin-Wire, Lock
21	120-9646	4	Washer-Flat
22	137-3042	4	Screw-HH
23	139-9942-01	1	Frame-Mounting [red]
24	3230-1	4	Bolt-CARR
25	32128-20	4	Nut-HF
26	116-8104	1	Shaft-Drive
27	116-8105	1	Key-Round End
28	116-7930	1	Pulley-Impeller
28:1	3246-18	2	Setscrew
29	3256-8	1	Washer-Flat
30	3216-7	1	Screw-HH
31	116-8106	1	Pin-Swing
32	116-8107	1	Spring-Compression
33	302-19	1	Fitting-Grease
34	116-7671	1	Cable-Angle, Broom
35	3217-26	1	Nut-Hex
36	116-8108	1	Cap
37	116-8103	2	Bearing-Shaft


Broom Assembly



Broom Assembly (continued)

Ref.	Part Number	Qty.	Description
1	116-8119	2	Core-Broom
2	116-8120	18	Segment-Poly
3	116-8121	2	Plate-End, Retainer
4	139-2597	6	Screw-HHF

Engine Assembly




Engine Assembly (continued)

Ref.	Part Number	Qty.	Description
1		1	Engine-Kohler, Ch270 ●■
2	144-1240	2	Sheave-Traction
3	144-1241	1	Spacer-Pulley
4	137-6179	1	Pulley-Impeller
5	109-7299	1	Belt,3L P21 Drive
6	144-1242	1	Spacer
7	115-1166	1	Washer-Flat
8	120-2302	1	Screw-HH
9	116-8721	1	Adapter
10	01-201-4520	1	Cap
11	133-8062	1	Decal-Arrestor, Spark
12	126-4178-03	1	Deflector-Debris, Muffler
13	33103-025	1	Screw-HHF
15	144-2816	1	Guide-Belt
16	140-7945-03	1	Cover-Crank
17	144-1625	1	Engine Plate ASM (G250)
17:1	144-1626	1	Plate-Engine
17:2	136-7178	4	Stud-Press 95/16-18 X 1.625)
18	32144-70	4	Screw-HWHTF
19	137-3089	4	Nut-Hex
20	138-0690	2	Screw-HH
21	80-3590	1	V-Belt
24	136-6644-03	1	Bracket-Control, Traction
25	32144-85	2	Screw-HWH Thd Form

● Not serviced separately

■ Obtain parts from www.kohlerplus.com

Handle Assembly




Handle Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-6224-03	1	HD Handle ASM
2	137-6233-01	1	Trim-Metal, HD
3	137-6221-03	2	Bracket-Handle, Lower
4	120-9686	4	Screw-HH
5	138-8401	12	Nut-HF
6	106-4509	2	Clamp-Cable
7	138-3653	2	Screw-HHF
8	137-3094	2	Nut-Hex
9	120-1333	2	Grip-Handle
10	138-8402	2	Bolt-CARR
11	137-3052	4	Screw-HH
14	137-3107	2	Screw-Handle
15	145-4075-01	1	Brace-Console
16	105-9980	2	Mount-Lever, Clutch
17	137-3099	3	Screw-Plastite, HWH
18	106-4505	2	Lever-Clutch
19	1-808265	2	Pin-Clevis
20	108-2992	2	Pin-Hair
21	137-6171	2	Lever-Control
22	144-1343	1	Rod-Lockout
23	138-0678	1	Spring-Torsion, Handle Return
24	145-0660	2	Screw-HSH,Spl
25	131-8641	2	Nut-Lock
26	138-3661	1	Cable-Auger
27	138-0728	1	Cable-Traction
99	130-8332	1	Adhesive-Loctite 608 ●

● Not illustrated


Control Assembly



Control Assembly (continued)

Ref.	Part Number	Qty.	Description
1	144-1346	1	Panel-Control
2	99-7420	1	Plug-Hole
3	138-8401	7	Nut-HF
4	137-6187-03	1	Gate-Shift
5	137-6188-03	1	Bracket-Shift
6	137-3099	4	Screw-Plastite, HWH
7	137-3103	2	Screw-Shoulder, HH
8	137-6231-03	1	Selector-Speed
9	136-7121	1	Spring-Compression
10	137-3038	2	Nut-HF
12	94-4496	1	Screw-PPH
13	115-1166	2	Washer-Flat
14	136-7193	1	Trunnion-Rod
15	137-3083	2	Pin-Hair
16	137-6225	1	Rod-Shift
17	139-9919-03	1	Bracket-Lever, Broom Angle
18	137-3111	2	Screw-HHF
19	119-4040	5	Nut-HF, NI
20	92-9698	1	Screw-Shoulder
22	139-9920-03	1	Lever-Broom Angle
23	139-1709	1	Screw-Shoulder
25	142-9546	1	Decal-Warning
26	144-0316	1	Decal-Control Panel
27	144-0315	1	Decal-Console
28	139-9927-03	1	Plate-Cover, CONT Pnl
29	137-3011	2	Bolt-CARR
31	105-9999	1	Knob-Shift, LH
32	106-4423	1	Knob-Shift, RH
33	138-0719	1	Nut-HF

Traction Drive Assembly



Traction Drive Assembly (continued)

Ref.	Part Number	Qty.	Description
1	136-6668	1	LH Wheel And Tire ASM
2	136-6667	1	RH Wheel And Tire ASM
3	125-1135	1	Shaft-Hex
4	108-7319	2	Retainer-Bearing
5	32144-85	6	Screw-HWH Thd Form
6	32121-9	2	Pin-Roll, Slotted
7	137-6162	1	Shift Rod
8	119-7684	1	Spacer-Plate, Shift
9	121-6835	1	Bearing-Ball
10	32144-86	1	Screw-HWHTF
11	137-3091	4	Nut-Hex
12	119-7630	1	Trunnion
13	119-1567	1	Wheel-Friction
14	137-6246	3	Screw-Shoulder
15	136-6640	2	Axle
16	106-7259	1	Tube-Axle
17	137-3051	1	Screw-HH
18	137-3089	1	Nut-Hex
19	136-6641	2	Bushing-Axle
20	138-0725	2	Washer-Thrust
21	136-6642	2	Gear-Axle
22	138-0720	2	Bolt-Shoulder, HSH
23	137-3093	2	Nut-Hex
24	107-8883	1	Shaft-Intermediate
25	107-8894	2	11T Gear ASM
25:2	108-2973	2	Bushing-Flange
26	108-0015	4	Washer-Flat
27	107-8895	2	32T Sprocket ASM
27:2	108-2973	2	Bushing-Flange
28	107-8885	6	Spring-Compression
29	107-8899	6	Pin-Dowel
30	107-8879	6	Pawl-Clutch
31	107-8889	4	Guide-Collar
32	136-6648-03	1	Brace-Shift, Collar
33	138-3653	2	Screw-HHF
34	119-4040	2	Nut-HF, NI
35	107-8887	1	Collar-Shift, LH
36	107-8888	1	Collar-Shift, RH
37	107-8891	2	Washer-Thrust
38	108-0016	2	Chain-Roller
39	107-8893	2	Spring-Extension
40	107-8880	6	Support-Pawl
41	137-3010	12	Screw-BHCS
42	136-7318	2	Retainer-Pawl, Pin
43	107-8896	2	Cable-Clutch
44	136-6647-03	1	Retainer-Rod, Shift
45	125-1134	2	Gear-Pinion, 8 Tooth
46	36-4780	2	Washer-Plain
47	32144-14	2	Screw-HWHTF
48	138-3642	2	Pin-Klik

Attachments and Accessories

For 38701 Power Broom

Product Name	Model/Part
Dirt Deflector Kit	116-8229
Black Snow/Ice Wafers	116-8232
Yellow Turf Wafers	116-8233
Kit-Caster, Turf Broom	135-2311
Kit-Cab	139-1640
Tire Chain Kit, 16in Tires	38215

Notes:



Count on it.