Form No. 3327–460

Tree Fork

Dingo® Attachment

Model No. 22438—220000001 and Up

Parts Catalog

PROTOTYPE

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.


Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 2002
All Rights Reserved



Sheet No.: 1

Tree Fork Assembly

Ref. No.	Part No.	Qty.	Description
1	99–1669	1	Shield ASM
1:2	100–4650	1	Decal–Warning
1:3	100–4690	1	Decal–Load Rating
2	3274–10	4	Screw–HSH
3	3253–4	4	Washer–Lock
4	99–1672	1	Pin
5	98–3206	1	Decal–Logo, Toro
6	99–1680	1	Frame
9	99–1686	1	Connector–Straight
10	3256–10	2	Washer–Flat
11	32121–9	1	Pin–Spring
12	99–1683	1	Arm–Pivot, LH
13	3219–6	2	Nut–Hex
14	3253–8	2	Washer–Lock
15	99–1682	1	Arm–Pivot, RH
16	99–1667	1	Cylinder–Fork, Tree
*16:1	100–4695	1	Kit–Seal
17	99–1689	2	Clip–Pin
18	99–1688	1	Pin–Pivot, Cylinder
19	99–1687	1	Connector–Oriface, Straight
20	3214–15	2	Screw–HH
21	99–1685	2	HYD Hose ASM
22	104–6134	1	Coupler–Face, Flush
*22:1	105–8396	1	Kit–Seal

Ref. No.	Part No.	Qty.	Description
23	100–4701	1	Nipple–Connect, Pressure
*23:1	100–6120	1	Kit–Seal
24	3256–1	2	Washer–Flat
25	3274–8	2	Screw–HSH
26	98–3269	1	Decal–Made In USA
27	100–4618	2	Adapter–HYD
27:1	237–80	1	O–Ring

PROTOTYPE

* Not illustrated