


**TORO®**

MODEL NO. 21738-9000001 &amp; UP

**PARTS  
CATALOG****21" SELF PROPELLED KEY-LECTRIC®  
SIDE DISCHARGE****HOUSING ASSEMBLY**

| Ref. No. | Part No. | Description                                        | No. Used |
|----------|----------|----------------------------------------------------|----------|
| 1        | 20-4690  | Decal Toro                                         | 1        |
| 2        | 20-2800  | Deflector Cover Assembly<br>(Incl. Ref. #1, 3 & 6) | 1        |
| 3        | 20-4330  | Decal Caution                                      | 1        |
| 4        | 22-7350  | Decal — Danger                                     | 1        |
| 5        | 12-3270  | Screw Special                                      | 2        |
| 6        | 20-2640  | Hinge Spring                                       | 1        |
| 7        | 3256-1   | Washer                                             | 2        |
| 8        | 20-2130  | Pivot Arm "B"                                      | 1        |
| 9        | 8-0649   | Housing                                            | 1        |
| 10       | 21-5580  | Pulley Driver                                      | 1        |
| 11       | 6-4500   | Plug Washout                                       | 1        |
| 12       | 5-2490   | Shoulder Screw                                     | 2        |
| 13       | 22-4950  | Rear Safety Shield                                 | 1        |
| 14       | 12-2080  | Nut — Handle Pivot                                 | 2        |


| Ref. No. | Part No. | Description                         | No. Used |
|----------|----------|-------------------------------------|----------|
| 15       | 5-2446   | Handle Latch                        | 2        |
| 16       | 3-3287   | Spacer — Handle Latch               | 2        |
| 17       | 33-3201  | Rod Shield                          | 1        |
| 18       | 25-7740  | Knob Arm                            | 2        |
| 19       | 32146-6  | Locknut                             | 2        |
| 20       | 20-2140  | Pivot Arm "A"                       | 1        |
| 21       | 27-6200  | Wheel & Tire Assy. (Incl. Ref. #33) | 2        |
| 22       | 27-6230  | Wheel Bolt                          | 2        |
| 23       | 3-0655   | Pivot Screw                         | 2        |
| 24       | 25-8000  | Spring Arm                          | 2        |
| 25       | 5-4460   | Pivot Washer                        | 2        |
| 26       | 27-6300  | Square Key                          | 1        |
| 27       | 20-2750  | Blade Retainer                      | 1        |
| 28       | 20-2720  | Blade                               | 1        |
| 29       | 8-4240   | Cup Anti Scalp                      | 1        |

COPYRIGHT © ALL RIGHTS RESERVED

**The Toro Company — 1979**

MINNEAPOLIS, MN 55420 — U.S.A.

**PRICE \$1.00**




## HOUSING ASSEMBLY (Continued)

| Ref. No. | Part No. | Description   | No. Used |
|----------|----------|---------------|----------|
| 30       | 3-5246   | Screw Special | 1        |
| 31       | 3253-22  | Lockwasher    | 1        |
| 32       | 38-2530  | Decal — Deck  | 1        |

| Ref. No. | Part No. | Description              | No. Used |
|----------|----------|--------------------------|----------|
| 33       | 27-6250  | Bushing                  | 4        |
| *        | 8-0269   | Loose Parts              | 1        |
| *        | 25-9150  | Decal Serial Replacement | 1        |

\*Not Illustrated




## ENGINE ASSEMBLY

| Ref. No. | Part No. | Description                 | No. Used |
|----------|----------|-----------------------------|----------|
| 1        | 24-9770  | Switch & Junction Box       | 1        |
| 2        | 221-616  | Engine                      | 1        |
| 3        | 37-1580  | Decal — Maintenance         | 1        |
| 4        | 38-3080  | Cover Assembly              | 1        |
| 5        | 25-1570  | Clip Wire                   | 2        |
| 6        | 32121-90 | Spring Pin                  | 1        |
| 7        | 27-7870  | Gas Cap (Incl. Ref. #8 & 9) | 1        |
| 8        | 2210-144 | Gasket                      | 1        |
| 9        | 2210-143 | Baffle                      | 1        |
| 10       | 12-3270  | Screw Special               | 1        |

| Ref. No. | Part No. | Description                         | No. Used |
|----------|----------|-------------------------------------|----------|
| 11       | 11-9760  | Screw Special                       | 1        |
| 12       | 23-1260  | Decal Engine                        | 1        |
| 13       | 28-4730  | Cover Belt Drive                    | 1        |
| 14       | 32144-11 | Screw Hex Hd.                       | 1        |
| 15       | 11-0580  | Screw                               | 3        |
| 16       | 5-4769   | Muffler Assy. (Incl. Ref. #17 & 18) | 1        |
| 17       | 3-5094   | Locking Clip                        | 1        |
| 18       | 321-20   | Screw Hex Hd.                       | 2        |
| 19       | 12-5450  | Screw Special                       | 2        |
| *        | 33-2930  | Starter Rope                        | 1        |

\*Not Illustrated




## STARTER MOTOR

| Ref. No. | Part No. | Description     | No. Used |
|----------|----------|-----------------|----------|
| 1        | 32151-47 | Retaining Ring  | 1        |
| 2        | 25-3970  | Washer          | 1        |
| 3        | 25-3960  | Pinion Assembly | 1        |
| 4        | 23-9590  | Spacer          | 1        |

| Ref. No. | Part No. | Description                                | No. Used |
|----------|----------|--------------------------------------------|----------|
| 5        | 218-472  | Mounting Bracket                           | 1        |
| 6        | 25-3950  | Starter Motor                              | 1        |
| 7        | 218-494  | End Plate                                  | 1        |
| *        | 25-3940  | Starter Motor Assembly<br>(Incl. Ref. 1-7) | 1        |

\*Not Illustrated



## GEAR CASE ASSEMBLY


| Ref. No. | Part No. | Description                    | No. Used |
|----------|----------|--------------------------------|----------|
| 1        | 5-3247   | Shifter Fork                   | 1        |
| 2        | 25-7740  | Knob Arm                       | 2        |
| 3        | 38-2220  | Pivot Arm (Incl. Ref.#20 & 40) | 2        |
| 4        | 37-9440  | Drive Shaft                    | 1        |
| 5        | 3-0731   | Spring                         | 1        |
| 6        | 5-3248   | Shifter Rod                    | 1        |
| 7        | 32121-1  | Roll Pin                       | 2        |
| 8        | 20-2780  | Pulley                         | 1        |
| 9        | 3290-346 | Push On Retainer               | 1        |
| 10       | 5-4505   | V-Belt                         | 1        |
| †11      | 33-2080  | Cover Gear Case                | 1        |
| ‡ *      | 39-1100  | Cover Gear Case                | 1        |
| 12       | 32140-64 | Self Tapping Screw             | 1        |
| 13       | 32121-23 | Roll Pin                       | 1        |
| 14       | 5-3252   | Shifter Arm                    | 1        |
| 15       | 3-2615   | Transmission Dust Cover        | 1        |
| 16       | 3-0681   | Latch Plate                    | 1        |
| 17       | 36-1000  | Gasket Gear Case               | 1        |
| †18      | 251-144  | Ball Bearing                   | 1        |
| ‡ *      | 251-284  | Ball Bearing                   | 1        |
| 19       | 25-7930  | Spring Arm L.H.                | 1        |
| 20       | 256-206  | Bushing                        | 2        |
| 21       | 32121-98 | Spiral Pin                     | 2        |
| 22       | 18-9820  | Wheel Cover                    | 2        |
| 23       | 18-9810  | Thrust Washer                  | 2        |
| 24       | 18-9690  | Gear Pinion                    | 2        |

| Ref. No. | Part No. | Description                            | No. Used |
|----------|----------|----------------------------------------|----------|
| 25       | 27-6230  | Wheel Bolt                             | 2        |
| 26       | 36-7790  | Wheel & Tire Assembly                  | 2        |
| 27       | 32146-6  | Locknut                                | 2        |
| 28       | 3-2646   | End Cap                                | 2        |
| 29       | 253-140  | Oil Seal                               | 2        |
| 30       | 256-110  | Bushing                                | 1        |
| †31      | 6-9949   | Worm Shaft & Gear<br>(Incl. Ref. #42)  | 1        |
| ‡ *      | 8-5679   | Worm Shaft & Gear<br>(Incl. Ref. #42)  | 1        |
| 32       | 8-0479   | Gear Case<br>(Incl. Ref. # 29-30 & 35) | 1        |
| 33       | 11-9760  | Screw                                  | 4        |
| 34       | 28-1550  | Screw Nylon                            | 1        |
| 35       | 256-263  | Bushing                                | 1        |
| 36       | 24-7920  | Cover Drive Shaft                      | 1        |
| 37       | 17-4490  | Spring Belt Tension                    | 1        |
| 38       | 25-7920  | Spring Arm R.H.                        | 1        |
| 39       | 32121-98 | Spiral Pin                             | 1        |
| 40       | 3-0721   | Sleeve                                 | 1        |
| 41       | 19-5660  | Clutch Jaw                             | 1        |
| 42       |          | Helical Gear                           | 1        |
| 43       | 3-0724   | Thrust Washer                          | 1        |
| 44       | 256-1    | Bushing                                | 2        |
| *        | 33-2150  | Gear Case Assembly Complete            | 1        |

\*Not Illustrated

†Used on units with Serial No. 9000001 thru 9499999.


‡Used on units with Serial No. 9500000 & up.



## HANDLE ASSEMBLY


| Ref. No. | Part No. | Description         | No. Used |
|----------|----------|---------------------|----------|
| 1        | 218-466  | Clip                | 1        |
| 2        | 26-0540  | Upper Handle        | 1        |
| 3        | 21-5160  | Control Plate       | 1        |
| 4        | 26-2220  | Decal Control Plate | 1        |
| 5        | 33-2546  | Throttle Control    | 1        |
| 6        | 218-412  | Key                 | 2        |
| 7        | 218-461  | Nut                 | 1        |
| 8        | 3296-9   | Nut                 | 2        |
| 9        | 33-2556  | Traction Control    | 1        |
| 10       | 3256-21  | Washer              | 2        |
| 11       | 24-9760  | Safety Switch       | 1        |
| 12       | 3290-124 | Screw               | 2        |
| 13       | 25-1590  | Cover Switch        | 1        |
| 14       | 23-0660  | Starter Switch      | 1        |
| 15       | 25-0090  | Wiring Harness      | 1        |
| 16       | 3254-5   | Lockwasher          | 1        |
| 17       | 32104-76 | Screw               | 4        |
| 18       | 3290-378 | Cable Tie           | 2        |

| Ref. No. | Part No. | Description                                     | No. Used |
|----------|----------|-------------------------------------------------|----------|
| 19       | 39-0630  | Cover                                           | 1        |
| 20       | 32104-29 | Self Tapping Screw                              | 2        |
| 21       | 36-5380  | Decal                                           | 1        |
| 22       | 38-4180  | Battery Assembly<br>(Incl. Ref. #19-21 & 23-24) | 1        |
| 23       | 11-3790  | Plug & Wire Assembly                            | 1        |
| 24       | 39-0640  | Container Battery                               | 1        |
| 25       | 25-5650  | Cover-Wiring Harness Upper                      | 1        |
| 26       | 17-9420  | Handle Screw                                    | 2        |
| 27       | 6-9780   | Battery Charger                                 | 1        |
| 28       | 38-2620  | Lower Handle                                    | 1        |
| 29       | 17-9380  | Handle Pin                                      | 2        |
| 30       | 32146-8  | Locknut                                         | 2        |
| 31       | 3290-255 | Hair Pin Cotter                                 | 2        |
| 32       | 2412-49  | Breakout Fitting                                | 1        |
| 33       | 19-4050  | Handle Knob                                     | 2        |
| 34       | 25-5660  | Cover-Wiring Harness Lower                      | 1        |
| 35       | 2412-48  | Ring Fitting                                    | 1        |



## BAGGING KIT NO. 36-8380 (Optional)

| Ref. No. | Part No. | Description                     | No. Used | Ref. No. | Part No. | Description     | No. Used |
|----------|----------|---------------------------------|----------|----------|----------|-----------------|----------|
| 1        | 6-0929   | Grass Bag                       | 1        | 4        | 3295-26  | Rivet           | 2        |
| 2        | 20-4590  | Bag Rod                         | 1        | 5        | 20-4650  | Handle Chute    | 1        |
| 3        | 6-1089   | Grass Chute (Incl. Ref. #4 & 5) | 1        | 6        | 36-5230  | Bag Chute Decal | 1        |




## GIANT BAGGING KIT NO. 29-9750 (Optional)

| Ref. No. | Part No. | Description | No. Used |
|----------|----------|-------------|----------|
| 1        | 2410-29  | Cap         | 1        |
| 2        | 29-7000  | Tube 25"    | 1        |
| *        | 11-0650  | Tube 28"    | 1        |

| Ref. No. | Part No. | Description         | No. Used |
|----------|----------|---------------------|----------|
| 3        | 8-4719   | Bag (Incl. Ref. #5) | 1        |
| 4        | 22-4820  | Hanger Rod          | 1        |
| 5        | 3-2781   | Bag Cord Fasteners  | 1        |

\*Not Illustrated






## CARBURETOR NO. 632050

| Ref. No. | Part No. | Description                   | No. Used |
|----------|----------|-------------------------------|----------|
| 1        | 631615   | Shaft & Lever Assy., Throttle | 1        |
| 3        | 631616   | Shutter, Throttle             | 1        |
| 4        | 650506   | Screw, Throttle Shutter       | 1        |
| 5        | 632016   | Spring, Return                | 1        |
| 6        | 631971   | Seal, Dust                    | 1        |
| 7        | 631184   | Washer                        | 1        |
| 8        | 631972   | Retainer, Dust Seal           | 1        |
| 9        | 632047   | Bulb & Retainer, Primer       | 1        |
| 11       | 631027   | Plug, Welch                   | 1        |

| Ref. No. | Part No. | Description                                          | No. Used |
|----------|----------|------------------------------------------------------|----------|
| 12       | 631021   | Inlet Needle, Seat & Clip Assy.<br>(Incl. Ref. # 13) | 1        |
| 13       | 631022   | Clip, Inlet Needle                                   | 1        |
| 14       | 632019   | Float, Carburetor                                    | 1        |
| 15       | 631024   | Shaft, Float                                         | 1        |
| 16       | 631700   | Bowl, Float                                          | 1        |
| 21       | 631334   | Gasket, Bowl-to-Body                                 | 1        |
| 22       | 631935   | Nut, Float Bowl                                      | 1        |
| 25       | 631028   | Gasket, Bowl-to-Body                                 | 1        |
| 26       | 631807   | Fitting, Fuel Inlet                                  | 1        |

# ENGINE TECUMSEH MODEL NO. TNT 100-10056C



# ENGINE TECUMSEH MODEL NO. TNT 100-10056C

| Ref. No. | Part No. | Description                                                    | No. Used |
|----------|----------|----------------------------------------------------------------|----------|
| 1        | 34429    | Cylinder Assy. (Incl. Ref. #2 & 4)                             | 1        |
| 2        | 26727    | Pin, Dowel                                                     | 2        |
| 4        | 32600    | Seal, Oil                                                      | 1        |
| 5        | 30589    | Rod, Governor (Incl. Ref. #6)                                  | 1        |
| 6        | 28277    | Washer, Flat                                                   | 1        |
| 7        | 32651    | Lever, Governor                                                | 1        |
| 8        | 31335    | Clamp, Governor Lever                                          | 1        |
| 9        | 650548   | Screw, Hex Washer Hd.                                          | 1        |
| 10       | 34440    | Crankshaft                                                     | 1        |
| 13       | 32603A   | Piston, Pin & Ring Assembly (Incl. Ref. #14 & 15) (Std.)       | 1        |
| 13       | 32604A   | Piston, Pin & Ring Assy. (Incl. Ref. #14 & 15) (.010 Oversize) | 1        |
| 13       | 32605A   | Piston, Pin & Ring Assy. (Incl. Ref. #14 & 15) (.020 Oversize) | 1        |
| 14       | 20381    | Ring, Piston Pin Retaining                                     | 2        |
| 15       | 32606    | Ring Set, Piston (Std.)                                        | 1        |
| 15       | 32607    | Ring Set, Piston (.010 Oversize)                               | 1        |
| 15       | 32608    | Ring Set, Piston (.020 Oversize)                               | 1        |
| 16       | 30963B   | Rod Assy., Connecting (Incl. Ref. #17)                         | 1        |
| 17       | 32610A   | Bolt, Connecting Rod                                           | 2        |
| 20       | 27241    | Lifter, Valve                                                  | 2        |
| 21       | 33553    | Camshaft (Mech. Comp. Release)                                 | 1        |
| 22       | 29914    | Pump Assembly, Oil                                             | 1        |
| 24       | *26750A  | Gasket, Mounting Flange                                        | 1        |
| 25       | 30594B   | Flange Assy., Mounting (Incl. Ref. #26 thru 30)                | 1        |
| 26       | *28833   | Gasket, Oil Drain Plug                                         | 1        |
| 27       | 27244    | Plug, Oil Drain                                                | 1        |
| 28       | 26208    | Seal, Oil                                                      | 1        |
| 30       | 30574    | Shaft, Mechanical Governor                                     | 1        |
| 31       | 30590A   | Washer, Flat                                                   | 1        |
| 32       | 30591    | Gear Assy., Gov. (Incl. Ref. #31)                              | 1        |
| 33       | 30588A   | Spool, Governor                                                | 1        |
| 34       | 29193    | Ring, Retaining                                                | 2        |
| 35       | 650488   | Screw, Hex Hd. Sems                                            | 6        |
| 36       | 29314A   | Valve, Intake (Std.) (Incl. Ref. #38, 39 & 40)                 | 1        |
| 36       | 29315B   | Valve, Intake (1/32" Oversize) (Incl. Ref. #38, 39 & 40)       | 1        |
| 37       | 29313B   | Valve, Exhaust (Std.) (Incl. Ref. #38, 39 & 40)                | 1        |
| 37       | 29315B   | Valve, Exhaust (1/32" Oversize) (Incl. Ref. #38, 39 & 40)      | 1        |
| 38       | 31671    | Cap, Upper Valve Spring                                        | 2        |
| 39       | 31672    | Spring, Valve                                                  | 2        |
| 40       | 31673    | Cap, Lower Valve Spring                                        | 2        |
| 41       | 650489   | Screw, Hex Hd. Sems                                            | 2        |
| 42       | 610118   | Cover, Spark Plug                                              | 1        |
| 44       | 33876    | Gasket, Stator                                                 | 1        |
| 45       | 34214    | Breather Assy. (Incl. Ref. #46, 47, 49, 50 & 51)               | 1        |
| 46       | 33734    | Element, Breather                                              | 1        |
| 47       | *33735   | Gasket, Breather                                               | 1        |
| 49       | 650768   | Screw, Hex Hd. Thread Forming W/Conical Washer                 | 2        |
| 50       | 33886    | Tube, Breather                                                 | 1        |
| 51       | 33887    | Clip, Breather Tube                                            | 1        |
| 52       | 34459    | Wire, Ground                                                   | 1        |
| 53       | 610995   | Key, Flywheel                                                  | 1        |
| 54       | 34461    | Pulley, Starter                                                | 1        |
| 55       | 650815   | Washer, Belleville                                             | 1        |
| 56       | 650816   | Nut, Flywheel                                                  | 1        |
| 57       | *33015   | Gasket, Cylinder Head                                          | 1        |
| 58       | 34342    | Head, Cylinder                                                 | 1        |
| 60       | 6021A    | Screw, Hex Flange Hd.                                          | 8        |
| 64       | 33636    | Plug, Spark (Champion J-8 Or Equivalent)                       | 1        |
|          |          | Except For Canada                                              |          |

| Ref. No. | Part No. | Description                                                                    | No. Used |
|----------|----------|--------------------------------------------------------------------------------|----------|
| 64       | 34251    | Resistor Spark Plug (Canadian Regulations Require RJ-17LM Resistor Spark Plug) | 1        |
| 65       | *27234   | Gasket, Valve Spring Cover                                                     | 1        |
| 66       | 32755    | Cover, Valve Spring Box                                                        | 1        |
| 67       | 650128   | Screw, Fil. Hd. Sems                                                           | 2        |
| 68       | *32649   | Gasket, Intake Pipe                                                            | 1        |
| 69       | 33004    | Pipe, Intake                                                                   | 1        |
| 70       | 650451   | Screw, Hex Hd. Sems                                                            | 2        |
| 71       | *31688   | Gasket, Carburetor                                                             | 1        |
| 72       | 6201     | Screw, Hex Hd.                                                                 | 2        |
| 73       | 29752    | Nut & Lockwasher Assembly                                                      | 2        |
| 74       | 30705    | Line, Fuel                                                                     | 1        |
| 75       | 26460    | Clamp, Fuel Line                                                               | 2        |
| 76       | 34310    | Lever, Control                                                                 | 1        |
| 77       | 33889A   | Control Assy., Speed (Incl. Ref. #76 & 78)                                     | 1        |
| 78       | 650804   | Screw, Hex Washer Hd. Shoulder Self-Tap                                        | 1        |
| 79       | 27793    | Clip, Conduit                                                                  | 1        |
| 80       | 28942    | Screw, Hex Washer Hd. Sems                                                     | 1        |
| 81       | 34336    | Link, Governor-to-Throttle                                                     | 1        |
| 82       | 33151    | Link, Governor Spring                                                          | 1        |
| 83       | 33890    | Spring, Governor                                                               | 1        |
| 85       | 33907A   | Housing, Blower                                                                | 1        |
| 86       | 650497   | Screw, Flex Pan Hd.                                                            | 2        |
| 87       | 30200    | Screw, Hex Washer Hd. Self-Tap Sems                                            | 2        |
| 88       | *30081   | Gasket, Exhaust                                                                | 1        |
| 90       | 29443    | Clip, Fuel Line                                                                | 1        |
| 91       | 34431    | Lamination & Coil Assembly                                                     | 1        |
| 91A      | 650814   | Screw, Hex Washer Hd. Sems                                                     | 2        |
| 92       | 33895    | Body, Air Cleaner                                                              | 1        |
| 93       | 33896    | Filter, Air Cleaner                                                            | 1        |
| 94       | 33897    | Cover, Air Cleaner                                                             | 1        |
| 95       | 650762   | Screw, Fil. Hd. Sems                                                           | 2        |
| 96       | 650784   | Screw, Hex Hd. W/Flatwasher Taptite                                            | 1        |
| 97       | *33051   | Gasket, Air Cleaner                                                            | 1        |
| 98       | 33904A   | Tank, Fuel                                                                     | 1        |
| 99       | 28763    | Screw, Hex Washer Hd. Shakeprf.                                                | 2        |
| 100      | 33894A   | Dipstick, Oil (Incl. Ref. #101) (Twist Lock)                                   | 1        |
| 101      | 33590    | "O" Ring                                                                       | 1        |
| 102      | 34265    | Gasket                                                                         | 1        |
| 103      | 650562   | Screw, Hex Washer Hd. Shakeprf.                                                | 2        |
| 104      | 34380    | Tube, Oil Filler (Plastic)                                                     | 1        |
| 105      | 590343   | Rope Assembly, Starter                                                         | 1        |
| 106      | 611010   | Flywheel                                                                       | 1        |
| 107      | 30551    | Spring, Breaker Box Dust Cover                                                 | 1        |
| 108      | 610947   | Cover, Breaker Box Dust                                                        | 1        |
| 109      | 610955   | Gasket, Dust Cover                                                             | 1        |
| 110      | 30992    | Cam, Breaker                                                                   | 1        |
| 111      | 30547A   | Breaker Assembly                                                               | 1        |
| 112      | 610385   | Washer, Terminal                                                               | 1        |
| 113      | 610408   | Nut, Terminal                                                                  | 1        |
| 114      | 29181    | Screw & Washer Assy., Breaker                                                  | 1        |
| 115      | 610593   | Screw, Condenser Fastening                                                     | 1        |
| 116      | 33356    | Tab, Ground Terminal                                                           | 1        |
| 117      | 30548B   | Condenser                                                                      | 1        |
| 118      | 611008   | Core & Plate Group                                                             | 1        |
| 119      | 611006   | Stator Assembly (Incl. Ref. #107, 111-118 & 120)                               | 1        |
| 120      | 30549    | Felt, Cam Wiper                                                                | 1        |
| 121      | 632050   | Carburetor (Incl. Ref. #71)                                                    | 1        |
| 123      | 33906    | Gasket Set (Incl. Items Marked*)                                               | 1        |

# THE TORO PROMISE

It is Toro's policy to design and produce TORO products to provide our customers with a high level of performance and durability in normal operation. Our products, however, are produced in high volume, and it is inevitable that occasionally a unit will reach a customer with a defect in materials or workmanship which causes the unit to fall below the normal high

level of TORO performance. Invariably, such a defect will be noticed in a residential product within one year after purchase. Recognizing this possibility, Toro has established a simple guarantee policy and procedure that is intended to assure customer satisfaction. This guarantee statement is as follows:

## The Toro Promise

### A One Year Limited Warranty

*The Toro Company promises to repair any TORO Product if defective in materials or workmanship. The following time periods from the date of purchase apply:*

Residential Product . . . . . 1 Year  
Residential Products Used Commercially . . . 45 Days

*The costs of parts and labor are included, but the customer pays the transportation costs. Just return any residential product to an Authorized TORO Service Dealer or TORO Distributor.*

Should you feel your TORO is defective and wish to rely on The Toro Promise, the following procedure is recommended:

1. Contact any Authorized TORO Service Dealer, TORO Master Service Dealer, or TORO Distributor (the Yellow Pages of your telephone directory is a good reference source).
2. He will either instruct you to return the product to him or recommend another Authorized TORO Service outlet which might be more convenient.
3. Bring the product along with your original sales slip, or other evidence of purchase date, to the service dealer.
4. The servicing dealer will inspect the unit, advise you whether the product is defective and, if so, make all repairs necessary to correct the defect without extra charge to you.

If for any reason you are dissatisfied with the dealer's analysis of the defect or the service performed, you may contact us.

Write:

TORO Customer Service Department  
8111 Lyndale Avenue South  
Minneapolis, Minnesota 55420

The above remedy of product defects through repair by an Authorized TORO Service Dealer is the purchaser's sole remedy for any defect.

THERE IS NO OTHER EXPRESS WARRANTY. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND

FITNESS FOR USE ARE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY.

Some states do not allow limitation on how long implied warranty lasts, so the above limitation may not apply to you.

This warranty applies only to parts or components which are defective and does not cover repairs necessary due to normal wear, misuse, accidents, or lack of proper maintenance. Regular, routine maintenance of the unit to keep it in proper operating condition is the responsibility of the owner.

All warranty repairs reimbursable under The Toro Promise must be performed by an Authorized TORO Service Dealer using Toro approved replacement parts.

Repairs or attempted repairs by anyone other than an Authorized TORO Service Account are not reimbursable under The Toro Promise. In addition, these unauthorized repair attempts may result in additional malfunctions, the correction of which is not covered by warranty.

The Toro Company is not liable for indirect, incidental or consequential damages in connection with the use of the product including any cost or expense of providing substitute equipment or service during periods of malfunction or non-use.

Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

## PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change apparently has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

## PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change apparently has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

## IDENTIFICATION AND ORDERING

### Model and Serial Numbers

The mower has two identification numbers: a model number and a serial number. The two numbers are stamped on a decal which is located on the mower housing between the rear wheels. In any correspondence concerning the mower, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Distributor, supply the following information:

1. Model and serial numbers of the mower.
2. Part number, description, and quantity of part(s) desired.

**NOTE:** Do not order by reference number if a parts catalog is being used; use the **PART NUMBER**.

## IDENTIFICATION AND ORDERING

### Model and Serial Numbers

The mower has two identification numbers: a model number and a serial number. The two numbers are stamped on a decal which is located on the mower housing between the rear wheels. In any correspondence concerning the mower, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Distributor, supply the following information:

1. Model and serial numbers of the mower.
2. Part number, description, and quantity of part(s) desired.

**NOTE:** Do not order by reference number if a parts catalog is being used; use the **PART NUMBER**.

## IDENTIFICATION AND ORDERING

### Model and Serial Numbers

The mower has two identification numbers: a model number and a serial number. The two numbers are stamped on a decal which is located on the mower housing between the rear wheels. In any correspondence concerning the mower, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Distributor, supply the following information:

1. Model and serial numbers of the mower.
2. Part number, description, and quantity of part(s) desired.

**NOTE:** Do not order by reference number if a parts catalog is being used; use the **PART NUMBER**.

## IDENTIFICATION AND ORDERING

### Model and Serial Numbers

The mower has two identification numbers: a model number and a serial number. The two numbers are stamped on a decal which is located on the mower housing between the rear wheels. In any correspondence concerning the mower, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Distributor, supply the following information:

1. Model and serial numbers of the mower.
2. Part number, description, and quantity of part(s) desired.

**NOTE:** Do not order by reference number if a parts catalog is being used; use the **PART NUMBER**.

- ## IDENTIFICATION AND ORDERING
- ### Model and Serial Numbers
- The mower has two identification numbers: a model number and a serial number. The two numbers are stamped on a decal which is located on the mower housing between the rear wheels. In any correspondence concerning the mower, supply model and serial numbers to assure that correct information and replacement parts are obtained.
- To order replacement parts from an Authorized TORO Distributor, supply the following information:
1. Model and serial numbers of the mower.
  2. Part number, description, and quantity of part(s) desired.
- NOTE:** Do not order by reference number if a parts catalog is being used; use the **PART NUMBER**.

## IDENTIFICATION AND ORDERING

### Model and Serial Numbers

The mower has two identification numbers: a model number and a serial number. The two numbers are stamped on a decal which is located on the mower housing between the rear wheels. In any correspondence concerning the mower, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Distributor, supply the following information:

1. Model and serial numbers of the mower.
2. Part number, description, and quantity of part(s) desired.

**NOTE:** Do not order by reference number if a parts catalog is being used; use the **PART NUMBER**.

***Keep Your TORO All Toro***  ***Insist on Genuine Toro Parts***

## MAINTENANCE RECORD

[illegible]

## MAINTENANCE RECORD

[illegible]

## MAINTENANCE RECORD

[illegible]

## MAINTENANCE RECORD

[illegible]