



Form No. 3449-222 Rev C

**Count on it.**

# Parts Catalog

## TimeCutter® 42in Riding Mower

Model No. 75746TA—Serial No. 410040000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

Frame Assembly..... 4

Deck Lift Assembly..... 6

Tire and Caster Assembly..... 8

Traction Drive Assembly..... 10

LH Hydro Transmission Assembly No. 139-7450..... 12

RH Hydro Transmission Assembly No. 139-7451..... 14

Brake Assembly..... 16

Rear Tire Assembly..... 18

Seat Pan Assembly..... 20

Seat Assembly No. 147-5157..... 22

Motion Control Assembly..... 24

Engine and Muffler Assembly..... 26

Fuel Pod Assembly..... 28

Electrical Assembly..... 30


42in Deck and Decal Assembly..... 32

Frame Decal Assembly..... 34

Clutch Assembly..... 36

Attachments and Accessories..... 38

# Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 137-9820-01        | 1           | Frame Assembly             | 17          | 138-7200           | 2           | Cap-Grease         |
| 2           | 140-5045           | 1           | Pan-Floor ASM              | 18          | 117-1232-03        | 1           | Bracket-Hitch      |
| 2:2         | 144-5288           | 1           | Decal-Warning              | 20          | 139-5890           | 1           | Decal-Timecutter   |
| 3           | 138-7520-01        | 2           | Plate-Mount, Hydro         | 21          | 139-2387           | 1           | Decal-Timecutter   |
| 5           | 137-7020-01        | 1           | Mount-Hydro, Front (Right) | 22          | 121-2989           | 2           | Decal-Bypass       |
| 6           | 139-3211-01        | 1           | Mount-Hydro, Front (Left)  | 26          | 138-9753           | 20          | Screw              |
| 7           | 138-9791-01        | 1           | Brace-Cross                | 27          | 139-2429           | 4           | Screw-HHF          |
| 9           | 138-0867-03        | 1           | Guard-Muffler              | 28          | 3234-29            | 14          | Screw-HHF          |
| 10          | 138-6036-03        | 1           | Support-Seat               | 30          | 139-2428           | 4           | Screw-HWH          |
| 11          | 138-2548           | 2           | Spring-Compression         | 32          | 139-2430           | 4           | Nut-HF, NI         |
| 12          | 138-9820-03        | 1           | Guard-Engine               | 33          | 104-8300           | 14          | Nut-HF, NI         |
| 14          | 138-9827-01        | 1           | Footrest                   | 35          | 139-3220           | 1           | Tread-Step         |
| 15          | 140-2098           | 2           | Axle Stub ASM              | 36          | 701178             | 2           | Cap-Protector      |
| 15:2        | 109-3678           | 2           | Bearing-Ball               |             |                    |             |                    |

# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 137-7093-03        | 1           | Deck Lift ASM           | 15          | 138-9753           | 5           | Screw              |
| 2           | 138-6021           | 2           | Bracket-Pivot, Decklift | 16          | 3234-29            | 1           | Screw-HHF          |
| 3           | 137-9844           | 1           | LH Arm ASM              | 18          | 137-9847           | 2           | Screw-Shoulder     |
| 4           | 137-9846           | 1           | RH Arm ASM              | 20          | 93-8806            | 2           | Washer-Hardened    |
| 5           | 139-2350-01        | 1           | Bracket-HOC             | 21          | 3256-26            | 7           | Washer-Flat        |
| 6           | 138-2564           | 2           | Plate-Adjustment, HOC   | 23          | 104-8300           | 1           | Nut-HF, NI         |
| 7           | 137-7087-03        | 1           | Lever-Lift              | 24          | 104-8301           | 2           | Nut-HF, NI         |
| 8           | 138-6050           | 1           | Rod-Mount, Deck         | 25          | 3296-19            | 1           | Nut-Hex            |
| 9           | 119-8810           | 1           | Pin-Pivot               | 26          | 139-2392           | 1           | Decal-HOC          |
| 14          | 1-806005           | 7           | Pin-Cotter              | 27          | 1-633268           | 1           | Grip-Lever         |

# Tire and Caster Assembly



## Tire and Caster Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 139-3274-01        | 2           | Fork ASM           | 2:99        | 105-0844           | 1           | Tube-Inner●■       |
| 2           | 139-5842           | 2           | Tire ASM           | 5           | 138-7240           | 2           | Bushing-Spanner    |
| 2:1         | 140-2736           | 1           | Tire               | 6           | 325-22             | 2           | Screw-HH           |
| 2:3         | 114-1640           | 2           | Bushing-Flange     | 7           | 3296-45            | 2           | Nut-Hex            |
| 2:4         | 232-27             | 1           | Stem-Valve         | 8           | 3256-68            | 2           | Washer-Flat        |
| 2:5         | 302-5              | 1           | Fitting-Grease     | 9           | 3234-47            | 2           | Screw-HHF          |

● Not illustrated

■ Optional Equipment


# Traction Drive Assembly



## Traction Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 139-7450           | 1           | LH Hydro Transaxle ASM | 14          | 3230-8             | 1           | Screw-CARR         |
| 2           | 139-7451           | 1           | RH Hydro Transaxle ASM | 15          | 115-1794           | 1           | Screw-HHF          |
| 3           | 138-2571-03        | 1           | Crossplate-Hydro       | 16          | 138-7590           | 4           | Screw-HHF          |
| 4           | 139-2399           | 1           | V-Belt                 | 17          | 322-11             | 4           | Screw-HH           |
| 5           | 138-9809           | 1           | Spacer                 | 18          | 324-8              | 2           | Screw-HH           |
| 6           | 138-7276           | 1           | Arm-Idler              | 19          | 324-10             | 4           | Screw-HH           |
| 7           | 138-7277           | 1           | Spacer-Arm, Idler      | 21          | 5-4460             | 1           | Washer-Pivot       |
| 8           | 68-0030            | 1           | Idler                  | 22          | 104-8300           | 10          | Nut-HF, NI         |
| 9           | 138-7597           | 1           | Pulley-Idler, Flat     | 24          | 3296-48            | 6           | Nut-Hex            |
| 10          | 137-7040           | 1           | Spring-Return, Pedal   | 25          | 242-50             | 8           | Nut-Lug            |
| 11          | 138-7245           | 1           | Rod-Bypass, RH         | 32          | 3256-25            | 6           | Washer-Flat        |
| 12          | 138-7243           | 1           | Rod-Bypass, LH         | 33          | 3256-23            | 2           | Washer-Plain       |
| 13          | 3290-307           | 2           | Pin-Cotter             | 34          | 119-8952           | 2           | Washer             |

# LH Hydro Transmission Assembly No. 139-7450




# LH Hydro Transmission Assembly No. 139-7450 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 120-5532           | 1           | Main Housing ASM         | 81          | 104-5317           | 1           | Gear-10T/48T              |
| 2           | 120-5534           | 1           | Housing Side Kit         | 82          | 104-5318           | 1           | Gear-Jackshaft, 10T       |
| 5           | 104-2189           | 1           | Plug-Thread, Straight    | 83          | 104-5329           | 1           | Pin-Jackshaft             |
| 7           | 117-5359           | 16          | Screw-HHF                | 91          | 120-5539           | 1           | Gear-Bull                 |
| 10          | 104-2147           | 1           | Sealant ●                | 92          | 104-2142           | 1           | Nut-HJ                    |
| 31          | 106-8677           | 1           | Ring-Retaining, External | 93          | 115-8314           | 1           | Bushing-Inboard           |
| 32          | 106-8678           | 1           | Rod-Bypass               | 94          | 120-5540           | 1           | Shaft-Axle                |
| 33          | 106-8679           | 1           | Ring-Retaining, Internal | 95          | 120-5541           | 1           | Bearing-Sleeve            |
| 40          | 104-5304           | 1           | Swashplate-Trunnion      | 100         | 106-8694           | 1           | Disc-Brake, Cog           |
| 42          | 104-2116           | 1           | Stud                     | 110         | 106-8677           | 1           | Ring-Retaining, External  |
| 43          | 112-9853           | 1           | Puck-Friction            | 130         | 103-2666           | 1           | Cylinder Block Kit        |
| 50          | 133-1793           | 1           | Spring-Block             | 131         | 110-8561           | 1           | Pump Block ASM            |
| 51          | 120-5538           | 1           | Washer                   | 132         | 117-5362           | 1           | Control Arm Kit           |
| 52          | 104-5306           | 1           | Shaft-Input              | 133         | 106-8688           | 1           | Brake Arm Kit             |
| 53          | 104-5311           | 1           | Bearing-Ball             | 134         | 112-9861           | 1           | Center Section Filter Kit |
| 54          | 104-5307           | 1           | Ring-Retaining           | 135         | 114-1634           | 1           | Filter Kit                |
| 55          | 104-5308           | 1           | Spacer                   | 136         | 121-5730           | 1           | RH Expansion Tank Kit     |
| 56          | 104-5310           | 1           | Seal-Lip                 | 137         | 120-5549           | 1           | Bypass Kit                |
| 57          | 104-5309           | 1           | Ring-Retaining           | 138         | 121-5731           | 1           | Hub Kit                   |
| 58          | 104-2147           | 1           | Sealant                  | 139         | 135-7349           | 1           | Fan And Pulley Kit        |
| 60          | 94-6922            | 2           | Bearing-Thrust           | 150         | 104-5349           | 1           | Fitting-SAE               |
| 70          | 104-5339           | 1           | Washer-Flat              | 151         | 115-8302           | 1           | Hose                      |
| 71          | 104-5340           | 1           | Ring-Retaining           | 152         | 104-5361           | 1           | O-Ring                    |
| 72          | 104-5316           | 1           | Gear-Pinnion, 13T        | 159         | 121-5728           | 1           | Case-Tube                 |
| 73          | 106-8683           | 1           | Shaft-Motor              | 160         | 125-0041           | 1           | Cap-Axle                  |
| 74          | 104-5360           | 1           | Washer                   | 162         | 139-3278           | 1           | Breather ASM Kit          |
| 80          | 119-5541           | 1           | Washer                   | 163         | 120-7103           | 1           | Seal And Ring Kit         |

● Not illustrated

# RH Hydro Transmission Assembly No. 139-7451



# RH Hydro Transmission Assembly No. 139-7451 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 120-5531           | 1           | Main Housing ASM         | 81          | 104-5317           | 1           | Gear-10T/48T              |
| 2           | 120-5533           | 1           | Housing Side Kit         | 82          | 104-5318           | 1           | Gear-Jackshaft, 10T       |
| 5           | 104-2189           | 1           | Plug-Thread, Straight    | 83          | 104-5329           | 1           | Pin-Jackshaft             |
| 7           | 117-5359           | 16          | Screw-HHF                | 91          | 120-5539           | 1           | Gear-Bull                 |
| 10          | 104-2147           | 1           | Sealant ●                | 92          | 104-2142           | 1           | Nut-HJ                    |
| 31          | 106-8677           | 2           | Ring-Retaining, External | 93          | 115-8314           | 1           | Bushing-Inboard           |
| 32          | 106-8678           | 1           | Rod-Bypass               | 94          | 120-5540           | 1           | Shaft-Axle                |
| 33          | 106-8679           | 1           | Ring-Retaining, Internal | 95          | 120-5541           | 1           | Bearing-Sleeve            |
| 40          | 104-5304           | 1           | Swashplate-Trunnion      | 100         | 106-8694           | 1           | Disc-Brake, Cog           |
| 42          | 104-2116           | 1           | Stud                     | 110         | 106-8677           | 1           | Ring-Retaining, External  |
| 43          | 112-9853           | 1           | Puck-Friction            | 130         | 103-2666           | 1           | Cylinder Block Kit        |
| 51          | 133-1793           | 1           | Spring-Block             | 131         | 110-8561           | 1           | Pump Block ASM            |
| 51          | 120-5538           | 1           | Washer                   | 132         | 117-5362           | 1           | Control Arm Kit           |
| 52          | 104-5306           | 1           | Shaft-Input              | 133         | 106-8688           | 1           | Brake Arm Kit             |
| 53          | 104-5311           | 1           | Bearing-Ball             | 134         | 112-9862           | 1           | Center Section Filter Kit |
| 54          | 104-5307           | 1           | Ring-Retaining           | 135         | 114-1634           | 1           | Filter Kit                |
| 55          | 104-5308           | 1           | Spacer                   | 136         | 121-5735           | 1           | LH Expansion Tank Kit     |
| 56          | 104-5310           | 1           | Seal-Lip                 | 137         | 107-2489           | 1           | Bypass Arm Kit            |
| 57          | 104-5309           | 1           | Ring-Retaining           | 138         | 121-5731           | 1           | Hub Kit                   |
| 58          | 104-2147           | 1           | Sealant                  | 139         | 135-7349           | 1           | Fan And Pulley Kit        |
| 60          | 94-6922            | 2           | Bearing-Thrust           | 150         | 104-5349           | 1           | Fitting-SAE               |
| 70          | 104-5339           | 1           | Washer-Flat              | 151         | 115-8302           | 1           | Hose                      |
| 71          | 104-5340           | 1           | Ring-Retaining           | 152         | 104-5361           | 1           | O-Ring                    |
| 72          | 104-5316           | 1           | Gear-Pinnion, 13T        | 159         | 121-5728           | 1           | Case-Tube                 |
| 73          | 106-8683           | 1           | Shaft-Motor              | 160         | 125-0041           | 1           | Cap-Axle                  |
| 74          | 104-5360           | 1           | Washer                   | 162         | 139-3278           | 1           | Breather ASM Kit          |
| 80          | 119-5541           | 1           | Washer                   | 163         | 120-7103           | 1           | Seal And Ring Kit         |

● Not illustrated

# Brake Assembly



## Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 138-2514           | 1           | Brake Box ASM        | 7           | 3290-307           | 2           | Pin-Cotter         |
| 2           | 133-9284-03        | 1           | Bracket-Mount, Brake | 8           | 32144-36           | 4           | Screw-PPH          |
| 3           | 138-2591           | 1           | Rod-Brake, LH        | 9           | 32144-4            | 2           | Screw-HWH          |
| 4           | 138-2592           | 1           | Rod-Brake, RH        | 10          | 119-8952           | 6           | Washer             |
| 5           | 117-1169           | 4           | Spring-Compression   | 11          | 3296-42            | 2           | Nut-Lock, NI       |

# Rear Tire Assembly




# Rear Tire Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 139-5846           | 2           | Tire ASM           | 1:3         | 232-27             | 1           | Stem-Valve         |
| 1:1         | 140-2729           | 1           | Tire               | 1:99        | 107-2491           | 1           | Tube-Tire ●        |

● Not illustrated


# Seat Pan Assembly



## Seat Pan Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 138-9781-03        | 1           | Pan-Seat           | 8           | 5-4460             | 2           | Washer-Pivot       |
| 2           | 138-7555           | 1           | Rod-Pivot          | 9           | 322-2              | 2           | Screw-HH           |
| 3           | 108-0035           | 2           | Screw              | 12          | 139-2398           | 1           | Cable-Lanyard      |
| 4           | 147-5157           | 1           | Seat-16 In         | 13          | 120-7950           | 1           | Screw-Torx         |
| 6           | 37-8771            | 2           | Bolt-Shoulder, HF  |             |                    |             |                    |


# Seat Assembly No. 147-5157



## Seat Assembly No. 147-5157 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 139-5891           | 1           | Seat-16 In         |
| 2           | 147-2983           | 1           | Cover-Seat         |
| 3           | 82-2190            | 1           | Switch-Bail        |


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 138-7598-03        | 1           | Plate-Control Box, LH | 20          | 120-2273           | 2           | Washer-Nylon          |
| 2           | 138-7599-03        | 1           | Plate-Control Box, RH | 21          | 119-8925           | 2           | Washer-Belleville     |
| 3           | 139-3279           | 1           | Box-Storage           | 22          | 119-8952           | 2           | Washer                |
| 4           | 119-3470           | 2           | Actuator Arm ASM      | 23          | 139-5811           | 2           | Bolt-Pivot, Eccentric |
| 4:2         | 256-156            | 2           | Bushing-Flange        | 24          | 117-1198           | 2           | Bolt-Pivot            |
| 5           | 133-9299-05        | 2           | Arm-Control           | 25          | 120-7950           | 4           | Screw-Torx            |
| 6           | 139-5803           | 2           | Eccentric             | 26          | 138-7218           | 2           | Mount-Rod, Hydro      |
| 7           | 138-7539           | 2           | Spring-Torsion        | 27          | 115-5099           | 2           | Bolt-Pivot            |
| 8           | 133-7055           | 1           | Handle-Control, LH    | 28          | 94-4496            | 1           | Screw-PPH             |
| 8:1         | 121-0726           | 1           | Grip                  | 29          | 32144-1            | 2           | Screw-Taptite         |
| 9           | 133-7057           | 1           | Handle-Control, RH    | 30          | 3229-11            | 4           | Screw-CARR            |
| 9:1         | 121-0726           | 1           | Grip                  | 31          | 138-9753           | 10          | Screw                 |
| 10          | 138-2580           | 2           | Rod-Hydro, Front      | 32          | 3234-42            | 4           | Screw-HHF             |
| 11          | 144-1818           | 2           | Rod-Hydro, Rear       | 33          | 104-7201           | 4           | Nut-HF, NI            |
| 12          | 121-1753           | 2           | Pin-Rod, Hydro        | 34          | 3296-42            | 6           | Nut-Lock, NI          |
| 13          | 138-9750           | 1           | Speed Control ASM     | 35          | 117-1240           | 2           | Washer                |
| 14          | 138-7541           | 2           | Plate-Retainer        | 36          | 119-4041           | 2           | Nut-HF                |
| 15          | 132-9368           | 1           | Knob-RH               | 37          | 104-8301           | 4           | Nut-HF, NI            |
| 16          | 132-9369           | 1           | Knob-LH               | 38          | 139-3280-01        | 1           | Plate-Kick            |
| 17          | 132-6853           | 2           | Damper-Non Cavitating | 39          | 138-7252           | 2           | Spring-Compression    |
| 18          | 138-7215           | 2           | Stud-Damper           | 40          | 120-9683           | 2           | Washer-Plain          |
| 19          | 93-6079            | 2           | Spacer-Nylon          |             |                    |             |                       |

# Engine and Muffler Assembly



## Engine and Muffler Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           |                    | 1           | Engine-Kohler, Kt725 ■▲ |
| 1:1         | 110-6697           | 2           | Gasket-Exhaust ●        |
| 1:3         | 281-2              | 1           | Plug-Pipe, SQH ●        |
| 2           | 139-5868           | 1           | Muffler                 |
| 5           | 32144-109          | 4           | Screw-Thd               |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 3256-24            | 3           | Washer-Flat        |
| 7           | 117-1261           | 1           | Hose-Drain, Oil    |
| 8           | 614249             | 1           | Tie-Cable          |
| 10          | 33004-00           | 4           | Nut-HF             |

● Not illustrated  
 ▲ Obtain parts from [www.kohlerplus.com](http://www.kohlerplus.com)

■ Not serviced separately


# Fuel Pod Assembly



## Fuel Pod Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 138-6070-03        | 1           | Support-Pod, RH         | 14          | 139-3267           | 1           | Cable-Throttle     |
| 2           | 138-6071-03        | 1           | Support-Pod, LH         | 15          | 139-2402           | 1           | Cable-Choke        |
| 3           | 139-3271-03        | 1           | Support-Tank, Fuel      | 18          | 110-5702           | 1           | Hose-Fuel          |
| 4           | 138-6074           | 1           | Pod-LH                  | 19          | 136-6345           | 1           | Hose-Fuel          |
| 5           | 138-6075           | 1           | Pod-RH                  | 20          | 132-0918           | 1           | Hose-Fuel          |
| 6           | 144-5304           | 1           | Tank-Fuel ASM           | 23          | 144-1983           | 1           | Adapter Orifice    |
| 6:1         | 139-1091           | 1           | Connector-Elbow, 90 DEG | 24          | 2412-98            | 2           | Clamp-Hose         |
| 6:2         | 144-5302           | 1           | Fitting-Elbow 90        | 25          | 614249             | 5           | Tie-Cable          |
| 6:3         | 46-6560            | 2           | Bushing                 | 26          | 3258-166           | 1           | Screw-PRH          |
| 7           | 609830             | 2           | Spring                  | 27          | 120-7950           | 6           | Screw-Torx         |
| 8           | 137-4119           | 1           | Cap-Fuel, Ratcheting    | 28          | 138-9753           | 6           | Screw              |
| 9           | 107069             | 1           | Clip                    | 31          | 120-7893           | 1           | Bumper-Grommet     |
| 10          | 139-2380-03        | 1           | Panel - Control         | 50          | 2412-80            | 1           | Clamp-Hose         |
| 11          | 139-2391           | 1           | Decal-Panel, Control    |             |                    |             |                    |


# Electrical Assembly



## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 138-2521           | 1           | Harness-Wire        | 10          | 139-2431           | 1           | Cable-Battery, Red (8 |
| 1:1         | 109355             | 1           | Fuse-Blade, 15 Amp  |             |                    |             | Gauge)                |
| 1:2         | 109102             | 1           | Fuse-Blade, 25 Amp  | 11          | 121-5726           | 1           | Cable-Battery, Black  |
| 2           | 105-1692           | 1           | Battery, 230CCA W/O | 13          | 3256-22            | 2           | Washer-Flat           |
|             |                    |             | Electrolyte         | 14          | 32144-4            | 2           | Screw-HWH             |
| 3           | 117-1197           | 1           | Solenoid            | 15          | 321-3              | 1           | Screw-HH              |
| 4           | 137-4100           | 1           | Switch-Ignition     | 17          | 3229-1             | 1           | Screw-CARR            |
| 5           | 63-8360            | 1           | Key-Ignition        | 18          | 32128-33           | 2           | Nut-HF                |
| 6           | 103-5221           | 1           | Switch-PTO          | 19          | 32103-22           | 1           | Nut-Wing              |
| 7           | 110-6765           | 2           | Switch              | 20          | 3220-2             | 2           | Nut-Jam               |
| 8           | 139-2381           | 1           | Strap-Rubber        | 22          | 140-2080           | 1           | Cover-Solenoid        |
| 9           | 140-2713           | 1           | Cable-Battery, Pos  | 23          | 140-2081           | 1           | Cap-Solenoid          |


# 42in Deck and Decal Assembly



## 42in Deck and Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 138-9769           | 1           | 42In Deck And Decal ASM    | 20          | 115-4986           | 1           | Spacer              |
| 1:3         | 93-7009            | 1           | Decal-Danger               | 21          | 104-8301           | 6           | Nut-HF, NI          |
| 1:4         | 132-0872           | 2           | Decal-Danger, Deck         | 22          | 138-7262           | 1           | Arm-Idler           |
| 1:5         | 105-7015           | 1           | Decal-Routing, Belt        | 23          | 119-8819           | 1           | V-Belt              |
| 5           | 140-2123           | 1           | Decal-Deck                 | 24          | 137-2019           | 1           | Rod-Pivot           |
| 6           | 139-3214           | 2           | Spindle ASM                | 25          | 138-7502           | 1           | Deflector-Discharge |
| 6:2         | 120-7935           | 2           | Spacer                     | 26          | 138-7268           | 1           | Spring-Torsion      |
| 6:3         | 138-9770           | 2           | Bearing-Ball               | 27          | 3296-59            | 1           | Nut-Lock, NI        |
| 7           | 32144-41           | 8           | Screw-Taptite              | 28          | 1-603299           | 2           | Roller-Scalp, Anti  |
| 8           | 117-7268           | 2           | Shaft-Spindle              | 29          | 112-3977           | 2           | Bolt-Shoulder       |
| 9           | 139-2433           | 2           | Pulley                     | 30          | 133-9289           | 1           | Fitting-Washout     |
| 10          | 3219-6             | 2           | Nut-Hex                    | 30:2        | 133-9290           | 1           | O-Ring              |
| 11          | 137-1999-03        | 2           | Blade                      | 31          | 32144-4            | 2           | Screw-HWH           |
| 12          | 3290-465           | 2           | Washer-Belleville          | 32          | 138-7267           | 1           | Hook-Spring, Return |
| 13          | 26-0671            | 2           | Screw-HH                   | 33          | 138-7265           | 1           | Spring Extension    |
| 14          | 132-9420           | 2           | Pulley-Idler, Flat         | 34          | 139-5871           | 2           | Pin-Deck            |
| 15          | 3256-24            | 1           | Washer-Flat                | 35          | 144-1905           | 2           | Cover-Belt          |
| 16          | 323-9              | 3           | Screw-HH                   | 36          | 95-3270            | 1           | Connector-Hose      |
| 17          | 110-9981           | 1           | Washer-Plain               | 37          | 139-3272-03        | 2           | Bracket-Cover, Belt |
| 18          | 63-7400            | 2           | Washer-Rebound             | 38          | 144-1944           | 2           | Pin-Hair            |
| 19          | 114-0463           | 2           | Washer-Friction, Composite | 39          | 94-6961            | 2           | Screw               |

# Frame Decal Assembly



## Frame Decal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 10          | 140-2099           | 1           | Decal              |

# Clutch Assembly



## Clutch Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 138-7275           | 1           | Stop-Clutch (Narrow) | 5           | 104-8301           | 1           | Nut-HF, NI         |
| 2           | 138-9792           | 1           | Pulley-Engine        | 6           | 120-2217           | 1           | Isolator-Clutch    |
| 3           | 117-7468           | 1           | Clutch-Electric      | 7           | 3212-16            | 1           | Screw-HH           |
| 4           | 3234-42            | 1           | Screw-HHF            |             |                    |             |                    |

# Attachments and Accessories

## For 75746TA TimeCutter 42in Riding Mower

| Product Name                                                                    | Model/Part   |
|---------------------------------------------------------------------------------|--------------|
| Hourmeter Kit .....                                                             | 116-5461     |
| Seat Cover W/O Arm Rest - TC 18in.....                                          | 117-0096     |
| Jack Kit .....                                                                  | 127-6666     |
| Fuel Stabilizer .05 oz .....                                                    | 130-2393     |
| 4-Cycle Fuel, Snow And Lawn 32oz Can .....                                      | 131-3823     |
| Toro Premium Fuel Treatment 12 Oz Bottle .....                                  | 131-6572     |
| Replacement Blade Kit .....                                                     | 137-1999-03P |
| 42 Inch Recycler Kit.....                                                       | 139-3265     |
| 42 Inch Bagging Enhancement Kit.....                                            | 139-7478     |
| Front Weight Kit.....                                                           | 140-2050     |
| Assist Bar Kit .....                                                            | 140-2052     |
| Sunshade Kit .....                                                              | 140-2054     |
| LED Light Kit.....                                                              | 140-2056     |
| Deluxe Seat Kit.....                                                            | 140-2057     |
| Armrest Kit.....                                                                | 140-2058     |
| Deck Footlift Assist Kit .....                                                  | 140-2059     |
| Floormat Kit .....                                                              | 140-2060     |
| Jack Mount Kit .....                                                            | 140-2711     |
| 42 Inch Striping Kit.....                                                       | 140-5159     |
| Caster Wheel Kit.....                                                           | 145-0475     |
| 10w30 4-Cycle Engine Oil (32oz Bottle).....                                     | 38280        |
| Toro 4-Cycle SAE 30 Oil (32oz Bottle) .....                                     | 38903        |
| Storage Cover .....                                                             | 490-7516     |
| Mower Deck Drive Belt, TimeCutter SS Riding Mower with 42-inch Mowing Deck..... | 79004        |
| Twin Bagger, Timecutter 42 Inch Fab.....                                        | 79411        |
| ROPS Kit .....                                                                  | 79485        |
| Slope Sensor Kit.....                                                           | 79486        |

**Notes:**



**Count on it.**