



Wheel Weight Kit Groundsmaster® 117

Part No. 56-6620

Part No. 99-5890

Note: If unit is equipped with the optional Brake Kit, refer to the Brake Kit Installation Instructions for additional information on mounting of wheel weights.

1. Remove cap from valve stem and install valve stem extension.
2. Slide wheel weight onto mounting position over valve stem, aligning weight with (2) mounting holes in wheel.
3. Secure weight to wheel with (2) 5/16-18 x 4" lg. capscrews and flat washers.
4. Repeat procedure on opposite wheel.

