



Hydraulic Motor Kit

Reelmaster[®] 216

Model No. 99-4997

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.




PROTOTYPE

Ref. No.	Part No.	Qty.	Description
1 ☆2	26-3790	1 1	Nut-Lock Hydraulic Motor ASM

Ref. No.	Part No.	Qty.	Description
OTOTYPE			

2



Sheet No.:A1

Hydraulic Motor Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	106-2668	1	Body				
3	65-4600	1	Washer				
4	106-2666	1	Shaft-Taper				
5	3257-15	1	Key-Woodruff				
7	65-4500	1	Ring-Retaining				
9	106-2670	1	Plate-Commutator				
10	106-2667	1	Igr ASM				
11	98-3449	1	Ring-Snap				
12	65-4560	1	Plug				
13	65-4680	1	Cover ASM				
14	106-2669	8	Screw-Cap, HH				
15	106-2672	1	Washer-Thrust				
16	106-2671	1	Washer-Thrust				
☆17		1	Plate-Valve				
18	105-4064	1	Seal Kit				
☆18:2		1	O-Ring Seal				
☆18:6		1	Seal/Retainer ASM				
☆18:8		3	Seal-Ring, Square				
19	65-4550	2	Ball-Valve, Check				

☆ Not serviced separately



PROTOTYPE