



Form No. 3459-501 Rev A

**Count on it.**

# Parts Catalog

## **Groundsmaster® 5900** **Rotary Mower**

Model No. 31698—Serial No. 412500000 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                                                   |    |
|-------------------------------------------------------------------|----|
| Frame Assembly . . . . .                                          | 6  |
| Rear Axle Assembly . . . . .                                      | 8  |
| Axle Assembly No. 114-5982-03 . . . . .                           | 10 |
| Tie Rod Assembly No. 110-6049-03 . . . . .                        | 11 |
| Engine and Mount Assembly . . . . .                               | 12 |
| Alternator Assembly . . . . .                                     | 14 |
| Hydraulic Cooling Assembly . . . . .                              | 16 |
| Radiator and Cooling Fan Assembly . . . . .                       | 18 |
| Air Cleaner Assembly . . . . .                                    | 20 |
| Fuel System Assembly . . . . .                                    | 22 |
| Traction Hydraulic Assembly . . . . .                             | 24 |
| Piston Pump Assembly No. 130-9150 . . . . .                       | 26 |
| Hydraulic Gear Pump Assembly No. 130-2520 . . . . .               | 28 |
| Traction Manifold Assembly . . . . .                              | 30 |
| Hydraulic Traction Valve Manifold Assembly No. 137-5623 . . . . . | 32 |
| Hydraulic Traction Motors Assembly . . . . .                      | 34 |
| Hydraulic Motor Assembly No. 125-5434 . . . . .                   | 36 |
| Hydraulic Motor Assembly No. 125-5391 . . . . .                   | 38 |
| Hydraulic Traction Assembly . . . . .                             | 40 |
| Hydraulic Motor Assembly No. 132-1425 . . . . .                   | 42 |
| Hydraulic Tank Assembly . . . . .                                 | 44 |
| Hydraulic Cutting Circuit Assembly . . . . .                      | 46 |
| Center Cutting Deck Drive Valve Assembly . . . . .                | 48 |
| Hydraulic Manifold Assembly No. 132-1394 . . . . .                | 49 |
| LH Cutting Deck Drive Valve Assembly . . . . .                    | 50 |
| Hydraulic Manifold Assembly No. 132-1396 . . . . .                | 51 |
| RH Cutting Deck Drive Valve Assembly . . . . .                    | 52 |
| Hydraulic Manifold Assembly No. 132-1396 . . . . .                | 53 |
| Hydraulic Motor Assembly No. 125-5392 . . . . .                   | 54 |
| Hydraulic Steering/Lift Circuit Assembly . . . . .                | 56 |
| Steering/Lift Valve Assembly No. 137-5626 . . . . .               | 58 |
| Hydraulic Steering/Lift Manifold Assembly No. 137-5625 . . . . .  | 60 |
| Hydraulic Cylinder Assembly No. 114-4830 . . . . .                | 62 |
| Hydraulic Cylinder Assembly No. 114-4831 . . . . .                | 63 |
| Hydraulic Cylinder Assembly No. 114-5685 . . . . .                | 64 |
| Manual Parking Brake Manifold Assembly No. 132-1378 . . . . .     | 65 |
| Hydraulic Parking Brake Manifold Assembly No. 132-1399 . . . . .  | 66 |
| Hydraulic Steering Assembly . . . . .                             | 68 |
| Steering Valve Assembly No. 132-6256 . . . . .                    | 70 |
| Hydraulic Cylinder Assembly No. 132-1308 . . . . .                | 72 |
| Hydraulic Filter Manifold Assembly . . . . .                      | 73 |
| Side Panel and Bumper Assembly . . . . .                          | 74 |
| Hood Assembly . . . . .                                           | 76 |
| Center Front Deck Connection Assembly . . . . .                   | 78 |
| LH Front Lift Arm Assembly No. 138-6368 . . . . .                 | 80 |
| RH Front Lift Arm Assembly No. 138-6369 . . . . .                 | 82 |
| Center Front and Winglet Deck Assembly . . . . .                  | 84 |
| Center Front Deck and Decal Assembly No. 130-9201 . . . . .       | 85 |
| Right Front Deck and Decal Assembly No. 130-9218 . . . . .        | 86 |
| Left Front Deck and Decal Assembly No. 130-9210 . . . . .         | 87 |
| Center Deck Belt, Pulley and Spindle Assembly . . . . .           | 88 |
| Single Driving Spindle Assembly No. 139-1034 . . . . .            | 90 |
| Double Driven Spindle Assembly No. 139-1033 . . . . .             | 92 |
| High Driven Spindle Assembly No. 139-1032 . . . . .               | 94 |


# Contents (continued)

|                                                                |     |
|----------------------------------------------------------------|-----|
| Center Deck Roller, Skid and Caster Wheel Assembly . . . . .   | 96  |
| 10 Inch Wheel Assembly No. 93-4240 . . . . .                   | 97  |
| Center Front Deck Spindle and Blade Assembly . . . . .         | 98  |
| Center Front Deck Belt Cover Assembly . . . . .                | 99  |
| Center Front Deck Chamber and Discharge Assembly . . . . .     | 100 |
| Center Front Deck Transport Damper Assembly . . . . .          | 101 |
| Left Hand Deck Connection Assembly . . . . .                   | 102 |
| Left Hand Deck Belt, Pulley and Spindle Assembly . . . . .     | 104 |
| Left Hand Deck Decal Assembly No. 130-9271 . . . . .           | 106 |
| Left Hand Deck Skid and Caster Wheel Assembly . . . . .        | 107 |
| Left Hand Deck Spindle and Blade Assembly . . . . .            | 108 |
| Left Hand Deck Belt Cover Assembly . . . . .                   | 109 |
| Left Hand Deck Chamber Assembly . . . . .                      | 110 |
| Left Hand Deck Stop Assembly . . . . .                         | 111 |
| Left Hand Deck Impact Arm and Limit Switch Assembly . . . . .  | 112 |
| Impact Damper Assembly No. 137-1648 . . . . .                  | 114 |
| Left Hand Deck Transport Lock Assembly . . . . .               | 116 |
| Right Hand Deck Connection Assembly . . . . .                  | 118 |
| Right Hand Deck Belt, Pulley and Spindle Assembly . . . . .    | 120 |
| Right Hand Deck Decal Assembly No. 130-9241 . . . . .          | 122 |
| Right Hand Deck Spindle and Blade Assembly . . . . .           | 123 |
| Right Hand Deck Belt Cover Assembly . . . . .                  | 124 |
| Right Hand Deck Chamber Assembly . . . . .                     | 126 |
| Right Hand Deck Impact Arm and Limit Switch Assembly . . . . . | 128 |
| Right Hand Deck Transport Lock Assembly . . . . .              | 130 |
| Platform Assembly . . . . .                                    | 132 |
| Seat Mount Assembly . . . . .                                  | 134 |
| Air Ride Seat Suspension Assembly No. 130-2702 . . . . .       | 136 |
| Control Console Assembly . . . . .                             | 138 |
| Traction Pedal Assembly . . . . .                              | 140 |
| Steering Column Assembly . . . . .                             | 142 |
| Steering Column Assembly No. 132-6230 . . . . .                | 143 |
| Front Electrical Component Assembly . . . . .                  | 144 |
| Mid Electrical Component Assembly . . . . .                    | 145 |
| Rear Electrical Component Assembly . . . . .                   | 146 |
| Battery Cable Routing Assembly . . . . .                       | 148 |
| Wire Harness Assembly . . . . .                                | 150 |
| Platform Wire Harness Assembly No. 122-1964 . . . . .          | 152 |
| Rear Wire Harness Assembly No. 122-1963 . . . . .              | 154 |
| Engine Wire Harness Assembly No. 122-1556 . . . . .            | 156 |
| Roll-Over Protection System Assembly . . . . .                 | 158 |
| Light Mount Kit Assembly No. 140-6698 . . . . .                | 160 |
| Vinyl Premium Seat Assembly No. 117-5676 . . . . .             | 161 |
| Cylinder Block Assembly . . . . .                              | 162 |
| Gear Housing Assembly . . . . .                                | 163 |
| Cylinder Head and Cover Assembly . . . . .                     | 164 |
| Flywheel Housing and Oil Sump Assembly . . . . .               | 166 |
| Suction Manifold Assembly . . . . .                            | 167 |
| Diesel Particulate Filter Assembly . . . . .                   | 168 |
| Exhaust Manifold Assembly . . . . .                            | 170 |
| Camshaft and Driving Gear Assembly . . . . .                   | 171 |
| Turbine Assembly . . . . .                                     | 172 |
| Crankshaft and Piston Assembly . . . . .                       | 173 |
| Lubrication and Oil System Assembly . . . . .                  | 174 |

# Contents (continued)

|                                       |     |
|---------------------------------------|-----|
| Lubrication Oil Pipe Assembly .....   | 175 |
| Cooling Water System Assembly.....    | 176 |
| Fuel Supply Pump Assembly .....       | 177 |
| Fuel Injection Valve Assembly .....   | 178 |
| Fuel Pipe Assembly .....              | 179 |
| Starter Motor Assembly.....           | 180 |
| Generator Assembly .....              | 181 |
| Electronic Control Unit Assembly..... | 182 |
| Electric Parts Assembly.....          | 183 |
| Gasket Set.....                       | 184 |
| Attachments and Accessories .....     | 186 |


Frame Assembly



## Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 130-2450-01        | 1           | Frame                       | 16          | 321-14             | 2           | Screw-HH              |
| 2           | 137-5608-01        | 1           | Frame-Front                 | 17          | 130-2570-0P        | 1           | Bracket-Mount, Fuse   |
| 3           | 100-6116           | 14          | Screw-HHF                   | 18          | 104-8300           | 2           | Nut-HF, NI            |
| 4           | 3256-26            | 14          | Washer-Flat                 | 19          | 3230-7             | 2           | Bolt-CARR             |
| 5           | 99-5107            | 10          | Nut-Lock                    | 20          | 104-7201           | 5           | Nut-HF, NI            |
| 6           | 325-12             | 2           | Screw-HH                    | 21          | 3231-2             | 4           | Bolt-CARR             |
| 7           | 115-5465           | 1           | Seal-Trim                   | 22          | 108-8014           | 4           | Tape-Reflective (Red) |
| 8           | 114-5969-01        | 1           | Crossmember                 | 24          | 136-4429-01        | 1           | Cover-Frame           |
| 9           | 114-5990           | 2           | Plate-Tapped                | 25          | 3253-21            | 2           | Washer-Lock           |
| 10          | 132-1387           | 1           | Cooler Mount ASM            | 26          | 323-7              | 2           | Screw-HH              |
| 11          | 3234-42            | 8           | Screw-HHF                   | 28          | 3234-38            | 8           | Screw-HHF             |
| 12          | 104-8301           | 6           | Nut-HF, NI                  | 29          | 132-1401-0P        | 1           | Strap-Support, Tank   |
| 13          | 115-5458-0P        | 1           | Shim-Bumper                 | 30          | 3234-36            | 4           | Screw-HHF             |
| 14          | 131-2310-03        | 1           | Bumper                      | 31          | 107-3677           | 2           | Spacer-Tube           |
| 15          | 92-7760            | 1           | Emblem-Vehicle, Slow Moving | 32          | 115-5103           | 3           | Screw-HHF             |
|             |                    |             |                             | 33          | 140-6842-03        | 1           | Mount-Smv             |


# Rear Axle Assembly



## Rear Axle Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 114-5982-03        | 1           | Axle ASM                 | 16          | 114-4681           | 1           | Screw-HHF                |
| 2           | 3218-5             | 2           | Nut-Jam                  | 17          | 98-1452            | 3           | Washer-Thrust            |
| 3           | 325-7              | 2           | Screw-HH                 | 18          | 3296-68            | 1           | Nut-Lock, NI             |
| 4           | 99-5107            | 2           | Nut-Lock                 | 19          | 130-9033-01        | 2           | Guard-Hose               |
| 5           | 2811-7             | 1           | Elbow                    | 20          | 100-6116           | 4           | Screw-HHF                |
| 6           | 114-5586           | 1           | Hose ASM (With Fitting)  | 21          | 100-4196           | 2           | Ring-Retaining           |
| 7           | 100-2508           | 2           | Washer-Thrust            | 22          | 100-3362           | 2           | Cap-Spindle              |
| 8           | 110-6049-03        | 1           | Tie Rod ASM              | 23          | 3234-12            | 2           | Screw-HHF                |
| 9           | 3272-12            | 6           | Pin-Cotter               | 24          | 127-3509           | 2           | Wheel And Tire ASM       |
| 11          | 32136-13           | 2           | Nut-SHH                  | 24:1        | 125-5379           | 1           | Wheel                    |
| 12          | 130-9043-03        | 1           | Spindle-Steer,LH [black] | 24:2        | 117-2901           | 1           | Tire                     |
| 13          | 106-6895-03        | 2           | Ball Joint ASM           | 24:3        | 5108               | 1           | Valve                    |
| 13:1        |                    | 1           | Joint-Ball ●             | 25          | 130-9041-03        | 1           | Spindle-Steer,RH [black] |
| 13:1:1      | 32136-13           | 1           | Nut-SHH                  | 26          | 325-5              | 20          | Screw-HH                 |
| 13:1:2      | 106-6896           | 1           | Seal                     | 28          | 327-3              | 16          | Screw-HH                 |
| 13:1:3      | 302-5              | 1           | Fitting-Grease           | 29          | 131-2380           | 2           | Wheel And Tire ASM       |
| 13:1:4      | 3210-7             | 1           | Screw-HH                 | 29:1        | 131-2381           | 1           | Wheel                    |
| 13:1:5      | 32152-5            | 1           | Nut-Hex                  | 29:2        | 131-2382           | 1           | Tire                     |
| 14          | 110-6033-03        | 1           | Support - Axle [black]   | 29:3        | 232-24             | 1           | Stem-Valve               |
| 15          | 144-4158           | 1           | Pin-Axle                 | 30          | 104-8301           | 1           | Nut-HF, NI               |

● Not serviced separately



## Axle Assembly No. 114-5982-03

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 69-6470     | 2    | Bushing-Caster |
| 2    | 100-2506    | 4    | Bushing-Caster |
| 3    | 302-5       | 2    | Fitting-Grease |




## Tie Rod Assembly No. 110-6049-03

| Ref.  | Part Number | Qty. | Description        |
|-------|-------------|------|--------------------|
| 1     | 110-6141-03 | 1    | RH Tie Rod End ASM |
| 1:1   |             | 1    | Rod End-Tie, RH ●  |
| 1:1:1 | 302-5       | 1    | Fitting-Grease     |
| 1:1:2 | 32136-2     | 1    | Nut-SHH            |
| 2     | 110-6142-03 | 1    | LH Tie Rod End ASM |
| 2:1   |             | 1    | Rod End-Tie, LH ●  |
| 2:1:1 | 302-5       | 1    | Fitting-Grease     |
| 2:1:2 | 32136-2     | 1    | Nut-SHH            |
| 3     | 44-2200     | 1    | Screw-Blade        |
| 4     | 32153-7     | 1    | Nut-Lock           |

● Not serviced separately


# Engine and Mount Assembly



## Engine and Mount Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 138-6921           | 1           | Engine-Yanmar           | 20          | 130-2585           | 1           | Coupler-Flywheel         |
| 2           | 136-4885           | 4           | Mount-Engine            | 21          | 130-9095           | 1           | Cover-Flywheel           |
| 3           | 130-2409-0P        | 2           | Mount-Motor, Rear       | 22          | 139-1027           | 1           | Plate-Retention, Harness |
| 4           | 132-1356           | 4           | Mount-Isolator          | 23          | 3234-29            | 2           | Screw-HHF                |
| 5           | 323-6              | 8           | Screw-HH                | 24          | 3229-11            | 2           | Screw-CARR               |
| 6           | 104-8301           | 8           | Nut-HF, NI              | 25          | 139-1026           | 2           | Plate-Retention, Harness |
| 7           | 87-5100            | 4           | Washer-Snubbing         | 26          | 32180-031          | 2           | Clip-Tree (W/Tie)        |
| 8           | 130-2415-0P        | 1           | Mount-Motor, RH Front   | 27          | 104-8300           | 2           | Nut-HF, NI               |
| 9           | 324-12             | 4           | Screw-HH                | 28          | 33015-00           | 4           | Nut-Hex                  |
| 10          | 114-8417           | 4           | Nut-HF, NI              | 29          | 33095-00           | 4           | Washer-Flat              |
| 11          | 33104-030          | 2           | Screw-HHF               | 30          | 33105-025          | 30          | Screw-HHF                |
| 13          | 130-2414-0P        | 1           | Mount-Motor, LH Front   | 33          | 137-5505-0P        | 1           | Mount-Shield             |
| 14          | 130-2424           | 1           | Bracket-Exhaust         | 34          | 137-5506-0P        | 1           | Shield-Starter           |
| 15          | 32180-030          | 1           | Clip-Tie                | 35          | 33105-020          | 2           | Screw-HHF                |
| 16          | 104-7201           | 10          | Nut-HF, NI              | 36          | 3290-199           | 2           | Nut-Speed                |
| 17          | 107-1413           | 8           | Washer-Hardened         | 37          | 99-6810            | 2           | Screw-HHF                |
| 18          | 121-5592           | 1           | Electronic Control Unit | 43          | 33115-020          | 8           | Screw-HH                 |
| 19          | 132-1628           | 1           | Pipe-Exhaust            |             |                    |             |                          |


# Alternator Assembly



## Alternator Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 139-7797-0P        | 1           | Mount-Alternator, Rear  | 13          | 144-7160           | 1           | Idler Arm ASM             |
| 2           | 139-7796-0P        | 1           | Mount-Alternator, Front | 13:2        | 112-1626           | 2           | Bushing-Flange            |
| 3           | 144-5156-03        | 1           | Support-Idler           | 14          | 119-4061           | 2           | Screw-HHF                 |
| 4           | 3231-25            | 8           | Bolt-CARR               | 15          | 140-3102           | 1           | Spring-Torsion            |
| 5           | 104-8301           | 13          | Nut-HF, NI              | 16          | 130-2403           | 1           | Pulley                    |
| 6           | 130-2491           | 1           | Alternator-24V          | 17          | 33115-030          | 3           | Screw-HH                  |
| 7           | 323-23             | 4           | Screw-HH                | 18          | 139-7848           | 1           | Belt-Poly V               |
| 8           | 107-1413           | 7           | Washer-Hardened         | 19          | 121-1524           | 1           | Screw-HH                  |
| 9           | 93-8806            | 8           | Washer-Hardened         | 20          | 47-4420            | 1           | Spacer-Sleeve, Adjustment |
| 10          | 131-2313           | 4           | Bushing-Alternator      | 21          | 135-5662           | 1           | Pulley-Idler, Flat        |
| 11          | 131-2315           | 4           | Washer-Delrin           | 22          | 3296-45            | 1           | Nut-Hex                   |
| 12          | 130-9162           | 1           | Pulley                  | 23          | 302-40             | 1           | Fitting-Grease, 90 DEG    |


# Hydraulic Cooling Assembly



## Hydraulic Cooling Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------|
| 1           | 104-3509           | 1           | Fitting-HYD, 45 DEG | 8           | 130-9170           | 1           | Rod-Prop, Cooler   |
| 1:1         | 237-146            | 1           | O-Ring              | 9           | 130-9171-0P        | 1           | Plate-Seal, Cooler |
| 1:2         | 340-65             | 1           | O-Ring              | 10          | 132-1385           | 1           | Cooler Top ASM     |
| 2           | 114-2120           | 4           | Washer              | 11          | 130-9173           | 2           | Foam-Cooler, Long  |
| 3           | 104-3797           | 1           | Fitting-Straight    | 12          | 130-9174           | 2           | Foam-Cooler, Short |
| 3:1         | 237-146            | 1           | O-Ring              | 13          | 130-9175           | 2           | Foam-Cooler, Top   |
| 3:2         | 340-65             | 1           | O-Ring              | 14          | 323-10             | 4           | Screw-HH           |
| 4           | 104-8301           | 4           | Nut-HF, NI          | 15          | 3256-24            | 1           | Washer-Flat        |
| 5           | 119-1415           | 1           | Pin-Cotter, Locking | 16          | 104-7201           | 8           | Nut-HF, NI         |
| 6           | 144-5153           | 2           | Fan-Spal            | 17          | 3234-21            | 8           | Screw-HHF          |
| 7           | 130-2573           | 1           | Oil Cooler ASM      | 18          | 3210-2             | 4           | Screw-HH           |
| 7:1         | 132-1361           | 4           | Mount-Isolator      | 19          | 3256-23            | 4           | Washer-Plain       |


# Radiator and Cooling Fan Assembly



## Radiator and Cooling Fan Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                 | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 130-2572           | 1           | Radiator ASM                       | 21          | 132-1386           | 1           | Fan Shroud ASM         |
| 1:1         | 132-1361           | 4           | Mount-Isolator                     | 21:2        | 117-4766           | 2           | Decal-Warning, Fan     |
| 1:2         | 94-7220            | 1           | Fitting-Barb, Hose                 | 22          | 144-5153           | 2           | Fan-Spal               |
| 2           | 127-3638-0P        | 1           | Bracket-Mount, RH Radiator         | 23          | 132-1347           | 1           | Radiator Foam ASM      |
| 3           | 127-3631-0P        | 1           | Bracket-Mount, LH Radiator         | 24          | 3234-21            | 8           | Screw-HHF              |
| 4           | 3231-6             | 2           | Screw-CARR                         | 25          | 104-7201           | 8           | Nut-HF, NI             |
| 5           | 114-2120           | 4           | Washer                             | 26          | 130-9183           | 1           | Foam-Radiator, Top     |
| 6           | 323-10             | 2           | Screw-HH                           | 27          | 121-7536           | 4           | Clamp-Torque, Constant |
| 7           | 3234-19            | 2           | Screw-HHF                          | 28          | 130-9020           | 2           | Plate-Cover            |
| 8           | 104-8301           | 7           | Nut-HF, NI                         | 29          | 323-6              | 1           | Screw-HH               |
| 9           | 130-2592-0P        | 1           | Bracket-Tank, Radiator<br>Overflow | 30          | 130-9021-0P        | 1           | Rod-Prop, Radiator     |
| 10          | 144-6219           | 1           | Reservoir-Coolant ASM              | 31          | 66-2920            | 2           | Washer-Friction        |
| 10:1        | 87-7050            | 1           | Cap-Reservoir                      | 33          | 110-4109           | 1           | Hose-Fuel              |
| 11          | 104-8300           | 8           | Nut-HF, NI                         | 34          | 2412-108           | 1           | Clamp-Worm             |
| 12          | 3230-1             | 6           | Bolt-CARR                          | 35          | 116-5087           | 1           | Hose-Fuel              |
| 13          | 3230-7             | 2           | Bolt-CARR                          | 36          | 354-94             | 1           | Fitting-Female, Barbed |
| 14          | 130-9159           | 1           | Hose-Radiator, Lower               | 37          | 93-5528            | 1           | Fitting-Cock, Drain    |
| 15          | 127-3616           | 1           | Hose-Radiator, Upper               | 38          | 115-2370           | 1           | Hose-Fuel              |
| 16          | 131-2356           | 1           | Radiator Cap ASM                   | 39          | 131-2289           | 2           | Foam-Radiator          |
| 16:2        | 117-3276           | 1           | Decal-Danger                       | 40          | 131-2322           | 1           | Foam-Shroud, Lower     |
| 17          | 130-9185-0P        | 1           | Plate-Seal, Radiator               | 41          | 3256-23            | 4           | Washer-Plain           |
| 18          | 3210-3             | 4           | Screw-HH                           | 42          | 108-0342           | 1           | Fitting-Straight       |
| 19          | 130-9181           | 4           | Foam-Radiator, Long                | 43          | 2412-36            | 4           | Clamp-Hose             |
| 20          | 130-9182           | 2           | Foam-Radiator, Short               | 44          | 144-4159-03        | 1           | Support-Screen         |


# Air Cleaner Assembly



## Air Cleaner Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 130-9176-0P        | 1           | Airbox                 | 11          | AU110569           | 1           | Clamp-Torque, Constant |
| 2           | 130-9160           | 1           | Air Filter ASM         | 12          | 131-2229           | 1           | Clamp-Hose             |
| 2:1         | 108-3815           | 1           | Filter-Air             | 13          | 115-8155           | 1           | Decal-Warning          |
| 2:2         | 130-9070           | 1           | Element-Filter, Safety | 14          | 140-5839-0P        | 1           | Mount-Sensors, Rear    |
| 2:3         | 69-1940            | 1           | Indicator-Electrical   | 15          | 140-5838-0P        | 1           | Mount-Sensors, Front   |
| 3           | 130-2512           | 1           | Hose-Intake, Air       | 16          | 140-5842-0P        | 1           | Mount-Sensors, Main    |
| 4           | 130-2579           | 1           | Grommet                | 17          | 32128-32           | 7           | Nut-HHF                |
| 5           | 130-9179           | 1           | Foam-Airbox            | 18          | 3256-2             | 2           | Washer-Flat            |
| 6           | 130-9180           | 1           | Foam-Airbox, Rear      | 19          | 3274-9             | 2           | Screw-HSH              |
| 7           | 3231-5             | 2           | Screw-CARR             | 20          | 1-807512           | 5           | Bolt-CARR              |
| 8           | 104-8301           | 2           | Nut-HF, NI             | 21          | 32180-030          | 1           | Clip-Tie               |
| 9           | 104-8300           | 2           | Nut-HF, NI             | 22          | 3290-378           | 2           | Tie-Cable              |
| 10          | 132-3837           | 2           | Screw-HHF              |             |                    |             |                        |


# Fuel System Assembly



## Fuel System Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 121-5613           | 1           | Pump-Fuel, Electric         | 20          | 3234-42            | 2           | Screw-HHF             |
| 2           | 125-2914           | 1           | Filter-Separator            | 21          | 104-8301           | 2           | Nut-HF, NI            |
| 2:1         | 125-2915           | 1           | Filter-Fuel/Water Separator | 22          | 114-4939-03        | 1           | Cover-Fitting, Fuel   |
| 3           | 353-783            | 1           | Fitting-STR                 | 23          | 2412-36            | 4           | Clamp-Hose            |
| 4           | 119-7748           | 1           | Pipe-Stand, Fuel            | 24          | 3234-4             | 2           | Screw-HHF             |
| 5           | 2412-108           | 8           | Clamp-Worm                  | 25          | 104-7201           | 2           | Nut-HF, NI            |
| 6           | 131-2284           | 1           | Fuel Tank ASM               | 26          | 1-543286           | 1           | Grommet               |
| 7           | 94-6821            | 2           | Clamp-Wire                  | 27          | 130-9191           | 2           | Hose-Fuel             |
| 8           | 117-2382           | 4           | Plug-Plastic                | 28          | 108-0342           | 1           | Fitting-Straight      |
| 9           | 125-9171           | 1           | Cap-Fuel                    | 29          | 130-9143           | 1           | Hose-Fuel             |
| 10          | 104-0790           | 2           | Bushing                     | 30          | 108-3282           | 1           | Hose-Fuel             |
| 11          | 46-6560            | 1           | Bushing                     | 32          | 104-8300           | 3           | Nut-HF, NI            |
| 12          | 46-6550            | 1           | Fitting-Elbow, 90 DEG       | 33          | 3234-29            | 2           | Screw-HHF             |
| 13          | 130-9149           | 1           | Pipe-Stand, Return          | 34          | 120-1959           | 2           | Clamp                 |
| 14          | 121-1688           | 1           | Gauge-Fuel                  | 35          | 109-0308           | 1           | Hose-Fuel             |
| 15          | 3274-31            | 3           | Screw-HSBH                  | 36          | 114-0832           | 1           | Hose-Fuel             |
| 16          | 3253-15            | 5           | Washer-Lock                 | 37          | 3234-7             | 1           | Screw-HHF             |
| 17          | 32122-24           | 5           | Screw-PTH                   | 38          | 132-1329           | 1           | Bracket-Hose Retainer |
| 18          | 121-1707           | 1           | Gasket-Fuel, Viton          | 39          | 237-124            | 1           | Grommet               |
| 19          | 114-0094           | 1           | Hold Down-Tank              |             |                    |             |                       |

# Traction Hydraulic Assembly




## Traction Hydraulic Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|--------------------------------|
| 1           | 130-9150           | 1           | Hydraulic Piston Pump ASM      |
| 2           | 130-2520           | 1           | Hydraulic Triple Gear Pump ASM |
| 3           |                    | 1           | Manifold-Traction ●            |
| 4           | 99-3017            | 1           | Fitting                        |
| 4:1         | 237-81             | 1           | O-Ring                         |
| 5           | 59-7410            | 3           | Fitting-Diagnostic             |
| 5:1         | 237-42             | 1           | O-Ring                         |
| 6           | 354-79             | 3           | Cap-Dust                       |
| 7           | 340-2              | 1           | Fitting-Straight               |
| 7:1         | 237-22             | 1           | O-Ring                         |
| 7:2         | 237-42             | 1           | O-Ring                         |
| 9           | 127-3450           | 1           | Hydraulic Hose ASM             |
| 10          | 127-3451           | 1           | Hydraulic Hose ASM             |
| 11          | 127-3521           | 1           | Hydraulic Hose ASM             |
| 12          | 104-8301           | 1           | Nut-HF, NI                     |
| 14          | 107-9447           | 1           | O-Ring                         |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 15          | 110-8829           | 1           | Sender-Temperature  |
| 15:1        | 237-42             | 1           | O-Ring              |
| 16          | 115-5523           | 1           | Guard-Hose          |
| 17          | 121-1525           | 2           | Screw-HH            |
| 18          | 121-3903           | 2           | Flange Kit          |
| 18:1        | 121-3904           | 1           | O-Ring              |
| 18:2        | 33116-045          | 4           | Screw-HH            |
| 18:3        | 100-7336           | 4           | Washer              |
| 18:4        |                    | 2           | Flange ●            |
| 19          | 130-2550           | 1           | Hose-Suction        |
| 20          | 130-2571           | 1           | Tab-Mount, Manifold |
| 21          | 131-2220           | 6           | Screw-HHF           |
| 22          | AU426-824          | 4           | Screw-HH            |
| 23          | 2412-111           | 2           | Clamp-Hose, W/Liner |
| 24          | 3290-379           | 2           | Tie-Cable           |
| 25          | 87-7270            | 6           | Washer-Thrust       |

● Not serviced separately


# Piston Pump Assembly No. 130-9150



## Piston Pump Assembly No. 130-9150 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 125-5266           | 2           | Screen                | 20          | 125-5281           | 4           | Screw                       |
| 2           | 75-0170            | 2           | Plug-Thread, Straight | 21          | 125-5282           | 4           | Screw                       |
| 2:1         | 92-8777            | 1           | O-Ring                | 22          | 125-5287           | 1           | Plate-Thrust                |
| 3           | 69-3130            | 2           | Plug                  | 23          | 125-5291           | 2           | Valve-Relief, High Pressure |
| 4           | 125-5267           | 1           | Cylinder Block Kit    | 24          | 125-5292           | 2           | Pressure Limiter Plug ASM   |
| 5           | 125-5268           | 1           | Valve Plate, CW       | 25          | 125-5293           | 1           | Swashplate Bearing Kit      |
| 6           | 125-5271           | 1           | Servo Piston ASM      | 26          | 125-5295           | 1           | Control Kit (12 Volt)       |
| 7           | 125-5270           | 8           | Screw                 | 26:1        | 125-5272           | 6           | Screw                       |
| 8           | 125-5276           | 2           | Orifice (0.8)         | 26:2        | 125-5273           | 1           | Nut-Seal                    |
| 9           | 125-5277           | 4           | Screw                 | 26:3        | 125-5302           | 1           | Plug                        |
| 10          | 125-5300           | 4           | Plug ASM              | 26:4        | 125-5266           | 1           | Screen                      |
| 11          | 125-5275           | 2           | Screw                 | 26:5        | 125-5269           | 1           | Ring-Locking                |
| 12          | 125-5301           | 1           | Plug                  | 26:6        | 125-5274           | 6           | Screw                       |
| 13          | 125-5278           | 1           | Shaft                 | 26:7        | 125-5294           | 2           | Coil Kit                    |
| 14          | 125-5279           | 1           | Bearing-Roller        | 26:8        | 125-5283           | 1           | Gasket-Control              |
| 15          | 125-5280           | 1           | Ring-Retaining        | 26:9        | 125-5288           | 2           | O-Ring                      |
| 16          | 125-5296           | 1           | Shaft Seal Kit        | 27          | 125-5303           | 2           | Plug ASM                    |
| 17          | 125-5284           | 1           | Adapter               | 28          | 125-5297           | 1           | Charge Relief Kit           |
| 18          | 125-5285           | 1           | Seal-Adapter          | 29          | 125-5299           | 1           | Overhaul Seal Kit           |
| 19          | 125-5286           | 1           | Coupling              |             |                    |             |                             |

# Hydraulic Gear Pump Assembly No. 130-2520




# Hydraulic Gear Pump Assembly No. 130-2520 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 133-2484           | 1           | Seal Kit           |
| 1:1         |                    | 2           | Seal ●             |
| 1:2         |                    | 4           | Seal ●             |
| 1:3         |                    | 2           | Seal-Standard ●    |
| 1:4         |                    | 2           | Seal-Standard ●    |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1:5         |                    | 1           | Seal-Shaft ●         |
| 1:6         |                    | 2           | Antiextrusion ●      |
| 1:7         |                    | 4           | Ring-Antiextrusion ● |
| 1:8         |                    | 1           | Seal-Shaft ●         |

● Not serviced separately

# Traction Manifold Assembly



## Traction Manifold Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 137-5623           | 1           | Manifold-Traction     | 5:1         | 237-81             | 1           | O-Ring             |
| 2           | 340-129            | 2           | Fitting-Elbow, 90 DEG | 5:2         | 237-65             | 1           | O-Ring             |
| 2:1         | 237-146            | 1           | O-Ring                | 6           | 340-8              | 1           | Fitting-Straight   |
| 2:2         | 340-65             | 1           | O-Ring                | 6:1         | 237-65             | 1           | O-Ring             |
| 3           | 100-5530           | 1           | Fitting-45 DEG        | 6:2         | 237-81             | 1           | O-Ring             |
| 3:1         | 237-58             | 1           | O-Ring                | 7           | 340-4              | 2           | Fitting-Straight   |
| 3:2         | 237-81             | 1           | O-Ring                | 7:1         | 237-30             | 1           | O-Ring             |
| 4           | 340-9              | 7           | Fitting-STR           | 7:2         | 237-79             | 1           | O-Ring             |
| 4:1         | 237-58             | 1           | O-Ring                | 8           | 340-3              | 1           | Fitting-Straight   |
| 4:2         | 237-81             | 1           | O-Ring                | 8:1         | 237-22             | 1           | O-Ring             |
| 5           | 340-139            | 1           | Fitting-Elbow 90      | 8:2         | 237-79             | 1           | O-Ring             |

This diagram illustrates the exploded view of a hydraulic valve assembly. The central component is a rectangular valve block with multiple ports labeled with symbols such as  $\Delta$ ,  $\nabla$ ,  $\square$ ,  $\circ$ , and  $\square$ . The assembly includes various hydraulic components, each identified by a number and a ratio (e.g., 13, 13:1, 15, 15:1). The components are arranged around the valve block, with dashed lines indicating their assembly paths. The components include:

- 13**: Main valve body or connector.
- 13:1**: Variant or sub-component of 13.
- 15, 15:1**: Small connector or plug.
- 16, 16:1**: Small connector or plug.
- 17, 17:1**: Small connector or plug.
- 18, 18:1**: Small connector or plug.
- 19, 19:1**: Small connector or plug.
- 20**: Small connector or plug.
- 21, 21:1**: Small connector or plug.
- 22**: Small connector or plug.
- 23, 23:1**: Small connector or plug.
- 24**: Small connector or plug.
- 25**: Small connector or plug.
- 4, 4:1**: Small connector or plug.
- 5, 5:1**: Small connector or plug.
- 6, 6:1**: Small connector or plug.
- 7**: Small connector or plug.
- 8**: Small connector or plug.
- 9**: Small connector or plug.
- 10**: Small connector or plug.
- 11, 11:1**: Small connector or plug.
- 12**: Small connector or plug.
- 14, 14:1**: Small connector or plug.


# Hydraulic Traction Valve Manifold

## Assembly No. 137-5623 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|---------------------------|
| 4           | 353-990            | 9           | Plug ASM                   | 15          | 105-9321           | 1           | Check Valve ASM           |
| 4:1         | 237-78             | 1           | O-Ring                     | 15:1        | 105-9156           | 1           | Seal Kit                  |
| 5           | 353-989            | 13          | Plug-Hex, Hollow           | 16          | 110-8881           | 3           | Valve-Check               |
| 5:1         | 237-42             | 1           | O-Ring                     | 16:1        | 105-9159           | 1           | Seal Kit ●                |
| 6           | 353-988            | 2           | Plug-Hex                   | 17          | 132-4912           | 1           | Valve-Check               |
| 6:1         | 237-79             | 1           | O-Ring                     | 17:1        | 105-9159           | 1           | Seal Kit                  |
| 7           | 133-2444           | 5           | Zero-Leak Plug, SAE-12     | 18          | 132-4911           | 1           | Valve-Relief, Poppet Type |
| 8           | 110-5973           | 1           | Orifice-0.030              | 18:1        | 130-8183           | 1           | Seal Kit                  |
| 9           | 133-2445           | 2           | Plug-Socket, Hex           | 19          | 132-4910           | 1           | Regulator-Flow, Pressure  |
| 10          | 353-512            | 3           | Plug                       |             |                    |             | Comp                      |
| 10:1        | 237-78             | 1           | O-Ring                     | 19:1        | 107-7527           | 1           | Seal Kit                  |
| 11          | 353-508            | 1           | Plug-HH                    | 20          | 132-4909           | 1           | Valve-Shuttle, Hot Oil    |
| 11:1        | 237-42             | 1           | O-Ring                     | 21          | 138-3828           | 1           | Valve-Solenoid, 3 Way 2   |
| 12          | 132-4915           | 1           | Fitting-Adapter, Temp      |             |                    |             | Position                  |
|             |                    |             | Sensor                     | 21:1        | 138-3831           | 1           | Seal Kit                  |
| 13          | 132-4914           | 5           | Valve-Piloted Directional, | 22          | 138-3827           | 2           | Screw                     |
|             |                    |             | Vented                     | 23          | 59-7410            | 1           | Fitting-Diagnostic        |
| 13:1        | 137-5511           | 1           | Seal Kit                   | 23:1        | 237-42             | 1           | O-Ring                    |
| 14          | 132-4913           | 1           | Vent-External, Piloted     | 24          | 354-79             | 1           | Cap-Dust                  |
| 14:1        | 110-8908           | 1           | Spool Valve Seal Kit       | 25          | 138-3825           | 1           | Plate-Mounting, Standard  |

● Not illustrated


# Hydraulic Traction Motors Assembly



## Hydraulic Traction Motors Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|----------------------------------|
| 1           | 125-5391           | 1           | LH Hydraulic Motor ASM | 14:1        | 237-30             | 1           | O-Ring                           |
| 2           | 125-5434           | 1           | RH Hydraulic Motor ASM | 15          | 130-2541           | 1           | Hydraulic Tube ASM               |
| 3           | 340-9              | 4           | Fitting-STR            | 15:1        | 237-22             | 1           | O-Ring                           |
| 3:1         | 237-58             | 1           | O-Ring                 | 16          | 130-9075           | 1           | Hydraulic Tube ASM               |
| 3:2         | 237-81             | 1           | O-Ring                 | 17          | 130-2554           | 1           | Hydraulic Tube ASM               |
| 4           | 340-7              | 2           | Fitting-Straight       | 18          | 130-2555           | 1           | Hydraulic Tube ASM               |
| 4:1         | 237-65             | 1           | O-Ring                 | 19          | 2412-87            | 2           | Clamp-Cable                      |
| 4:2         | 237-80             | 1           | O-Ring                 | 20          | 3234-4             | 2           | Screw-HHF                        |
| 5           | 340-4              | 2           | Fitting-Straight       | 21          | 104-7201           | 2           | Nut-HF, NI                       |
| 5:1         | 237-30             | 1           | O-Ring                 | 22          | 130-2556           | 1           | Hydraulic Tube ASM               |
| 5:2         | 237-79             | 1           | O-Ring                 | 23          | 94-5350            | 1           | Fitting-Tee                      |
| 6           | 340-77             | 2           | Fitting-Elbow, 90 DEG  | 23:1        | 237-65             | 3           | O-Ring                           |
| 6:1         | 237-22             | 1           | O-Ring                 | 24          | 340-74             | 1           | Nut-Lock, Bulkhead               |
| 6:2         | 237-42             | 1           | O-Ring                 | 25          | 117-3297           | 3           | Fitting-Cap                      |
| 10          | 130-2533           | 1           | Hydraulic Tube ASM     | 99          | 144-7177           | 1           | Kit-Parking Brake O-Ring Removal |
| 10:1        | 237-21             | 1           | O-Ring                 | 99:1        | 144-7176           | 1           | Tool, Parking Brake Belleville   |
| 11          | 130-2534           | 1           | Hydraulic Tube ASM     | 99:2        | 107-3395           | 1           | Washer-Hardened                  |
| 11:1        | 237-21             | 1           | O-Ring                 | 99:3        | 33016-00           | 1           | Nut-Hex                          |
| 12          | 130-2537           | 1           | Hydraulic Tube ASM     | 99:4        | 33116-080          | 1           | Screw-HH                         |
| 13          | 130-9074           | 1           | Hydraulic Tube ASM     |             |                    |             |                                  |
| 14          | 130-2540           | 1           | Hydraulic Tube ASM     |             |                    |             |                                  |

# Hydraulic Motor Assembly No. 125-5434




## Hydraulic Motor Assembly No. 125-5434 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 137-5627           | 1           | Bearing            |
| 2           | 137-5628           | 1           | Bearing            |
| 3           | 137-5649           | 1           | Screw              |
| 4           | 137-5629           | 1           | Shear Ball         |
| 5           | 137-5630           | 1           | Master Seal Kit    |
| 6           | 137-5631           | 1           | Screw              |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 137-5632           | 1           | Stud               |
| 8           | 137-5633           | 1           | Lug Nut            |
| 9           | 137-5634           | 1           | Shaft              |
| 10          | 137-5578           | 1           | Rotating Group ASM |
| 11          | 137-5583           | 1           | Spring             |

# Hydraulic Motor Assembly No. 125-5391




## Hydraulic Motor Assembly No. 125-5391 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 137-5627           | 1           | Bearing            |
| 2           | 137-5628           | 1           | Bearing            |
| 3           | 137-5649           | 1           | Screw              |
| 4           | 137-5629           | 1           | Shear Ball         |
| 5           | 137-5630           | 1           | Master Seal Kit    |
| 6           | 137-5631           | 1           | Screw              |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 137-5632           | 1           | Stud               |
| 8           | 137-5633           | 1           | Lug Nut            |
| 9           | 137-5634           | 1           | Shaft              |
| 10          | 137-5578           | 1           | Rotating Group ASM |
| 11          | 137-5583           | 1           | Spring             |

# Hydraulic Traction Assembly




## Hydraulic Traction Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 131-2377-01        | 2           | Support-Bulkhead   |
| 2           | 340-126            | 4           | Nut-Bulkhead       |
| 3           | 340-127            | 2           | Nut-Bulkhead       |
| 6           | 131-2378           | 1           | Hydraulic Tube ASM |
| 6:1         | 237-58             | 1           | O-Ring             |
| 7           | 131-2397           | 1           | Hydraulic Tube ASM |
| 8           | 131-2379           | 1           | Hydraulic Tube ASM |
| 8:1         | 237-58             | 1           | O-Ring             |
| 9           | 131-2398           | 1           | Hydraulic Tube ASM |
| 10          | 130-2464           | 1           | Hydraulic Tube ASM |
| 10:1        | 237-58             | 1           | O-Ring             |
| 11          | 131-2388           | 1           | Hydraulic Tube ASM |
| 11:1        | 237-58             | 1           | O-Ring             |
| 12          | 131-2389           | 1           | Hydraulic Tube ASM |
| 12:1        | 237-58             | 1           | O-Ring             |
| 13          | 130-2467           | 1           | Hydraulic Tube ASM |
| 13:1        | 237-58             | 1           | O-Ring             |
| 14          | 131-2384           | 1           | Hydraulic Tube ASM |
| 14:1        | 237-30             | 1           | O-Ring             |
| 15          | 131-2385           | 1           | Hydraulic Tube ASM |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 15:1        | 237-30             | 1           | O-Ring              |
| 16          | 131-2386           | 1           | Hydraulic Tube ASM  |
| 16:1        | 237-30             | 2           | O-Ring              |
| 17          | 131-2387           | 1           | Hydraulic Tube ASM  |
| 17:1        | 237-30             | 1           | O-Ring              |
| 19          | 132-1425           | 2           | Hydraulic Motor ASM |
| 20          | 127-3568           | 2           | Hydraulic Hose ASM  |
| 21          | 127-3569           | 2           | Hydraulic Hose ASM  |
| 22          | 131-2383           | 2           | Hydraulic Hose ASM  |
| 23          | 340-4              | 2           | Fitting-Straight    |
| 23:1        | 237-30             | 1           | O-Ring              |
| 23:2        | 237-79             | 1           | O-Ring              |
| 28          | 3231-42            | 4           | Screw-CARR          |
| 29          | 104-8301           | 4           | Nut-HF, NI          |
| 30          | 340-7              | 4           | Fitting-Straight    |
| 30:1        | 237-65             | 1           | O-Ring              |
| 30:2        | 237-80             | 1           | O-Ring              |
| 31          | 3334-945           | 4           | Tie-Cable           |
| 32          | 132-1393           | 2           | Foam-Support, Tube  |

# Hydraulic Motor Assembly No. 132-1425




## Hydraulic Motor Assembly No. 132-1425 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 133-2517           | 1           | Nut-Flange         |
| 2           | 133-2518           | 1           | Rotating Group ASM |
| 3           | 137-5583           | 1           | Spring             |
| 4           | 133-2520           | 1           | Seal Kit           |
| 5           | 137-5635           | 1           | Shaft              |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 137-5636           | 1           | Bearing            |
| 7           | 137-5637           | 1           | Bearing            |
| 8           | 137-5638           | 1           | Screw              |
| 9           | 137-5639           | 1           | Stud               |


# Hydraulic Tank Assembly



## Hydraulic Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-----------------------|
| 2           | 125-5357           | 1           | Hydraulic Tube ASM | 23          | 114-0941           | 1           | Plate-Latch           |
| 2:1         | 237-30             | 1           | O-Ring             | 24          | 1-803001           | 2           | Nut-Push              |
| 3           | 130-2553           | 1           | Hydraulic Tube ASM | 25          | 3274-47            | 2           | Screw-HSFH            |
| 3:1         | 237-22             | 2           | O-Ring             | 26          | 3274-31            | 2           | Screw-HSBH            |
| 4           | 130-2511           | 1           | Hydraulic Tube ASM | 27          | 58-4250            | 1           | Catch-Magnetic        |
| 5           | 130-2543           | 1           | Hydraulic Hose ASM | 28          | 94-8166            | 1           | O-Ring                |
| 6           | 130-9036           | 1           | Hydraulic Tube ASM | 29          | 353-508            | 1           | Plug-HH               |
| 6:1         | 237-30             | 1           | O-Ring             | 29:1        | 237-42             | 1           | O-Ring                |
| 7           | 114-4919-0P        | 1           | Plate-Mount, Tube  | 30          | 139-7819-01        | 1           | Keeper-Tank           |
| 8           | 114-4920           | 4           | Hose               | 31          | 3231-22            | 2           | Screw-CARR            |
| 9           | 104-7546           | 1           | Tank Strainer ASM  | 33          | 114-0094           | 1           | Hold Down-Tank        |
| 9:1         | 340-136            | 1           | O-Ring             | 34          | 3234-42            | 3           | Screw-HHF             |
| 10          | 56-7977            | 2           | Clamp-Tube         | 35          | 104-8301           | 4           | Nut-HF, NI            |
| 11          | 94-5780            | 2           | Screw-HWH          | 36          | 137-5592-03        | 1           | Cover-Tank, Hydraulic |
| 12          | 104-8300           | 4           | Nut-HF, NI         | 37          | 93-6686            | 1           | Decal-Oil, HYD        |
| 13          | 322-5              | 2           | Screw-HH           | 38          | 46-6560            | 1           | Bushing               |
| 14          | 2412-36            | 8           | Clamp-Hose         | 39          | 46-6550            | 1           | Fitting-Elbow, 90 DEG |
| 16          | 119-7726           | 1           | Hydraulic Tank ASM | 41          | 105-4886           | 1           | Nut-Tinnerman         |
| 17          | 104-0790           | 4           | Bushing            | 42          | 139-7809-01        | 1           | Support-Tank          |
| 18          | 132-1384           | 4           | Tube-Drop          | 43          | 105-2812           | 1           | Dipstick              |
| 20          | 93-7498            | 1           | Plug-Plastic       | 44          | 131-2213           | 1           | Plate-Case Drain      |
| 21          | 114-0940           | 2           | Bracket-Hinge      | 45          | 56-7971            | 2           | Clamp-Tube            |
| 22          | 114-0904           | 1           | Rod                |             |                    |             |                       |


# Hydraulic Cutting Circuit Assembly



## Hydraulic Cutting Circuit Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-----------------------|
| 1           |                    | 1           | Center Deck Manifold ASM ● | 20          | 132-1377-0P        | 1           | Bracket-Hydraulic     |
| 2           | 104-3509           | 2           | Fitting-HYD, 45 DEG        | 21          | 125-5392           | 3           | Hydraulic Motor ASM   |
| 2:1         | 237-146            | 1           | O-Ring                     | 22          | 56-7974            | 2           | Clamp-Tube            |
| 2:2         | 340-65             | 1           | O-Ring                     | 23          | 69-9761            | 1           | Plate-Cover           |
| 3           |                    | 1           | LH Deck Manifold ASM ●     | 24          | 104-3797           | 1           | Fitting-Straight      |
| 4           | 130-2549           | 1           | Hydraulic Tube ASM         | 24:1        | 237-146            | 1           | O-Ring                |
| 4:1         | 340-65             | 1           | O-Ring                     | 24:2        | 340-65             | 1           | O-Ring                |
| 5           | 125-5346           | 1           | Hydraulic Hose ASM         | 25          | 125-5326           | 2           | Hydraulic Tube ASM    |
| 6           |                    | 1           | RH Deck Manifold ASM ●     | 25:1        | 237-22             | 1           | O-Ring                |
| 7           | 121-7536           | 4           | Clamp-Torque, Constant     | 26          | 125-5356           | 1           | Hydraulic Tube ASM    |
| 8           | 340-129            | 5           | Fitting-Elbow, 90 DEG      | 26:1        | 237-65             | 3           | O-Ring                |
| 8:1         | 237-146            | 1           | O-Ring                     | 27          | 340-2              | 2           | Fitting-Straight      |
| 8:2         | 340-65             | 1           | O-Ring                     | 27:1        | 237-22             | 1           | O-Ring                |
| 9           | 125-5325           | 1           | Hydraulic Tube ASM         | 27:2        | 237-42             | 1           | O-Ring                |
| 10          | 132-1383           | 2           | Clamp-Belville Sprg        | 28          | 140-5801           | 2           | Hydraulic Hose ASM    |
| 11          | 125-5328           | 1           | Hydraulic Hose ASM         | 29          | 140-5802           | 2           | Hydraulic Hose ASM    |
| 12          | 127-3466           | 1           | Hose-Hydraulic             | 30          | 130-9154           | 2           | Hydraulic Hose ASM    |
| 13          | 127-3467           | 1           | Hose-Hydraulic             | 31          | 132-1389           | 1           | Hydraulic Hose ASM    |
| 14          | 127-3468           | 1           | Hose-Hydraulic             | 32          | 140-5803           | 2           | Hydraulic Hose ASM    |
| 15          | 92-7526            | 2           | Fitting-HYD 90 Spcl        | 34          | 3256-56            | 6           | Washer-Flat           |
| 15:1        | 237-101            | 1           | O-Ring                     | 35          | 340-74             | 2           | Nut-Lock, Bulkhead    |
| 16          | 353-987            | 1           | Fitting-Elbow, 90          | 37          | 322-12             | 1           | Screw-HH              |
| 16:1        | 237-81             | 1           | O-Ring                     | 38          | 340-77             | 1           | Fitting-Elbow, 90 DEG |
| 17          | 130-9133           | 6           | Screw-HH                   | 38:1        | 237-22             | 1           | O-Ring                |
| 18          | 104-8300           | 7           | Nut-HF, NI                 | 38:2        | 237-42             | 1           | O-Ring                |
| 19          | 132-1374           | 1           | Hydraulic Tube ASM         | 39          | 3334-945           | 2           | Tie-Cable             |

● Not serviced separately



## Center Cutting Deck Drive Valve Assembly


| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 132-1394    | 1    | Center Deck Manifold ASM |
| 2    | 104-3509    | 3    | Fitting-HYD, 45 DEG      |
| 2:1  | 237-146     | 1    | O-Ring                   |
| 2:2  | 340-65      | 1    | O-Ring                   |
| 3    | 104-3797    | 1    | Fitting-Straight         |
| 3:1  | 237-146     | 1    | O-Ring                   |
| 3:2  | 340-65      | 1    | O-Ring                   |
| 4    | 340-5       | 1    | Fitting-Straight         |
| 4:1  | 237-42      | 1    | O-Ring                   |
| 4:2  | 237-30      | 1    | O-Ring                   |



## Hydraulic Manifold Assembly No. 132-1394


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 2    | 132-4896    | 2    | Element-Logic           |
| 2:1  | 139-7839    | 1    | Seal Kit                |
| 3    | 353-990     | 1    | Plug ASM                |
| 3:1  | 237-78      | 1    | O-Ring                  |
| 4    | 353-508     | 1    | Plug-HH                 |
| 4:1  | 237-42      | 1    | O-Ring                  |
| 5    | 132-4894    | 1    | Valve-Relief, Poppet    |
| 6    | 132-4893    | 1    | Valve-Sequence, 110 PSI |
| 7    | 353-988     | 1    | Plug-Hex                |
| 7:1  | 237-79      | 1    | O-Ring                  |

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 8    | 117-0227    | 1    | Valve-Relief, Proportional |
| 8:1  | 105-9156    | 1    | Seal Kit                   |
| 8:2  | 130-8180    | 1    | Nut-Coil (9/16-24 Unef-2B) |
| 9    | 119-4619    | 1    | Coil-Solenoid              |
| 11   | 132-4891    | 1    | Disc-Orifice               |
| 12   | 59-7410     | 1    | Fitting-Diagnostic         |
| 12:1 | 237-42      | 1    | O-Ring                     |
| 13   | 354-79      | 1    | Cap-Dust                   |
| 14   | 130-8180    | 1    | Nut-Coil (9/16-24 Unef-2B) |



## LH Cutting Deck Drive Valve Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 132-1395    | 1    | LH Deck Manifold ASM  |
| 2    | 340-99      | 1    | Fitting-HYD, 90 DEG   |
| 2:1  | 237-30      | 1    | O-Ring                |
| 2:2  | 237-42      | 1    | O-Ring                |
| 3    | 340-129     | 3    | Fitting-Elbow, 90 DEG |
| 3:1  | 237-146     | 1    | O-Ring                |
| 3:2  | 340-65      | 1    | O-Ring                |
| 4    | 104-3797    | 1    | Fitting-Straight      |
| 4:1  | 237-146     | 1    | O-Ring                |
| 4:2  | 340-65      | 1    | O-Ring                |



## Hydraulic Manifold Assembly No. 132-1396


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 2    | 132-4896    | 2    | Element-Logic           |
| 2:1  | 139-7839    | 1    | Seal Kit                |
| 3    | 132-4895    | 1    | Orifice                 |
| 4    | 353-508     | 1    | Plug-HH                 |
| 4:1  | 237-42      | 1    | O-Ring                  |
| 5    | 132-4894    | 1    | Valve-Relief, Poppet    |
| 6    | 132-4893    | 1    | Valve-Sequence, 110 PSI |
| 7    | 353-988     | 1    | Plug-Hex                |
| 7:1  | 237-79      | 1    | O-Ring                  |

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 8    | 117-0227    | 1    | Valve-Relief, Proportional |
| 8:1  | 105-9156    | 1    | Seal Kit                   |
| 8:2  | 130-8180    | 1    | Nut-Coil (9/16-24 Unef-2B) |
| 9    | 119-4619    | 1    | Coil-Solenoid              |
| 11   | 132-4891    | 1    | Disc-Orifice               |
| 12   | 59-7410     | 1    | Fitting-Diagnostic         |
| 12:1 | 237-42      | 1    | O-Ring                     |
| 13   | 354-79      | 1    | Cap-Dust                   |
| 14   | 130-8180    | 1    | Nut-Coil (9/16-24 Unef-2B) |



## RH Cutting Deck Drive Valve Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 132-1396    | 1    | RH Deck Manifold ASM  |
| 2    | 340-99      | 1    | Fitting-HYD, 90 DEG   |
| 2:1  | 237-30      | 1    | O-Ring                |
| 2:2  | 237-42      | 1    | O-Ring                |
| 3    | 104-3797    | 1    | Fitting-Straight      |
| 3:1  | 237-146     | 1    | O-Ring                |
| 3:2  | 340-65      | 1    | O-Ring                |
| 4    | 340-129     | 2    | Fitting-Elbow, 90 DEG |
| 4:1  | 237-146     | 1    | O-Ring                |
| 4:2  | 340-65      | 1    | O-Ring                |
| 5    | 104-3509    | 1    | Fitting-HYD, 45 DEG   |
| 5:1  | 237-146     | 1    | O-Ring                |
| 5:2  | 340-65      | 1    | O-Ring                |




## Hydraulic Manifold Assembly No. 132-1396

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 2    | 132-4896    | 2    | Element-Logic           |
| 2:1  | 139-7839    | 1    | Seal Kit                |
| 3    | 132-4895    | 1    | Orifice                 |
| 4    | 353-508     | 1    | Plug-HH                 |
| 4:1  | 237-42      | 1    | O-Ring                  |
| 5    | 132-4894    | 1    | Valve-Relief, Poppet    |
| 6    | 132-4893    | 1    | Valve-Sequence, 110 PSI |
| 7    | 353-988     | 1    | Plug-Hex                |
| 7:1  | 237-79      | 1    | O-Ring                  |

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 8    | 117-0227    | 1    | Valve-Relief, Proportional |
| 8:1  | 105-9156    | 1    | Seal Kit                   |
| 8:2  | 130-8180    | 1    | Nut-Coil (9/16-24 Unef-2B) |
| 9    | 119-4619    | 1    | Coil-Solenoid              |
| 11   | 132-4891    | 1    | Disc-Orifice               |
| 12   | 59-7410     | 1    | Fitting-Diagnostic         |
| 12:1 | 237-42      | 1    | O-Ring                     |
| 13   | 354-79      | 1    | Cap-Dust                   |
| 14   | 130-8180    | 1    | Nut-Coil (9/16-24 Unef-2B) |

# Hydraulic Motor Assembly No. 125-5392




# Hydraulic Motor Assembly No. 125-5392 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 115-4110           | 1           | Seal Kit                |
| 1:1         |                    | 2           | Seal-Shaft ●            |
| 1:2         |                    | 2           | Seal-Plate, Balancing ● |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1:3         |                    | 2           | Seal-Anti Extrusion ● |
| 1:4         |                    | 2           | O-Ring (Housing) ●    |

● Not serviced separately


# Hydraulic Steering/Lift Circuit Assembly



## Hydraulic Steering/Lift Circuit Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|--------------------------------|
| 1           | 137-5626           | 1           | Manifold-Steering/Lift | 18          | 130-9038           | 1           | Hydraulic Tube ASM             |
| 2           | 75-1310            | 1           | Filter-HYD             | 19          | 131-2298           | 2           | Hydraulic Hose ASM             |
| 3           | 340-68             | 1           | Fitting-Tee, Bulkhead  | 21          | 3256-23            | 2           | Washer-Plain                   |
| 3:1         | 237-22             | 3           | O-Ring                 | 22          | 131-2299           | 2           | Hydraulic Hose ASM             |
| 4           | 340-70             | 4           | Nut-Lock               | 23          | 104-8300           | 2           | Nut-HF, NI                     |
| 5           | 114-4831           | 1           | LH Lift Cylinder ASM   | 26          | 340-121            | 2           | Fitting-Tee                    |
| 6           | 340-2              | 8           | Fitting-Straight       | 26:1        | 237-30             | 3           | O-Ring                         |
| 6:1         | 237-22             | 1           | O-Ring                 | 27          | 340-127            | 2           | Nut-Bulkhead                   |
| 6:2         | 237-42             | 1           | O-Ring                 | 29          | 3234-12            | 4           | Screw-HHF                      |
| 7           | 114-4830           | 1           | RH Lift Cylinder ASM   | 32          | 132-1378           | 1           | Manual Park Brake Manifold ASM |
| 8           | 302-60             | 2           | Fitting-Grease         | 33          | 132-1380           | 1           | Hydraulic Tube ASM             |
| 9           | 302-5              | 4           | Fitting-Grease         | 33:1        | 237-22             | 1           | O-Ring                         |
| 11          | 131-2216           | 3           | Hydraulic Hose ASM     | 34          | 132-1381           | 1           | Hydraulic Tube ASM             |
| 12          | 131-2217           | 1           | Hydraulic Hose ASM     | 34:1        | 237-22             | 1           | O-Ring                         |
| 13          | 130-9035           | 1           | Hydraulic Tube ASM     | 35          | 132-1382           | 2           | Hydraulic Hose ASM             |
| 14          | 131-2374           | 1           | Hydraulic Tube ASM     | 37          | 69-8970            | 2           | Spacer                         |
| 14:1        | 237-30             | 1           | O-Ring                 | 38          | 69-8940            | 4           | Washer                         |
| 16          | 114-5685           | 2           | HYD Cylinder ASM       | 39          | 240-4              | 2           | Grommet-Rubber                 |
| 17          | 131-2371           | 1           | Hydraulic Tube ASM     | 40          | 322-13             | 2           | Screw-HH                       |
| 17:1        | 237-22             | 1           | O-Ring                 |             |                    |             |                                |

# Steering/Lift Valve Assembly No. 137-5626




## Steering/Lift Valve Assembly No. 137-5626 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|
| 1           | 137-5625           | 1           | Manifold-Steering/Lift |
| 2           | 340-2              | 3           | Fitting-Straight       |
| 2:1         | 237-22             | 1           | O-Ring                 |
| 2:2         | 237-42             | 1           | O-Ring                 |
| 3           | 340-77             | 3           | Fitting-Elbow, 90 DEG  |
| 3:1         | 237-22             | 1           | O-Ring                 |
| 3:2         | 237-42             | 1           | O-Ring                 |
| 4           | 340-4              | 1           | Fitting-Straight       |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 4:1         | 237-30             | 1           | O-Ring                |
| 4:2         | 237-79             | 1           | O-Ring                |
| 5           | 340-7              | 1           | Fitting-Straight      |
| 5:1         | 237-65             | 1           | O-Ring                |
| 5:2         | 237-80             | 1           | O-Ring                |
| 6           | 340-17             | 1           | Fitting-Elbow, 90 DEG |
| 6:1         | 237-65             | 1           | O-Ring                |
| 6:2         | 237-80             | 1           | O-Ring                |

# Hydraulic Steering/Lift Manifold Assembly No. 137-5625




# Hydraulic Steering/Lift Manifold

## Assembly No. 137-5625 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-------------------------------------|-------------|--------------------|-------------|---------------------------|
| 2           | 125-7551           | 1           | Nipple-Filter                       | 20:2        | 110-2634           | 1           | Nut-Coil                  |
| 3           | 132-4916           | 1           | Valve-Check                         | 21          | 132-4918           | 1           | Orifice-Control, Flow     |
| 4           | 353-989            | 7           | Plug-Hex, Hollow                    | 22          | 340-4              | 1           | Fitting-Straight          |
| 4:1         | 237-42             | 1           | O-Ring                              | 22:1        | 237-30             | 1           | O-Ring                    |
| 5           | 353-988            | 6           | Plug-Hex                            | 22:2        | 237-79             | 1           | O-Ring                    |
| 5:1         | 237-79             | 1           | O-Ring                              | 23          | 130-1674           | 1           | Orifice-Control, Flow     |
| 6           | 354-70             | 1           | Plug-Hex, Hollow                    | 24          | 139-7834           | 1           | Pressure Compensator      |
| 6:1         | 237-80             | 1           | O-Ring                              | 24:1        | 110-6111           | 1           | Seal Kit                  |
| 7           | 105-9321           | 1           | Check Valve ASM                     | 25          | 132-4920           | 1           | Valve-Solenoid            |
| 7:1         | 105-9156           | 1           | Seal Kit                            | 26          | 132-4921           | 1           | Valve-Relief, Poppet Type |
| 8           | 138-3828           | 1           | Valve-Solenoid, 3 Way 2<br>Position | 27          | 132-4923           | 1           | Vented Logic Element      |
| 8:1         | 138-3831           | 1           | Seal Kit                            | 28          | 353-990            | 15          | Plug ASM                  |
| 9           | 138-3827           | 2           | Screw                               | 28:1        | 237-78             | 1           | O-Ring                    |
| 10          | 110-5973           | 2           | Orifice-0.030                       | 29          | 132-4922           | 1           | Valve-Relief, Poppet Type |
| 11          | 353-512            | 4           | Plug                                | 30          | 110-8881           | 1           | Valve-Check               |
| 11:1        | 237-78             | 1           | O-Ring                              | 30:1        | 105-9159           | 1           | Seal Kit ●                |
| 12          | 125-7556           | 4           | Solenoid Valve ASM                  | 31          | 110-2634           | 8           | Nut-Coil                  |
| 12:1        | 107-7813           | 1           | Seal Kit                            | 32          | 130-8181           | 1           | Nut-Coil (1/2-20 Unf-2B)  |
| 13          | 110-6344           | 5           | Coil-12V, DC                        | 33          | 353-508            | 2           | Plug-HH                   |
| 15          | 112-9206           | 3           | Solenoid Valve ASM                  | 33:1        | 237-42             | 1           | O-Ring                    |
| 15:1        | 105-9156           | 1           | Seal Kit                            | 34          | 340-77             | 1           | Fitting-Elbow, 90 DEG     |
| 15:2        | 110-2634           | 1           | Nut-Coil                            | 34:1        | 237-22             | 1           | O-Ring                    |
| 16          | 110-0497           | 4           | Coil-Solenoid                       | 34:2        | 237-42             | 1           | O-Ring                    |
| 17          | 132-4917           | 2           | Orifice-Check, 0.088 DIA            | 35          | 59-7410            | 3           | Fitting-Diagnostic        |
| 18          | 340-2              | 1           | Fitting-Straight                    | 35:1        | 237-42             | 1           | O-Ring                    |
| 18:1        | 237-22             | 1           | O-Ring                              | 36          | 115-9148           | 1           | Fitting-Elbow-90          |
| 18:2        | 237-42             | 1           | O-Ring                              | 36:1        | 237-42             | 1           | O-Ring                    |
| 19          | 110-8887           | 2           | Plug-Orifice (0.055)                | 37          | 354-79             | 4           | Cap-Dust                  |
| 20          | 115-5405           | 1           | Solenoid Valve ASM                  | 38          | 138-3825           | 1           | Plate-Mounting, Standard  |
| 20:1        | 115-5413           | 1           | Seal Kit                            |             |                    |             |                           |


● Not illustrated



## Hydraulic Cylinder Assembly No. 114-4830

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 114-5611           | 1           | Seal Kit           |
| 1:1         |                    | 1           | O-Ring ●           |
| 1:2         |                    | 1           | Backup ●           |
| 1:3         |                    | 1           | Seal-Bp ●          |
| 1:4         |                    | 1           | Seal-Bs ●          |
| 1:5         |                    | 1           | Ring-Wear ●        |
| 1:6         |                    | 1           | Seal-Dust ●        |
| 1:7         |                    | 1           | O-Ring ●           |


● Not serviced separately



## Hydraulic Cylinder Assembly No. 114-4831

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 114-5611           | 1           | Seal Kit           |
| 1:1         |                    | 1           | O-Ring ●           |
| 1:2         |                    | 1           | Backup ●           |
| 1:3         |                    | 1           | Seal-Bp ●          |
| 1:4         |                    | 1           | Seal-Bs ●          |
| 1:5         |                    | 1           | Ring-Wear ●        |
| 1:6         |                    | 1           | Seal-Dust ●        |
| 1:7         |                    | 1           | O-Ring ●           |


● Not serviced separately



## Hydraulic Cylinder Assembly No. 114-5685

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 114-5612           | 1           | Seal Kit           |
| 1:1         |                    | 1           | O-Ring ●           |
| 1:2         |                    | 1           | Backup ●           |
| 1:3         |                    | 1           | Seal-Bp ●          |
| 1:4         |                    | 1           | Ring-Wear ●        |
| 1:5         |                    | 1           | Seal-Bs ●          |
| 1:6         |                    | 1           | Ring-Wear ●        |
| 1:7         |                    | 1           | Seal-Dust ●        |
| 1:8         |                    | 1           | O-Ring ●           |
| 2           | 117-9407           | 1           | Bushing-Connex     |


● Not serviced separately



## Manual Parking Brake Manifold Assembly No. 132-1378

| Ref. | Part Number | Qty. | Description                    |
|------|-------------|------|--------------------------------|
| 1    | 132-1399    | 1    | Manual Park Brake Manifold ASM |
| 2    | 340-77      | 1    | Fitting-Elbow, 90 DEG          |
| 2:1  | 237-22      | 1    | O-Ring                         |
| 2:2  | 237-42      | 1    | O-Ring                         |
| 3    | 340-2       | 1    | Fitting-Straight               |
| 3:1  | 237-22      | 1    | O-Ring                         |
| 3:2  | 237-42      | 1    | O-Ring                         |

# Hydraulic Parking Brake Manifold Assembly No. 132-1399




# Hydraulic Parking Brake Manifold

## Assembly No. 132-1399 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 353-989            | 1           | Plug-Hex, Hollow   |
| 2:1         | 237-42             | 1           | O-Ring             |
| 3           | 353-990            | 2           | Plug ASM           |
| 3:1         | 237-78             | 1           | O-Ring             |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 4           | 132-4905           | 1           | Valve-Relief        |
| 5           | 132-4904           | 1           | Pump-Hand           |
| 6           | 132-4903           | 1           | Valve-2 Way, Manual |


# Hydraulic Steering Assembly



## Hydraulic Steering Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 132-6256           | 1           | Valve-Steer           | 13          | 114-4922           | 3           | HYD Hose ASM          |
| 2           | 340-2              | 3           | Fitting-Straight      | 14          | 114-4934           | 1           | HYD Hose ASM          |
| 2:1         | 237-22             | 1           | O-Ring                | 15          | 125-5352           | 1           | Hydraulic Tube ASM    |
| 2:2         | 237-42             | 1           | O-Ring                | 16          | 125-5353           | 1           | Hydraulic Tube ASM    |
| 3           | 139-0965           | 1           | Hydraulic Tube ASM    | 17          | 56-7973            | 6           | Clamp-Tube            |
| 3:1         | 237-22             | 1           | O-Ring                | 18          | 127-3492-0P        | 1           | Support-Hardlines     |
| 4           | 139-0964           | 1           | Hydraulic Tube ASM    | 19          | 322-38             | 2           | Screw-HH              |
| 4:1         | 237-22             | 1           | O-Ring                | 20          | 104-8300           | 6           | Nut-HF, NI            |
| 5           | 139-0963           | 1           | Hydraulic Tube ASM    | 21          | 3256-23            | 6           | Washer-Plain          |
| 5:1         | 237-22             | 2           | O-Ring                | 22          | 322-7              | 3           | Screw-HH              |
| 6           | 139-0966           | 1           | Hydraulic Tube ASM    | 23          | 2412-82            | 1           | Clamp-R               |
| 6:1         | 237-22             | 2           | O-Ring                | 24          | 340-77             | 1           | Fitting-Elbow, 90 DEG |
| 7           | 69-8940            | 4           | Washer                | 24:1        | 237-22             | 1           | O-Ring                |
| 8           | 340-68             | 2           | Fitting-Tee, Bulkhead | 24:2        | 237-42             | 1           | O-Ring                |
| 8:1         | 237-22             | 3           | O-Ring                | 25          | 322-6              | 1           | Screw-HH              |
| 9           | 340-70             | 6           | Nut-Lock              | 26          | 340-87             | 1           | Fitting-Elbow, 45 DEG |
| 10          | 132-1308           | 2           | HYD Cylinder ASM      | 26:1        | 237-22             | 1           | O-Ring                |
| 11          | 340-132            | 2           | Fitting-Elbow, 90 DEG | 26:2        | 237-42             | 1           | O-Ring                |
| 11:1        | 237-78             | 1           | O-Ring                | 27          | 139-0988           | 1           | Hose ASM              |
| 11:2        | 237-21             | 1           | O-Ring                | 28          | 139-0986           | 2           | Hose ASM              |
| 12          | 340-103            | 2           | Fitting-HYD, 45 DEG   | 29          | 139-0987           | 1           | Hose ASM              |
| 12:1        | 237-78             | 1           | O-Ring                | 30          | 139-0985           | 1           | Hose ASM              |
| 12:2        | 237-21             | 1           | O-Ring                | 31          | 3290-378           | 2           | Tie-Cable             |

# Steering Valve Assembly No. 132-6256



## Steering Valve Assembly No. 132-6256 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 106-6716           | 1           | Seal Kit           |




9 = all items included in seal repair kit

## Hydraulic Cylinder Assembly No. 132-1308

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 2    | 82-5730     | 1    | Tie Rod End ASM  |
| 2:1  | 105-7941    | 1    | Nut-Hex, Slotted |
| 2:2  | 105-7835    | 1    | Seal             |
| 2:3  | 302-5       | 1    | Fitting-Grease   |
| 3    | 69-1980     | 1    | Nut-Jam          |
| 4    | 32121-34    | 1    | Pin-Roll         |
| 6    | 133-2476    | 1    | Piston           |
| 7    | 133-2477    | 1    | Nut-Lock         |
| 8    | 133-2478    | 1    | Head             |

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 9    | 133-2479    | 1    | Seal Repair Kit |
| 9:1  |             | 1    | O-Ring ●        |
| 9:2  |             | 1    | Ring-Backup ●   |
| 9:3  |             | 1    | Seal-Bt ●       |
| 9:4  |             | 1    | Seal-Psp ●      |
| 9:5  |             | 1    | Seal-Psp ●      |
| 9:6  |             | 1    | O-Ring ●        |
| 10   | 133-2482    | 1    | Collar-Internal |
| 11   | 3272-12     | 1    | Pin-Cotter      |

● Not serviced separately




## Hydraulic Filter Manifold Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 130-2510    | 1    | Manifold-Suction    |
| 1:1  | 237-65      | 1    | O-Ring              |
| 2    | 130-2548    | 1    | Hydraulic Tube ASM  |
| 2:1  | 340-65      | 2    | O-Ring              |
| 2:2  | 237-22      | 1    | O-Ring              |
| 3    | 132-1404    | 1    | Filter Head ASM     |
| 3:1  |             | 1    | Head-Filter ●       |
| 3:2  | 86-6110     | 1    | Filter-Hydraulic    |
| 4    | 104-3797    | 1    | Fitting-Straight    |
| 4:1  | 237-146     | 1    | O-Ring              |
| 4:2  | 340-65      | 1    | O-Ring              |
| 6    | 104-3509    | 1    | Fitting-HYD, 45 DEG |
| 6:1  | 237-146     | 1    | O-Ring              |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 6:2  | 340-65      | 1    | O-Ring             |
| 7    | 127-3519    | 1    | Hydraulic Hose ASM |
| 8    | 340-7       | 2    | Fitting-Straight   |
| 8:1  | 237-65      | 1    | O-Ring             |
| 8:2  | 237-80      | 1    | O-Ring             |
| 10   | 130-2544    | 1    | Hydraulic Hose ASM |
| 11   | 340-128     | 1    | Nut-Bulkhead       |
| 12   | 130-2514    | 1    | Hydraulic Hose ASM |
| 13   | 125-5366    | 1    | Hydraulic Hose ASM |
| 15   | 131-2216    | 1    | Hydraulic Hose ASM |
| 18   | 323-6       | 4    | Screw-HH           |
| 19   | 3253-21     | 4    | Washer-Lock        |

● Not serviced separately


# Side Panel and Bumper Assembly



## Side Panel and Bumper Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 130-9028           | 1           | Shroud-Rear, Lower        | 12          | 114-4869           | 4           | Grommet            |
| 2           | 139-2071           | 2           | Light-Rear Tail/Stop/Turn | 13          | 92-9674            | 4           | Knob               |
| 3           | 3230-22            | 4           | Screw-CARR                | 14          | 1-803035           | 8           | Rivet-Pop          |
| 4           | 322-12             | 2           | Screw-HH                  | 16          | 3234-17            | 6           | Screw-HHF          |
| 6           | 117-5456           | 1           | Shroud-Front, LH          | 17          | 140-6929-03        | 1           | Bracket-Light, LH  |
| 7           | 117-5457           | 1           | Shroud-Front, RH          | 18          | 140-6930-03        | 1           | Bracket-Light, RH  |
| 8           | 131-2390-03        | 1           | Panel-Side, RH            | 19          | 104-8300           | 6           | Nut-HF, NI         |
| 9           | 131-2393-03        | 1           | Panel-Side, LH            | 20          | 131-2219           | 1           | Seal-Foam          |
| 10          | 139-1017           | 2           | Mount-Bumper              | 21          | 3250-23            | 4           | Screw-PPH          |
| 11          | 114-5619           | 4           | Plate-Grommet             | 22          | 120-4578           | 4           | Nut-HF             |


# Hood Assembly



## Hood Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 130-9011-0P        | 1           | Frame ASM-Hood [primed] | 15          | 120-4578           | 4           | Nut-HF              |
| 2           | 103-5752           | 4           | Stud-Ball               | 16          | 137-3101           | 6           | Screw-Plastic, HWH  |
| 3           | 32153-3            | 4           | Nut-Hex, Side Deform    | 17          | 104-1453           | 1           | Grommet             |
| 4           | 114-5532           | 2           | Cylinder-Gas            | 18          | 3256-3             | 2           | Washer-Flat         |
| 5           | 144-7165           | 1           | Hood ASM                | 19          | 3230-10            | 5           | Bolt-CARR           |
| 5:2         | 106-6754           | 2           | Decal-Danger            | 20          | 104-8300           | 13          | Nut-HF, NI          |
| 5:3         | 121-1594           | 2           | Decal-Smart Power       | 22          | 94-5780            | 4           | Screw-HWH           |
| 5:4         | 114-0990           | 2           | Decal                   | 23          | 283-55             | 2           | Pin-Clevis          |
| 5:5         | 130-9010-03        | 1           | Screen-Radiator, Hood   | 24          | 119-1416           | 2           | Pin-Cotter, Locking |
| 5:6         | 117-2382           | 42          | Plug-Plastic            | 25          | 130-9019           | 2           | Foam-Hood, Corner   |
| 5:7         | 130-9009-03        | 1           | Screen-Air Intake, Hood | 27          | 3256-57            | 2           | Washer-Flat         |
| 5:8         | 140-5844-03        | 1           | Screen-Cooler, Hood     | 28          | 104-7201           | 2           | Nut-HF, NI          |
| 9           | 65-5100            | 3           | Handle-Door             | 29          | 131-2359           | 1           | Foam-Hood           |
| 10          | 103-2898           | 2           | Latch-Rubber            | 30          | 3256-2             | 4           | Washer-Flat         |
| 11          | 120-4654           | 2           | Screw-HHF               | 31          | 130-5726           | 2           | Lanyard             |
| 12          | 103-2897           | 2           | Latch-Catch             | 32          | 120-9471           | 2           | Bolt-Shoulder       |
| 13          | 3274-39            | 4           | Screw-HSBH              | 33          | 614672             | 2           | Screw-Shoulder, HWH |
| 14          | 322-9              | 2           | Screw-HH                | 34          | 104-8301           | 2           | Nut-HF, NI          |

# Center Front Deck Connection Assembly




## Center Front Deck Connection Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           |                    | 1           | Front Center Deck ASM ● | 22:2        | 32121-110          | 1           | Pin-Roll, Slotted           |
| 2           | 138-6368           | 1           | LH Front Lift Arm ASM   | 23          | 3296-49            | 2           | Nut-Lock, NI                |
| 3           | AU495-81203        | 8           | Washer                  | 30          | 99-5107            | 4           | Nut-Lock                    |
| 4           | 302-5              | 4           | Fitting-Grease          | 31          | 104-3542           | 1           | Spider                      |
| 5           | 110-6006           | 2           | Pin-Clevis              | 32          | 110-8815           | 1           | Nut-Hex                     |
| 6           | 3256-29            | 4           | Washer-Flat             | 33          | 112-6957           | 1           | Washer-Hardened             |
| 7           | 3272-30            | 4           | Pin-Cotter              | 34          | 104-3541           | 1           | Hub-Spider                  |
| 8           | 138-6369           | 1           | RH Front Lift Arm ASM   | 35          | 3234-42            | 2           | Screw-HHF                   |
| 9           | 125-1912           | 2           | Pin-Pivot               | 36          | 3257-3             | 1           | Key-Woodruff                |
| 10          | 1-811010           | 2           | Plug                    | 37          | 133-2234-01        | 1           | Bracket-Sensor, Front       |
| 11          | 32180-030          | 1           | Clip-Tie                | 38          | 3229-1             | 2           | Screw-CARR                  |
| 12          | 119-4036           | 2           | Screw-HHF               | 39          | 3256-22            | 2           | Washer-Flat                 |
| 13          | 104-8300           | 2           | Nut-HF, NI              | 40          | 115-5300           | 1           | Proximity Switch ASM        |
| 16          | 3256-26            | 4           | Washer-Flat             | 40:1        | 117-3207           | 2           | Nut-Hex                     |
| 19          | 130-9233-01        | 2           | Plate-Reinforcing       | 40:2        | 117-3208           | 2           | Washer-Lock, Internal Tooth |
| 21          | 325-17             | 4           | Screw-HH                | 43          | 92-2743            | 2           | Pin-Clevis                  |
| 22          | 140-6337           | 2           | Pin ASM                 | 44          | 3290-467           | 2           | Pin-Hair                    |
| 22:1        | 140-6348           | 1           | Pin-Lift Arm            | 46          | 104-7201           | 2           | Nut-HF, NI                  |

● Not serviced separately

# LH Front Lift Arm Assembly No. 138-6368




## LH Front Lift Arm Assembly No. 138-6368 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 139-7837           | 1           | LH Lift Arm ASM      |
| 1:2         | 104-0015           | 2           | Bushing-Flange       |
| 1:3         | 302-11             | 2           | Fitting-Lube, 45 DEG |
| 1:4         | 105-7441           | 1           | Bearing-Spherical    |
| 1:5         | 32128-42           | 1           | Nut-HF               |
| 1:6         | 32151-34           | 1           | Ring-Retaining       |
| 1:7         | 105-7468           | 1           | Stud-Tapered         |
| 2           | 137-3581-01        | 1           | Hub Support ASM      |
| 3           | 86-1440            | 1           | Washer-Flat          |


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 4           | 3296-41            | 1           | Nut-Lock NI        |
| 5           | 104-0108           | 1           | U-Bolt             |
| 6           | 95-6231            | 1           | Chain-HOC          |
| 7           | 3256-26            | 4           | Washer-Flat        |
| 8           | 3218-5             | 2           | Nut-Jam            |
| 9           | 3296-25            | 2           | Nut-Lock, NI       |
| 10          | 139-7770           | 1           | Trigger-Sensor     |
| 11          | 3230-4             | 1           | Bolt-CARR          |
| 12          | 104-8300           | 1           | Nut-HF, NI         |

# RH Front Lift Arm Assembly No. 138-6369




## RH Front Lift Arm Assembly No. 138-6369 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 139-7847           | 1           | RH Lift Arm ASM      | 3           | 86-1440            | 1           | Washer-Flat        |
| 1:2         | 104-0015           | 2           | Bushing-Flange       | 4           | 3296-41            | 1           | Nut-Lock NI        |
| 1:3         | 302-11             | 2           | Fitting-Lube, 45 DEG | 5           | 104-0108           | 1           | U-Bolt             |
| 1:4         | 105-7441           | 1           | Bearing-Spherical    | 6           | 95-6231            | 1           | Chain-HOC          |
| 1:5         | 32128-42           | 1           | Nut-HF               | 7           | 3256-26            | 4           | Washer-Flat        |
| 1:6         | 32151-34           | 1           | Ring-Retaining       | 8           | 3218-5             | 2           | Nut-Jam            |
| 1:7         | 105-7468           | 1           | Stud-Tapered         | 9           | 3296-25            | 2           | Nut-Lock, NI       |
| 2           | 137-3581-01        | 1           | Hub Support ASM      |             |                    |             |                    |




## Center Front and Winglet Deck Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 130-9201    | 1    | Center Front Deck ASM |
| 2    | 130-9218    | 1    | Right Front Deck ASM  |
| 3    | 130-9210    | 1    | Left Front Deck ASM   |
| 4    | 69-9300     | 2    | Pad-Bumper            |
| 5    | 32108-103   | 4    | Screw-FH              |
| 6    | 104-8300    | 4    | Nut-HF, NI            |
| 7    | 325-35      | 4    | Screw-HH              |
| 8    | 99-5107     | 4    | Nut-Lock              |
| 9    | 138-6469    | 4    | Pin ASM               |
| 9:2  | 302-5       | 1    | Fitting-Grease        |
| 10   | 115-3367    | 4    | Eccentric             |




## Center Front Deck and Decal Assembly No. 130-9201

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 2    | 117-4979    | 1    | Decal-Warning            |
| 3    | 93-7818     | 1    | Decal-Torque, Blade Bolt |
| 4    | 114-0922    | 1    | Decal-Belt Routing       |
| 5    | 131-6027    | 1    | Decal-HOC                |
| 6    | 131-6026    | 1    | Decal-Rear HOC, RH       |
| 7    | 131-6025    | 1    | Decal-Rear HOC, LH       |
| 8    | 110-3510    | 1    | Nut-Retainer             |



## Right Front Deck and Decal Assembly No. 130-9218


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 2           | 120-6604           | 1           | Decal-Danger             |
| 3           | 93-7818            | 1           | Decal-Torque, Blade Bolt |
| 4           | 93-6674            | 1           | Decal-Warning            |
| 5           | 93-6687            | 1           | Decal-No Step            |
| 6           | 110-3510           | 1           | Nut-Retainer             |
| 7           | 92-3162            | 4           | Bushing                  |



## Left Front Deck and Decal Assembly No. 130-9210

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 2    | 120-6604    | 1    | Decal-Danger             |
| 3    | 93-7818     | 1    | Decal-Torque, Blade Bolt |
| 4    | 93-6674     | 1    | Decal-Warning            |
| 5    | 110-3510    | 1    | Nut-Retainer             |
| 6    | 92-3162     | 4    | Bushing                  |


# Center Deck Belt, Pulley and Spindle Assembly



## Center Deck Belt, Pulley and Spindle Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 139-1034           | 1           | Single Driving Spindle ASM | 18          | 01-182-0816        | 1           | Bolt-HH                 |
| 2           | 139-1033           | 2           | Double Driven Spindle ASM  | 19          | 3218-5             | 2           | Nut-Jam                 |
| 3           | 139-1032           | 2           | High Driven Spindle ASM    | 20          | 137-5640           | 3           | Idler Pivot ASM         |
| 4           | 132-9421           | 3           | Pulley-Idler, Flat         | 20:2        | 302-5              | 1           | Fitting-Grease          |
| 5           | 100-3102           | 2           | Washer-Flat                | 21          | 3231-2             | 9           | Bolt-CARR               |
| 6           | 108-1924           | 3           | Spacer-Idler               | 22          | 104-8301           | 28          | Nut-HF, NI              |
| 7           | 108-1993           | 3           | Screw-HSBH                 | 23          | 3256-26            | 2           | Washer-Flat             |
| 8           | 3296-45            | 3           | Nut-Hex                    | 24          | 3231-27            | 19          | Screw-CARR              |
| 9           | 108-1921           | 1           | Spring-Torsion             | 26          | 132-1611           | 1           | LH Spindle Plate ASM    |
| 10          | 112-7395           | 2           | Spring-Torsion             | 26:2        | 117-4979           | 1           | Decal-Warning           |
| 11          | 108-1926           | 3           | Washer                     | 27          | 132-1608           | 1           | Left Spindle Plate ASM  |
| 12          | 32120-84           | 3           | Ring-Snap, External        | 27:2        | 117-4979           | 1           | Decal-Warning           |
| 14          | 140-7079           | 2           | Idler Arm ASM              | 28          | 132-1602-01        | 1           | Plate-Spindle, Center   |
| 14:2        | 93-4510            | 2           | Bushing-Caster             | 29          | 132-1607           | 1           | Right Spindle Plate ASM |
| 15          | 112-7376           | 1           | Belt-V, B                  | 29:2        | 117-4979           | 1           | Decal-Warning           |
| 16          | 112-7377           | 2           | Belt-V, B                  | 30          | 132-1609           | 1           | RH Spindle Plate ASM    |
| 17          | 144-4150           | 1           | Idler Arm ASM              | 30:2        | 117-4979           | 1           | Decal-Warning           |
| 17:2        | 93-4510            | 2           | Bushing-Caster             |             |                    |             |                         |

# Single Driving Spindle Assembly No. 139-1034




## Single Driving Spindle Assembly No. 139-1034 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1           | 139-1042           | 1           | Spindle-Shaft         |
| 2           | 138-6416           | 1           | Spacer-Spindle, Shaft |
| 3           | 131-0767           | 1           | Spindle Housing ASM   |
| 3:1         |                    | 1           | Spindle ASM ●         |
| 3:1:2       | 114-8195           | 4           | Bolt-Neck, Ribbed     |
| 3:2         | 110-8297           | 1           | Bearing ASM           |
| 3:3         | 108-1954           | 1           | Bearing Spacer Set    |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 3:4         | 253-154            | 2           | Seal-Oil           |
| 3:5         | 302-60             | 1           | Fitting-Grease     |
| 4           | 106-7159           | 1           | O-Ring             |
| 5           | 104-3545           | 1           | Pulley-Driving     |
| 6           | 120-5576           | 1           | Washer-Hardened    |
| 7           | 3296-60            | 1           | Nut-Lock, NI       |
| 8           | 104-3544           | 1           | Mount-Motor, Drive |

● Not serviced separately

# Double Driven Spindle Assembly No. 139-1033




## Double Driven Spindle Assembly No. 139-1033 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1           | 139-1042           | 1           | Spindle-Shaft         |
| 2           | 138-6416           | 1           | Spacer-Spindle, Shaft |
| 3           | 119-4777           | 1           | Spindle ASM           |
| 3:1         |                    | 1           | Spindle ASM ●         |
| 3:1:2       | 114-8195           | 8           | Bolt-Neck, Ribbed     |
| 3:2         | 108-1954           | 1           | Bearing Spacer Set    |
| 3:3         | 110-8297           | 1           | Bearing ASM           |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 3:4         | 253-154            | 2           | Seal-Oil              |
| 3:5         | 302-60             | 1           | Fitting-Grease        |
| 4           | 106-7159           | 1           | O-Ring                |
| 5           | 104-3547           | 1           | Pulley-Driven, Double |
| 6           | 120-5576           | 1           | Washer-Hardened       |
| 7           | 3296-60            | 1           | Nut-Lock, NI          |

● Not serviced separately


# High Driven Spindle Assembly No. 139-1032



## High Driven Spindle Assembly No. 139-1032 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|---------------------|
| 1           | 139-1042           | 1           | Spindle-Shaft         | 3:4         | 253-154            | 2           | Seal-Oil            |
| 2           | 138-6416           | 1           | Spacer-Spindle, Shaft | 3:5         | 302-60             | 1           | Fitting-Grease      |
| 3           | 119-4777           | 1           | Spindle ASM           | 4           | 106-7159           | 1           | O-Ring              |
| 3:1         |                    | 1           | Spindle ASM ●         | 5           | 104-3548           | 1           | Pulley-Driven, High |
| 3:1:2       | 114-8195           | 8           | Bolt-Neck, Ribbed     | 6           | 120-5576           | 1           | Washer-Hardened     |
| 3:2         | 108-1954           | 1           | Bearing Spacer Set    | 7           | 3296-60            | 1           | Nut-Lock, NI        |
| 3:3         | 110-8297           | 1           | Bearing ASM           |             |                    |             |                     |


● Not serviced separately



## Center Deck Roller, Skid and Caster Wheel Assembly


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 93-4240     | 2    | 10 Inch Wheel ASM       |
| 2    | 130-7787    | 2    | Caster Arm ASM          |
| 2:2  | 302-5       | 1    | Fitting-Grease          |
| 2:3  | 69-6470     | 2    | Bushing-Caster          |
| 3    | 323-42      | 12   | Screw-HH                |
| 4    | 3256-24     | 12   | Washer-Flat             |
| 5    | 92-9727     | 2    | HOC Cap ASM             |
| 5:1  | 92-5581     | 1    | Ring-Rtng,Snap,Int,Flat |
| 5:2  | 92-5583     | 1    | Washer-Cap              |
| 5:3  | 92-9726     | 1    | Spring-Compression      |
| 5:4  | 92-8861     | 1    | Cap-HOC                 |
| 6    | 69-6860     | 8    | Washer-Thrust           |

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 7    | 69-1510     | 12   | Spacer            |
| 8    | 130-7784-01 | 2    | Fork-Caster       |
| 9    | 327-24      | 2    | Screw-HH          |
| 10   | 3296-53     | 2    | Nut-Lock, NI      |
| 11   | 112-1479    | 2    | Skid-Bumper, Deck |
| 12   | 9136144     | 2    | Screw-HWHTF       |
| 13   | 3231-33     | 4    | Screw-CARR        |
| 14   | 104-8301    | 16   | Nut-HF, NI        |
| 15   | 68-6710     | 1    | Roller            |
| 16   | 68-6840     | 1    | Shaft-Roller      |
| 17   | 3231-21     | 1    | Screw-CARR        |
| 18   | 3296-59     | 1    | Nut-Lock, NI      |




## 10 Inch Wheel Assembly No. 93-4240

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 93-4243     | 1    | Tire                  |
| 2    | 93-4244     | 1    | Tube-Inner (W/Valve)  |
| 3    | 93-4241     | 1    | Spacer-Bearing, Inner |
| 4    | 120-3366    | 2    | Bearing               |
| 5    | 32128-16    | 4    | Nut-HHF               |
| 7    | 93-4242     | 1    | Plate                 |
| 8    | 93-4239     | 1    | Rim-Wheel, Half       |
| 9    | 93-5980     | 1    | Hub                   |
| 10   | 95-2741     | 1    | Rim-Wheel, Half       |




## Center Front Deck Spindle and Blade Assembly

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 1    | 130-9151    | 5    | Blade-20 In     |
| 2    | 72-9361     | 5    | Cup-Scalp, Anti |
| 3    | 92-5816     | 5    | Bolt-Blade      |
| 4    | 104-8301    | 36   | Nut-HF, NI      |
| 5    | 323-6       | 4    | Screw-HH        |
| 6    | 3256-24     | 4    | Washer-Flat     |




## Center Front Deck Belt Cover Assembly

| Ref. | Part Number | Qty. | Description                     |
|------|-------------|------|---------------------------------|
| 1    | 131-2223    | 1    | Cover-Front Deck, Center        |
| 2    | 114-5632    | 1    | Cover-Front Deck, RH Transition |
| 3    | 114-5629    | 1    | Cover-Front Deck, LH            |
| 4    | 114-5631    | 1    | Cover-Front Deck, LH Transition |
| 5    | 114-5628    | 1    | Cover-Front Deck, RH            |
| 6    | 115-5424    | 2    | Shield-Deck, Flexible           |
| 7    | 117-2382    | 6    | Plug-Plastic                    |
| 8    | 110-3510    | 3    | Nut-Retainer                    |
| 9    | 3234-29     | 3    | Screw-HHF                       |
| 10   | 103-4080    | 4    | Latch-Rubber                    |
| 11   | 3274-39     | 8    | Screw-HSBH                      |



## Center Front Deck Chamber and Discharge Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1           | 132-1640-0P        | 1           | Chamber-Front, Left   |
| 2           | 133-2244-0P        | 1           | Chamber-Front, Lc     |
| 3           | 132-1644-0P        | 1           | Chamber-Front, Center |
| 4           | 133-2240-0P        | 1           | Chamber-Front, Rc     |
| 5           | 132-1647-0P        | 1           | Chamber-Front, Right  |
| 6           | 3230-10            | 28          | Bolt-CARR             |
| 7           | 104-8300           | 28          | Nut-HF, NI            |
| 8           | 133-2208-0P        | 2           | Angle-Deflector       |



## Center Front Deck Transport Damper Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 105-3249    | 1    | Damper             |
| 2    | 104-8331    | 1    | End-Rod, Spherical |
| 3    | 115-5455    | 1    | End-Rod, Clevis    |
| 4    | 115-5454    | 1    | Pin-Spring         |
| 5    | 322-17      | 1    | Screw-HH           |
| 6    | 115-2142    | 1    | Spacer             |
| 7    | 104-8300    | 1    | Nut-HF, NI         |

# Left Hand Deck Connection Assembly




## Left Hand Deck Connection Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|---------------------|
| 1           |                    | 1           | Left Deck ASM ●       | 20          | 136-0063-01        | 1           | Channel-LH          |
| 2           | 121-3882           | 1           | Shaft-Pivot, Lift Arm | 21          | 121-1759           | 2           | Spacer              |
| 3           | 302-60             | 1           | Fitting-Grease        | 22          | 136-0065-01        | 2           | Plate-Spacer        |
| 4           | 110-6767           | 4           | Washer-Thrust         | 23          | 3233-2             | 10          | Screw-CARR          |
| 5           | 110-6006           | 1           | Pin-Clevis            | 24          | 136-0040-03        | 1           | Stop-Deck ASM       |
| 6           | 3272-30            | 2           | Pin-Cotter            | 25          | 3253-7             | 2           | Washer-Lock         |
| 7           | 138-6396           | 1           | Lift Arm ASM, LH      | 26          | 325-4              | 2           | Screw-HH            |
| 7:2         | 114-5596           | 2           | Bushing-Straight      | 27          | 3233-1             | 6           | Screw-CARR          |
| 7:3         | 69-6470            | 2           | Bushing-Caster        | 28          | 112-7339           | 1           | Plate-Sensing       |
| 7:4         | 302-5              | 1           | Fitting-Grease        | 29          | 3230-3             | 2           | Screw-CARR          |
| 7:5         | 302-60             | 1           | Fitting-Grease        | 30          | 98-1452            | 1           | Washer-Thrust       |
| 8           | 125-1912           | 1           | Pin-Pivot             | 31          | 69-9290            | 2           | Pad-Bumper          |
| 9           | 302-5              | 1           | Fitting-Grease        | 32          | 32108-103          | 4           | Screw-FH            |
| 10          | 104-8300           | 7           | Nut-HF, NI            | 33          | 104-3542           | 1           | Spider              |
| 11          | 119-4036           | 1           | Screw-HHF             | 34          | 110-8815           | 1           | Nut-Hex             |
| 12          | 104-0721           | 2           | Washer-Thrust         | 35          | 112-6957           | 1           | Washer-Hardened     |
| 13          | 114-5640-03        | 1           | Joint Yoke ASM        | 36          | 104-3541           | 1           | Hub-Spider          |
| 13:1        |                    | 1           | Yoke-Joint ●          | 37          | 3234-42            | 2           | Screw-HHF           |
| 13:1:1      | 104-4299           | 1           | Cross And Bearing Kit | 38          | 3257-3             | 1           | Key-Woodruff        |
| 14          | 104-0719           | 1           | Washer-Hardened       | 39          | 136-0055-01        | 1           | Plate-Hose Retainer |
| 15          | 114-5641           | 1           | Washer-Thrust         | 40          | 130-9161           | 1           | Support-Hose        |
| 16          | 116-1399           | 1           | Locknut               | 41          | 321-5              | 2           | Screw-HH            |
| 17          | 136-0061-03        | 1           | Mount-Deck, Machining | 42          | 104-7201           | 2           | Nut-HF, NI          |
| 18          | 104-0720           | 1           | Spacer                | 43          | 99-5107            | 16          | Nut-Lock            |
| 19          | 32120-42           | 2           | Ring-Retaining        |             |                    |             |                     |


● Not serviced separately

# Left Hand Deck Belt, Pulley and Spindle Assembly



## Left Hand Deck Belt, Pulley and Spindle Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-------------------------------|
| 1           | 130-9271           | 1           | Left Deck ASM              | 15          | 108-1921           | 2           | Spring-Torsion                |
| 2           | 139-1034           | 1           | Single Driving Spindle ASM | 16          | 112-7377           | 2           | Belt-V, B                     |
| 3           | 139-1033           | 1           | Double Driven Spindle ASM  | 17          | 137-5640           | 2           | Idler Pivot ASM               |
| 4           | 139-1032           | 1           | High Driven Spindle ASM    | 17:2        | 302-5              | 1           | Fitting-Grease                |
| 5           | 132-9421           | 2           | Pulley-Idler, Flat         | 18          | 3231-2             | 6           | Bolt-CARR                     |
| 6           | 100-3102           | 1           | Washer-Flat                | 20          | 3256-26            | 1           | Washer-Flat                   |
| 7           | 108-1993           | 2           | Screw-HSBH                 | 21          | 104-8301           | 16          | Nut-HF, NI                    |
| 8           | 108-1924           | 2           | Spacer-Idler               | 22          | 3231-27            | 10          | Screw-CARR                    |
| 9           | 3296-45            | 2           | Nut-Hex                    | 23          | 132-1621           | 1           | Inner Spindle Plate ASM       |
| 10          | 140-7079           | 1           | Idler Arm ASM              | 23:2        | 117-4979           | 1           | Decal-Warning                 |
| 10:2        | 93-4510            | 2           | Bushing-Caster             | 24          | 132-1622-01        | 1           | Plate-Spindle, Center         |
| 11          | 108-1926           | 2           | Washer                     | 25          | 132-1620           | 1           | Outer Spindle Plate ASM       |
| 12          | 32120-84           | 2           | Ring-Snap, External        | 25:2        | 117-4979           | 1           | Decal-Warning                 |
| 14          | 140-7078           | 1           | Idler Arm ASM              | 25:3        | 114-4883           | 1           | Decal-Belt Routing, Deck (LH) |
| 14:2        | 93-4510            | 2           | Bushing-Caster             |             |                    |             |                               |



## Left Hand Deck Decal Assembly No. 130-9271


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 2           | 117-4979           | 1           | Decal-Warning            |
| 3           | 120-6604           | 1           | Decal-Danger             |
| 4           | 93-7818            | 1           | Decal-Torque, Blade Bolt |
| 5           | 110-3510           | 4           | Nut-Retainer             |
| 6           | 131-6027           | 1           | Decal-HOC                |






## Left Hand Deck Spindle and Blade Assembly

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 1    | 92-5816     | 3    | Bolt-Blade      |
| 2    | 72-9361     | 3    | Cup-Scalp, Anti |
| 3    | 130-9151    | 3    | Blade-20 In     |
| 4    | 323-6       | 4    | Screw-HH        |
| 5    | 3256-24     | 4    | Washer-Flat     |
| 6    | 104-8301    | 20   | Nut-HF, NI      |




## Left Hand Deck Belt Cover Assembly

| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 1    | 114-5633    | 1    | Cover-Deck, LH Wing (Inside)  |
| 2    | 114-5634    | 1    | Cover-Deck, LH Wing (Outside) |
| 3    | 114-5637    | 1    | Cover-Deck, LH Wing (Fixed)   |
| 4    | 110-3510    | 4    | Nut-Retainer                  |
| 5    | 136-0079    | 1    | Plug-Rubber                   |
| 6    | 3229-2      | 2    | Screw-CARR                    |
| 7    | 104-7201    | 2    | Nut-HF, NI                    |
| 8    | 3234-29     | 4    | Screw-HHF                     |
| 9    | 115-3362    | 1    | Guide-Hose                    |
| 10   | 3230-10     | 2    | Bolt-CARR                     |
| 11   | 104-8300    | 2    | Nut-HF, NI                    |
| 12   | 103-4080    | 4    | Latch-Rubber                  |
| 13   | 3274-39     | 8    | Screw-HSBH                    |



## Left Hand Deck Chamber Assembly


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 132-1600-0P | 1    | Chamber-Left, Inner  |
| 2    | 131-6005-0P | 1    | Chamber-Left, Center |
| 3    | 131-6001-0P | 1    | Chamber-Left, Outer  |
| 4    | 3230-10     | 12   | Bolt-CARR            |
| 5    | 104-8300    | 12   | Nut-HF, NI           |
| 6    | 133-2248-0P | 1    | Deflector-LH         |



## Left Hand Deck Stop Assembly

| Ref. | Part Number | Qty. | Description  |
|------|-------------|------|--------------|
| 1    | 33025-00    | 1    | Nut-Lock, NI |
| 2    | 87-3470     | 1    | Bumper       |
| 3    | 325-14      | 2    | Screw-HH     |
| 4    | 115-2144    | 2    | Tube-Spacer  |
| 5    | 115-3366    | 2    | Roller       |
| 6    | 3296-45     | 2    | Nut-Hex      |
| 7    | 321-5       | 2    | Screw-HH     |
| 8    | 130-9161    | 1    | Support-Hose |
| 9    | 104-7201    | 2    | Nut-HF, NI   |


# Left Hand Deck Impact Arm and Limit Switch Assembly



## Left Hand Deck Impact Arm and Limit Switch Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 137-1648           | 1           | Impact Damper ASM  | 9           | 115-5300           | 1           | Proximity Switch ASM        |
| 2           | 98-1452            | 1           | Washer-Thrust      | 9:1         | 117-3207           | 2           | Nut-Hex                     |
| 3           | 106-2008           | 1           | Washer-Thrust      | 9:2         | 117-3208           | 2           | Washer-Lock, Internal Tooth |
| 4           | 325-5              | 1           | Screw-HH           | 10          | 3229-34            | 2           | Screw-CARR                  |
| 5           | 136-0077           | 2           | Spacer             | 11          | 3296-2             | 2           | Nut-Lock, NI                |
| 6           | 117-5479           | 2           | Pin-Spring         | 12          | 328-8              | 1           | Screw-HH                    |
| 7           | 133-2236           | 1           | Bracket-Support    | 13          | 3296-51            | 1           | Nut-Lock, NI                |
| 8           | 3290-412           | 3           | Rivet-Blind        | 14          | 133-2235           | 1           | Bracket-Sensor, Side        |


Impact Damper Assembly No. 137-1648



## Impact Damper Assembly No. 137-1648 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 138-5253           | 1           | Pivot Hub ASM      | 9           | 323-7              | 4           | Screw-HH           |
| 1:2         | 302-60             | 1           | Fitting-Grease     | 10          | 138-5266           | 1           | Shaft-Spring       |
| 1:3         | 115-5469           | 2           | Bushing-Flange     | 11          | 114-5986           | 3           | Washer-Plain       |
| 1:4         | 114-5680           | 2           | Bushing-Flange     | 12          | 114-5993           | 1           | Spring-Compression |
| 2           | 137-5596           | 1           | Arm-Impact, Rear   | 13          | 114-5992           | 1           | Bearing-Plastic    |
| 3           | 94-6604            | 1           | Tube-Spacer        | 14          | 3256-62            | 1           | Washer-Flat        |
| 4           | 3256-7             | 2           | Washer-Flat        | 15          | 3220-9             | 2           | Nut-Jam            |
| 5           | 327-23             | 1           | Screw-HH           | 16          | 285-17             | 1           | Plug-Pipe          |
| 6           | 3296-53            | 1           | Nut-Lock, NI       | 17          | 114-5989           | 1           | Bushing-Plain      |
| 7           | 138-5250           | 1           | Housing ASM        | 18          | 105-2806           | 1           | End-Rod            |
| 8           | 104-8301           | 4           | Nut-HF, NI         | 19          | 3220-7             | 1           | Nut-Jam            |


# Left Hand Deck Transport Lock Assembly



# Left Hand Deck Transport Lock Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 119-8275-01        | 1           | Pad-Transport, LH  | 13          | 114-5675           | 1           | Shim-Pad           |
| 2           | 87-3470            | 1           | Bumper             | 14          | 69-9300            | 2           | Pad-Bumper         |
| 3           | 115-8826           | 1           | Shim-Bumper        | 15          | 32108-107          | 2           | Screw-FH           |
| 4           | 33025-00           | 1           | Nut-Lock, NI       | 16          | 119-7723-03        | 1           | Latch-Wing         |
| 5           | 104-8300           | 3           | Nut-HF, NI         | 17          | 3256-26            | 1           | Washer-Flat        |
| 6           | 3234-17            | 1           | Screw-HHF          | 18          | 99-5107            | 1           | Nut-Lock           |
| 7           | 323-14             | 1           | Screw-HH           | 19          | 114-5659-03        | 1           | Handle-Latch       |
| 8           | 104-8301           | 5           | Nut-HF, NI         | 20          | 119-1846           | 1           | Grip               |
| 9           | 3234-42            | 2           | Screw-HHF          | 21          | 3231-25            | 2           | Bolt-CARR          |
| 10          | 117-5476           | 1           | Pad-Roller         | 22          | 104-3577           | 2           | Washer             |
| 11          | 1-807512           | 4           | Bolt-CARR          | 23          | 3234-46            | 1           | Screw-HHF          |
| 12          | 104-7201           | 4           | Nut-HF, NI         | 24          | 52-2861            | 1           | Washer             |

# Right Hand Deck Connection Assembly




## Right Hand Deck Connection Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|---------------------|
| 1           |                    | 1           | Right Deck ASM ●      | 20          | 136-0064-01        | 1           | Channel-RH          |
| 2           | 121-3882           | 1           | Shaft-Pivot, Lift Arm | 21          | 121-1759           | 2           | Spacer              |
| 3           | 302-60             | 1           | Fitting-Grease        | 22          | 136-0065-01        | 2           | Plate-Spacer        |
| 4           | 110-6767           | 4           | Washer-Thrust         | 23          | 3233-2             | 10          | Screw-CARR          |
| 5           | 110-6006           | 1           | Pin-Clevis            | 24          | 136-0080-03        | 1           | Stop-Deck, RH       |
| 6           | 3272-30            | 2           | Pin-Cotter            | 25          | 3253-7             | 2           | Washer-Lock         |
| 7           | 138-6395           | 1           | Lift Arm ASM, RH      | 26          | 325-4              | 2           | Screw-HH            |
| 7:2         | 114-5596           | 2           | Bushing-Straight      | 27          | 3233-1             | 6           | Screw-CARR          |
| 7:3         | 69-6470            | 2           | Bushing-Caster        | 28          | 112-7339           | 1           | Plate-Sensing       |
| 7:4         | 302-5              | 1           | Fitting-Grease        | 29          | 3230-3             | 2           | Screw-CARR          |
| 7:5         | 302-60             | 1           | Fitting-Grease        | 30          | 98-1452            | 1           | Washer-Thrust       |
| 8           | 125-1912           | 1           | Pin-Pivot             | 31          | 69-9290            | 2           | Pad-Bumper          |
| 9           | 302-5              | 1           | Fitting-Grease        | 32          | 32108-103          | 4           | Screw-FH            |
| 10          | 104-8300           | 7           | Nut-HF, NI            | 33          | 104-3542           | 1           | Spider              |
| 11          | 119-4036           | 1           | Screw-HHF             | 34          | 110-8815           | 1           | Nut-Hex             |
| 12          | 104-0721           | 2           | Washer-Thrust         | 35          | 112-6957           | 1           | Washer-Hardened     |
| 13          | 114-5640-03        | 1           | Joint Yoke ASM        | 36          | 104-3541           | 1           | Hub-Spider          |
| 13:1        |                    | 1           | Yoke-Joint ●          | 37          | 3234-42            | 2           | Screw-HHF           |
| 13:1:1      | 104-4299           | 1           | Cross And Bearing Kit | 38          | 3257-3             | 1           | Key-Woodruff        |
| 14          | 104-0719           | 1           | Washer-Hardened       | 39          | 136-0055-01        | 1           | Plate-Hose Retainer |
| 15          | 114-5641           | 1           | Washer-Thrust         | 40          | 130-9161           | 1           | Support-Hose        |
| 16          | 116-1399           | 1           | Locknut               | 41          | 321-5              | 2           | Screw-HH            |
| 17          | 136-0061-03        | 1           | Mount-Deck, Machining | 42          | 104-7201           | 2           | Nut-HF, NI          |
| 18          | 104-0720           | 1           | Spacer                | 43          | 99-5107            | 16          | Nut-Lock            |
| 19          | 32120-42           | 2           | Ring-Retaining        |             |                    |             |                     |


● Not serviced separately

# Right Hand Deck Belt, Pulley and Spindle Assembly




## Right Hand Deck Belt, Pulley and Spindle Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-------------------------------|
| 1           | 130-9241           | 1           | Right Deck ASM             | 16          | 140-7078           | 1           | Idler Arm ASM                 |
| 2           | 139-1034           | 1           | Single Driving Spindle ASM | 16:2        | 93-4510            | 2           | Bushing-Caster                |
| 3           | 139-1033           | 1           | Double Driven Spindle ASM  | 17          | 137-5640           | 2           | Idler Pivot ASM               |
| 4           | 139-1032           | 1           | High Driven Spindle ASM    | 17:2        | 302-5              | 1           | Fitting-Grease                |
| 5           | 112-7377           | 2           | Belt-V, B                  | 18          | 3231-2             | 6           | Bolt-CARR                     |
| 6           | 140-5847           | 2           | Pulley-Idler               | 20          | 3256-26            | 4           | Washer-Flat                   |
| 7           | 140-7079           | 1           | Idler Arm ASM              | 21          | 104-8301           | 18          | Nut-HF, NI                    |
| 7:2         | 93-4510            | 2           | Bushing-Caster             | 22          | 3231-27            | 12          | Screw-CARR                    |
| 8           | 108-1926           | 2           | Washer                     | 23          | 132-1617           | 1           | Outer Spindle Plate ASM       |
| 9           | 100-3102           | 1           | Washer-Flat                | 23:2        | 117-4979           | 1           | Decal-Warning                 |
| 10          | 3274-5             | 2           | Screw-HSH                  | 24          | 132-1618           | 1           | Center Spindle Plate ASM      |
| 11          | 108-1924           | 2           | Spacer-Idler               | 24:2        | 114-0974           | 1           | Decal-Belt Routing, Deck (RH) |
| 12          | 3296-45            | 2           | Nut-Hex                    | 25          | 132-1615-01        | 1           | Plate-Spindle, Inner          |
| 13          | 108-1921           | 2           | Spring-Torsion             |             |                    |             |                               |
| 14          | 32120-84           | 2           | Ring-Snap, External        |             |                    |             |                               |



## Right Hand Deck Decal Assembly No. 130-9241


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 2           | 117-4979           | 2           | Decal-Warning            |
| 3           | 120-6604           | 1           | Decal-Danger             |
| 4           | 93-7818            | 1           | Decal-Torque, Blade Bolt |
| 5           | 110-3510           | 4           | Nut-Retainer             |
| 6           | 131-6027           | 1           | Decal-HOC                |



## Right Hand Deck Spindle and Blade Assembly

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 1    | 130-9151    | 3    | Blade-20 In     |
| 2    | 72-9361     | 3    | Cup-Scalp, Anti |
| 3    | 92-5816     | 3    | Bolt-Blade      |
| 4    | 104-8301    | 20   | Nut-HF, NI      |
| 5    | 323-6       | 4    | Screw-HH        |
| 6    | 3256-24     | 4    | Washer-Flat     |


# Right Hand Deck Belt Cover Assembly



## Right Hand Deck Belt Cover Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 114-5635           | 1           | Cover-Deck, RH Wing<br>(Inside)  | 6           | 3229-2             | 2           | Screw-CARR         |
| 2           | 114-5636           | 1           | Cover-Deck, RH Wing<br>(Outside) | 7           | 104-7201           | 2           | Nut-HF, NI         |
| 3           | 114-5638           | 1           | Cover-Deck, RH Wing<br>(Fixed)   | 8           | 3234-29            | 4           | Screw-HHF          |
| 4           | 110-3510           | 4           | Nut-Retainer                     | 9           | 115-3362           | 1           | Guide-Hose         |
| 5           | 136-0079           | 1           | Plug-Rubber                      | 10          | 3230-10            | 2           | Bolt-CARR          |
|             |                    |             |                                  | 11          | 104-8300           | 2           | Nut-HF, NI         |
|             |                    |             |                                  | 12          | 103-4080           | 4           | Latch-Rubber       |
|             |                    |             |                                  | 13          | 3274-39            | 8           | Screw-HSBH         |


# Right Hand Deck Chamber Assembly



## Right Hand Deck Chamber Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|--------------------|
| 1           | 132-1637-0P        | 1           | Chamber-Right, Inner  | 5           | 104-8300           | 20          | Nut-HF, NI         |
| 2           | 132-1634-0P        | 1           | Chamber-Right, Center | 6           | 133-2249-0P        | 1           | Deflector-RH       |
| 3           | 132-1630-0P        | 1           | Chamber-Right, Outer  | 7           | 133-2205-0P        | 2           | Deflector          |
| 4           | 3230-10            | 20          | Bolt-CARR             |             |                    |             |                    |


# Right Hand Deck Impact Arm and Limit Switch Assembly



## Right Hand Deck Impact Arm and Limit Switch Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 137-1648           | 1           | Impact Damper ASM  | 9           | 115-5300           | 1           | Proximity Switch ASM        |
| 2           | 98-1452            | 1           | Washer-Thrust      | 9:1         | 117-3207           | 2           | Nut-Hex                     |
| 3           | 106-2008           | 1           | Washer-Thrust      | 9:2         | 117-3208           | 2           | Washer-Lock, Internal Tooth |
| 4           | 325-5              | 1           | Screw-HH           | 10          | 3229-34            | 2           | Screw-CARR                  |
| 5           | 136-0077           | 2           | Spacer             | 11          | 3296-2             | 2           | Nut-Lock, NI                |
| 6           | 117-5479           | 2           | Pin-Spring         | 12          | 328-8              | 1           | Screw-HH                    |
| 7           | 133-2236           | 1           | Bracket-Support    | 13          | 3296-51            | 1           | Nut-Lock, NI                |
| 8           | 3290-412           | 3           | Rivet-Blind        | 14          | 133-2235           | 1           | Bracket-Sensor, Side        |


# Right Hand Deck Transport Lock Assembly



## Right Hand Deck Transport Lock Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 119-8270-01        | 1           | Pad-Transport, RH  | 13          | 114-5675           | 1           | Shim-Pad           |
| 2           | 87-3470            | 1           | Bumper             | 14          | 69-9300            | 2           | Pad-Bumper         |
| 3           | 115-8826           | 1           | Shim-Bumper        | 15          | 32108-107          | 2           | Screw-FH           |
| 4           | 33025-00           | 1           | Nut-Lock, NI       | 16          | 119-7723-03        | 1           | Latch-Wing         |
| 5           | 104-8300           | 3           | Nut-HF, NI         | 17          | 3256-26            | 1           | Washer-Flat        |
| 6           | 3234-17            | 1           | Screw-HHF          | 18          | 99-5107            | 1           | Nut-Lock           |
| 7           | 323-14             | 1           | Screw-HH           | 19          | 114-5659-03        | 1           | Handle-Latch       |
| 8           | 104-8301           | 5           | Nut-HF, NI         | 20          | 119-1846           | 1           | Grip               |
| 9           | 3234-42            | 2           | Screw-HHF          | 21          | 3231-25            | 2           | Bolt-CARR          |
| 10          | 117-5476           | 1           | Pad-Roller         | 22          | 104-3577           | 2           | Washer             |
| 11          | 1-807512           | 4           | Bolt-CARR          | 23          | 3234-46            | 1           | Screw-HHF          |
| 12          | 104-7201           | 4           | Nut-HF, NI         | 24          | 52-2861            | 1           | Washer             |


# Platform Assembly



## Platform Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|----------------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 137-5600           | 1           | Platform ASM                     | 5:3         | 139-0977           | 1           | Decal-Service           |
| 1:2         | 132-1321           | 1           | Decal-Instructions,<br>Operating | 6           | 3256-55            | 10          | Washer-Flat             |
| 1:3         | 133-8062           | 1           | Decal-Arrestor, Spark            | 7           | 117-2382           | 6           | Plug-Plastic            |
| 1:4         | 114-0849           | 1           | Decal-Pedal, Traction            | 8           | 3274-69            | 2           | Screw-HSBH              |
| 1:5         | 140-5829           | 1           | Decal-Fuse                       | 9           | 110-5954           | 4           | Mount-Center, Bonded    |
| 1:6         | 132-1406           | 1           | Decal-Release, Parking<br>Brake  | 10          | 115-5519           | 4           | Washer-Plain            |
| 2           | 112-7316           | 1           | Cover-Storage, Center            | 11          | 92-2651            | 6           | Washer                  |
| 3           | 114-5508           | 1           | Rod-Hinge                        | 12          | 702093             | 2           | Screw-HH                |
| 4           | 115-5417           | 2           | Strip-Foam                       | 13          | 99-5107            | 4           | Nut-Lock                |
| 5           | 139-0996           | 1           | Lid-Center, Storage              | 14          | 126-3900           | 2           | Screw-HHF               |
| 5:2         | 117-2754           | 1           | Decal-Warning                    | 15          | 138-6367           | 1           | Wrench-Castor Cap/Latch |
|             |                    |             |                                  | 16          | 104-7201           | 2           | Nut-HF, NI              |

## Seat Mount Assembly




## Seat Mount Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Seat And Suspension ASM<br>● | 18          | 104-8300           | 11          | Nut-HF, NI         |
| 1:1         | 130-2702           | 1           | Air Ride Seat Suspension     | 19          | 116749             | 1           | Horn               |
| 1:3         | 132-1304           | 1           | Backrest Adjustment Kit      | 20          | 322-3              | 2           | Screw-HH           |
| 2           | 3212-8             | 1           | Screw-HH                     | 24          | 131-2355-03        | 1           | Support-Arm        |
| 3           | 17-7190            | 1           | Spacer-Finger                | 25          | 131-2352-03        | 1           | Channel-Support    |
| 4           | 110-0413           | 1           | Seatbelt-Retractable         | 26          | 3230-1             | 5           | Bolt-CARR          |
| 5           | 3256-25            | 4           | Washer-Flat                  | 27          | 131-2351           | 1           | Strap-Support      |
| 6           | 3212-4             | 1           | Screw-HH                     | 28          | 107-1865           | 2           | R-Clamp            |
| 7           | 119-7742           | 1           | Screw-Cushion                | 29          | 104-7050           | 1           | Tube-Manual        |
| 8           | 3231-22            | 4           | Screw-CARR                   | 30          | 104-7048           | 1           | Cap-Housing        |
| 9           | 104-8301           | 6           | Nut-HF, NI                   | 31          | 104-7201           | 2           | Nut-HF, NI         |
| 10          | 107-3154           | 4           | Nut-Push                     | 32          | 32105-15           | 2           | Screw-HWH          |
| 11          | 114-5553           | 4           | Shim-Pad                     | 34          | 3253-4             | 1           | Washer-Lock        |
| 16          | 69-9290            | 2           | Pad-Bumper                   | 35          | 33114-010          | 1           | Screw-HH           |
| 17          | 32108-103          | 4           | Screw-FH                     | 36          | 112-7405           | 1           | Nut-Hex, Coupling  |

● Not serviced separately

# Air Ride Seat Suspension Assembly No. 130-2702




## Air Ride Seat Suspension Assembly No. 130-2702 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 130-2709           | 1           | Cover ASM          | 9           | 130-2719           | 1           | Compressor              |
| 1:1         | 130-2710           | 1           | Cover Kit          | 9:1         | 130-2720           | 1           | Compressor Kit          |
| 2           | 108-8027           | 1           | Cover              | 10          | 130-2721           | 1           | Bellows ASM             |
| 3           | 130-2711           | 1           | Control-Level      | 10:1        | 130-2722           | 1           | Bellows Kit             |
| 4           | 108-8029           | 1           | Valve-Control, Air | 11          | 130-2723           | 1           | Tether                  |
| 5           | 130-2712           | 1           | Shock Absorber ASM | 11:1        | 130-2724           | 1           | Tether Kit              |
| 5:1         | 130-2713           | 1           | Shock Absorber Kit | 12          | 130-2725           | 1           | Wear Parts Kit ●        |
| 6           | 130-2714           | 1           | Air Spring ASM     | 13          | 130-2726           | 1           | Handle                  |
| 6:1         | 130-2715           | 1           | Air Spring Kit     | 14          | 130-2727           | 1           | Upper Suspension Kit    |
| 7           | 130-2716           | 1           | Air Tube ASM       | 15          | 130-2728           | 1           | Lower Suspension Kit    |
| 7:1         | 130-2717           | 1           | Air Tube Kit       | 16          | 130-2729           | 1           | Adjuster Mounting Kit ● |
| 8           | 130-2718           | 1           | Harness-Wire       | 17          | 130-2730           | 1           | Limiter-Thrust          |

● Not illustrated


# Control Console Assembly



## Control Console Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|---------------------------------|
| 1           | 136-0071           | 1           | Console Arm ASM              | 16          | 136-0069-03        | 1           | Cover-Right                     |
| 1:2         | 32148-6            | 10          | Nut-Clinch                   | 17          | 131-2222           | 1           | Strip-Foam                      |
| 2           | 3231-22            | 2           | Screw-CARR                   | 18          | 114-5554           | 1           | Decal-Center, Info              |
| 3           | 104-8301           | 2           | Nut-HF, NI                   | 20          | 100-1535           | 5           | Switch-Rocker,<br>(On)-Off-(On) |
| 4           | 104-8300           | 3           | Nut-HF, NI                   | 21          | 132-7668           | 4           | Screw-PPH                       |
| 5           | 3234-5             | 5           | Screw-HHF                    | 22          | 125-7996           | 1           | Switch-Pb, Momentary            |
| 6           | 136-1072-03        | 1           | Panel-Control Arm            | 23          | 131-8388           | 1           | Socket-USB                      |
| 7           | 136-1003           | 1           | Decal-Console, Cruise        | 27          | 93-9999            | 1           | Switch-PTO                      |
| 8           | 94-2413            | 4           | Nut-U                        | 28          | 107-8034           | 2           | Switch-Rocker, On-Off-On        |
| 9           | 111-2254           | 1           | Switch-Rocker,<br>On-None-On | 29          | 131-9637           | 1           | Armrest-Quick Find              |
| 10          | 121-1630           | 1           | Plate-Cover                  | 30          | 131-2340-03        | 1           | Cover-Gate                      |
| 11          | 32144-18           | 2           | Screw-HWH                    | 31          | 32144-85           | 12          | Screw-HWH Thd Form              |
| 12          | 121-5159           | 1           | Switch-Ignition              | 33          | 131-2338           | 1           | Top Front Cover ASM             |
| 12:1        | 121-5160           | 1           | Nut-Hex                      | 33:1        | 131-2339-03        | 1           | Cover-Front, Top                |
| 12:2        | 122-2704           | 1           | Nut-Face, M22 (Plastic)      | 33:2        | 115-5417           | 2           | Strip-Foam                      |
| 12:3        | 121-5162           | 1           | Set-Key, Ignition            | 34          | 136-1004           | 1           | Decal-Console, Main             |
| 13          | 104-9007           | 1           | Switch-Rocker                | 35          | 144-7166           | 1           | Decal-Console, Display          |
| 14          | 99-7420            | 3           | Plug-Hole                    | 37          | 139-2080           | 1           | Flasher-Dual Rate               |
| 15          | 125-5320           | 1           | Infocenter                   | 38          | 120-4578           | 1           | Nut-HF                          |
| 15:1        | 115-8884           | 4           | Nut-Thumb                    | 39          | 32105-23           | 1           | Screw                           |
| 15:2        | 115-8885           | 4           | Stud                         | 40          | 119-7769           | 1           | Switch-Rocker, On/None/On       |

# Traction Pedal Assembly




## Traction Pedal Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 136-4384-0P        | 1           | Bracket-Sender        | 20          | 84-9100            | 1           | Spring                |
| 2           | 140-6215           | 1           | Bushing Hub ASM       | 21          | 3256-24            | 1           | Washer-Flat           |
| 2:1         | 95-7497            | 1           | Bushing-Wheel         | 22          | 3296-6             | 1           | Nut-Lock              |
| 3           | 114-5608           | 2           | Spacer-Standoff       | 23          | 131-2250-0P        | 1           | Bracket-Pedal, Outer  |
| 4           | 114-5595           | 1           | Plate-Capture         | 24          | 117-5454           | 1           | Plate-Butterfly       |
| 5           | 114-5609           | 1           | Sensor-Position       | 25          | 32121-78           | 1           | Pin-Roll              |
| 6           | 32105-25           | 2           | Screw-SHH             | 26          | 117-5455           | 1           | Plate-Cover           |
| 7           | 3296-9             | 2           | Nut-Hex               | 27          | 256-236            | 1           | Bearing-Mount, Flange |
| 8           | 114-7728           | 2           | Screw-HF              | 28          | 3230-22            | 1           | Screw-CARR            |
| 9           | 131-2245           | 1           | Shaft-Pedal, Traction | 29          | 104-8300           | 7           | Nut-HF, NI            |
| 10          | 131-2252-0P        | 1           | Bracket-Spring        | 30          | 3234-47            | 1           | Screw-HHF             |
| 11          | 92-7610            | 1           | Retainer-Spring       | 31          | 93-7960            | 1           | Spacer                |
| 12          | 3256-5             | 1           | Washer-Flat           | 32          | 322-14             | 1           | Screw-HH              |
| 13          | 117-5446           | 1           | Shaft-Spring          | 33          | 136-4368-01        | 1           | Pedal-Traction        |
| 14          | 3219-3             | 1           | Nut-Hex               | 35          | 93-5347            | 1           | Abrasive-Pedal        |
| 15          | 2411-36            | 1           | Bearing-End, Rod      | 36          | 104-7201           | 2           | Nut-HF, NI            |
| 16          | 117-5459           | 2           | Block-Clamp           | 37          | 93-5368            | 1           | Abrasive-Pedal        |
| 17          | 323-7              | 1           | Screw-HH              | 38          | 3230-2             | 2           | Bolt-CARR             |
| 18          | 3296-59            | 1           | Nut-Lock, NI          | 39          | 3230-23            | 5           | Bolt-CARR             |
| 19          | 321-37             | 2           | Screw-HH              |             |                    |             |                       |




| <b>Ref.</b> | <b>Part Number</b> | <b>Qty.</b> | <b>Description</b> |
|-------------|--------------------|-------------|--------------------|
| 12          | 3231-2             | 6           | Bolt-CARR          |
| 13          | 137-5607           | 1           | Cover-Steering     |
| 14          | 107069             | 2           | Clip               |
| 15          | 105-1217           | 1           | Decal              |
| 16          | 3234-4             | 4           | Screw-HHF          |
| 17          | 98-1459            | 1           | Decal              |
| 18          | 137-5606-0P        | 1           | Support-Column     |
| 19          | 323-6              | 2           | Screw-HH           |
| 20          | 3253-21            | 2           | Washer-Lock        |
| 21          | 609900             | 2           | Nut-Speed          |
| 22          | 3274-7             | 4           | Screw-HSH          |
| 23          | 105-2409           | 4           | Screw-HSH          |



## Steering Column Assembly No. 132-6230

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 110-6462    | 1    | Bellows-Rubber       |
| 2    | 110-6463    | 1    | Cylinder Service Kit |
| 2:1  |             | 1    | Cylinder-Gas ●       |
| 2:2  |             | 1    | Block-Pedal ●        |
| 2:3  |             | 2    | Bolt ●               |
| 2:4  |             | 1    | Pin ●                |
| 2:5  |             | 2    | Washer-Lock ●        |
| 3    | 136-4385    | 1    | Pedal Service Kit    |
| 3:1  |             | 1    | Pedal ●              |
| 3:2  |             | 1    | Pin ●                |
| 3:3  |             | 1    | Spring ●             |
| 4    | 120-6256    | 1    | Universal Joint Kit  |


● Not serviced separately



## Front Electrical Component Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 132-1332    | 1    | Electrical Plate ASM    |
| 1:2  | 32148-9     | 2    | Nut-Clinch              |
| 2    | 114-3321    | 2    | Controller-Tec          |
| 4    | 80-9330     | 1    | Audio Alarm ASM         |
| 4:1  | 104-5107    | 1    | Nut-Plastic, Knurled    |
| 5    | 42862       | 1    | Block-Terminal, Ground  |
| 6    | 99-7435     | 4    | Relay                   |
| 7    | 130-9034-01 | 1    | Plate-Cover, Electrical |
| 8    | 32151-72    | 2    | Ring-Retaining          |
| 9    | 131-2221    | 1    | Strip-Foam              |
| 10   | 130-9174    | 3    | Foam-Cooler, Short      |
| 12   | 99-7430     | 1    | Relay-Mini              |
| 13   | 125-8067    | 4    | Plug-Plastic            |
| 14   | 104-0395    | 1    | Plug-Plastic            |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 15   | 3229-3      | 8    | Screw-CARR            |
| 16   | 104-7201    | 8    | Nut-HF, NI            |
| 17   | 42863       | 1    | Strip-Jumper          |
| 18   | 32105-13    | 6    | Screw-HWH             |
| 19   | 120-4578    | 10   | Nut-HF                |
| 20   | 3256-38     | 1    | Washer-Flat           |
| 22   | 3256-3      | 2    | Washer-Flat           |
| 23   | 95-9648     | 2    | Knob                  |
| 24   | 99-3481     | 2    | Grommet               |
| 25   | 3234-29     | 4    | Screw-HHF             |
| 26   | 104-8300    | 4    | Nut-HF, NI            |
| 27   | 32146-2     | 1    | Nut-Hex               |
| 28   | 3290-321    | 4    | Screw-HWH             |
| 29   | 3254-6      | 1    | Washer-Lock, Internal |



## Mid Electrical Component Assembly

| Ref. | Part Number | Qty. | Description                  |
|------|-------------|------|------------------------------|
| 1    | 120-4578    | 2    | Nut-HF                       |
| 2    | 99-7435     | 2    | Relay                        |
| 3    | 99-7430     | 1    | Relay-Mini                   |
| 4    | 32105-13    | 2    | Screw-HWH                    |
| 5    | 32180-030   | 1    | Clip-Tie                     |
| 6    | 3290-378    | 2    | Tie-Cable                    |
| 7    | 132-9627    | 1    | Bracket-Harness              |
| 8    | 33105-020   | 1    | Screw-HHF                    |
| 13   | 136-0074-01 | 1    | Bracket-Bulkhead, Electrical |
| 14   | 3230-1      | 2    | Bolt-CARR                    |
| 15   | 104-8300    | 2    | Nut-HF, NI                   |
| 16   | 32180-031   | 1    | Clip-Tree (W/Tie)            |


# Rear Electrical Component Assembly



## Rear Electrical Component Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 122-0518-0P        | 1           | Bracket-Electrical      | 20          | 32105-13           | 1           | Screw-HWH             |
| 2           | 122-0624-0P        | 1           | Bracket-Fuse            | 22          | 122-0701           | 1           | Ground Jumper         |
| 3           | 139-0997           | 1           | Contactor-12V           | 23          | 122-0603           | 1           | Switch-Disconnect     |
| 4           | 122-1546           | 1           | Cable-Battery, Positive | 23:1        | 33006-00           | 1           | Nut-HF                |
| 5           | 114-3318           | 2           | Holder-Fuse, Mega       | 24          | 3231-2             | 2           | Bolt-CARR             |
| 6           | AU126232           | 1           | Fuse-100A               | 25          | 3234-29            | 2           | Screw-HHF             |
| 7           | 120-4578           | 1           | Nut-HF                  | 27          | 132-1364           | 1           | Stud-Jumper, Positive |
| 8           | 122-0628           | 1           | Fuse-Mega               | 28          | 132-1365           | 1           | Stud-Jumper, Negative |
| 9           | 99-7430            | 1           | Relay-Mini              | 29          | 3230-7             | 3           | Bolt-CARR             |
| 10          | 104-8301           | 2           | Nut-HF, NI              | 30          | 99-3641            | 2           | Clamp-Tube            |
| 11          | 139-0995-0P        | 1           | Mount-Contactor         | 31          | 114-0989           | 1           | Plate-Cover           |
| 12          | 104-8300           | 7           | Nut-HF, NI              | 32          | 3256-22            | 2           | Washer-Flat           |
| 13          | 139-1016-0P        | 1           | Mount-Disconnect        | 33          | 321-18             | 2           | Screw-HH              |
| 14          | 32180-009          | 1           | Insulator-Lug, Red      | 34          | 139-1031           | 1           | Decal-Fuse            |
| 15          | 99-6810            | 2           | Screw-HHF               | 35          | 132-1313           | 1           | Decal-Disconnect      |
| 16          | 3234-4             | 2           | Screw-HHF               | 37          | 3229-1             | 2           | Screw-CARR            |
| 17          | 104-7201           | 8           | Nut-HF, NI              | 38          | 139-1025           | 1           | Retainer-Harness      |
| 18          | 127-2371           | 4           | Nut-HF                  | 39          | 3230-10            | 1           | Bolt-CARR             |
| 19          | 107-0380           | 2           | Nut-HHF                 | 40          | 32180-030          | 1           | Clip-Tie              |


# Battery Cable Routing Assembly



## Battery Cable Routing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 130-9077           | 4           | Mount-ISO                   | 21          | 3255-9             | 1           | Washer-Lock                |
| 2           | 130-9084-0P        | 1           | Tray-Battery                | 22          | 62-4300            | 2           | Pad-Skid, Anti             |
| 3           | 3231-6             | 4           | Screw-CARR                  | 23          | 107-3154           | 2           | Nut-Push                   |
| 4           | 114-2120           | 4           | Washer                      | 24          | 94-8105            | 2           | Clamp-Tube                 |
| 5           | 104-8301           | 7           | Nut-HF, NI                  | 25          | 122-0404           | 1           | Cable-Battery, Negative    |
| 6           | 139-1005           | 1           | Battery Kit                 | 26          | 122-0329           | 1           | Cable-Battery              |
| 6:1         | 127-7507           | 1           | Battery                     | 27          | 122-0604           | 1           | Bracket-Battery Cable      |
| 6:2         | 139-1006           | 1           | Decal                       | 28          | 32180-187          | 1           | Clip-Double Tie Mount      |
| 7           | 104-8162           | 1           | Battery                     | 29          | 322-12             | 1           | Screw-HH                   |
| 8           | 132-1388           | 2           | Bracket-Battery             | 30          | 122-0617           | 1           | Cable-Battery, Negative    |
| 8:2         | 132-1318           | 1           | Decal-24 Volt               | 31          | 69-9761            | 1           | Plate-Cover                |
| 9           | 104-8567           | 4           | Holdown-Battery             | 32          | 122-0331           | 1           | Cable-Battery              |
| 10          | 104-7201           | 4           | Nut-HF, NI                  | 33          | 33004-00           | 2           | Nut-HF                     |
| 11          | 138-6335           | 2           | Retainer-Battery            | 34          | 133-8571           | 1           | Trim-Seal                  |
| 12          | 3231-5             | 2           | Screw-CARR                  | 35          | 3334-945           | 2           | Tie-Cable                  |
| 13          | 122-0401           | 1           | Cable-Battery, Positive     | 36          | 119-4061           | 1           | Screw-HHF                  |
| 14          | 122-1146           | 1           | Cable-Battery, Positive ASM | 37          | 3290-378           | 6           | Tie-Cable                  |
| 15          | 3230-23            | 4           | Bolt-CARR                   | 38          | 32180-030          | 1           | Clip-Tie                   |
| 16          | 32149-1            | 4           | Nut-Keps                    | 39          | 32180-031          | 2           | Clip-Tree (W/Tie)          |
| 17          | 122-0402           | 1           | Cable-Battery, Jumper (24V) | 40          | 108-9470           | 1           | Harness-Wire, Fusible Link |

# Wire Harness Assembly



## Wire Harness Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                 |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|------------------------------------|
| 1           | 122-1964           | 1           | Harness-Wire, Platform | 6           | 32180-149          | 1           | Tie-Button Head                    |
| 2           | 122-1963           | 1           | Harness-Wire, Rear     | 7           | 3290-378           | 12          | Tie-Cable                          |
| 3           | 122-1556           | 1           | Harness-Wire, Engine   | 8           | 122-1561           | 1           | Harness-Wire, Fuel Level<br>Jumper |
| 4           | 33105-025          | 1           | Screw-HHF              | 9           | 122-1961           | 1           | Harness-Wire, Dpf                  |
| 5           | 32180-030          | 2           | Clip-Tie               |             |                    |             |                                    |


Platform Wire Harness Assembly No. 122-1964



## Platform Wire Harness Assembly No. 122-1964 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|-------------------------|
| 14          | 32180-167          | 5           | Diode-Mini Fuse, 6A      | 27          | 121-8866           | 6           | Fuse-Mini Blade, 10 Amp |
| 17          | 32180-043          | 1           | Resistor-120 Ohm         | 28          | 121-8867           | 1           | Fuse-Mini Blade, 15 Amp |
| 18          | 32180-089          | 1           | Cap-Plug, 3 Way          | 29          | 121-8870           | 1           | Fuse-Mini Blade, 30 Amp |
| 19          | 32180-156          | 1           | Cap-Plug, 6 Way          | 30          | 104-4022           | 1           | Resistor-75 Ohm         |
| 20          | 32180-091          | 1           | Cap-Dust, 2 Way          | 32          | 32180-174          | 2           | Washer-Lock             |
| 21          | 32180-135          | 1           | Nut-Connector            | 33          | 32180-175          | 2           | Nut-Connector           |
| 22          | 32180-143          | 1           | Washer-Lock              | 35          | 32180-190          | 1           | Resistor-2K Ohm         |
| 25          | 121-8861           | 4           | Fuse-Mini Blade, 2 Amp   | 36          | 32180-191          | 2           | Cover                   |
| 26          | 121-8865           | 6           | Fuse-Mini Blade, 7.5 Amp |             |                    |             |                         |

# Rear Wire Harness Assembly No. 122-1963




## Rear Wire Harness Assembly No. 122-1963 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 16          | 121-8864           | 1           | Fuse-Mini Blade, 5 Amp  |
| 17          | 121-8869           | 1           | Fuse-Mini Blade, 25 Amp |
| 26          | 122-0392           | 1           | Voltage Divider-Sealed  |
| 32          | 32180-056          | 1           | Cap                     |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 34          | 32180-101          | 3           | Cover-Fuse, Single      |
| 35          | 121-8866           | 1           | Fuse-Mini Blade, 10 Amp |
| 36          | 32180-091          | 1           | Cap-Dust, 2 Way         |


Engine Wire Harness Assembly No. 122-1556



## Engine Wire Harness Assembly No. 122-1556 (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 15          | 100-4918           | 2           | Diode               |
| 16          | 121-8891           | 1           | Resistor (1.6K Ohm) |

# Roll-Over Protection System Assembly




## Roll-Over Protection System Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 132-1416           | 1           | ROPS ASM               | 19          | 140-6773           | 1           | LH Light ASM             |
| 3           | 104-8301           | 2           | Nut-HF, NI             | 19:2        | 140-6698           | 1           | Light Mount Kit          |
| 7           | 114-0938           | 1           | Tube-Vent              | 20          | 117-5676           | 1           | Premium Seat ASM         |
| 8           | 114-0937           | 1           | Tube-Vent              | 22          | 110-6008           | 2           | Decal-Hood               |
| 9           | 3290-412           | 4           | Rivet-Blind            | 23          | 110-4110           | 2           | Hose-LP                  |
| 11          | 2412-72            | 4           | Clip-Closed, Insulated | 24          | 140-6838-03        | 2           | Bracket-Headlight, Long  |
| 12          | 2412-108           | 4           | Clamp-Worm             | 25          | 3256-45            | 2           | Washer-Flat              |
| 14          | 2412-134           | 2           | Clamp-R                | 26          | 323-10             | 2           | Screw-HH                 |
| 15          | 49-2040            | 2           | Screw-HWHTF            | 27          | 140-6772           | 1           | RH Light ASM             |
| 16          | 3256-27            | 4           | Washer-Flat            | 27:2        | 140-6698           | 1           | Light Mount Kit          |
| 17          | 327-3              | 4           | Screw-HH               | 28          | 132-1334           | 1           | Tread-Foot, Abrasive     |
| 18          | 132-1333           | 1           | Tread-Foot, Abrasive   | 32          | 144-3373           | 2           | Tape-Reflective (Yellow) |



## Light Mount Kit Assembly No. 140-6698

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 139-2092           | 1           | Mount-Light        |
| 2           | 107-7983           | 1           | Screw-HH           |
| 3           | 33116-030          | 1           | Screw-HH           |
| 4           | 48-8070            | 2           | Washer-Lock        |
| 5           | 33026-00           | 2           | Nut-Hex            |




## Vinyl Premium Seat Assembly No. 117-5676

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 108-8016    | 1    | Backrest Cushion ASM    |
| 1:1  | 119-7742    | 4    | Screw-Cushion           |
| 2    | 108-8017    | 1    | Seat Cushion ASM        |
| 2:1  | 119-7742    | 3    | Screw-Cushion           |
| 3    | 108-8018    | 1    | Cover-Armrest           |
| 4    | 108-8019    | 1    | LH Armrest ASM          |
| 4:1  | 82-9650     | 1    | Nut                     |
| 4:2  | 107-1198    | 1    | Washer                  |
| 6    | 108-8021    | 1    | Cover-Armrest           |
| 7    | 108-8022    | 2    | Cover-Black             |
| 8    | 108-8024    | 1    | Switch Kit              |
| 8:1  |             | 3    | Wire Tie ●              |
| 8:2  |             | 4    | Rivet ●                 |
| 8:3  |             | 1    | Sensor-Seat Switch ●    |
| 8:4  |             | 2    | Spring-Compression ●    |
| 8:5  |             | 2    | Bumper-Pressure Plate ● |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 8:6  |             | 1    | Spring-Extension ●    |
| 8:7  |             | 1    | Plate-Mounting ●      |
| 8:8  |             | 1    | Magnet ●              |
| 9    | 108-8025    | 1    | Adjustment Rail Set   |
| 9:1  |             | 1    | Rail-Adjustment, RH ● |
| 9:2  |             | 1    | Rail-Adjustment, LH ● |
| 9:3  |             | 1    | Stop-Rail ●           |
| 9:4  |             | 1    | Handle ●              |
| 9:5  |             | 3    | Screw ●               |
| 9:6  |             | 3    | Washer ●              |
| 9:7  |             | 1    | Screw ●               |
| 10   | 110-6189    | 1    | Switch Kit            |
| 10:1 |             | 1    | Switch ●              |
| 10:2 |             | 3    | Wire Tie ●            |
| 10:3 |             | 2    | Rivet ●               |


● Not serviced separately



## Cylinder Block Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 133-6785    | 1    | Cylinder Block ASM |
| 4    | 133-6627    | 1    | Plug               |
| 5    | 125-7170    | 1    | Plug               |
| 6    | 133-6628    | 10   | Bolt               |
| 9    | 133-6630    | 1    | Bushing-Camshaft   |
| 10   | 133-2507    | 8    | Plug               |
| 11   | 125-7184    | 2    | Pin-Spring         |
| 12   | 133-6798    | 1    | Plug               |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 13   | 133-6798    | 1    | Plug                  |
| 14   | 133-6798    | 1    | Plug                  |
| 24   | 133-6631    | 2    | Bearing-Thrust        |
| 27   | 133-6626    | 18   | Bolt-Head             |
| 28   | 133-6700    | 1    | Gasket-Head, Cylinder |
| 29   | 133-2508    | 5    | Bearing-Main          |
| 32   | 133-6629    | 5    | Bearing               |
| 35   | 133-6632    | 2    | Bearing-Thrust        |




## Gear Housing Assembly

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 133-6754    | 1    | Case-Gear        |
| 2    | 125-6995    | 4    | Pin              |
| 3    | 133-6653    | 1    | O-Ring           |
| 4    | 133-6654    | 1    | O-Ring           |
| 5    | 133-6664    | 1    | Oil Pump ASM     |
| 6    | 133-6672    | 1    | Gasket-CW P, Out |
| 7    | 93-0400     | 1    | O-Ring           |
| 8    | 125-7214    | 4    | Bolt             |
| 9    | 125-7219    | 3    | Bolt             |
| 10   | 125-6972    | 1    | Cover-Filler     |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 11   | 125-7197    | 1    | O-Ring             |
| 12   | 133-6701    | 1    | Gearcase Cover ASM |
| 14   | 133-6669    | 1    | Seal-Oil           |
| 15   | 133-6703    | 1    | Gearcase Cover ASM |
| 17   | 125-6977    | 1    | Cover              |
| 18   | 125-7214    | 2    | Bolt               |
| 19   | 125-7214    | 4    | Bolt               |
| 20   | 125-7218    | 10   | Bolt               |
| 21   | 133-2492    | 7    | Bolt               |

## Cylinder Head and Cover Assembly




## Cylinder Head and Cover Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 127-2996           | 8           | Cap-Valve               | 47          | 133-6696           | 1           | Spring-Plate            |
| 2           | 133-6756           | 1           | Cylinder Head ASM       | 48          | 133-6661           | 1           | Baffle-Breather         |
| 8           | 133-6797           | 1           | Plug                    | 49          | 133-2502           | 2           | Screw                   |
| 9           | 125-7240           | 1           | Plug                    | 50          | 133-2505           | 1           | Screw                   |
| 10          | 133-6633           | 4           | Valve-Intake            | 51          | 125-7118           | 1           | Baffle-Breather         |
| 11          | 133-6634           | 4           | Valve-Exhaust           | 52          | 125-6959           | 1           | Diaphragm               |
| 12          | 133-6635           | 8           | Spring-Valve            | 53          | 125-6960           | 1           | Plate                   |
| 13          | 127-3013           | 8           | Retainer-Spring         | 54          | 125-6961           | 1           | Plate-Breather          |
| 14          | 127-2986           | 4           | Seal-Stem, Valve        | 55          | 125-6962           | 1           | Spring-Diaphragm        |
| 15          | 127-3027           | 4           | Seal-Stem, Valve        | 57          | 133-6603           | 1           | Elbow                   |
| 16          | 127-3186           | 8           | Pin-Cotter              | 58          | 127-3026           | 1           | Joint                   |
| 18          | 127-3021           | 4           | Gasket-Injector         | 59          | 132-4907           | 1           | Gasket-Cover, Head      |
| 19          | 133-6707           | 4           | Retainer-Injector       | 60          | 127-3029           | 1           | Sensor-Pressure         |
| 20          | 127-2980           | 4           | Washer-Injector         | 61          | 127-3032           | 2           | O Ring-Sensor, Pressure |
| 21          | 125-7217           | 4           | Bolt                    | 62          | 125-6913           | 2           | Plug                    |
| 22          | 133-6636           | 1           | Arm Support ASM         | 63          | 125-7186           | 7           | Screw                   |
| 23          | 133-6637           | 1           | Rocker Shaft ASM        | 64          | 125-7186           | 6           | Screw                   |
| 26          | 133-6638           | 3           | Spring-Arm, Rocker      | 65          | 127-3184           | 2           | Bolt                    |
| 27          | 133-6639           | 3           | Support-Arm, Rocker     | 66          | 93-0418            | 3           | O-Ring                  |
| 28          | 133-6640           | 1           | Support-Arm, Rocker     | 67          | 125-7197           | 1           | O-Ring                  |
| 29          | 133-6642           | 4           | Arm-Rocker              | 68          | 133-6779           | 1           | Lifter-Engine           |
| 30          | 125-7013           | 4           | Screw-Adjust, Valve     | 69          | 133-6695           | 1           | Lifter                  |
| 32          | 125-7014           | 4           | Nut                     | 70          | 125-7595           | 4           | Bolt                    |
| 33          | 133-6643           | 4           | Arm-Rocker              | 71          | 127-3128           | 1           | Joint-Breather          |
| 34          | 125-7013           | 4           | Screw-Adjust, Valve     | 72          | 133-6787           | 1           | Breather Hose ASM       |
| 36          | 125-7014           | 4           | Nut                     | 75          | 125-7040           | 2           | Clip-Hose               |
| 37          | 133-6794           | 2           | Ring                    | 76          | 127-3133           | 1           | Hose-Intake             |
| 38          | 133-2503           | 1           | Screw                   | 77          | 127-3030           | 1           | Sensor-Temp, Air        |
| 39          | 133-6641           | 3           | Stud                    | 78          | 127-3033           | 1           | O-Ring                  |
| 40          | 133-2498           | 1           | Bolt                    | 79          | 125-7190           | 2           | Clamp-Hose              |
| 41          | 125-7230           | 3           | Nut                     | 80          | 125-7207           | 1           | Bolt                    |
| 42          | 125-6972           | 1           | Cover-Filler            | 81          | 131-2704           | 1           | Harness-Wire            |
| 43          | 125-6974           | 3           | Knob                    | 82          | 127-2991           | 4           | Plug-Glow               |
| 44          | 133-6755           | 1           | Cylinder Head Cover ASM | 83          | 133-6750           | 1           | Connector-Plug, Glow    |
| 45          | 133-6704           | 1           | Plate-Baffle            | 84          | 127-2997           | 8           | Guide-Valve             |
| 46          | 133-6705           | 1           | Cover-Plate, Spring     |             |                    |             |                         |



## Flywheel Housing and Oil Sump Assembly


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 125-6995    | 2    | Pin                  |
| 2    | 133-6702    | 1    | Housing-Flywheel     |
| 3    | 125-6910    | 1    | Cap                  |
| 4    | 133-2499    | 9    | Bolt                 |
| 5    | 133-2500    | 4    | Bolt                 |
| 6    | 133-6668    | 1    | Seal                 |
| 7    | 133-6691    | 1    | Oil Sump ASM         |
| 8    | 125-6912    | 1    | Plug-Drain           |
| 10   | 125-7177    | 1    | Washer-Seal          |
| 11   | 125-7212    | 16   | Bolt                 |
| 12   | 127-3062    | 1    | Sensor-Rev, Flywheel |
| 13   | 127-3184    | 1    | Bolt                 |



## Suction Manifold Assembly


| Ref. | Part Number | Qty. | Description          | Ref. | Part Number | Qty. | Description            |
|------|-------------|------|----------------------|------|-------------|------|------------------------|
| 1    | 133-6708    | 1    | Gasket-Manifold      | 19   | 133-6717    | 1    | Gasket-V Spacer, E G R |
| 2    | 133-6758    | 1    | Intake Manifold ASM  | 20   | 127-3080    | 1    | Joint-Hose             |
| 3    | 133-6757    | 1    | Manifold-Intake, Air | 21   | 133-6743    | 1    | Joint-Hose             |
| 4    | 127-3180    | 2    | Stud                 | 22   | 127-3166    | 2    | Washer-Seal            |
| 5    | 127-3031    | 1    | Sensor-Temp, Air     | 23   | 125-7207    | 2    | Bolt                   |
| 6    | 125-7219    | 1    | Bolt                 | 24   | 125-7217    | 4    | Bolt                   |
| 7    | 125-7221    | 4    | Bolt                 | 25   | 127-3180    | 2    | Stud                   |
| 8    | 133-6764    | 1    | Duct-Intake          | 26   | 127-3178    | 1    | Bolt                   |
| 9    | 127-3096    | 1    | Joint-Rubber         | 27   | 133-2493    | 2    | Bolt                   |
| 10   | 133-6765    | 1    | Joint-Hose           | 28   | 133-2501    | 2    | Stud                   |
| 11   | 127-3170    | 2    | Clamp-Hose           | 29   | 125-7229    | 2    | Nut                    |
| 12   | 125-7190    | 1    | Clamp-Hose           | 30   | 127-3035    | 1    | Bend-Inlet             |
| 13   | 127-3171    | 1    | Clamp-Hose           | 31   | 127-3036    | 1    | Body-Throttle          |
| 14   | 133-6709    | 1    | Gasket-Collector     | 32   | 127-3037    | 2    | Gasket-Throttle        |
| 15   | 133-6760    | 1    | Collector ASM        | 33   | 125-7209    | 2    | Bolt                   |
| 16   | 133-6759    | 1    | Collector            | 34   | 125-7211    | 4    | Bolt                   |
| 17   | 133-6762    | 1    | Valve-Reed           | 35   | 127-3177    | 2    | Bolt                   |
| 18   | 133-6716    | 1    | Spacer-Valve, E G R  |      |             |      |                        |

# Diesel Particulate Filter Assembly



## Diesel Particulate Filter Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|------------------------------|
| 1           | 127-2987           | 1           | Gasket-Silencer              | 29          | 127-3057           | 2           | Clip-Hose                    |
| 2           | 133-6793           | 4           | Bolt                         | 30          | 127-3059           | 1           | Exhaust Pressure Hose<br>ASM |
| 3           | 133-6783           | 1           | Band-D P F                   | 32          | 127-3058           | 2           | Clip-Hose                    |
| 5           | 127-4764           | 1           | Sensor-Temp, Exhaust         | 33          | 127-3060           | 1           | Sensor-Pressure              |
| 6           | 127-4765           | 1           | Sensor-Temp, Exhaust         | 34          | 133-6773           | 1           | Bracket-Sensor               |
| 7           | 133-6786           | 1           | D P F ASM                    | 35          | 125-7208           | 2           | Bolt                         |
| 10          | 130-8348R          | 1           | Case-Soot Filter, Recon      | 36          | 125-7215           | 2           | Bolt                         |
| 10          | 130-8348           | 1           | Case-Soot Filter             | 37          | 127-3087           | 1           | Band-Clip                    |
| 12          | 133-6781           | 1           | Flange-Outlet                | 38          | 127-3124           | 1           | Band                         |
| 13          | 127-3162           | 2           | Gasket-D P F                 | 39          | 127-3088           | 2           | Clip-Connector               |
| 14          | 127-3055           | 20          | Bolt                         | 40          | 93-0417            | 2           | Washer                       |
| 15          | 127-3144           | 1           | Lifter-D P F                 | 41          | 93-0417            | 1           | Washer                       |
| 16          | 127-3145           | 5           | Stiffener-D P F, A           | 42          | 133-2497           | 2           | Bolt                         |
| 17          | 133-6728           | 1           | Stiffener-D P F, B           | 43          | 125-7230           | 1           | Nut                          |
| 18          | 127-3147           | 1           | Stiffener-D P F, C           | 44          | 125-7230           | 4           | Nut                          |
| 19          | 133-6699           | 1           | Stiffener-D P F, C           | 45          | 133-2506           | 2           | Nut                          |
| 20          | 125-7213           | 2           | Bolt                         | 46          | 133-6774           | 1           | Stay-D P F                   |
| 21          | 125-7229           | 20          | Nut                          | 47          | 125-7595           | 5           | Bolt                         |
| 23          | 127-3039           | 2           | Bolt-Joint, Pipe             | 48          | 133-6715           | 4           | Bolt                         |
| 24          | 133-6775           | 1           | Exhaust Pressure Pipe ASM    | 49          | 133-6782           | 1           | Stay-D P F                   |
| 25          | 127-3056           | 4           | Gasket-Sensor                | 50          | 127-2987           | 1           | Gasket-Silencer              |
| 26          | 133-6776           | 1           | Exhaust Pressure Pipe ASM    |             |                    |             |                              |
| 27          | 133-6777           | 1           | Exhaust Pressure Hose<br>ASM |             |                    |             |                              |



## Exhaust Manifold Assembly

| Ref. | Part Number | Qty. | Description                  |
|------|-------------|------|------------------------------|
| 1    | 133-6761    | 1    | Manifold-Exhaust             |
| 2    | 133-6710    | 1    | Gasket-Manifold              |
| 3    | 133-6791    | 8    | Bolt                         |
| 4    | 133-6718    | 1    | Sensor-Temp, Exhaust         |
| 5    | 127-3087    | 2    | Band-Clip                    |
| 6    | 125-7043    | 4    | Stud                         |
| 7    | 133-6711    | 1    | Pipe-Pressure, Exhaust       |
| 8    | 127-3039    | 1    | Bolt-Joint, Pipe             |
| 9    | 133-6712    | 1    | Exhaust Pressure Hose<br>ASM |
| 11   | 127-3041    | 2    | Clip-Hose                    |
| 12   | 127-3174    | 2    | Gasket                       |
| 13   | 125-7214    | 2    | Bolt                         |
| 14   | 133-6713    | 1    | Cooler-E G R                 |
| 15   | 133-6698    | 2    | Gasket-Cooler, E G R         |
| 16   | 133-6714    | 2    | Bolt                         |
| 17   | 133-6792    | 1    | Bolt                         |
| 18   | 133-6720    | 1    | E G R-C Out Bend ASM         |
| 19   | 133-6721    | 1    | Bend-Out, E G R-C            |
| 20   | 125-7043    | 2    | Stud                         |


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 21   | 125-7595    | 2    | Bolt                   |
| 22   | 127-2984    | 4    | Stud                   |
| 23   | 127-2987    | 1    | Gasket-Silencer        |
| 24   | 133-6697    | 1    | Pipe-Exhaust           |
| 25   | 133-6788    | 1    | Pipe-Exhaust           |
| 26   | 133-6792    | 2    | Bolt                   |
| 27   | 133-6606    | 1    | Bolt                   |
| 28   | 133-6619    | 1    | Gasket                 |
| 29   | 125-6906    | 3    | Stud                   |
| 30   | 125-7229    | 3    | Nut                    |
| 31   | 125-7230    | 4    | Nut                    |
| 32   | 127-3047    | 1    | Sensor-Gas Temp, E G R |
| 33   | 133-6719    | 1    | E G R Pipe ASM         |
| 34   | 127-3016    | 1    | Gasket                 |
| 35   | 133-2496    | 2    | Bolt                   |
| 36   | 125-7229    | 2    | Nut                    |
| 37   | 133-6722    | 1    | Valve-E G R            |
| 38   | 133-6723    | 1    | Gasket-In, E G R-V     |
| 39   | 133-6724    | 1    | Gasket-Out, E G R-V    |
| 40   | 93-0479     | 4    | Bolt                   |



## Camshaft and Driving Gear Assembly


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 125-7016    | 8    | Tappet             |
| 2    | 133-6644    | 8    | Rod-Push           |
| 3    | 133-6726    | 1    | Cam Shaft ASM      |
| 4    | 125-7008    | 1    | Metal-Thrust       |
| 6    | 133-6725    | 1    | Gear-Camshaft      |
| 7    | 125-7185    | 1    | Key                |
| 8    | 133-6727    | 1    | Pulser-Gear, Cam   |
| 9    | 125-7182    | 1    | Pin-Spring         |
| 10   | 125-7213    | 2    | Bolt               |
| 11   | 133-2504    | 2    | Screw              |
| 12   | 127-3054    | 1    | Sensor-Rev, Gear   |
| 13   | 127-3184    | 1    | Bolt               |
| 14   | 133-6731    | 1    | Shaft-Gear A, Idle |
| 15   | 133-6652    | 1    | Idle Gear ASM      |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 18   | 125-7220    | 3    | Bolt                |
| 19   | 133-6737    | 1    | Gear-Pump, Supply   |
| 20   | 127-3167    | 1    | Washer-Spring       |
| 21   | 127-3185    | 1    | Nut-Lock            |
| 22   | 133-6732    | 1    | Shaft-Gear B, Idle  |
| 23   | 133-6734    | 1    | Idle Gear B ASM     |
| 26   | 133-6735    | 1    | Plate-Shaft B, Idle |
| 27   | 125-7219    | 3    | Bolt                |
| 28   | 133-6736    | 1    | L O Pipe ASM        |
| 29   | 133-6600    | 2    | Bolt-Joint, Pipe    |
| 30   | 125-7174    | 4    | Washer-Seal         |
| 31   | 133-6624    | 1    | Bushing-Gear, Idle  |
| 32   | 133-6733    | 1    | Bushing             |



## Turbine Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1           | 133-6763           | 1           | Turbocharger-R H F5 |
| 2           | 133-6625           | 1           | Gasket              |
| 3           | 125-6906           | 4           | Stud                |
| 4           | 125-7229           | 4           | Nut                 |



## Crankshaft and Piston Assembly

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 133-6663    | 1    | Crankshaft ASM   |
| 3    | 133-6645    | 1    | Gear-Crankshaft  |
| 4    | 133-6611    | 1    | Pin              |
| 5    | 133-6612    | 1    | Pin-Parallel     |
| 6    | 125-7185    | 1    | Key              |
| 7    | 133-6670    | 1    | Bolt             |
| 8    | 133-6662    | 1    | Pulley-V         |
| 9    | 133-6693    | 1    | Packing-Washer   |
| 10   | 133-6694    | 1    | Washer-Pulley, V |
| 11   | 133-6610    | 6    | Bolt-Flywheel    |
| 12   | 133-6778    | 1    | Flywheel ASM     |
| 14   | 133-6646    | 1    | Gear-Ring        |


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 16   | 133-6766    | 4    | Piston ASM           |
| 18   | 133-6729    | 4    | Ring ASM             |
| 24   | 133-6607    | 4    | Pin-Piston           |
| 25   | 133-6795    | 8    | Ring                 |
| 26   | 133-6647    | 4    | Connecting Rod ASM   |
| 29   | 133-6648    | 8    | Bolt-Rod, Connecting |
| 30   | 133-6649    | 4    | Bearing-Pin, Crank   |
| 32   | 133-6651    | 4    | Bearing-Pin, Piston  |
| 33   | 133-6650    | 4    | Bearing              |
| 35   | 133-6767    | 4    | Piston ASM           |
| 37   | 133-6730    | 4    | Ring ASM             |



## Lubrication and Oil System Assembly

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 1    | 127-3014    | 1    | Cooler ASM      |
| 2    | 127-2985    | 1    | O-Ring          |
| 3    | 133-6622    | 1    | Bolt-Cooler     |
| 4    | 127-3015    | 1    | Bracket-Cooler  |
| 5    | 125-6990    | 1    | Joint           |
| 6    | 133-6667    | 1    | Pipe-Water      |
| 7    | 127-3003    | 1    | Elbow           |
| 8    | 133-6620    | 1    | Pipe-Water      |
| 10   | 133-6621    | 1    | Tube-Corrugated |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 11   | 125-7188    | 4    | Clamp-Hose         |
| 12   | 127-3176    | 1    | O-Ring             |
| 13   | 125-7171    | 1    | Plug-Drain         |
| 14   | 133-6655    | 1    | Dipstick-Oil       |
| 15   | 125-6954    | 1    | Guide-Dipstick     |
| 17   | 133-6653    | 1    | O-Ring             |
| 18   | 133-6656    | 1    | Oil Inlet Pipe ASM |
| 23   | 125-7212    | 2    | Bolt               |
| 24   | 125-7025    | 1    | Filter-Engine, Oil |



## Lubrication Oil Pipe Assembly

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 125-6918    | 1    | Switch-Oil       |
| 2    | 125-7174    | 1    | Washer-Seal      |
| 3    | 125-7212    | 1    | Bolt             |
| 4    | 125-6952    | 1    | Bolt-Joint, Pipe |
| 5    | 133-6768    | 1    | L O Pipe ASM     |
| 6    | 133-6623    | 2    | Retainer         |
| 7    | 125-6988    | 1    | Joint Bolt ASM   |
| 8    | 125-7174    | 1    | Washer-Seal      |
| 9    | 125-7194    | 1    | Bolt-Joint       |
| 10   | 125-7174    | 2    | Washer-Seal      |
| 11   | 125-7193    | 2    | Gasket           |


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 12   | 125-7212    | 2    | Bolt                |
| 13   | 125-6971    | 1    | Elbow               |
| 14   | 133-6769    | 1    | Pipe-L O Return T/C |
| 15   | 133-6666    | 1    | Gasket              |
| 16   | 125-6958    | 1    | Hose                |
| 17   | 125-7188    | 2    | Clamp-Hose          |
| 18   | 125-7208    | 2    | Bolt                |
| 19   | 133-6665    | 4    | Check Valve ASM     |
| 25   | 133-6602    | 4    | Nozzle              |
| 26   | 125-7182    | 4    | Pin-Spring          |



## Cooling Water System Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 133-6657    | 1    | Water Pump ASM        |
| 10   | 133-6658    | 1    | Gasket-Pump, Water    |
| 11   | 131-2739    | 2    | Bolt                  |
| 12   | 125-7221    | 5    | Bolt                  |
| 13   | 133-6659    | 1    | V Pulley-Pump, CW     |
| 14   | 133-6799    | 1    | V-Belt                |
| 15   | 133-2495    | 4    | Bolt                  |
| 16   | 133-6740    | 1    | Thermostat Case ASM   |
| 17   | 125-7124    | 1    | Sensor-Thermostat, CW |
| 18   | 127-3017    | 1    | Joint                 |
| 19   | 133-6671    | 1    | Cover-Thermostat      |
| 20   | 133-6613    | 1    | Gasket-Thermostat     |
| 21   | 133-6614    | 1    | Gasket-Thermostat     |
| 22   | 133-6615    | 1    | Thermostat            |
| 24   | 125-7176    | 1    | Washer-Seal           |

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 25   | 133-6796    | 2    | Plug                   |
| 26   | 125-7209    | 4    | Bolt                   |
| 27   | 133-6660    | 1    | Gasket                 |
| 28   | 125-7192    | 1    | Gasket                 |
| 29   | 125-7212    | 1    | Bolt                   |
| 30   | 125-7222    | 3    | Bolt                   |
| 31   | 125-6953    | 2    | Plug                   |
| 32   | 125-6979    | 2    | Gasket                 |
| 33   | 127-3017    | 1    | Joint                  |
| 34   | 133-6738    | 1    | E G R-C In Hose ASM    |
| 36   | 127-3020    | 2    | Clip-Hose              |
| 38   | 133-6739    | 1    | E G R-C Out A Hose ASM |
| 39   | 127-3020    | 2    | Clip-Hose              |
| 42   | 133-6784    | 1    | E G R-C Out B Hose ASM |
| 43   | 127-3020    | 2    | Clip-Hose              |





## Fuel Supply Pump Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 127-3073    | 1    | Fuel Pump ASM      |
| 2    | 131-2103    | 1    | Valve ASM          |
| 3    | 131-2105    | 1    | Ring-Sealing       |
| 4    | 131-2106    | 1    | O-Ring             |
| 5    | 131-2107    | 2    | Bolt               |
| 6    | 131-2108    | 1    | Sensor-Temperature |
| 7    | 127-3074    | 1    | O-Ring             |
| 8    | 125-7216    | 3    | Bolt               |




## Fuel Injection Valve Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 133-6770    | 4    | Injector-C R           |
| 4    | 130-7430    | 4    | Ring-Retaining         |
| 6    | 127-3118    | 1    | Rail ASM               |
| 7    | 131-2709    | 1    | Sensor-Pressure, Rail  |
| 8    | 131-2710    | 1    | Valve ASM              |
| 9    | 130-7433    | 1    | O-Ring                 |
| 10   | 125-7215    | 2    | Bolt                   |
| 11   | 127-2982    | 4    | Retainer               |
| 13   | 133-6745    | 1    | Rail Injector Pipe ASM |
| 15   | 133-6746    | 1    | Injector No 1 Pipe ASM |
| 16   | 133-6747    | 1    | Injector No 2 Pipe ASM |
| 17   | 133-6748    | 1    | Injector No 3 Pipe ASM |
| 18   | 133-6749    | 1    | Injector No 4 Pipe ASM |
| 19   | 125-7231    | 4    | Nut                    |



## Fuel Pipe Assembly


| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 1    | 133-6744    | 1    | Fuel/Oil Return Pipe ASM    |
| 4    | 127-3172    | 1    | Clamp-Hose                  |
| 5    | 133-6741    | 1    | Fuel/Oil Return Hose ASM    |
| 8    | 125-7191    | 2    | Clamp-Hose                  |
| 9    | 133-6742    | 1    | Fuel/Oil Return Hose ASM    |
| 10   | 127-2950    | 2    | Clip-Hose                   |
| 13   | 127-3087    | 1    | Band-Clip                   |
| 16   | 121-5613    | 1    | Pump-Fuel, Electric         |
| 17   | 127-3075    | 1    | Fuel/Oil Filter ASM         |
| 18   | 127-3076    | 1    | Fuel/Oil Filter Bracket ASM |
| 19   | 125-8752    | 1    | Filter-Fuel/Oil             |
| 20   | 131-2731    | 1    | Bracket-Filter, Fuel        |
| 21   | 125-7216    | 2    | Bolt                        |
| 22   | 133-2496    | 2    | Bolt                        |



## Starter Motor Assembly


| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 133-6673    | 1    | Starter          |
| 2    | 133-6674    | 1    | Armature ASM     |
| 5    | 133-6675    | 1    | Field Coil ASM   |
| 6    | 133-6676    | 4    | Screw            |
| 7    | 133-6677    | 1    | O-Ring           |
| 8    | 133-6678    | 2    | Brush            |
| 9    | 133-6679    | 1    | Cover            |
| 10   | 133-6680    | 1    | Brush Holder ASM |
| 11   | 133-6681    | 1    | Spring           |
| 12   | 133-6682    | 2    | Brush            |
| 13   | 133-6683    | 1    | Switch ASM       |
| 14   | 133-6684    | 1    | Case-Gear        |
| 15   | 133-6685    | 1    | Retainer         |

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 16   | 133-6686    | 1    | Lever Set      |
| 17   | 133-6687    | 1    | Dust Cover ASM |
| 18   | 133-6688    | 2    | Bolt-Through   |
| 19   | 133-6689    | 4    | Bolt           |
| 20   | 133-6690    | 2    | Screw          |
| 21   | 133-6616    | 1    | Pinion ASM     |
| 22   | 133-6617    | 1    | Clutch ASM     |
| 23   | 133-2510    | 2    | Bearing-Ball   |
| 24   | 133-6618    | 1    | Shaft          |
| 25   | 133-6604    | 1    | Stopper Kit    |
| 29   | 133-6609    | 1    | Cover-Terminal |
| 30   | 133-6601    | 2    | Bolt           |
| 31   | 125-7225    | 2    | Bolt           |




## Generator Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 125-7120    | 1    | Alternator-12V     |
| 9    | 125-7121    | 1    | Bolt-Stopper       |
| 10   | 125-7122    | 1    | Piece-Distance     |
| 11   | 125-7230    | 1    | Nut                |
| 12   | 133-6692    | 1    | Adjuster           |
| 13   | 133-6608    | 1    | Spacer             |
| 14   | 133-6605    | 1    | Adjuster Block ASM |
| 16   | 133-2494    | 1    | Bolt               |
| 17   | 125-7229    | 1    | Nut                |
| 18   | 133-2491    | 1    | Bolt               |
| 19   | 125-7219    | 1    | Bolt               |



## Electronic Control Unit Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 8           | 121-5592           | 1           | Electronic Control Unit |



## Electric Parts Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 133-6706    | 2    | Bracket-Harness         |
| 2    | 133-6751    | 1    | Bracket-Connector       |
| 3    | 133-6771    | 1    | Harness-B, E C O        |
| 12   | 133-6752    | 1    | Harness-C, E C O Engine |
| 17   | 131-2713    | 1    | Boot-Cap                |
| 18   | 127-3090    | 1    | Bracket-Harness         |
| 19   | 133-6753    | 1    | Bracket-Harness         |
| 20   | 133-6772    | 1    | Bracket-Harness         |
| 21   | 125-7206    | 4    | Bolt                    |
| 22   | 125-7212    | 2    | Bolt                    |
| 23   | 125-7212    | 2    | Bolt                    |
| 24   | 125-7212    | 2    | Bolt                    |
| 25   | 125-7212    | 2    | Bolt                    |
| 26   | 127-3188    | 1    | Band                    |

# Gasket Set



## Gasket Set (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 133-2509           | 1           | Gasket Kit             | 24          | 133-6654           | 1           | O-Ring             |
| 2           | 133-6700           | 1           | Gasket-Head, Cylinder  | 25          | 127-2985           | 1           | O-Ring             |
| 3           | 132-4907           | 1           | Gasket-Cover, Head     | 26          | 133-6666           | 1           | Gasket             |
| 4           | 127-2986           | 4           | Seal-Stem, Valve       | 27          | 133-6658           | 1           | Gasket-Pump, Water |
| 5           | 127-3027           | 4           | Seal-Stem, Valve       | 28          | 125-6979           | 2           | Gasket             |
| 6           | 127-3021           | 4           | Gasket-Injector        | 29          | 133-6613           | 1           | Gasket-Thermostat  |
| 7           | 133-6708           | 1           | Gasket-Manifold        | 30          | 133-6614           | 1           | Gasket-Thermostat  |
| 8           | 127-3033           | 1           | O-Ring                 | 31          | 133-6660           | 1           | Gasket             |
| 9           | 133-6709           | 1           | Gasket-Collector       | 32          | 131-2106           | 1           | O-Ring             |
| 10          | 127-3037           | 2           | Gasket-Throttle        | 33          | 127-3074           | 1           | O-Ring             |
| 11          | 133-6710           | 1           | Gasket-Manifold        | 34          | 130-7433           | 1           | O-Ring             |
| 12          | 127-2987           | 3           | Gasket-Silencer        | 35          | 125-7174           | 7           | Washer-Seal        |
| 13          | 133-6698           | 2           | Gasket-Cooler, E G R   | 36          | 125-7176           | 1           | Washer-Seal        |
| 14          | 133-6717           | 1           | Gasket-V Spacer, E G R | 37          | 127-3166           | 2           | Washer-Seal        |
| 15          | 127-3016           | 1           | Gasket                 | 38          | 125-7177           | 1           | Washer-Seal        |
| 16          | 133-6723           | 1           | Gasket-In, E G R-V     | 39          | 125-7192           | 1           | Gasket             |
| 17          | 133-6724           | 1           | Gasket-Out, E G R-V    | 40          | 125-7193           | 2           | Gasket             |
| 18          | 127-3162           | 2           | Gasket-D P F           | 41          | 127-3174           | 2           | Gasket             |
| 19          | 127-3056           | 4           | Gasket-Sensor          | 42          | 93-0400            | 1           | O-Ring             |
| 20          | 133-6619           | 1           | Gasket                 | 43          | 93-0418            | 3           | O-Ring             |
| 21          | 133-6625           | 1           | Gasket                 | 44          | 125-7197           | 1           | O-Ring             |
| 22          | 133-6693           | 2           | Packing-Washer         | 45          | 127-3176           | 1           | O-Ring             |
| 23          | 133-6653           | 2           | O-Ring                 |             |                    |             |                    |

# Attachments and Accessories

## For 31698 Groundsmaster 5900 Rotary Mower

| Product Name                                                                | Model/Part |
|-----------------------------------------------------------------------------|------------|
| 10in Foam Filled Castor Wheel.....                                          | 93-5973    |
| CE Kit, 2016 and After Groundsmaster 5900 Tier 4 Series Traction Unit ..... | 132-1340   |
| EU Light Kit Conversion.....                                                | 31695      |
| Beacon Kit .....                                                            | 119-8256   |
| Leaf Mulching Kit .....                                                     | 31604      |
| White Universal Sunshade .....                                              | 30669      |
| Center Deck.....                                                            | 31601      |
| Vinyl Backrest Extension Kit .....                                          | 119-7718   |
| Right Wing Deck .....                                                       | 31602      |
| Left Wing Deck .....                                                        | 31603      |
| Polycarbonate Window Kit.....                                               | 132-3550   |
| 2 Post ROPS Extension Kit.....                                              | 31353      |
| Fluid/Filter MVP Kit .....                                                  | 31609      |
| Atomic Blade Service Pack (20in).....                                       | 132-1391   |
| Standard Blade Service Pack (20in) .....                                    | 132-1392   |
| Blade/Belt Kit .....                                                        | 132-1440   |
| Premium All Purpose Grease (Tube) .....                                     | 108-1190   |
| Safety Air Filter Element .....                                             | 130-9070   |
| PX Hydraulic Fluid (55 Gal).....                                            | 133-8087   |
| Primary Engine Air Filter .....                                             | 108-3815   |
| PX Hydraulic Fluid (5 Gal) .....                                            | 133-8086   |
| Fuel/Water Separator Filter.....                                            | 125-2915   |
| Engine Oil Filter .....                                                     | 125-7025   |
| Fuel Filter.....                                                            | 125-8752   |
| Hydraulic Filter.....                                                       | 86-6110    |
| Hydraulic Filter.....                                                       | 75-1310    |
| Auxiliary Braking System .....                                              | 31701      |
| Wrench-Caster Cap/Latch .....                                               | 138-6367   |
| 1000 Hour MVP Kit .....                                                     | 44958      |
| Manual Flow Divider Kit .....                                               | 140-5800   |
| Red Universal Sunshade .....                                                | 30671      |
| Backup Alarm Kit .....                                                      | 31512      |
| Premium Engine Oil 15w40 (55 Gallon Drum) .....                             | 121-6394   |
| Premium Engine Oil 15w40 (5 Gallon Pail) .....                              | 121-6395   |
| Exterior Mirror Kit.....                                                    | 130-5448   |

**Notes:**



**Count on it.**