



Exhaust Kit

International 100 Series Z Master[®]

Part No. 105-9371

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.



Sheet No.: 0
C-3032

Exhaust Assembly

Ref. No.	Part No.	Qty.	Description
1	105-9370-03	1	LH Exhaust Guard ASM
2	103-2564-03	1	RH Exhaust Guard ASM
3	103-2560-03	1	Shield-Heat
4	103-2630	1	Clamp
5	103-2631	1	Clamp
6	103-2751-03	1	Guard-Strap, LH
7	322-3	11	Screw-HH
8	32128-20	11	Nut-HF
10	103-2599	1	Tailpipe
☆15		1	Shield-Heat, Fuel Pump
☆15:1		1	Shield-Heat
☆15:2		1	Tube-Vent
☆15:3		1	Bracket
☆15:4		1	Screw
16	105-9365-03	1	LH Rear Guard ASM
17	105-9369-03	1	RH Exhaust Guard ASM

Ref. No.	Part No.	Qty.	Description

☆ Obtain Replacement From Kawasaki